




TAPECASTER MODEL 700 150 Hz AUXILIARY CUE GENERATOR




ALL VOLTAGES SHOWN ARE POSITIVE

TAPECASTER SERIES 700 AUXILIARY 150 Hz CUE TONE SENSOR




CONNECT AS SHOWN ABOVE TO START TWO OR MORE SERIES 700 TAPECASTERS IN SEQUENCE



400 mh. PREMIUM CUE TONE
RECORD HEAD LOWER TRK.




400 mh. PREMIUM AUDIO
RECORD HEAD UPPER TRK.


TAPECASTER MODEL X-700 MONO RECORD BOARD



ALL VOLTAGES SHOWN ARE POSITIVE, IN THE RECORD MODE


REVISED 1977







TAPECASTER
Model 700AX 7-72
Audio Playback Amplifier


115 VOLTS
60 Hz




TAPECASTER Model 700 Relay Control Board



NEM 2065 "SUPER-TORQUE" MOTOR
READS 66 OHMS BETWEEN ANY TWO WIRES



REVO A DEBAT
 DIT 1934
 10000 10000 10000



TAPECASTER MODEL 600-RP

