

**1 9 3 4**  
**◆ Official ◆**  
**Radio Service Manual**

---

Complete Directory of all  
1933-1934 Radio Receivers

---

FULL RADIO SERVICE GUIDE

---

Vol. No. 4

**HUGO GERNSBACK**

*Editor*

**C. W. PALMER**

*Associate Editor*



**GERNSBACK PUBLICATIONS, INC.**  
**PUBLISHERS**

96-98 PARK PLACE, NEW YORK, N. Y.

**NEW YORK**

## ..Introduction..

**I**N preparing the 1934 edition of the OFFICIAL RADIO SERVICE MANUAL, the editors have made every effort to give the Service Man as complete and concise a volume of practical data as could be selected from the available service material, which has been obtained from every conceivable source.

Special care has been taken to prevent duplication of material previously published. All the material in this edition is new and original. In fact, many pages in the book were held open until the last minute so that material which was not available before could be included.

The outstanding problems of the Service Man have been kept in mind in the compilation of this book—methods of servicing, material essential to correct servicing, the new equipment and tools constantly needed to cope with new sets and tubes as well as other fields in radio, including public address systems, short waves, auto radio, centralized installations and others.

It will be found that the illustrations in the 1934 OFFICIAL RADIO SERVICE MANUAL are much more explicit than before; the diagrams are not limited to the schematic circuit but other illustrations such as parts layouts, positions of trimmers, voltage and resistance readings, parts lists, etc., are included. There are hundreds of new circuits in this volume, and not one has been published in a previous issue.

A new section in the back of the book lists the essential data for practically every tube available, including socket connections. In this section, too, will be found a list of the broadcasting stations and police stations in the United States.

We will be pleased to receive suggestions and criticisms from any of the readers of this book. It has been written for Service Men and any suggestions for improving future issues will be useful to us.

To the Manufacturers who have furnished service data and information used in compiling this Manual, and to the thousands of readers who have written in during the course of the year, we wish to extend our most sincere thanks, and the hope that the present volume will find a myriad of uses to the radio Service Man.

—THE EDITORS.

# INDEX

## 1931, 1932, 1933 and 1934 Manuals

**T**HIS INDEX includes material printed in the 1931, 1932 and 1933 Manuals, as well as the present volume. To differentiate between the various volumes, a Roman numeral follows the page number of each set listed. Thus the numeral I refers to the 1931 issue, II refers to the 1932 issue, etc. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements of the 1931 or 1932 Manuals.

### A

#### A. C. DAYTON CO.

AC-63	79-I
AC-65	79-I
AC-66	78-I
XL-5 Battery	80-I
XL-10 Battery	80A-Is
XL-20 Battery	77-I
XL-25 Battery	77-I
XL-30 Battery	77-I
XL-50 AC	80B-Is
XL-60 Battery	80B-Is
XL-61 Battery	78-I
XL-70 Battery	80A-Is
Navigator AC	80-I

#### ACME ELECTRIC CO.

88—Screen-Grid	81-I
AC-7	81-I

#### ALL-AMERICAN MOHAWK CORP.

See also Wurlitzer Radio Co.

44 Battery	84B-Is
60 AC	82-I
61 AC	82-I
62 AC	82-I
65 AC	82-I
66 AC	82-I
70 AC	83-I
73 AC	83-I
75 AC	83-I
77-6 tube A. C.	355-III
80 AC	82-I
83 AC	82-I
84 AC	82-I
85 AC	82-I
86 AC	82-I
88 AC	82-I
90 AC-60 Cycles	83-I, 130-II, 131-II
90 AC-25 Cycles	84-I, 130-II, 131-II
96 AC	84-I, 131-II
115 battery	353-III
115 Electric	353-III
226-227 Mohawk	85-I
226-7 Contact Power Pack	361-III
226-12 Contact Power	

Pack	361-III
A1, A3 and A4 Constant	
B Eliminator	356-III
A8 B Eliminator	359-III
A9 B Eliminator	359-III
A10 Eliminator	360-III
A10 Power Unit	360-III
B-7 Lyric Battery	136-II
B-9 Lyric Battery	358C-Is
C-6 Lyric AC	136-II
C-6 Lyric AC	343-III
"D" AC	4H-Is
"D" AC	84A-Is
DC Lyric	137-II
DC-7 220 Volts	4M-Is
"H" AC	84B-Is
"H" AC	4I-II
"J" Lyric AC	134-II
"J" Junoir	4J-Is
"K" AC	138-II
"K" AC	4K-Is
"P" AC	139-II
"P" AC	4L-Is
R	350-III
S-6 Lyric AC	135-II
S-7 Lyric AC	133-II
S-8 Lyric AC	132-II
S-10	358-III
S-63 Lyric	357-III
S-80	4N-Is
5 tube VA circuit	351-III
"W" 6 & 8 Tube AC	82-Is
All Electric 1926	352-III
Chieftain Battery	350-III
Forte, Lorraine & Sovereign	
7 tube Battery	355-III
Kellogg Type	354-III
Navajo Battery	351-III
Sextette 6 tube	352-III
Sextette & Duet 6 tube	354-III
7 tube 110 V. D. C.	356-III

#### ALLIED ENGINEERING INSTITUTE

Find-All Receiver	455A-Is
-------------------	---------

#### AMERICAN BOSCH MAGNETO CORP.

See United American Bosch Corp.

#### AMERICAN TRANSFORMER COMPANY

2 AP Amplifier	342-I
----------------	-------

21 D Hi-Power Box	342-I
25 A Amplifier	334A-Is
ABC Hi-Power Box	26-I
PF-524A Amplifier	145-II
PF-250 Amplifier	334-I
PF-281 Amplifier	144-II
PF-250 Amplifier	144-II
Approved Audio Circuits	334A-Is
De Luxe Recording Amplifier	143-II
Hum Reduction Chart	145-II
Pick Up Matching Circuit	143-II
Plate Supply Transformer Connections	334B-Is

#### AMRAD CORPORATION

80 Battery	94-I
81 AC Bell Canto Series	96-I
82 Battery	94-I
83 Battery	94-I
84 AC	96A-Is
2364 Amplifier	95-I
3475 Tuner	95-I
3500-1 Battery	95-I
3500-2 Battery	95-I
3590 Battery	95-I
3730 Tuner	95-I
7100 AC	94-I, 309-III
7191 Power Unit	95-I, 293-III
AC 5 Neutrodyne	92-I
AC 6 Concerto Nocturne	92-I
AC 7 Neutrodyne	93-I, 96A-Is
DC 6 Neutrodyne	92-I
DC 7 Neutrodyne	93-I
S-522 Battery	94-I
S-733 Battery	95-I

#### AMY, ACEVES & KING, Inc.

Riser Circuit for Multi-coupler installation	295-II
--	--------

#### ANSLEY RADIO LAB.

DC Electric	146-II
MD-1	146-II

#### ARGUS RADIO CORP.

B-125	326-I
-------	-------

B-195	326-I
-------	-------

#### ATWATER KENT MFG. CO.

19 No. 4880 Battery	97-I
20 No. 4640 Battery	97-I
20 Compact Battery	97-I
20 Compact No. 7960	196P-Is
21 No. 7780 Battery	98-I
30 Battery	99-I
32 Battery	98-I
33 Battery	99-I
35	99-I, 342-III
36 AC	98-I, 340-III
37 AC	100-I, 306-III, 310-III, 340-III, 346-III
38 AC	100-I, 340-III, 346-III
40 AC	101-I, 310-III, 340-III, 341-III, 346-III
41 Battery	102-I
41 DC	298-III, 302-III, 306-III
41 Second Type Power Unit	103-I
41 Third Type Power Unit	103-I
42 AC	101-I, 340-III, 344-III
43 AC	102-I, 4JJ-Is, 4KK-Is
44 AC	101-I, 340-III, 344-III
44 Second Type Power Unit	103-I
46	4JJ-Is, 4KK-Is
47	4JJ-Is, 4KK-Is
48 Battery	99-I
49 Battery	99-I
50 Battery	103-I
52 AC	101-I, 340-III
53	4JJ-Is, 4KK-Is
55 AC	104-I, 306-III, 342-III
55C AC	104-I
55F Early Type AC	160-II
55F Later Type AC	160-II
55FC Early Type AC	160-II
55FC Later Type AC	160-II
60 Early Type AC	167-II
60 Later Type AC	162-II, 342-III
60C Early Type AC	167-II
60C Later Type AC	162-II
60C Third Type AC	328-I
61 Early Type DC	161-II
61 Later Type DC	161-II
61C Early Model DC	161-II
61C Later Model DC	161-II
66 AC	163-II
67 Early Type Battery	162-II
67 Later Type Battery	163-II
67C Early Type Battery	162-II
67C Later Type Battery	163-II
70 AC	312-III

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

70 DC	312-III
80 AC	153-II
80F	153-II
81 Auto Set	150-II
81B	150-II
81C	150-II
82 AC	151-II
82D DC	152-II
82F	151-II
82Q	18-IV, 19-IV
83 AC	153-II, 327-III
83F	153-II
84 Early Type AC	149-II
84 Later Type AC	155-II
84D DC	152-II
84F	155-II
84Q Battery	154-II
85 AC	156-II, 327-III
85F	156-II
85Q Battery	157-II
86	20-IV
86F	20-IV
87 AC	158-II
87D	21-IV, 22-IV
89 AC	159-II
89F	159-II
89P AC	159-II
90	23-IV
90F	23-IV
91	24-IV
91B	24-IV
91C	24-IV
92	25-IV
92F	26-IV
93 S. W. Converter	27-IV
94	28-IV
94F	28-IV
96 Third Type	29-IV
96F	30-IV
99 Third Type	31-IV
155 Third Type	32-IV
165	33-IV
188 Second Type	34-IV, 35-IV, 36-IV, 37-IV
246	38-IV, 39-IV
260 Third Type	40-IV
266	38-IV, 39-IV
448	41-IV
469 Second Type	42-IV
469D	43-IV, 45-IV, 46-IV, 47-IV
469Q	44-IV, 45-IV, 46-IV, 47-IV
480	48-IV, 49-IV, 50-IV, 51-IV
555 Second Type	52-IV
558	53-IV
558D	43-IV, 45-IV, 46-IV, 47-IV
558Q	44-IV, 45-IV, 46-IV, 47-IV
612	54-IV, 60-IV
627	55-IV
812	57-IV, 60-IV
"D-1" DC	164-II
"D-2" DC	165-II
"F" AC	166-II
"H-1" AC	148-II
"H-2" AC	147-II
"L-1" AC	165-II
"L-2" AC	164-II
"P" AC	166-II
"Q-2" Battery	164-II
Output Measuring Circuit	58-IV, 59-IV

**AUDIOLA RADIO CO.**

4T31RF	168-II
4T32	364-III
6T-31 Pentode	168-II
7T Super-Het 1931	174-II

8T Super-Het	173-II
9T 45 Super-Het 1931	175-II
9T Pentode Super-Het 1931	172-II
10T Super-Het	171-II
13S6	362-III
13S9	363-III
13T5	170-II
23T5	368-III
23T5 SW	364-III
23S8	365-III
23S8Q	366-III
31	170-II, 140A-II
32S11	367-III
Audiola Junior	329-III
Junior 5 Tube AC	169-II
Super-Het, 8 Tube AC	176-II, 140B-II
SW Chassis	368-III

**AUTOMATIC RADIO CO.**

P25	176B-II
P34	176D-II
P35	176D-II
44	176F-II
C45, V45	176F-II
P46, V46	176F-II
Tom Thumb Midget	176H-II
Tom Thumb Portable	340-I

**AZTEC RADIO COMPANY**

5 Tube Pentode	177-II
----------------	--------

**B**

**BALKEIT RADIO CO.**

"E"	178B-II
KP	370-III
L7, LC7	178A-II
L8	369-III
M	371-III
S. G. 6 Midget	178B-II

**BEDE ELECTRICAL INSTRUMENT CORP.**

Preston Model 1931	440-II
--------------------	--------

**BELMONT RADIO CORPORATION**

40	178-II, 182A-II
45	179-II
46	179-II
47	182A-II
48	182A-II
50	180-II
50A	182B-II
50B	182C-II
50C	182D-II
60	182E-II, 182F-II
65	181-II
66	181-II

70	182-II
110	182G-II

**BRANDES PRODUCTS CORP.**

B-11	178-II
B-12	187-II
K-24	189-II
25	188-II
K-38	190-II
K-42	191-II
K-48	61-IV
K-60	193-II
K-62	193-II
K-70	194-II
K-72	194-II
K-80	195-II
K-82	195-II
K-90	196-II
K-92	196-II
6 Tube AC	185-II
7 Tube AC	183-II, 184-II
"B" Power Unit	197-II
Columbia Electric Phonograph	197-II
Columbia C-5	198-II
Columbia 950	198-II

**BREMER - TULLY MFG. CO.**

6-40 Receiver	107-I
6-40 Power Unit	106-I
7-70	108-I
7-71	108-I
8-20A	107-I
8-21A	107-I
81	110A-Is
82	110A-Is
820A	297-III, 346-III
S-81	110B-Is, 110C-Is
S-81	110B-Is, 110C-Is
S-82	110B-Is, 110C-Is
Counterphase, 6	106-I
Counterphase, 8	106-I

**BROWNING DRAKE CORP.**

20	376-III, 4MM-II
MB-30	108A-Is
34	350-I
36	350-I
38	350-I
40	373-III, 4NN-II
54	374-III
69	108B-Is
70	108B-Is
71	108B-Is
80	375-III, 400-II
100	372-III, 4PP-II
JR	372-III, 4PP-II
4 Tube Battery	108C-Is

**BRUNSWICK-BALKE-COLLENDER CO.**

3	267-I
10	267-I, 204-II
11	203-II
12	203-II
12	203-II
14 AC Receiver	202-II
14 Power Unit	109-I, 201-II
14 DC Receiver	206-II
15 Battery	205-II
16	203-II

17	207-II
21 AC Receiver	202-II
21 Power Unit	109-I, 201-II
21 DC Receiver	206-II
24	207-II
25	207-II
31 DC Receiver	206-II
31 Combination Panatropo	110-I
N-1102	199-II
RPA-1A	265-I
RPA-4	265-I
RPA-5 (AP-952)	200-II

**BRUNSWICK RADIO CORP.**

10 A. C.	333-III
14	295-III, 323-III
15	315-III, 321-III, 328-III, 110J-Is
21	295-III, 323-III
22 A. C.	312-III, 315-III, 316-III, 319-III
31	312-III, 323-III
31 A. C.	320-III
2KR0	110H-Is
2KR6	110H-Is
3KR8	110F-Is
3KR0	110H-Is
3NC8	110E-Is
3NW8	110-Is
5KR	110H-Is
5KR6	110H-Is
5KR0	110H-Is
SNO	110D-Is
B-15	110K-Is
DC-15	110L-Is
R-1	110J-Is
S-14	110C-Is
S-21	110C-Is
S-31	319-III
SPU-X-60	110G-Is
SPU-X-341	110G-Is
SPU-X-355	110F-Is
SPU-X-900	110D-Is
SPU-X-901	110E-Is
SPU-X-902	110J-Is
X-822 Chassis	110F-Is
X-1101 Chassis	110D-Is
X-1103 Chassis	110E-Is
X-1104 Chassis	110J-Is

**BUCKINGHAM RADIO CORP.**

Model 80	348-I
----------	-------

**BUD MFG. CO.**

Control Panel	208-II
---------------	--------

**BULOVA CLOCK COMPANY**

M501	377-III
M701	377-III
C751	378-III

**BUSH AND LANE PIANO CO.**

10 De Luxe	111-I
12 Screen Grid	111-I

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

**C**

**CANADIAN MARCONI CO.**

10 De Luxe .....111-I  
 12 Screen Grid .....111-I  
 19 DC .....370-I  
 20 Chassis .....363-I  
 20 Power Unit .....363-I  
 21 Chassis .....364-I  
 21 Power Unit .....365-I  
 22 Chassis .....366-I  
 22 Power Unit .....367-I  
 23 Chassis .....368-I  
 23 Power Unit .....369-I  
 26 .....379-III  
 26 SW .....379-III  
 26 SW & 27 SW con-  
 verter units .....380-III  
 27 SW receiver  
 381-III, 382-III  
 28 .....373-I  
 29 .....373-I  
 31-31 SW .....383-III  
 31 SW converter .....384-III  
 32 .....385-III  
 70 .....374-I  
 80 .....376-I  
 89 .....376-I  
 90 .....377-I  
 99 .....373-I  
 110 .....379-I  
 120 .....380-I  
 III .....370E-Is  
 IV .....370E-Is  
 V .....370C-Is  
 VI .....370E-Is  
 VII .....370C-Is  
 VIII .....370F-Is  
 IX .....370F-Is  
 X Tuner .....370A-Is  
 X—Power Unit .....370F-Is  
 XI .....370B-Is  
 XII Tuner .....370B-Is  
 XII Power Unit .....370D-Is  
 XIII .....370A-Is  
 XIII Power Unit .....370D-Is  
 XIV DC .....360-I  
 XV .....361-I  
 XVI Tuner .....361-I  
 XVI Power Unit .....361-I  
 XVII .....361-I  
 XVIII .....361-I

**CANADIAN WESTINGHOUSE CO., Ltd.**

18 Power Unit .....372-I  
 28 .....373-I  
 29 .....373-I  
 53 .....62-IV, 63-IV  
 55 .....371-I  
 61 .....400-III  
 69 .....373-I  
 70 .....374-I  
 71 .....410-III  
 80 .....375-I  
 81 .....410-III  
 82 .....64-IV, 65-IV  
 89 .....376-I  
 90 .....377-I  
 99 .....378-I  
 101 .....416-III  
 102 .....66-IV, 67-IV  
 110 .....379-I  
 112 SW Converter .....68-IV

120 .....380-I  
 122 .....69-IV, 70-IV, 71-IV  
 801 .....433-III  
 W55A .....371-I  
 W57 .....371-I  
 W58 .....371-I  
 W60 .....371-I  
 Service Oscillator No.  
 H25405 .....388-III  
 Universal Tube Tester.....386-III  
 6 Tube AC, 1928 Model  
 372-I

**CAPEHART CORP.**

28GB Orchestrope .....350-I  
 120 .....440-III  
 140 .....441-III  
 181 .....442-III  
 181½ .....442-III  
 400 .....350C-Is, 350D-Is  
 401 .....350C-Is, 350D-Is  
 402 .....350C-Is, 350D-Is

**CARTER GENEMOTOR CORP.**

Directions for installing  
 Genemotor .....72-IV

**CENTRAL RADIO LAB.**

Volume Control Re-  
 placement Data, 537—544-II

**CLEARTONE RADIO CORP.**

60 Goldcrest .....112-I  
 70 Clearodyne .....113-I  
 80 .....112-I  
 100 Cleartone .....113-I  
 110 Compact .....114-I  
 112 .....114-I

**COLONIAL RADIO CORP.**

16 Battery .....116B-Is  
 31 AC .....115-I, 299-III  
 31 DC .....116-I, 300-III, 340-III  
 32 AC .....117-I, 302-III, 304-III,  
 308-III, 313-III, 317-III,  
 318-III, 320-III  
 32 D.C. ....302-III, 308-III,  
 313-III, 317-III, 320-III  
 33 .....309-III, 319-III, 321-III  
 33 A. C. ....307-III, 314-III  
 34 .....319-III, 321-III  
 36 .....314-III  
 47 .....327-III  
 Colonial D. C. ....306

**COLUMBIA PHONOGRAPH CO., Inc.**

C—1 6 tubes 60 Cycles 118-I  
 C—2 7 Tubes 60 Cycles.118-I  
 C—3 6 Tubes 25 Cycles.118-I  
 C—4 7 Tube 25 Cycles.119-I  
 C—5 .....119-I  
 C—6 6 Tube DC .....123-I

C—7 6 Tube DS .....123-I  
 C—25—31 .....209-II  
 C—25—32 .....209-II  
 C—25—33 .....208-II  
 C—25—34 .....208-II  
 C—31 .....209-II  
 C—32 .....209-II  
 C—33 .....208-II  
 C—34 .....208-II  
 C—34 .....208-II  
 C—80-A .....210E-Is  
 C—80-B .....210F-Is  
 C—90-A, C—90-B, .....210C-Is  
 C—100 .....536-II  
 300 Phonograph .....120-I  
 C—800 .....210D-Is  
 900 Phonograph .....122-I  
 901 Phonograph .....122-I  
 902 Phonograph .....121-I  
 930 Phonograph .....125-I  
 931 Phonograph .....120-I  
 950 Combination .....121-I  
 980 Combination .....124-I  
 980 Power Pack .....123-II

**COLUMBIA RADIO CO.**

Screen Grid 8, 118B-Is, 125-I

**CONSOLIDATED INDUSTRIES PRODUCTS, Ltd.**

See also De Forest-Crosley Ltd.

608-A-B-C-D .....73-IV  
 608-G .....74-IV  
 708-A-B-F .....75-IV  
 801-802 .....76-IV  
 855-855B .....77-IV  
 905 .....78-IV  
 907 .....79-IV

**CONTINENTAL RADIO CORP.**

**(SLAGLE RADIO CO.)**

29-A with 171-L .....126-I  
 29-A with 250-L .....127-I  
 29-B with 171-L .....126-I  
 29-B with 250-L .....127-I  
 29-C with 171-L .....127-I  
 29-C with 250-L .....128-I  
 29-D with 250-L .....128-I  
 29 Series Circuit Data, 128-I  
 Model Nine .....126-I  
 Eleven Tube Model .....129-I

**CROSLEY RADIO CORP.**

3B .....131-I  
 3C .....131-I  
 3R3 .....131-I  
 4-29 .....132-I  
 5-38 .....131-I  
 6-60 .....139-I  
 8-85 .....139-I  
 7 .....444-III  
 7-1 .....451-III  
 7-2 .....451-III  
 20 .....210-II  
 21 .....210-II  
 22 .....210-II

26 .....138D-Is  
 27 .....445-III  
 28 .....445-III  
 28 Series B .....212-II  
 30S .....132-I  
 31S .....132-I  
 33S .....132-I  
 34S .....132-I  
 40S .....132-I, 133-I  
 41A .....139-I  
 41S .....132-I, 133-I  
 42 .....139-I  
 42S .....132-I, 133-I  
 47 .....210A, B-Is  
 51 .....131-I  
 54 .....354-I  
 55 .....138C-Is  
 56 .....138C-Is  
 58 .....138A-Is  
 59 .....138D-Is  
 60S .....134-I  
 61S .....134-I  
 62S .....134-I  
 63S .....134-I  
 76 .....138D-I  
 77 .....213-II, 138F-Is  
 77-1 .....138A-Is  
 82S .....132-I, 153-I  
 84 .....138F-Is  
 90 .....80-IV  
 91 .....138B-Is, 80-IV  
 92 .....80-IV  
 92 Battery .....212-II  
 92 Series B .....212-II  
 104 Power Unit .....213-II  
 104R Power Unit .....213-II  
 105 Power Unit .....213-II  
 105R Power Unit .....213-II  
 106 Power Unit .....213-II  
 120 .....138E-Is  
 121 Series A .....445-III  
 121 Series B .....212-II  
 121-1 Series B .....212-II  
 122 .....214-II, 215-II  
 123 .....214-II, 215-II  
 124 .....215-II, 322-III  
 124-1 .....81-IV, 82-IV  
 125 .....444-III  
 126 .....446-III  
 126-1 .....446-III  
 127 .....445-III  
 128 .....447-III  
 129, 129-1 .....83-IV  
 131 .....447-II  
 132 .....85-IV  
 133 .....86-IV  
 134 434-1 .....87-IV  
 185 .....89-IV  
 136-1 .....90-IV  
 137 .....91-IV  
 141 .....92-IV  
 146-146-1 .....93-IV, 94-IV  
 147 .....95-IV  
 148 .....96-IV  
 150 .....97-IV  
 154 .....98-IV  
 155 .....99-IV  
 156 .....100-IV  
 157 .....101-IV  
 158 .....102-IV  
 150 .....103-IV  
 163 .....104-IV  
 287 Speaker .....215-II  
 297 Speaker .....215-II  
 305-J Speaker .....215-II  
 306-J Speaker .....215-II  
 306-M Speaker .....215-II  
 401 .....133-I  
 401A .....140-I  
 601 .....135-I  
 602 .....219-II, 140-I  
 608 .....133-I  
 609 .....137-I, 306-III  
 610 .....137-I, 306-III

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

704	137-I	810B Motor Board	406-I
704A	134-I	DC-5	381-I
704B	136-I	C-6	381-I
705	211-II, 136A-Is	Bandbox Jr.	382-I
706	136-I	Balmoral	382-I
804	136-Is, 137-I	Barcarolle	383-I
AC-7	130-I	Berwick	382-I, 384-I
AC-7A	130-I	Concerto	384-I
RFL-90	138-I	Conway	381-I
V	131-I	Etude	384-I
XI	131-I	Etude Power Unit	383-I
XJ	210-II	Hastings	381-I, 383-I
XL	210-II	Hastings Power Unit	382-I
Buddy	140-I, 333-III	Minuet	383-I
Chum	140-I, 333-III	Nocturne	384-I
Roamio	211-II	Opera	384-I
Showbox	299-III, 328-III, 342-III	Serenata	344-III
Showchest	299-III	Sonata	384-I
		Symphony	383-I, 384-I
		Warwick	381-I
		Windsor	381-I

## D

### DAVEN RADIO CO.

Bass Note Circuit .....136B-Is

### DAY-FAN ELECTRIC CO.

See also General Motors  
Radio Corp.

A-5003	216-II
5050	216-II
5066	217-II
5069	217-II
5072	218-II
5091	218-II

### DE FOREST CROSLEY, Ltd.

See also Consolidated  
Industries Products, Ltd.

400	385-I
402	389-I
403	389-I
410	385-I
410 Motor Board	391-I
420	385-I
500	452-III
501	452-III
603	392-I
605	392-I
700	388-I, 393-I
701	394-I
702	395-I
705	396-I
707	397-I
749	386-I
740B	398-I
741	399-I
742	400-I
743	401-I
750	386-I
750 Motor Board	402-I
762	403-I
766	404-I
800	387-I
810	387-I
810 Motor Board	388-I
810B	405-I

### DE FOREST RADIO COMPANY

CS-5	353-I
F-5	353-I
D-17	353-I

### DELCO APPLIANCE CORP.

RA-3	288A-Is, 244-II
RB-B & RA-B 2V	466-III
RB-1 & RC-1 110 V. A. C.	469-III
RB-3	238A-Is, 244-II
RC-3	238A-Is, 244-II
3002	219-II
Automobile Set	184-I
Police Set	76A-Is

### DETROLA RADIO CORP.

Roadmaster	510D-Is
------------	---------

## E

### EARL RADIO CORP.

See Chas. Freshman Co., Inc.

### ECHOPHONE RADIO MFG. CO.

S-3	220-II
S-3 Improved	221-II
S-4	222-II
S-5	223-II
40	226-II
60	227-II
80	224-II
90	228-II
F	225-II

### THOMAS A. EDISON, Inc.

C-1	142-I
-----	-------

C-2	142-I, 143-I
C-4	141-I
R-1	142-I
RT-1	143-I
R-2	142-I, 143-I
R-4 AC	141-I
R-4 DC	140D-Is
R-5 AC	141-I
R-5 DC	140D-Is
R-6	140B-Is, 140C-Is
R-7	140B-Is, 140C-Is

### ELECTRAD, Inc.

B-235 Tuner	229-II
B-245 Amplifier	229-II
250 Amplifier	358B-Is
250 Push Pull	358B-Is
D-250 Amplifier	230-II
E-250 Amplifier	230-II
Loftin-White Circuit	63-I
Replacement Resistor	Information 545 to 547-II

### ELECTRICAL RESEARCH LABORATORIES, Inc.

224	142A-Is
225	142B-Is
248 Revised	231-II
250	231-II
271	142D-Is
271A	232-II
Battery operated screen grid receiver	232A-III, 232B-III, 232C-III

### EMERSON RADIO & PHONOGRAPH CORP.

30	107-IV
250	107-IV
300	107-IV
B-10	105-IV
B-AC-10	105-IV
DC-4	106-IV
F	356-I
H-5	107-IV
J	471-III
K-S	471-III
L-AC-4	108-IV
L-AC-5	109-IV
L-456	106-IV
L-457	106-IV
L-458	108-IV
L-459	106-IV
L-460	108-IV
L-556	109-IV
L-557	109-IV
L-559	109-IV
M-AC-7	110-IV
M-755	110-IV
T	471-III
T-S	471-III
Emerson	315-III

## F

### FADA RADIO & ELECTRIC CORP.

7 AC	150-I, 151-I
10 60 Cycles	144-I, 299-III, 307-III
10Z 25 Cycles	144-I
11 60 Cycles	144-I
11Z 25 Cycles	144-I
15	307-III, 309-III
16 60 Cycles	144-I, 299-III, 300-III, 301-III, 307-III
16Z 25 Cycles	144-I
17 60 Cycles	144-I
18 DC	145-I
20 60 Cycles	146-I, 300-III, 301-III
20Z 25 Cycles	146-I
22 Battery	145-I
25 60 Cycles	146-I, 309-III
25 with M-250-Z	147-I
25Z 25 Cycles	147-I
25 with M-250-Z	147-I
32 60 Cycles	144-I, 320-III
30Z 25 Cycles	144-I
31 60 Cycles	144-I
31Z 25 Cycles	144-I
32 60 Cycles	144-I, 320-III
32Z 25 Cycles	144-I
35 60 Cycles	147-I, 304-III, 307-III, 309-III
35Z 25 Cycles	147-I
40 Using P-250 and 7-A	148-I
41 60 Cycles, 154B-Is, 317-III	154B-Is
42 60 Cycles	154B-Is, 313-III, 317-III
43	236E-Is, 326-III
44	317-III, 320-III
45	331-III
46 60 Cycles	154B-Is, 316-III, 317-III, 320-III
47 60 Cycles, 154B-Is, 317-III	331-III
48	238F-II, 331-III
49	148-I, 149-I, 344-III
50 AC	148-I, 149-I, 154-I
62-R	154-I
66Q	154-I
70 AC	148-I, 149-I
71 AC	148-I, 149-I
72 AC	148-I, 149-I
75 60 Cycles	150-I
77 60 Cycles	150-I
86-V	154-I
86-W	154-I
160	154A-Is
192-A Battery	149-I
192-BS Battery	149-I
192-S Battery	149-I
262-UA or CA	153-I
265-A Battery	151-I
265-UA or CA	153-I
460-A Battery	152-I
472-UA or CA	150-I
475-A Battery	151-I
475-UA or CA	152-I
480-A	152-I
480-B	153-I
ABC 6-Volt Unit	154-I
C Electric Unit 60 Cycles	154-I
E-180 Power Unit	149-I
E-420 Power Unit	149-I
J Electric Unit 25 Cycles	154-I
KA-60	154B-Is
KO KOC	236-Is
KU	235-Is
KW	237Is
KY 10 tube, first production	236B-Is
KY 10 tube, second production	236C-Is
R-60	152-I
R-80-A	152-I
RC 11 tube chassis	236D-Is
RE 7 tube chassis	236A-Is
RL	111-IV

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

RP-62-UA or CA	153-I
RP-65-UA or CA	153-I
SF-45/72-UA or CA	150-I
SF-45/75-UA or CA	150-I
SF-50/80-A	152-I
SF-50/80-B	153-I
Neutrodyne, 5 Tubes	154-Is

**FANSTEEL PRODUCTS CO.**

A Receiver	108C-Is
A-3 Receiver	352-I
A-5 Receiver	352-I
A-7 Receiver	352-I
AB 6-135 Form A	104A-Is
AB 6-135 Form B	104A-Is
AB 6-180 Form A	26-I
B-135	104B-Is
B-180 Form B	104B-Is
B, Model D Power Unit	104B-Is
BW	104B-Is
BX	104A-Is
B-11	104B-Is
C Receiver	105-I
F Receiver	105-I
KN	104A-Is
Socket Power "A" Supply	23-I

**FEDERAL RADIO CORP.**

D Ortho Sonic	155-I
D Series Filament	155-I
E Series Filament	158-I
F Series Filament	157-I
H	157-I
K	156-I
L	136B-Is
M	158-I

**FEDERATED PURCHASER, Inc.**

2	234-II
35	233-II
40	233-II
107	233-II

**FORDSON RADIO MFG. CO.**

6T	112-IV, 113-IV
----	----------------

**FREED-EISEMANN RADIO CORP.**

30	162-I
30N	162-I
40	162-I
40N	162-I
48N	162-I
50	162-I
53	166-I
90-S	165-I
91 D. C.	472-III
92 A. C.	472-III
130	163-I
470	165-I
457 Power Unit	164-I
800	166-I
FE-15	114-IV
FE-18	114-IV
FE-96	473-III
FE-98	474-III
NR-5	166A-Is

NR-6	159-I
NR-7	159-I
NR-9	159-I
NR-9A	159-I
NR-10	160-I
NR-11	160-I
NR-12	160-I
NR-20	161-I
NR-55	166B-Is
NR-78	166B-Is
NR-80 AC	166A-Is, 308-III
NR-50 AC	164-I
NR-85	166-I
NR-95	165-I
NR-215	163-I
NR-400	163-I

**JESSE FRENCH & SONS PIANO CO.**

5-093	475-III
G Junior Model	355-I
H-1	232-II
H-2	481-III
U-1	480-III

**CHAS. FRESHMAN CO., Inc. Earl Models:**

21	167-I
21 D. C.	312-III
22	167-I
24 DC	175-I
31	167-I
31 DC	175-I
32	167-I
33S AC	176-I
33 DC	175-I
41	170-I
Earl D. C.	308-III

**Freshman Models:**

2N	173-I, 220-III
3N-12	176A-Is
3Q-15	174-I
3Q-16	174-I
21 AC	174-I
21 DC	175-I
22	174-I
31	176-I
31S	176-I
32	176-I
32S	176-I
41	176-I
121	175-I
G	169-I
H-9	171-I
K	172-I
M	170-I
N	168-I
Q	176A-Is
Q-15	173-I
Q-16	173-I, 313-III, 314-III
QD-16S	168-I, 172-I
Equaphase	171-I, 308-III
Masterpiece	171-I, 308-III

**G**

**GALVIN MFG. CORP.**

4T-47A	437-III
5T-71	482-III
6 Tube Set	486-III
7 Tube Set	455-III
61	483-III
61 Motorola	264E-11s
88	484-III
Motorola	482-III

**GAROD RADIO CO.**

EA	188D-Is
----	---------

**GENERAL ELECTRIC CO.**

B40	115-IV, 116-IV
BX	117-IV
E-52 Phono Circuit	234-II
H-31	266A-Is, 266I-Is
H-32	242-II
H-51	266D-Is, 266H-Is
H-51R	238-II, 239-II
H-71	266B-Is, 266G-Is
H-71R	238-II, 239-II
H-72	238F-11s, 238G-11s
H-91	242A to 242I-11s
H-91R	242A to 242I-11s
J-70	238C, D, E-11s
J-75	238C, D, E-11s
J-80	238H-11s, 238I-11s
J-85	238H-11s, 238I-11s
J-109, 118-IV, 119-IV, 120-IV	
J-125 "Convention" Model	424N-11s
K-40-A	121-IV
K-50-P	122-IV
K-51-P	122-IV
K-54-P	123-IV
K-50-P	124-IV
K-62	243-II
K-65-P	124-IV
L-50	125-IV
L-51	125-IV
S-22	266G-Is
S-42	266G-Is
S-42-B	236F-11s
S-132	238J-11s
T-12	241-II
T-12D	238B-11s
T-41	240-II

**GENERAL MOTORS RADIO CORP.**

**General Motors Models:**

211	176E-11s
216	245-II
217	245-II
219	245-II
220	176C-11s
250	245-II
251	246-II
252	244-II
253	244-II
254	244-I
255	244-II
256	244-II
257	244-IV
258	244-II
281 Converter	242-I-11s
A Chassis	184-I
MA Little General	488-III
S-2-A	246-II
S-2-B	246-II

**Day Fan Models:**

**See also Day Fan Elec. Co.**

5 AC	181-I
5 Tube, 1925 Model	177-I
6 Tube, DC	181-I
6 Tube, 32 Volts	182-I
6-61	180-I
6 AC	180-I, 181-I
6B	180-I
6 Junior	180-I, 181-I
7 Tube	179-I
8 AC	183-I
35	181-I
527	179-I
5044	178-I
5055	358A-Is
5057	183-I
5080	183-I
OEM-7	177-I
OEM-11	177-I
Motor Generator Set	181-I
Power Supply System	182-I
Six	179-I
Seven	179-I

**GILFILLAN BROS., Inc.**

60	185-I
100	185-I
105	176B-Is
106	176B-Is
GN6	176B-Is

**GRAYBAR ELECTRIC CO.**

8	247-II, 266G-Is
700	266A-Is, 266H-Is
770	266D-Is, 266A-Is
900	266B-Is, 266H-Is
Graybarette 4	126-IV

**GRAY & DANIELSON MFG. (Remler)**

R-14	220F-Is
Infradyne, 1927	220F-Is
Infradyne, 1928	220F-Is

**A. H. GREBE & CO.**

AH-1	188B-Is, 188C-Is
CR-6	186-I
CR-13	186-I
CR-18	186-I
MU-1	187-I
ROHN Amplifier	186-I
SK-4	188-I, 188A-Is
671B Power Unit	188B-Is
Synchrophase 7AC	188-I, 189-I
Battery Set, 1923	187-I

**GRIFFIN-GRUNOW CO.**

7F3 Power Unit	194-I, 341-III
7F6 Power Unit	194-I, 341-III
7B13 Power Unit	190-I, 341-III
7B16 Power Unit	190-I, 341-III

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

8P3 Power Unit .....195-I  
 8P6 Power Unit .....195-I  
 9P3 Power Unit .....339-III  
 9P6 Power Unit .....339-III  
 10 S. W. Converter.....258A-Is  
 11 .....182H-Is  
 15 .....250-II  
 15B .....250-II  
 20 .....248-II, 318-III  
 .....329-III, 345-III, 346-III  
 21 .....333-III  
 22 .....248-II, 318-III  
 .....329-III, 345-III, 346-III  
 23 .....248-II, 318-III  
 .....329-III, 345-III, 346-III  
 25 .....256-II  
 25B .....258B-Is, 258D-Is  
 30 .....249-II, 251-II  
 31 .....249-II, 251-II  
 35 .....258C-Is, 258D-Is  
 50 .....192B-Is, 314-III  
 51 .....192B-Is  
 52 .....192B Is, 333-III  
 55 .....255A-Is  
 60 .....252-II  
 .....190-I, 323-III, 333-III  
 61 .....252-II, 190 I  
 62 .....252-II, 190-I  
 70 .....190-I, 333-III, 344-III  
 70B .....191-I  
 71 .....299-III, 344-III  
 72 .....191-I, 294-III  
 .....299-III, 340-III, 344-III  
 80 .....190-I  
 90 .....191-I, 192A-Is, 307-III  
 .....312-III, 324-III, 333-III  
 .....254-II, 192-I  
 90B .....299-III  
 91 .....299-III  
 92 .....299-III, 340-III  
 93 .....299-III  
 100 .....192-I  
 100B .....193-I, 312-III  
 101 .....192-I  
 .....193-I, 312-III  
 102 .....193-I, 312-III  
 103 .....193-I, 312-III  
 110 Auto Radio, 255-II, 256-II  
 116 Auto Radio .....127-IV  
 .....128-IV, 129-IV  
 116A Auto Radio .....130-IV  
 120 .....257-II, 490-III  
 120B .....490-III  
 130 .....196-I  
 130A .....196-I  
 131 .....319-III  
 132 .....319-III, 324-III  
 150 .....250-II  
 160 .....253-II  
 163 .....253-II  
 180 .....193-I  
 181 .....193-I  
 200 .....258E-Is, 182I-Is  
 210 .....258F-Is  
 220 Chassis .....250A to 250H-Is  
 230A .....196-I  
 233 .....196-I  
 290 .....489-III, 4LL-Is  
 291 Madison.....489-III, 4LL-Is  
 293 Adams .....489-III, 4LL-Is  
 294 Monroe .....489-III, 4LL-Is  
 300 .....131-IV, 132-IV, 133-IV  
 310A .....134-IV, 136-IV  
 310B .....135-IV, 136-IV  
 320 .....137-IV  
 330 .....138-IV, 193-IV, 140-IV  
 340 .....141-IV,  
 .....142-IV, 143-IV, 144-IV  
 340B .....141-IV,  
 .....142-IV, 143-IV, 144-IV  
 351 .....258C-Is  
 360 .....145-IV, 146-IV, 147-IV  
 370 .....148-IV  
 390 .....150-IV, 151-IV, 152-IV  
 400 .....153-IV, 154-IV, 155-IV

400A .....156-IV  
 411 .....153-IV, 154-IV, 155-IV  
 413 .....153-IV  
 Old Power Units .....25-I  
 Noise Eliminators .....192A-Is

**GULBRANSEN CO.**

See also Wells-Gardner

5 Tube DC.2580-Is, 258P-Is  
 8 Tube Model .....196H-Is  
 8 Tube Chassis .....258Q-Is, 258R-Is  
 9-in-Line .....197-I  
 13258G-Is, 258H-Is, 258I-Is  
 20 258J-Is, 258K-Is, 258L-Is  
 60 .....258-II  
 63 .....258-II  
 80A .....258M-Is,  
 .....258N-Is, 258P-Is  
 724 .....196H-Is  
 Champion Junior .....196G-Is

**H**

**HALSON RADIO MFG. COMPANY**

515 .....491-III  
 515 SW .....492-III  
 516 D. C. ....493-III  
 615 .....494-III  
 Long & Broadcast .....495-III

**HAMMARLUND MFG. CO.**

Comet .....258S-Is, 264A-Is  
 .....264B-Is, 264C-Is, 264D-Is  
 Comet Pro .....496-III  
 Hi-Q 5 Tube Battery, 356C-Is  
 Hi-Q 6 Tube Battery, 356C-Is  
 Hi-Q 6 Power Unit.....356C-Is  
 Hi-Q 30 AC .....51-I  
 Hi-Q 30 Battery .....356D-Is  
 Hi-Q 31 AC .....356-I  
 Z-4 Commander .....356D-Is

**HATRY & YOUNG, Inc.**

Short Wave 6 .....188D-Is

**HICKOCK ELECTRICAL INSTRUMENT CO.**

SG-4700 .....440-II  
 4949 Ohm-Capacity-Volt meter .....441-II

**HIGH FREQUENCY LAB.**

225 .....498-III  
 226 .....497-III  
 227 .....499-III

238 .....498-III  
 242 .....497-III  
 280 .....499-III  
 Mastertone, 1929 .....356B-Is  
 Mastertone, 1931 .....356A-Is  
 Nine-in-Line, Battery.....356B-Is

**CHAS. HOODWIN CO. (Aero)**

4T Series A .....506-III  
 5T-1933 Series A .....504-III  
 6-33 A. V. C. ....505-III  
 110 Volt D. C. ....504-III  
 1929-1930 Auto Radio.....196L-Is  
 1931 Auto Radio .....196O-Is  
 1931 Midget .....196O-Is  
 1932 Converter .....503-III  
 Aero Pentode Auto B.....500-III  
 Aero Seven .....196M-Is  
 Aero World Wide Series  
 Radio .....501-III  
 Aerodyne AC7 .....196N-Is  
 International All-Wave  
 .....196K-Is  
 Low Power Trans., 1931  
 .....196L-Is  
 Metropolitan AC Four  
 .....196K-Is  
 One Tube Transmitter, 267-H  
 Pentode Power Am-  
 plifier .....502-III  
 Pentode Power Am-  
 plifier model B .....502-III  
 Pentode Transmitter .....503-III  
 Short Wave Adapters 196M-Is  
 Short Wave Con-  
 verters .....196L-Is  
 Trio AC Three .....196N-Is  
 Two Tube Transmitter.268-II  
 Two Tube 15 watt  
 Trans. .....196K-Is  
 World Wide One Tube.....267-II

**HORN RADIO CO.**

15 .....358D-Is  
 49 .....265-II  
 59 .....265-II, 548-II  
 69 .....548-II  
 79 .....549-II  
 99 .....549-II  
 109 .....549-II

**HOWARD RADIO CO.**

8 Green Diamond .....196B-Is  
 45 .....258T-Is  
 60 Combination .....263-II  
 135 .....264-IF  
 AP .....157-IV  
 AVH .....261-II  
 H .....260-II  
 K .....158-IV, 159-IV  
 L .....160-IV, 161-IV  
 M .....162-IV  
 O .....261-II  
 SG-A .....196A-Is  
 SG-B Midget .....196C-Is, 259-II  
 SG-T .....258U-Is  
 SG-6 .....196D-Is

**I**

**INSULINE CORP. OF AMERICA**

Broadcast & long Wave  
 Combination AC .....269-II  
 Broadcast & Long Wave  
 Combination DC .....270-II  
 Insulette BC & LW .....272-II  
 Mascot .....272-II  
 Midget, 110 V. AC .....271-II  
 Midget, 110V. DC .....270-II  
 Midget, 220V. DC .....271-II  
 Short Wave Set AC .....340-I

**J**

**JACKSON-BELL, LTD.**

5 .....507-III  
 5A .....507-III  
 8 .....278B-Is  
 25 .....508-III  
 26 .....509-III  
 27 .....510-III  
 28 .....511-III  
 29 .....513-III  
 33 .....515-III  
 50 .....278C-Is  
 59 .....516-III  
 60 .....274-II  
 62 .....354-I, 517-III  
 63 .....517-III  
 64 .....517-III  
 68 .....278D-Is  
 69 DC .....278E-Is, F-Is  
 79 .....278G-Is  
 84 Peter Pan .....275-II  
 86 .....518-III  
 87 .....276-II  
 88 .....277-II  
 89 .....278H-Is  
 89A .....278-II  
 96 .....519-III  
 99 .....520-III  
 645M .....278I-Is  
 845 .....520-III  
 845S .....278J-Is  
 S .....278A-Is

**JENKINS & ADAIR, Inc.**

3-B Mixing Panel .....196E-Is  
 A Amplifying Panel.....196F-Is  
 C-6 Transmitter .....521-III  
 C-12 Condenser Trans-  
 mitter .....273-II  
 D Amplifying Panel, 196F-Is  
 D-6 .....521-III  
 GL-35 .....273-II  
 Level Indicator Panel  
 .....196E-Is

**JEWELL ELECTRICAL INSTRUMENT CORP.**



PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

**JEWELL ELECTRICAL INSTRUMENT CORP.**

214 Tube Checker	522-III
444 Tester	441-III
533 Tube Checker	523-III
534 Tube Checker	524-III
538 Tube Checker	522-III
560 Oscillator	442-II
WD209 Tube Checker	442-II

**K**

**KELLER- FULLER MFG. CO., Ltd.**

14F Radiette	355-I
20	279-II
30	525-III
40	525-III
50	328B-Is
60	328B-Is
70	280-II
80	281-II

**KELLOGG SWITCHBOARD & SUPPLY CO.**

B Chassis	199-I
6 Tube Battery	198-I
7 Tube AC	198-I
7 Tube RFL	201-I
523	200-I
524 Power Unit	199-I
525 Power Unit	199-I
526	200-I
527 Power Unit	199-I
528 Power Unit	199-I
533	200A-Is
534	200A-Is
535	200A-Is
536	200A-Is
Wave Master	201-I

**COLIN B. KENNEDY CORPORATION**

6	203-I
7 Comet DC	204-I
10	205-I
20	204-I, 205-I
23 DC	282-II
24	258V-1Is, W-1Is
26	283-II
30	204B-Is
32	204B-Is
34 SW	284-II
36 DC	282-II
38 DC	282-II
40 DC	282-II
42	285-II
50	282-II
52	285-II
53 SW	526-III
54	286-II
54A SW	527-III
55	527-III
56	258X-1Is
60	286-II
62	331-II, 528-II

62A	530-II
63	530-II
64	531-II
64B	531-III
66	532-III
66A	532-III
66B	532-III
80	204B-Is
110	202-I
220	202-I
281	202-I
430	203-I
431	203-I
435	204-I
521	204-I
525	204-I
526	319-III
632	325-III
826B	204A-Is

**KING MFG. CORP.**

10 KI	206-I
25	206-I
30	206-I
61	206-I
62	206-I
71	206-I
80	207-I
81	207-I
82	208-I
97	210-I
98	210-I
218	287-II
E	207-I
F	208-I
FF	220E-Is
G	211-I
H	209-I
J	210-I
Monarch	210-I
Power Packs	211-I

**KOLSTER RADIO, Inc.**

6 Battery	213-I
6H	214-I
6K	212-I, 340-III
7A	214-I
7B	214II
7 AC	213-I
8 A, B, C	214-I
B-10	217-I
B-15	290A-1Is, 217-I
B-16	290A-1Is, 217-I
K-20	218-I, 218A-1Is, 299-III, 307-III, 310-III, 312-III
K-21	218-I, 299-III
K-22	218-I, 218A-Is
K-23	218-I
K-24	218-I
K-25	218-I, 218A-Is
K-27	218-I, 218A-Is
K-28	218-I
K-30	218B-Is
K-32	218B-Is
K-37	218A-Is
K-42	218B-Is
K-43	215-I, 315-III, 319-III
K-44	215-I
K-45	216-I
K-60	288-II
K-62	288-II
K63	533-III
K65	310-III
K-70	289-II
K-72	289-II
K73	533-III
K-80	290-II

K-82	290-II
K83	534-III
K-90	291-II
K-92	291-II
K93	534-III
K103	533-III
K140	264F-1Is
K142	264F-1Is
930 Columbia	212-I

Unitune 8	556-II
-----------	--------

**MILLS NOVELTY CO.**

Phonograph Wiring	218C-Is, 218D-Is
-------------------	------------------

**MONTGOMERY WARD & CO.**

See also Wells-Gardner

11	539-III
12	539-III
17	541-III
20	296-II
22	551-III
26P	297-II
26PX	297-II
26W	300R-1Is
26-360	297-II
26-367	297-II
62-2	542-III
62-7	544-III
62-8	544-III
62-9	544-III
62-11	300C, D, E, F-1Is
62-13	300A, 300B-1Is
62-12	300C, D, E, F-1Is
62-14	300C, D, E, F-1Is
62-15	300A, 300B-1Is
62-16	300A, 300B-1Is
62-18	300A, 300B-1Is
62-20	300L, M, N-1Is
62-21	300G, H, I-1Is
62-22	300G, H, I-1Is
62-23	300J, 300K-1Is
62-25	300L, M, N-1Is
62-30	300G, H, I-1Is
62-34	545-III
62-38	546-III
62-44	546-III
62-50	546-III
62-52	300-O, P, Q-1Is
62-030	300S-1Is, 300T-1Is
62-060	300R-1Is
62-070	300R-1Is
62-232	300S-1Is, 300T-1Is
62-520	296-II
62-1040	299-II
62-1838	300, V, W-1Is
62-3235	300S-1Is, 300T-1Is
181	300-II
187	300-II
500	300Y-1Is
811	298-II
811X	298-II
1111	298-II
1111X	298-II
1838	300U, V, W-1Is
1355	298-II
1500	300X-1Is
1522-1562	218M-Is
1238	300U, V, W-II
1955	298-II
2822	218M-Is
2827	218M-Is
2895	218M-Is
8 AC	219-I
900	219-I
2955	218N-Is
2957	218N-Is
3035	218N-Is
3037	218N-Is
3065	218N-Is
3067	218N-Is
AC-9	550-II, 562-II
AC-11	560-II
Ultra 5	552 II
Ultra 6	554-II
Ultra 7	544-II
Ultra 8 Battery	558-II
Unitune 5	552-II
10,000	300Y-1Is
11,000	300Z, AA, BB-1Is
14,000	300CC-1Is
15,000	300X-1Is
62,000	300CC-1Is
AE-10	547-III

**L**

**LANG RADIO COMPANY**

BA-5 AC	293-II
BD-6 AC	292-II
DC-6	163-IV
F-9 DC	293-II
J-7 DC	292-II
M-7 AC	292-II
R-8 DC	293-II

**C. R. LEUTZ, Inc.**

Seven Seas Console	338-I
Universal Trans-Oceanic	338-I

**LINCOLN RADIO CORP.**

10 De Luxe	538-III
31	357-I
32 S. W.	538-III
DC-8	358C-Is

**LONG RADIO CO.**

70 Cardinal	108D-Is
-------------	---------

**M**

**MASTER RADIO MFG. CO., Ltd.**

424 Master Model	355-I
------------------	-------

**MC MILLAN RADIO CO.**

8 AC	219-I
900	219-I

**MIDWEST RADIO CORP.**

AC-9	550-II, 562-II
AC-11	560-II
Ultra 5	552 II
Ultra 6	554-II
Ultra 7	544-II
Ultra 8 Battery	558-II
Unitune 5	552-II

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

MOTOMETER GAUGE & EQUIPMENT CORP.

- 10A Motovox 164-IV
10E Motovox 164-IV

N

NATHANIEL BALDWIN CO.

- 80 324-I

NATIONAL CARBON CO. Inc.

- 1 220-I
2 220-I
3 220-I
20 220E-Is
21 220E-Is
30 221-I
30C 221-I
40 221-I
1929 340-III
Eveready 315-III
Eveready Tube Tables 630-III, 631-III

NATIONAL CO., Inc.

- MB-29 220B-Is
MB-30 220B-Is
SW-3 220A-Is
SW-4 220A-Is
SW-5 220C-Is
Auto Receiver 220C-Is
Browning Drake 4 Tube Bat. 301-II
Browning Drake 5 Tube Bat. 301-II
One Tube Reflex 301-II
Television Receiver 220C-Is

NATIONAL TRANSFORMER CO.

- Midget Six 358E-Is
Screen Grid 8 358F-Is

O

OZARKA, Inc.

- 5A Viking 358G-Is
78 358 I-Is
89 358H-Is, 343-III
90 358H-Is
91 290B-Is
91 AC 302-II, 358 I-Is
92 AC 561-III
93A 562-III

- 93B 565-III
93 Battery 566-III
94 A. V. C. 566-III
95WDI 302-II
S-5 358G-Is
S-7 358G-Is
S. W. Converter 567-III
V-16 567-III

P

PACENT ELECTRIC CO., Inc.

- Booth connections, film reproducer 303-II, 304-II
Disc and film reproducer 305-II

PFANSTIEHL PRODUCTS CO.

- 34 230F-Is
50 230F-Is

PHILCO RADIO & TELEVISION CORP.

- 4 S.W. Converter 310A-Is
5 230F-Is
7 569-III, 168-IV
14 187-IV
15 310 I-Is, 310J-Is, 310K-Is
16 170-IV, 171-IV, 172-IV, 173-IV
19 183-IV
20 226B-Is
20A 226B-Is
22L 570-III, 187-IV, 188-IV
23X 570-III
30 309-II
35 310-II
37 174-IV
40 222-I
41 222-I
43 175-IV, 176-IV, 177-IV, 178-IV
46 226G-Is
46E 226G-Is
47 571-III
48 179-IV, 180-IV, 181-IV, 182-IV, 183-IV
50 306-II
50A 306-II
51 310B-Is, 310C-Is
51A 310B-Is, 310C-Is
30 184-IV, 185-IV
65 223-I, 226B-Is, 308-III
70 326A-Is, 326B-Is, 226K-Is, 332-III
70A 326A-Is, 326B-Is, 226K-Is
71 573-III, 187-IV, 188-IV
76 223-I, 318-III, 345-III
77 224-II, 317-III, 345-III
77A 224-I
80 308D-Is, 308E-Is, 308F-Is, 188-IV, 189-IV
81 190-IV, 191-IV
82 224-I

- 86 224-I
87 225-I, 295-III, 305-III, 308-III
89 183-IV
90 326C-Is, 326D-Is, 226L-Is, 333-III
90A 226L-Is
91 310L-Is, 310M-Is, 310N-Is, 187-IV
91A 187-IV
95 226C-Is, 227-I, 345-III
95E 226C-Is
96 226-I, 226C-Is, 318-III, 345-III

- 96A 226-I, 226C-Is
96E 226C-Is
111 226D-Is, 226H-Is, 318-III, 333-III, 445-III

- 111A 226D-Is, 226H-Is
112 226 I-Is, 332-III
112A 226I-Is
112X 331-III
211 226F-Is
211A 226F-Is
212 226J-Is
212A 226J-Is
220 226E-Is
220A 226E-Is
270 226J-Is
270A 226J-Is
296 226-I, 226C-Is
296A 226-I, 226C-Is
296E 226C-Is
470 310D-Is, 310E-Is
470A 310D-Is, 310E-Is
490 310F-Is, 310G-Is
511 227-I
512 227-I
513 227-I
514 227-I
515 227-I
531 227-I
551 227-I
571 227-I

- Baby Grand 310-III, 317-III
Combination 315-III
Neutrodyne Plus 344-III

Power Units:

- AB-423 226A-Is
AB-463 226A-Is
AB-623 266A-Is
AB-663 266A-Is
B-253 266A-Is
B-603 266A-Is
DAB 226A-Is
DB 226A-Is
180 Volt "B" 226A-Is
Battery Life Chart 308

- 76-O-Is
By-Pass Condenser Data 326E-Is
Chassis Data 326F-Is
Oscillator Calibration 326G-Is

- Resistor Data 76-O-Is

Transitone:

- 3 307-III
5 165-IV, 166-IV, 167-IV
6 168-IV
6F 168-IV
8 169-IV
9 169-IV
12 169-IV
EG 167-IV
NR-109 75-I
TR-106 75-I

PIERCE AIRO, Inc.

- 14-45 311-II
24-45 352-I

- 273 DC 313-II
447M 313-II
524 355-I
534-5 312-II
547 314-II
547A 314-II
632 DC 358C-Is
637-8 319-II
646-7 315-II
724 316-II
727 DC 317-II
734-5 318-II
746-7 320-II

PILOT RADIO & TUBE CORP.

- 5 Tube TRF Midget 321-II
5 Tube BC & Long wave Midget 320E-Is
6 Tube Midget 354-I
7 Tube D. C. 580-III
7 Tube Super, 110v. DC 323-II
7 Tube Super, 220 v. DC 322-II
11 Dragon DC 194-IV
11-A DC 194-IV
11-R DC 194-IV
35 195-IV
39 195-IV
41 196-IV
C-151 230B-Is
C-153 230A-Is
C-154 230A-Is
C-157 230D-Is
C-157A 230D-Is
C-157B 230D-Is
C-158 230D-Is
C-162 230B-Is
K-106 230-I
K-108 230-I
K-10 Super Wasp 228-I
K-113 228-I
K-115 AC Super Wasp 73-I
K-139 230E-Is
PE-6 228-I
S-141 Universal 230E-Is
S-155 230D-Is
S-155A 230D-Is
S-155B 230D-Is
S-156 230D-Is
S-164 230B-Is
SG-8 229-I
SG-105 230-I
V-191 Converter 580-III
W-145 P.A. Amplifier 230C-Is

- A. C. Dragon 575-III
Automobile Receiver 229-I
Grimes DC New Yorker 229-I
Pilotone 6 228-I
Pre-Selector 358J-Is
SW Converter 321-II, 230C-Is

PRIESS RADIO CO.

- Nine-in-Line 357-I

R

RADIO PRODUCTS CO.

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

**RADIO PRODUCTS CO.**

L Tube Checker .....443-II  
880 .....443-II

**RADIO RECEPTOR, Inc.**

AR-3 .....363-II  
C Announcer .....352-II  
CAM-3 .....352-II  
H-1 .....358-II  
MM3-PMX3 .....361-II  
P-50-W .....359-II  
PMA-1 .....357-II  
PMA-1 AX-1 Panel .....359-II  
PMA-1 AX-2 Panel .....358-II  
PMA-2 .....354-II  
PSA-2 .....362-II  
PWA-1 .....356-II  
PX-245 .....360-II  
PXP-245, 355-II, 356-II, 361-II  
PXP-250A .....355-II  
PYP-245 .....357-II, 362-II  
PYP-245R .....354-II  
PYP-250 .....364-II  
R-80-81 .....353-II  
RS-81 .....364-II  
RXP-171 .....360-II

**RADIO TECHNIC LABORATORY**

Television Receiver .445D-IIs

**RCA-PHOTOPHONE, Inc.**

4-PA50A1 .....344-II  
4-PK1A2 .....341-II  
PG-5 .....343-II, 345-II  
PG-6 .....348-II, 351-II  
PG-7 .....349-II  
PG-10 .....350-II  
PG-13 .....347-II

**RCA-VICTOR, Inc.**

7-1 .....231-I  
7-2 .....233-I  
7-3 .....234-I  
7-10 .....234-I  
7-11 .....236-I  
7-25 .....237-I  
7-26 .....234-I, 242-I  
7-30 .....234-I  
9-1 .....233-I  
9-15 .....237-I  
9-18 .....241-I  
9-25 Electrola .....232-I  
9-40 Electrola .....232-I  
9-54 .....239-I, 242-I  
9-55 .....238-I  
10-51 .....240-I  
10-69 .....239-I, 240-I  
10-70 .....235-I, 242-I  
12-15 .....236-I  
12-25 .....235-I  
14 .....325-III  
16 .....234-I, 246-I, 296-III  
17 .....237-I, 252-I,  
296-III, 308-III, 340-III  
18 .....236-I  
252-I, 296-III, 308-III  
18 A. C. ....299-III, 300-III  
18 D. C. ....262-I, 305-III  
20 .....247-I, 340-III

22 .....264-I  
24 .....249-I  
25 AC .....330-II  
25 Battery .....250-I  
26 .....249-I  
28 .....331-II  
235-I, 242B-Is, 254-I, 266F-Is  
30 .....247-I  
30A .....264-I, 301-III, 313-III  
32 .....309-III, 340-III  
33 .....251-I, 305-III  
33 DC .....253-I  
35 .....342-III  
41 .....257-I, 340-III  
41 A. C. ....299-III, 310-III  
41 DC .....261-I  
42 .....326-III  
44 .....266-I, 267-I, 295-III,  
298-III, 302-III, 340-III  
44 A. C. ....301-III, 310-III  
45 .....214-III, 309-III  
46 .....298-III,  
302-III, 319-III, 332-III  
46 A. C. ....301-III, 310-III  
46 DC .....251-I  
47 .....255-I, 259-I, 315-III  
48 .....322-III,  
325-III, 326-III, 600-III,  
340-III  
50 .....260-I, 305-III  
51 DC .....261-I  
60 .....252-I,  
310-III, 318-III, 328-III  
62 .....262-I, 303-III, 310-III  
64 .....256-I, 302-III, 310-III  
66 .....263-I, 316-III  
67 .....248-I, 258-I, 316-III  
68 .....331-III  
80 .....325-III  
82 .....266D-Is, 325-III  
86 .....266B, C-Is, 325-III  
99X .....331-III  
100A Speaker .....324-I  
100B Speaker .....325-II  
103 Speaker .....325-II  
104 .....325-II  
104 RPA .....254-I  
105 .....257-I  
106 .....326-II, 266F-Is  
II .....244-I  
III .....243-I  
IIIA .....245-I  
IV .....244-I  
V .....244-I  
VI .....244-I  
VII .....243-I  
VIIB .....339-II, 246-I  
VIII .....249-I  
IX .....245-I  
AP-736 .....238-I  
AP-777C .....235-I  
AP-810 .....249-I  
AP-935 .....256-I  
AP-937 .....246-I  
AP-947 .....241-I  
AP-951 .....236-I, 256-I  
AP-952 .....236-I, 241-I  
AP-974A .....236-I  
AP-997 .....236-I, 241-I  
AP-997A .....236-I  
AP-997C .....328-I  
AR-812 .....249-I  
AR-1145 .....332-II  
CE-29 .....592-III  
M-30 .....300DD-IIs  
M-34 .....197-IV, 198-IV, 199-IV  
P-31 .....596-III  
PG-62 .....200-IV, 201-IV  
PT-15 .....202-IV  
R-5 .....334-II, 266J-Is  
R-5 DC .....336-II  
R-6 .....326H-IIs  
R-7 .....266G-Is

R-7A .....327-II  
R-7 DC .....337-II  
R-9 DC .....337-II  
R-10 .....584-III  
R-11 .....335-II, 330-III  
R-12 .....326 I to 326M-IIs  
R-14 .....242A-Is  
R-15 .....266D-Is  
R-20 .....326N to 326P-IIs, 234-I  
R-21 .....326N to  
326P-IIs, 264-I, 347-III  
R-24 .....203-IV, 204-IV  
205-IV, 206-IV, 207-IV  
R-27 .....208-IV, 209-IV  
R-28 .....210-IV, 211-IV  
R-28W .....212-IV, 213-IV  
R-32 .....240-I, 266-I,  
297-III, 341-III, 342-III  
R-35 .....266E-Is  
R-37 .....214-IV, 215-IV  
R-38 .....214-IV, 215-IV  
R-39 .....266E-Is  
R-42 .....240-I, 242A-Is  
R-43 .....333-II  
R-45 .....341-III  
R-50 .....338-II, 260-I, 330-III  
R-55 .....338-II, 330-III  
R-70 .....216-IV  
R-71 .....604-III  
R-71B .....217-IV, 218-IV  
R-72 .....604-III  
R-73 .....219-IV, 220-IV  
R-74 .....221-IV,  
222-IV, 223-IV, 224-IV  
R-75 .....225-IV, 226-IV  
R-76 .....221-IV  
222-IV, 223-IV, 224-IV,  
221-IV  
R-77 .....222-IV, 223-IV, 224-IV  
R-78 .....424N-IIs, 583-III  
R-80 .....266A-Is  
R-90 .....227-IV, 228-IV  
RAE-59 .....326Q-IIs, 326R-IIs  
RAE-68 .....340-II  
RAE-79 .....606-III  
RAE-84 .....229-IV,  
230-IV, 231-IV  
RE-17 .....226I-Is  
RE-35 .....321-III  
RE-39 .....321-III  
RE-40 .....232-IV, 233-IV  
RE-45 .....240-I, 297-III,  
316-III, 342-III, 344-III  
RE-57 .....266E-Is, 321-III  
RE-75 .....240-I  
RE-80 .....234-IV, 245-IV  
RE-81 .....326-IV, 237-IV  
RO-23 .....585-III  
RPA-1A .....265-I  
RPA-4 .....265-I  
SW-3 .....203-IV, 204-IV,  
205-IV, 206-IV, 207-IV  
SWA-2 .....616-III  
T-5 .....339-II  
Alhambra 1 .....231-I  
Alhambra 11 .....233-I  
Auditorium Phonograph  
340R to 340V-IIs  
Borgia 11 .....231-I  
Electrola Cromwell .....231-I  
Florenza .....233-I  
Radiola AR .....243-I  
Radiola RS .....243-I  
Radiola Grand .....245-I  
Radiola Senior .....243-I  
S. W Adapter .....617-III  
Theremin .....328-II

AF-6175 Speaker .....340C-IIs  
ER-1240 .....340D to 340H-IIs  
ER-124A 340 I to 340M-IIs  
ER-1240-AZ .....238-IV  
239-IV, 240-IV  
RF Distribution Sys-  
tem .....329-11  
RF-5100 DC .....340A-IIs  
RF-5600 .....340B-IIs

**READRITE METER WORKS**

245 Set & Tube Tester .....444-II  
400 Tube Tester .....445-II  
450 Short Checker .....444-II  
550 Oscillator .....445-II  
600-700 Tester .....446-II

**REMLER COMPANY, Ltd.**

10 .....618-III  
11 .....619-III  
14 .....345-I, 332-III  
15 .....366-II  
17 .....620-III  
19 .....310H-IIs  
21 .....365-II  
45 kc. Super .....340-I  
Adjustment diagrams,  
366B-IIs  
Cameo Screen Grid .....366A-IIs

**ROBERTSON-DAVIS CO.**

Melo-Heald, 11 Tube  
Super .....357-I

**ROLA COMPANY**

80 .....367-II  
90 .....367-II

S

**SAMSON ELECTRIC COMPANY**

PAM-5 .....371-II  
PAM-9 .....369-II  
PAM-16 .....372-II  
PAM-16N .....370-II  
PAM-17 .....372-II  
PAM-17M .....370-II  
PAM-19 .....374-II  
PAM-25 .....373-II  
PAM-M1K1 .....375-II

**SANGAMO ELECTRIC CO.**

250 Amplifier .....450-II  
3 Stage Amplifier .....450-II

**CENTRALIZED RADIO:**

AF-6100 .....340N to 340P-IIs

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

**E. H. SCOTT RADIO LABORATORIES**

All-Wave Super .....196P-Is

**SEARS, ROEBUCK & CO.**

36 .....376A-IIs, B-IIs  
 36P .....376C-IIs, D-IIs  
 37 .....376E-IIs, F-IIs, I-IIs  
 37P .....376D-IIs  
 39-125 .....621-III  
 40 .....623-III  
 41 .....376G-IIs, I-IIs, 628-III  
 41P .....376H-IIs  
 42 .....628-III  
 43 .....623-III  
 44 .....376J-IIs, K-IIs  
 46 .....627-III  
 47 .....376L-IIs, M-IIs, N-IIs  
 48 .....376L-IIs, M-IIs, N-IIs  
 49 .....625-III  
 50 AVC .....376-O-IIs, P-IIs  
 F .....200B-Is  
 FF .....200B-Is  
 G .....200B-Is  
 H .....200B-Is  
 J .....200B-Is

**SENTINEL RADIO CORP.**

7-Tube Band Pass.....495-II  
 7 Tube Super .....493-II  
 8 Tube Super .....494-Is  
 8 .....346B-Is  
 9 .....346B-Is  
 11 .....346A-Is  
 12 .....346A-Is  
 15 .....346A-Is  
 16 .....346A-Is  
 31 .....346B-Is  
 33 .....346B-Is  
 104 .....346A-Is  
 108A .....241-IV  
 109 .....241-IV  
 264 .....242-IV  
 444 .....495-IIs, 348-Is  
 513 .....243-IV  
 550 .....244-IV  
 610 .....245-IV  
 660 .....346-I  
 666C .....495A-IIs, 346-I

**SHORT WAVE AND TELEVISION LAB.**

Baird Television Receiver .....376-II

**SILVER-MARSHALL, Inc.**

30 .....268-I  
 30-B .....378-I, 268G-Is  
 33-A .....268A-Is  
 34-A .....268B-Is  
 35-A .....268B-Is  
 36-A .....268C-Is  
 37 .....268E-Is  
 38 .....268E-Is  
 39 .....268E-Is  
 60 .....268-I  
 75 .....268-I  
 95 .....268-I  
 630 .....268G-Is

677B .....394-II  
 679 .....394-II  
 679B .....391-II  
 683 .....383-II  
 684 .....384-II  
 686 .....389-II  
 690 .....340-I  
 692 .....385-II  
 712 .....268D-Is  
 714 .....268E-Is  
 716 .....383-II  
 720 .....59-I  
 722 AC .....286D-Is  
 722 DC .....379-II  
 724 .....268D-Is  
 726 SW .....381-II  
 737 .....393-II  
 738 .....392-II  
 739 .....386-II  
 782-16 .....377-II  
 A .....382-II  
 D .....387-II  
 F .....388-II  
 G .....390-II  
 Q .....394A-Is  
 R .....394B-Is  
 SMD-1 .....380-II  
 9 Tube Super, 1929 .....268A-Is

**SILVER MARSHALL MFG. CO.**

Z-13 .....246-IV

**SIMPLEX RADIO CO.**

H .....368-II  
 K .....368-II  
 L .....394A-IIs  
 N .....247-IV  
 N-D.C. ....247-IV  
 P .....248-IV  
 Q .....248-IV

**SONORA PHONOGRAPH**

**CO., Inc.**  
 2-RP-25 .....269-I  
 3-R .....270-I  
 3-RP .....271-I  
 4-R .....270-I  
 5-R .....272-I  
 7-P .....273-I  
 30 .....336-III  
 32 .....336-III  
 36 .....336-III  
 40 .....335-III, 336-III  
 44 .....300-III, 335-III, 336-III  
 46 .....335-III, 336-III  
 A-36 .....268H-Is, 335-III  
 A-44 .....313-III, 326-III  
 B-31 .....274-I  
 E-AC .....268H-Is  
 Combination .....320-III

**SPARKS-WITHINGTON COMPANY**

5 .....397-II  
 5-15 .....281-I  
 5-26 .....281-I  
 6-15 .....278-I  
 6-26 .....278-I  
 9 .....397-II

9A .....410-II  
 9-30 .....276-I  
 10 .....403-II  
 12 .....645-III  
 15 .....408-II  
 16 .....647-III  
 16AW Broadcast .....6:7-III  
 16AW Short Wave .....639-III, 640-III  
 25 .....413-II  
 26 .....413-II  
 26AW Short Wave .....639-III, 640-III  
 28 Triolian .....424R-IIs  
 30 .....407-II  
 31 .....404-II  
 39 .....275-I  
 40 .....406-II, 310R-IIs  
 41 .....654-III  
 45 .....641-III  
 49 .....276-I  
 51 .....405-II  
 52 .....405-II  
 56 .....643-III  
 60 Converter .....648-III  
 89 .....279-I  
 89A .....275-I, 345-III  
 101 .....649-III  
 103 .....398-II  
 109 .....279-I  
 110 .....281-I  
 210 .....329-III  
 235 .....409-II  
 301 AC .....280D-Is  
 301 DC .....300-III, 311-III  
 400 .....277-I  
 410 AC .....323-III  
 410 AC .....411-II  
 410 EC .....400-II  
 420 AC .....411-II  
 420 DC .....400-II  
 584 .....395-II  
 584 .....395-II  
 578 .....401-II  
 589 .....398-II  
 591 .....280C-Is  
 591 .....414-II, 331-III  
 593 .....414-II  
 600 AC .....412-II, 322-III  
 600 DC .....402-II  
 610 AC .....412-II  
 610 DC .....402-II  
 620 AC .....412-II, 322-III  
 620-DC .....402-II  
 737 .....399-II, 412-II  
 740 .....321-III, 322-III  
 740 DC .....395-II, 321-III, 322-III  
 750 .....402-II  
 750 DC .....395-II  
 870 .....402-II  
 930 .....401-II  
 930 .....651-III  
 931 AC .....652-III, 653-III, 310-III  
 931 DC .....280B-Is  
 AC-7 .....277-I, 300-III  
 AC-62 .....249-IV  
 AC-63 .....249-IV  
 AR-19 .....249-IV  
 AR-19 .....396-II  
 Sparks Ensemble .....280-I, 280A-Is  
 Sparton D. C. ....306-III  
 Sparton Tube Tables .....638-II  
 Tube used in Sparton Receivers .....634-III  
 635-III, 636-III, 637-III

**SPLITDORF ELECTRIC MFG. CO.**

171 .....324-I  
 M-5 .....322A-Is  
 M-6 .....322B-Is  
 PAD-4 .....322-I  
 R-100 .....322B-Is  
 R-200 .....322-I  
 RV-695 .....322A-Is  
 Abbey .....322-I  
 Inherently Electric .....324A-Is

**STAIRS-WINTERS CO.**

Television Receiver .....455C-IIs

**STANDARD RADIO CORP.**

29 .....342-I

**STANDARD RADIO MFG. CORP. Ltd. (Rogers)**

Advanced Chassis .....414A-IIs  
 220 .....414B-IIs  
 250 .....414C-IIs  
 400 .....414C-IIs  
 451 .....414E-IIs  
 545 .....414F-IIs  
 640 .....578C-IIs  
 831 .....578C-IIs

**STARCK RADIO CO.**

Starck .....345-III

**STEINITE RADIO CO.**

10 .....282B-Is  
 15 .....415-II  
 20 .....416-II  
 26 .....417-II  
 28 .....418-II  
 40C Power Pack .....282A-Is  
 50A .....282-I  
 60 Power Pack .....282A-Is  
 70 .....282B-Is  
 88 .....282B-Is  
 95 .....282B-Is  
 102A .....282-I  
 103C Power Pack .....282A-Is  
 261 .....283-I  
 262 .....283-I  
 991 .....283-I  
 992 .....283-I  
 993 .....283-I  
 Steinite .....345-III

**STENODE CORPORATION OF AMERICA**

Stenode Receiver .....419-II

**STERLING MFG. CO.**

4 .....284-I  
 5 D3A Receiver .....499D-II  
 517 Mutual Conductance

**SPIEGEL, MAY, STERN CO.**

Melrose, same as Apex .....306-I

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

Tester	466-II
B	268F-Is
Miniature Receiver	420-II
Midjet	268F-Is

**STEWART WARNER CORP.**

50, 51, 58 series 105, 424-O-IIs	
105	250-IV
108	251-IV
108X	251-IV
109	252-IV, 253-IV
202A	422-II
202B	422-II
202E	422-II
300	286-I
310A	424-II
301B	424-II
301E	424-II
305	286-I
310	286-I
315	286-I
320	286-I
325	286-I
330	286-I
335	286-I
340	286-I
345	286-I
350	286-I
355	286-I
360	286-I
385	286-I
390	286-I
500	287-I
520	287-I
525	287-I
530	287-I, 288-I
535	287-I, 288-I
700	287-I
705	287-I
710	287-I
715	287-I, 288-I
720	287-I, 288-I
750	289-I
801	421-II
802	421-II
806	421-II
900	394B-IIs, 291-I
950 Series Screen receivers	424A to 424M-IIs
950 Battery	394B-IIs, 289-I
950 DC	290-I
1090 to 1099	250-IV
R-100 All Lettered Models	290A-Is
R-101A	423-II
R-101B	423-II
R-102A	254-IV
R-102B	254-IV
R-102E	254-IV
R-104	254-IV, 256-IV
R-106	257-IV, 258-IV
servicing with the Jewell	
199	424P, Q-IIs
SW Converter	424-II

**STORY & CLARK RADIO CORP.**

36	290B-Is
42	290B-Is
51	290B-Is

**STROMBERG-CARLSON TELEPHONE MFG. CO.**

1A	435-II
----	--------

1B	298-I
10	432-II, 433-II, 311-III, 321-III, 335-III
11	432-II, 433-II, 434-II, 311-III, 321-III, 335-III
12	300B-Is, 335-III
14	300A-Is, B-Is, 335-III
16	439-II, 431-II
19	429-II, 334-III
20	429-II, 334-III
22	428-II, 331-III
25	427-II, 327-III
26	427-II, 327-III
27	434A-IIs, B-IIs
29	434C-IIs, D-IIs, 310-O-IIs
38	655-III, 656-III, 657-III, 658-III
39	655-III, 656-III, 657-III, 658-III
40	655-III, 656-III, 657-III, 658-III
48	259-IV, 260-IV, 261-IV, 262-IV, 263-IV
49	259-IV, 260-IV, 261-IV, 262-IV, 263-IV
50	259-IV, 260-IV, 261-IV, 262-IV, 263-IV
51	259-IV, 260-IV, 261-IV, 262-IV, 263-IV
54	314-III
403	298-I
403A	298-I
403AA	296-I
403B	296-I
404RA	296-I
404RAC	296-I
501	299-I, 334-III
502	299-I, 334-III
523	292-I, 298-III
524	DC
601	297-I, 334-III
602	297-I, 334-III
633	300-I, 334-III
634	300-I, 334-III
635	292-I, 296-III, 298-III, 300-III, 334-III
635	A. C. 310-III
635	DC 297-I
636	292-I, 296-III, 300-III, 334-III
638A	300A-Is
638B	300A-Is
638	DC 294-I
641	293-I, 304-III, 325-III, 334-III
642	293-I, 304-III, 321-III, 325-III, 334-III
642	A. C. 311-III
645	425-II, 426-II
652	294-I, 325-III, 334-III
654	294-I, 314-III, 321-III, 335-III
734	298-III
734B	300-I
744B	299-I
846	295-I, 304-III, 311-III, 334-III
D-968	292-I
Police Radio	
659-III, 660-III, 661-III	

**STUDEBAKER LABORATORIES**

31	436-II
42	439-II

**SUPREME INSTRUMENTS CORP.**

70 Oscillator	449-II
90 Tester	448-II
AAA-1	447-II
Ohmmeter	449-II
Tube Checker	449A-II

**TRAV-LER MFG. CO.**

6	322-I
7	332-I
8 Super	453-II
AC Power Pack	332-I
DC Power Pack	332-I
K	452-II
SG-AVC Super	455-II
SG-AC	451-II
SG-DC	455-II
Trav-lette	454-II

**T**

**TELEPHONE MAINTENANCE CO.**

Telmaco P-1	358-I
-------------	-------

**TEMPLE CORPORATION**

8-60	301-I, 340-III
8-61	302-I
8-80	301-I, 340-III
8-81	302-I
8-90	301-I, 340-III
8-91	302-I

**THORDARSON ELECTRIC MFG. CO.**

Class B Amplifier	264-IV, 265-IV, 266-IV, 267-IV
-------------------	--------------------------------

**TRANSFORMER CORP. OF AMERICA**

25-51	328-I
25-53	328-I
25-55	328-I
25-90	328A-Is
25-91	328A-Is
25-94	458-II, 459-II
40	456-II, 457-II, 463-II, 329-III
51	328-I
53	328-I
55	328-I
60	355-I
61	460-II, 462-II
70	460-II, 461-II, 462-II
80	465-II
88	466-II
84	662-III, 663-III, 664-III
85	662-III, 663-III, 664-III
90	464-II, 328A-Is
91	328A-Is
91A	328A-Is
92	467-II
94	458-II, 459-II
100	665-III, 666-III, 667-III
120	668-III
160AVC	182J-II
200 Series short wave	
	468A to 468G-IIs
220	468H to 468P-IIs
260	669-III, 670-III, 672-III
280	674-III
300	268-IV, 269-IV
820	270-IV
340	271-IV, 272-IV
360	273-IV

**U**

**UNITED AIR CLEANER CO.**

See Sentinel Radio Corp.

**UNITED AMERICAN BOSCH CORP.**

Also see American Bosch Magneto Corp.

4	274-IV, 276-IV
5 AC	90D-Is
10	274-IV, 275-IV, 276-IV
16	Amborola
	86-I, 307-III, 333-III
r7	307-III, 333-III
18	304-III, 309-III
20	AC 141-II
27	Amboroda Battery 86-I
28	298-III, 300-III, 303-III, 304-III
	306-III, 309-III, 315-III
	323-III, 343-III
28	A C 89-I
29	298-III, 300-III, 303-III, 304-III, 309-III, 315-III
31	277-IV, 278-IV
35	Cruiser, Royal Cruiser 87-I
36	279-IV
38	AC 25 Cycles 89-I
40	281-IV, 282-IV
46	AC 88-I
46	Little Six Battery 86-I
48	AC 60 Cycles 90-I, 298-III
48	D. C. 298-III
48	304-III, 307-III, 309-III, 315-III, 320-III, 333-III
49	304-III
49	AC 25 Cycles 90-I
54	DC 91-I
57	Battery 86-I
58	AC 90A-Is, 315-III, 320-III
60	AC 90B-Is, 90C-II, 90E-II, 315-III, 320-III
61	AC 90E-Is
62	DC 90F-Is
63	DC 90G-Is
66	AC 88-I
66	Battery 88-I
73	AC 140-II
74	AC 140-II
76	Battery 88-I
76L	Battery 88-I
80	Auto Receiver

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

84 Auto Receiver 91-I, 141-II, 142-II
87 Battery 86-I
91 283-IV, 284-IV
96 AC 88-I
96 DC 89-I
100 285-IV
107 AC 88-I
116 AC 88-I
126 AC 88-I
136 AC 88-I
146 AC 88-I
150 286-IV
166 AC 88-I
176 AC 88-I
200 287-IV, 288-IV
201 287-IV, 288-IV
205 289-IV, 290-IV
236 291-IV, 292-IV
237 291-IV, 292-IV
242 293-IV, 294-IV
243 293-IV, 294-IV
250 295-IV, 296-IV
251 295-IV, 296-IV
260 297-IV, 298-IV
261 297-IV, 298-IV
305A 299-IV, 300-IV
312 301-IV, 302-IV
313 301-IV, 302-IV
825 Power Pack 89-I
BAN Edition 2 90-I
BAN Editions 3 & 4 90-I
BAN Editions 5 & 6 90-I
J 333-III
"Vibro-Power" 512, 4HHH-IIIs

UNITED REPRODUCERS CORP.

20 Electrostatic 304-I
45 Arborphone 490-II
65 Electrostatic 489-II
65 Chassis 303-I
868 491-II
880 491-II
890 491-II
K-70 303-I, 343-III
Courier 325-III
Kilectron 305-III, 309-III

U. S. ELECTRIC WORKS

M Genemotor 492-II
T Genemotor 492-II
U Genemotor 492-II

U. S. RADIO & TELEVISION CORP.

3 488-II
5-A 304-IV, 305-IV, 306-IV
6 Tube Battery 487-II
7 488A, B-IIIs
7-D 307-IV, 308-IV
8 483-II, 484-II
9 309-IV, 310-IV, 311-IV
10 481-II, 482-II
12 312-IV, 313-IV
19 309-IV, 310-IV, 311-IV
20 478-II
24 314-IV, 315-IV, 316-IV, 317-IV
25 318-IV, 319-IV, 320-IV
26 479-II
26P 480II, 329-III
27 469-II, 470-II, 475-II

27P Motor Board 468-II
28 488C, D-IIIs
30 307-I
31 471 to 474-II
32 477-II
36 96B-Is
37 473-II
41 306-I
42 306-I
43 306-I
44 306-I
46 307-I
46A 307-I
47 307-I
47A 307-I
48 305-I
48A 305-I
69 321-IV, 322-IV, 323-IV
80 486-II, 305-I, 295-II
90 476-II
91 434F-IIIs
99X 434F-IIIs
120 312-IV, 313-IV
300 324-IV, 325-IV
400 314-IV, 315-IV, 316-IV, 317-IV
500 318-IV, 319-IV, 320-IV
502 303-IV, 304-IV, 305-IV, 306-IV
507 326-IV, 327-IV
700 307-IV, 308-IV
900 309-IV, 310-IV, 311-IV
902 309-IV, 310-IV, 311-IV
906 321-IV, 322-IV, 323-IV
1200 312-IV, 313-IV
3040 326-IV, 327-IV
3056 326-IV, 327-IV

W

WEBSTER ELECTRIC CO.

35TA 396-II
B-37-50 350B-Is
6005 350B-Is
6009 350B-Is
6013 496-II
6025-JD 350A-Is
6030-JE 350B-Is

WELLS GARDNER & CO. See also Gulbransen Co. and Montgomery-Ward & Co.

05-A 328-IV
022 329-IV
052 330-IV
062 510A-IIIs
092 331-IV
5 Tube DC 509-II, 510-II
8T-AC 497-II
9 in Line 197-I
10 501-II, 502-II
20 332-IV, 333-IV
40 334-IV, 335-IV
40-A 334-IV, 335-IV
50 336-IV, 337-IV
60 505-II, 506-II, 507-II
63 505-II, 506-II, 507-II
80 508-II
80A 498-II, 499-II, 500-II
92 338-IV
93 338-IV
322 339-IV
352 340-IV
502 341-IV
572 342-IV
872 343-IV

C, AC-9 503-II, 504-II
WENTARK RADIO STORES
Knight 8-9 324B-Is
Knight 6 Tube D. C. 301-III

WESTINGHOUSE ELECTRIC & MFG. CO.

WR-4 511-II, 512-II, 513-II
WR-5 266A-Is
WR-6 266D-Is
WR-6-R 526 to 529-II
WR-7 266B-Is
WR-7-R 526 to 529-II
WR-8 515-II, 517-II, 266H-Is
WR-8-R 514-II, 518-II, 519-II, 266H-Is
WR-10 521-II, 522-II, 523-II, 266G-Is
WR-10A 520-II
WR-14 525-II
WR-15 335-II

WESTON ELECTRICAL INSTRUMENT CORP.

566 Type 3 Analyzer 449C-II
Test Panel 449B-II
Adapters for Weston and Jewell analyzers 232J-IIIs, 232K-IIIs, 232L-IIIs

WHOLESALE RADIO SERVICE CO., Inc.

10 531-II, 532-II
20 533-II, 534-II
40 40A 534A, B, C, D-IIIs
VA 344-IV
Mighty Atom 535-II

WILCOX LABORATORIES Inc.

6 530-II

WILLARD STORAGE BATTERY CO.

"A" Units:
3262 304A-Is
3280 304A-Is
3290 304A-Is
3390 304A-Is
"B" Units
3095 304A-Is
3310 304A-Is
4095 304A-Is
4310 304A-Is

"A-B" Units
3301 304B-Is
4301 304B-Is
6301 304B-Is

WURLITZER RADIO CO. See also All-American Mohawk Corp.

B 536-II
B-80 345-IV
B-1930-31 346-IV
D.C.-7 347-IV
D.C.-65 348-IV
S-50 349-IV
S-63 350-IV

SA-65 351-IV
SA-90 352-IV
SA-91 353-IV
SA-130 354-IV
SW-80 355-IV
U-50 356-IV
U-500 357-IV

Z

ZANEY GILL CO.

Midget Receiver 495-IIIs

ZENITH RADIO CORPORATION


4-R 309-I
6-EP 570-II
10 572-II
10 A. C. 313-III, 315-III, 316-III
11 572-II, 308-I, 315-III, 316-III
11E 308-I, 295-III, 317-III
12 572-II, 308-I, 315-III, 316-III
14 308-I
14E 308-I
15 318-I
15E 318-I, 295-III, 304-III
15EP 318-I
16 318-I
16E 318-I, 304-III, 347-III
16EP 318-I, 304-III
18 295-III
27 311-I
30 295-III
31 Battery 311-I
32 Battery 311-I
33 312-I
33X 310-I
34 312-I
34P 310-I
35 312-I
35A 312-I
35 AP 313-I
35APX 316-I
35P 313-I
35PX 316-I
37A 313-I
39 315-I
39A 315-I, 304-III
40A 315-I
41 319-I, 295-III
42 318-I, 300-III, 306-III, 307-III, 313-III
50 295-III, 300-III, 302-III, 303-III, 304-III, 305-III, 308-III, 323-III
52 320-I, 300-III, 310-III, 329-III
53 320-I
54 320-I
60 317-I
61 317-I
62 317-I
64 317-I
67 317-I
70 321-I
80 576-II, 320A, B-Is
91 676-III, 678-III, 680-III, 682-III, 684-III, 686-III, 576A to I-IIIs
92 676-III, 678-III, 680-III, 682-III, 684-III, 686-III, 576A to I-IIIs
102 572-II
103. No. 5A 576Q-IIIs

PLEASE NOTE: A Roman numeral follows the page number of each set listed, to differentiate between the various volumes. Thus, the numeral I refers to the 1931 issue, II to the 1932 issue, III to the 1933 issue, and IV to the present volume. The small "s" following some of the Roman numerals specifies that the particular page is in one of the supplements to the 1931 or 1932 Manuals.

576R-IIIs, 576S-IIIs, 576T-IIIs	362	.....312-I	606	.....374-IV, 375-IV, 376-IV	ZE-6 Filter Unit	.....578-II	
112	.....572-II	362X	.....310-I	610	.....374-IV, 375-IV, 376-IV	ZE-7 Power Suply	.....568-II
122	.....572-II	392	.....315-I	612	.....317-I	ZE-8 Filter Unit	.....566-II
210	.....576O, P-IIIs	392A	.....315-I	616	.....374-IV, 375-IV, 376-IV	ZE-8P Filter Unit	.....566-II
215	.....358-IV, 359-IV, 360-IV	410	.....367-IV	618	.....374-IV, 375-IV, 376-IV	ZE-9 Power Supply	.....568-II
216	.....358-IV, 359-IV, 360-IV		.....368-IV, 369-IV, 370-IV	622	.....317-I	ZE10 Power Supply	.....309-I
225	.....358-IV, 359-IV, 360-IV	411	.....367-IV	642	.....317-I	ZE-11 Power Supply	.....314-I
230	.....361-IV, 362-IV, 363-IV		.....368-IV, 369-IV, 370-IV	672	.....317-I	ZE-13 Power Supply	.....314-I
240	.....361-IV, 362-IV, 363-IV	412	.....319-I	710	.....377-IV	ZE-14 Power Supply	.....314-I
244	.....361-IV, 362-IV, 363-IV	420	.....367-IV	2009-C-P (LP)	.....576L-IIIs	ZE-15 Power Supply	.....314-I
245	.....361-IV, 362-IV, 363-IV		.....368-IV, 369-IV, 370-IV	2009-C	.....576M-IIIs	ZE-17 Power Supply	.....317-I
250	.....364-IV, 365-IV, 366-IV	422	.....318-I	2022 (LH, WH, MH)	.....576J-IIIs	ZE-18 Power Supply	.....317-I
260	.....364-IV, 365-IV, 366-IV	430	.....371-IV	2036	.....361-IV, 362-IV	ZE-19 Power Unit	.....564-II
272	.....364-IV, 365-IV, 366-IV	440	.....371-IV	2037	.....374-IV, 375-IV, 376-IV	ZE-20 Audio Unit	.....564-II
333	.....316-I	460	.....372-IV, 373-IV	2022A & B	.....378-IV, 379-IV	ZE-50 Power Unit	.....576-II
342	.....312-I	500	.....374-IV, 375-IV, 376-IV	2044	.....358-IV, 359-IV, 360-IV	Model VII	.....566-II
342P	.....310-I	501	.....374-IV, 375-IV, 376-IV	2046	.....380-IV, 382-IV, 384-IV	Record Changer	.....578-II
352	.....312-I	503	.....374-IV, 375-IV, 376-IV	A, B, C, D	.....576K-IIIs	Zenette 5 Tube	.....574-II
352A	.....312-I	514	.....374-IV, 375-IV, 376-IV	AH-CH-RH-No. 3A		Zenette 6 Tube	.....574-II
352AP	.....313-I	515	.....374-IV, 375-IV, 376-IV	688-III, 690-III, 324-III			
352APX	.....316-I	518	.....374-IV, 375-IV, 376-IV	BH-LHB	.....576N-IIIs		
352P	.....313-I	600	.....374-IV, 375-IV, 376-IV	ZE-3 Power Supply	.....312-I		
352PX	.....316-I	602	.....317-I	ZE-4	.....312-I		
353A	.....316-I	604	.....374-IV, 375-IV, 376-IV	ZE-5 Power Unit	.....309-I		

TABLE OF INTERMEDIATE  
FREQUENCIES used in  
Superheterodynes  
632-II, 633-II

# ATWATER KENT MFG. CO. MODEL 82-Q



I. F. 130 KC.

FIG. 285. DIAGRAM OF MODEL 82-Q (BATTERY-OPERATED).

In some 82-Q receivers, the primary of the audio input transformer is connected as follows: Green to the plate, and white to the 1st-A. F. filter resistor.

208



# ATWATER KENT MFG. CO.

## VOLTAGE TABLE FOR MODELS

81, 81-B, 81-C, 82-D, 82-Q, 85-Q, 86, 87, 89, 90, 92, 92-F, 93, 94, 96, 96-F, 99, 99-F, 99-P

The voltages listed in this table are only approximate, and are measured values, not actual operating values.

Use 250-volt scale of a 1,000-ohm-per-volt D. C. voltmeter.

Turn volume control to maximum.

In all sets equipped with sensitivity switch, voltage switch, or neon tuning light potentiometer: Before making measurements, place sensitivity switch in NORMAL position, voltage switch in REDUCED VOLTAGE position, or neon tuning light potentiometer in full counter-clockwise position.

All plate, screen and grid measurements are made from cathode in heater-type tubes, and from —F in plain-filament-type tubes.

Line voltage=110 volts.

	81	82-D	82-Q	85-Q	86	87	89	90	92	92-F	93 <sup>**</sup>	94	96	96	96	96-F	99	99	99	99-F		
	81-B	81-C	2nd	2nd	2nd	3rd	3rd	3rd	3rd	3rd	3rd	3rd	1st	2nd	3rd	1st	2nd	3rd	1st	2nd	3rd	
	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type	Type
R. F. Tube	Filament 5.5	—	2	2	2.4	2.4	2.4	2.4	2.4	2.4	—	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate 125	—	125	132	122	160	120	210	120	125	—	190	100	150	205	195	130	135	135	130	135	180
	Screen 75	—	60	62	45	80	50	75	45	35	—	100	45	40	70	50	55	45	55	45	85	70
	Grid 1	—	3	4	4	8	4	2	2	2	—	3	3	3	3	3	3	3	3	3	4	3
1st Det. Tube	Filament 5.5	5.5	2	2	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate 95	70	125	132	112	160	115	200	115	120	90	185	110	135	150	150	105	110	110	110	255	210
	Screen —	50	40	40	40	80	40	70	40	30	20	90	40	35	70	45	40	35	40	35	70	55
	Grid 7	5	3	4	6	8	7	7	5	5	1	10	5	4	4	5	7	5	7	5	8	6
I. F. Tube	Filament —	6	2	2	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate —	95	125	132	115	160	120	205	120	125	115	190	100	150	205	195	130	135	135	130	135	180
	Screen —	50	60	62	45	80	50	75	45	35	—	100	45	40	70	50	55	45	55	45	85	70
	Grid —	1	3	4	4	8	4	2	2	2	—	3	3	3	3	3	3	3	3	3	4	3
2nd Det. Tube	Filament —	5.5	2	2	2.4	2.4	2.4	2.4	2.4	2.4	—	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate —	55	45	43	80	90	110	95	90	90	—	80	95	95	90	105	110	105	105	100	100	80
	Screen —	10	25	28	40	—	—	35	50	55	—	65	55	45	30	50	50	45	50	45	85	70
	Grid —	2	3	3	6	4	15	7	7	7	—	8	7	7	5	7	15	15	15	14	12	12
1st A. F. Tube	Filament 5.5	5.5	2	2	2.4	2.4	2.4	2.4	2.4	2.4	—	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate 120	75	55	67	175	100	115	200	195	205	—	185	200	200	195	225	110	115	110	115	120	100
	Screen 123	—	—	—	185	—	—	210	205	215	—	195	210	210	205	235	235	235	235	225	225	220
	Grid 11	3	3	3	4	3	5	4	5	5	—	6	3	4	4	4	4	4	4	4	4	4
2nd A. F. Tube	Filament —	2	2	2	—	—	2.4	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
	Plate —	85	120	127	—	—	185	210	—	—	—	—	—	—	—	—	—	—	—	—	—	—
	Screen —	90	125	132	—	—	190	215	—	—	—	—	—	—	—	—	—	—	—	—	—	—
	Grid —	7	15	15	—	—	12	14	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Osc. Tube	Filament —	5	2	2	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate —	100	60	62	80	80	90	75	80	85	110	100	80	70	80	80	75	65	75	65	115	90
	Screen —	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
	Grid —	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Control Tube	Filament 5.5	—	—	—	2.4	—	2.4	—	2.4	2.4	—	—	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4	2.4
	Plate 3	—	—	—	25	—	25	—	35	40	—	—	40	35	30	40	30	24	30	24	30	23
	Screen —	—	—	—	5	—	5	—	15	17	—	—	17	15	—	15	4	7	15	7	15	14
	Grid 2	—	—	—	3	—	3	—	15	17	—	—	15	15	3	15	4	4	4	4	4	3

\* The measured oscillator grid voltage will vary dependent on several factors. In some cases, no reading will be secured for grid bias. In other cases the reading will be only slight, or it may be as high as 10 volts.  
 \*\* In Model 93, make measurements with frequency range switch turned to low frequency scale.

# ATWATER KENT MFG. CO.

## MODEL 86, 86-F

I.F. 130 KC.




DIAGRAM OF MODEL 86 AND 86-F (A. C.-OPERATED).

The filter resistor is not used in Model 86-F, and the control plate resistor is red and gray. The electrolytic condenser is listed in the Parts List as filter condenser No. 3.

ATWATER KENT MFG. CO.

MODEL 87-D

I.F. 130 KC.




DIAGRAM OF MODEL 87-D.

The 2nd-A. F. grid resistors are colored gray and green.

# ATWATER KENT MFG. CO.

## MODEL 87-D (Direct Current Operated) RECEIVER


### GENERAL DESCRIPTION

Model 87-D is a console-type super-heterodyne receiver designed for 110-volt direct-current supply. It incorporates the following features—

1. Atwater Kent super-heterodyne circuit with single-spot selectivity.
2. Eight tubes, including three pentodes as audio-frequency amplifiers.
3. Quick-vision dial, tone control, electro-dynamic speaker.
4. Atwater Kent expert design and dependable construction.

### SERVICE NOTES

1. The intermediate frequency is 130 kilocycles.
2. Instructions regarding adjustment of trimmers have been given previously in the supplement for Type H chassis. Much of this information may be applied in servicing Model 87-D.
3. The readings given in the table below were obtained with the 250-volt scale of a 1000-ohm-per-volt D. C. voltmeter. The values given are only approximate and are the measured values, not the actual operating voltages. All measurements are made from cathode in heater tubes and from —F in plain-filament-type tubes.




TOP VIEW OF MODEL 87-D.

The circle in the top right-hand corner indicates the shield for the coupling unit between the 1st-detector and the I. F. tube.

**Voltage Table for Model 87-D**  
Turn Volume Control to Maximum  
Line Voltage, 120

APPROXIMATE VOLTAGES				
	FILAMENT	PLATE	SCREEN	GRID
R. F.	6	100	55	3
1ST-DET.	6	100	60	4
I. F.	6	100	60	3
2ND-DET.	6	65	40	SMALL
1ST-A. F.	6	93	98	4
2ND-A. F.	2	95	98	5
OSCILLATOR	6	100	—	5




CONNECTION OF PANEL UNITS AND I. F. TRANSFORMERS, MODEL 87-D.

# ATWATER KENT MFG. CO.

## MODEL 90, 90-F


### I.F. 130 KC.



The colors of bleeders No. 1 and No. 2 may be reversed in some sets. This does not affect the operation.

# ATWATER KENT MFG. CO.

## MODEL 91, 91-B AND 91-C MOTOR CAR RADIO (Intermediate Frequency, 260 Kilocycles)




The wiring of the control unit and speaker in Model 91 is the same as in Model 91.

# ATWATER KENT MFG. CO.

## MODEL 92

I.F. 130 KC.




The filter resistor (in the high-voltage center-tap lead) is not used in Model 92-F. The changes from early to late type consist of the addition of a choke in the R. F. cathode, the use of a separate control-plate by-pass, and a slight rearrangement of leads to the multiple by-pass.

# ATWATER KENT MFG. CO.

## MODEL 92-F

I. F. 130 KC.




The differences in this circuit, compared to the 60-cycle Model 92, are the omission of bleeder No. 5, the addition of a dry electrolytic filter condenser, and location of the sensitivity switch in the I. F. grid circuit instead of in the bleeder circuit.



# ATWATER KENT MFG. CO.

## MODEL 93 SHORT WAVE CONVERTER




THE INTERMEDIATE FREQUENCY IS 1,000 KILOCYCLES.

The two fixed condensers across contacts G and H of the antenna transformer are listed as "compensating condensers" in the parts list. In a few early-type sets, a paper-and-foil condenser is used instead of electrolytic filter condenser No. 1. In some Model 93 converters, an antenna choke, not shown above, is connected across the antenna condenser. This choke is No. 26510.

# ATWATER KENT MFG. CO.

## MODEL 94, 94-F

I. F. 130 KC.




The filter resistor (in the high-voltage center-tap lead) is not used in Model 94-F.

# ATWATER KENT MFG. CO.

MODEL 96 (3rd Type) Above Serial No. 7291674

I. F. 130 KC.




In some late type Model 96 receivers, a flexible type 1st-detector bias resistor (No. 16320) is connected in series with the red lead from the oscillator transformer, after by-pass 3. Also in some of these sets, a flexible bleeder No. 8 (No. 24450) is connected in series with the lead to the center contact of the potentiometer.

The neon-light potentiometer used in 3rd type Model 96 is marked with red paint as identification.

# ATWATER KENT MFG. CO.


MODEL 96-F  
I. F. 130 KC.



# ATWATER KENT MFG. CO.

## MODEL 99 (3rd Type) Above Serial No. 4884901


I.F. 130 K.C.



The neon-light potentiometer in 3rd type Model 99 is marked with green paint as identification.

# ATWATER KENT MFG. CO.

## MODEL 155, 3rd Type, ABOVE SERIAL No. 7088700



For parts not listed below, please order by description or name of part and model number of set.

Part No.	Name of Part	List Price
24293	Volume control, complete, less leads, .5 meg.	.75
24722	Cabinet complete.	3.50
24955	Triple dry electrolytic condenser 8, 8, 8MF, 150 volts.	1.50
*25317	Variable condenser rotor stator and frame (23 plates)	2.00

\* In 1st and 2nd type Model 155, the variable condenser is No. 24561, list price \$2.00 (21 plates).

TRANSFORMERS		
Dia. Code No.	Part No.	Name of Part
T-1	32210	No. 1 R. F. transformer
T-2	32220	No. 2 R. F. transformer
T-3	32190	Oscillator transformer
T-4	31790	No. 1 I. F. transformer
T-5	31780	No. 2 I. F. transformer
T-6	24897	Output transformer

RESISTORS		
R-Code	Part No.	Name of Part
R-1	30360	Blue-gray 1,000,000 ohms, 1/3 watt.
R-3	18520	Flexible 70 ohms.
R-4	30340	Red-blue 100,000 ohms, 1/3 watt.
R-6	30370	Green 2,000,000 ohms, 1/3 watt.
R-7	31980	Black 65,000 ohms, 1/3 watt.
R-8	30340	Red-blue 100,000 ohms, 1/3 watt.
R-9	30350	Black-purple 500,000 ohms, 1/3 watt.
R-10	30370	Green 2,000,000 ohms, 1/3 watt.
R-11	30340	Red-blue 100,000 ohms, 1/3 watt.
R-12	31970	Red-yellow 250,000 ohms, 1/3 watt.
R-13	30350	Black-purple 500,000 ohms, 1/3 watt.
R-14	16610	Flexible 19 ohms.
R-15	31690	Iron core 145 ohms.


FIXED CONDENSERS		
Dia. Code No.	Part No.	Name of Part
C-1	30260	50MMF, letter E stamped on washer.
C-2	31180	680MMF, 100 volts.
C-3	32760	.1MF, and .2MF, 100 volts.
C-16	31530	.1MF, 100 volts.
C-4	33640	.001MF, 450 volts.
C-5	33630	250MMF (double) 450 volts.
C-6	23250	.01MF, 450 volts.
C-7	27630	.01MF, 200 volts.
C-8	27630	.01MF, 200 volts.
C-9	31890	.05MF, .05MF, and .5MF, 100 volts.
C-10	26660	.1MF, 200 volts.
C-11		
C-12		
C-13		
C-14		

No. 24942 SPEAKER.		
Part No.	Name of Part	List Price
24942	Speaker, complete.	\$ 3.25
24897	Output transformer (T-6)	.85
25053	Field coil (2500 ohms)	1.25
24895	Cone assembly.	1.65

MISCELLANEOUS PARTS		
Part No.	Name of Part	List Price
24908	Instruction and log card (F-1056)	net \$ .01
24733	110-volt cable and plug.	.60
24727	Antenna lead (30 feet)	.75
24278	Knob for volume control or station selector.	.10
24892	A. C.—D. C. current switch.	.60

# ATWATER KENT MFG. CO.

## MODEL 165



Part No.	Name of Part	List Price
25309	Cabinet, complete	\$ 4.50
24293	Volume control and on-off switch (.5 meg.)	.75
25022	Variable condenser	2.25
25312	Police and tone control switch, complete	.40
25311	Switch base, complete	.25
25226	Switch shaft and blade	.05

Dia. Code No.	Part No.	Description	List Price
T-1	32430*	No. 1 R. F. T.	\$ 1.00
T-2	32440	No. 2 R. F. T.	1.00
T-3	32450	Oscillator transformer	1.00
T-4	32620	No. 1 I. F. transformer	.75
T-5	32630	No. 2 I. F. transformer	.35
T-6	21672	A. F. output transformer	1.25
T-7	25191	Power transformer	3.15

Dia. Code No.	Part No.	Description	List Price
C-3	25638	730MMF, 100-volts	.25
C-4	33660	.0022MF, 450-volts	.22
C-5	32360	.05, .05 and .05MF, 100-volts	.40
C-6	32350	.05, .05 and .2MF, 200-volts	.50
C-7	33630	250MMF (double), 450-volts	.25
C-8	33630	250MMF (double), 450-volts	.25
C-9	23250	.01MF, 450-volts	.31
C-10	27630	.01MF, 200-volts	.20
C-11	25167	4MF, 20-volts dry electrolytic	.40
C-12	27630	.01MF, 200-volts	.20
C-13	25168	8MF, 475-volts, electrolytic	.85
C-14	25168	8MF, 475-volts, electrolytic	.85
C-15	32740	.003MF, 500-volts	.40

\* In early 165, C-3 is No. 31180, 680MMF, 100 volts \$3.35.

Part No.	Description	List Price
R-1	30350 Black and purple, .5 meg., 1/3 watt	.10
R-2	33250 Blue, 2000 ohms, 1/3 watt	.10
R-3	28950 Flexible, 160 ohms	.17
R-4	30380 Red and green, 3300 ohms, 1/3 watt	.10
R-5	20980 Red and blue, .1 meg., 1/2 watt	.10
R-6	30340 Red and blue, .1 meg., 1/3 watt	.10
R-7	30370 Green, 2 meg., 1/3 watt	.10
R-8	30340 Red and blue, .1 meg., 1/3 watt	.10
R-9	31970 Red and yellow, .25 meg., 1/3 watt	.10
R-10	31970 Red and yellow, .25 meg., 1/3 watt	.10
R-11	32010 Blue, red and green, 500 ohms, 1 watt	.15
R-12	30350 Black and purple, .5 meg., 1/3 watt	.10
R-13	30370 Green, 2 meg., 1/3 watt	.10
R-14	31860 Flexible, 1 ohm, yellow covered	.17

\* In early 165, R-2 is No. 30380 red and green, 3300 ohms, 1/3 watt, \$.10.


Part No.	Description	List Price
C-1	30260 50MMF. Letter E stamped on washer	.15
C-2	33660 .0022MF, 400-volts	.22

Part No.	Description	List Price
25194	Cloth screen	\$ .40
25213	Cabinet foot	.02
24278	Station selector and volume control knob	.10
25145	Police and tone control switch knob	.15
24323	Power transformer cover (2 used)	.15
24554	I.F.T. shield and trimmer (A5)	.55
19566	110-volt cable and plug	.45
24732	110-volt plug	.06
15404	2.5-volt dial lamp	.15
22683	Tube shield	.10
24549	Dial assembly	.25
31870	Trimmer A6	.20
24495	Trimmer A4	.25
25196	Speaker socket	.10
24492	Rectifier socket	.10
24494	Small 6-prong socket (3 used)	.10
22733	Large 6-prong socket (1 used)	.10
25049	Instruction and log card (F-1059)	.01
25186	Switch instruction tag	.01
25189	Shipping container	.25

# ATWATER KENT MFG. CO.

## MODEL 188 (2nd Type)

I.F. 130 KC.





# ATWATER KENT MFG. CO.

## ATWATER KENT RADIO

### SERVICE DATA

#### WITH PARTS AND PRICE LISTS FOR

Models 188 (2nd Type), 260 (3rd Type), 469 (2nd Type), 469-D, 469-Q, 480, 558, 558-D, 558-Q, 612, 627 and 812

All Models listed in this supplement employ the Atwater Kent super-heterodyne circuit with an intermediate frequency of 130 kilocycles, except Model 480 which has an intermediate frequency of 472½ kilocycles.

#### TABULATED DATA FOR MODELS DESCRIBED IN THIS SUPPLEMENT

Model No.	Power Supply	Part No. Complete	Part No. Speaker	Tone-beam	Auto-matic Vol. Control	Auto-matic Silencing	Range Switch	R.F.	1st Det.	1st I.F.	2nd I.F.	2nd Det. Control	1st A.F.	osc. Silencing Tube	2nd A.F.	Driver Push-Push	Rect.	
188 Above 8074387	110-V., 60-C.	28400	28700	No	Yes	Yes	No	58	58	58	—	55	56	57	47	—	80	
188-F Above 5693025	110-V., 25-C.	29300	28700	No	Yes	Yes	No	58	58	58	—	55	56	57	47	—	80	
260 Above 8423096	110-V., 60-C.	28900	28800	Yes	Yes	Yes	No	58	58	58	58	55	56	57	47(2)	—	80	
260-F Above 6188242	110-V., 25-C.	29500	28800	Yes	Yes	Yes	No	58	58	58	58	55	56	57	47(2)	—	80	
469 Above 8498122	110-V., 60-C.	29000	28800	Yes	Yes	Yes	No	58	58	58	—	55	56	57	47(2)	—	80	
469-F Above 6186242	110-V., 25-C.	29400	28800	Yes	Yes	Yes	No	58	58	58	—	55	56	57	47(2)	—	80	
469-D	110-V., D. C.	31300	31600	No	Yes	Yes	No	39	39	39	—	85	37	36	48(2)	—	—	
469-Q	Battery	31100	31500	No	Yes	No	Yes	34	32*	34	34	30	32	*	—	30	30(2)	—
480	110-V., 60-C.	29600	28800	Yes	Yes	No	Yes	58	58	58	58	56	56	47(2)	56	—	—	80
480-F	110-V., 25-C.	29900	28800	Yes	Yes	No	Yes	58	58	58	58	56	56	47(2)	56	—	—	80
558	110-V., 60-C.	29800	17300	No	Yes	Yes	No	58	58	58	—	55	56	57	47	—	80	
558-F	110-V., 25-C.	30800	17300	No	Yes	Yes	No	58	58	58	—	55	56	57	47	—	80	
558-D	110-V., D. C.	31400	31800	No	Yes	Yes	No	39	39	39	—	85	37	36	48(2)	—	—	
558-Q	Battery	31200	31700	No	Yes	No	Yes	34	32*	34	34	30	32	*	—	30	30(2)	—
612	110-V., 60-C.	30000	{ 30200 30300	Yes	Yes	Yes	No	58	58	58	58	55	56	57	—	46	46(2)	83(2)
627	110-V., 60-C.	29700	17300	No	Yes	No	Yes	58	58	58	—	55	56	—	47	—	80	
627-F	110-V., 25-C.	30700	17300	No	Yes	No	Yes	58	58	58	—	55	56	—	47	—	80	
812	110-V., 60-C.	30500	{ 30400 30600	Yes	Yes	Yes	No	58	58	58	58	55	56	57	—	46	46(2)	83(2)

\*In Models 469-Q and 558-Q, the 1st-detector and oscillator are combined in one type 32 tube.

In Model 612, the 4-prong speaker, No. 30200, is type 324, and the 5-prong speaker, No. 30300, is type 326.

In Model 812, the 4-prong speaker, No. 30400, is type 336, and the 5-prong speaker, No. 30600, is type 338.

# ATWATER KENT MFG. CO.

## Parts and Price List for Model 188 (2nd Type), 260 (3rd Type), 469 (2nd Type), 612 and 812

NAME OF PART	188	260	469	612	812
Volume control, complete	23228	23228	23228	23228	23228
less leads.....	1.25	1.25	1.25	1.25	1.25
	28040	21530	21530	30270	30270
Tone-control condenser.....	.20	1.00	1.00	1.00	1.00
	28220	28220	28220	28220	28220
Silencing adjustment.....	1.25	1.25	1.25	1.25	1.25

**TRANSFORMERS**

Power transformer No. 1	26720	28680	28680	29170	28660
(Top).....	7.50	7.50	7.50	8.25	7.50
Power transformer No. 2					28650
(Bottom).....					6.00
	28490	26940	26940	28670	29960
Audio transformer unit.....	3.75	3.75	3.75	5.75	5.75
	23912	23823	23949	23823	23823
R.F. Transformer group.....	2.00	3.00	3.00	3.00	3.00
No. 1 I.F. Transformer,	23356	23535	23356	23535	23535
less trimmers.....	2.00	2.00	2.00	2.00	2.00
No. 2 I.F. Transformer,	22059	22913	22059	22913	22913
less trimmers.....	2.00	2.00	2.00	2.00	2.00
No. 3 I.F. Transformer,		22915		22915	22915
less trimmers.....		2.00		2.00	2.00
		27080	27040	27080	27080
Oscillator transformer.....	1.25	1.25		1.25	1.25
				28630	28630
Output transformer.....				2.25	2.25

**CHOKES**

		26960	26970	29410	28640
Filter choke unit.....	5.75	5.75	5.75	5.75	5.75
1st. Detector plate filter	19210			19210	
choke.....	.25			.25	
2nd. Detector plate	17390	17390	17390	17390	17390
choke.....	.60	.60	.60	.60	.60
			17015		
R.F. Plate choke.....			.50		
		19210			
R.F. Screen filter choke.....	.25				
		19210			
Cathode filter choke.....	.25				
1st. I.F. Plate filter	19210		19210	19210	
choke.....	.25		.25	.25	
2nd. I.F. Plate filter	19210		19210	19210	
choke.....	.25		.25	.25	
		19210			
I.F. Plate filter choke.....	.25				
		19210			
I.F. Cathode choke.....	.25				

**CONDENSERS**

Electrolytic filter	22538	22538	22538	23498	23498
condenser No. 1.....	2.50	2.50	2.50	2.50	2.50
Electrolytic filter	22538	22538	22538	22538	22538
condenser No. 2.....	2.50	2.50	2.50	2.50	2.50
Electrolytic filter				22538	23481
condenser No. 3.....				2.50	2.50
Electrolytic filter				22538	22538
condenser No. 4.....				2.50	2.50
Filter condenser unit,	26620		26620		
paper and foil.....	1.00		1.00		
				30250	30250
Quality condenser.....				.20	.20
	26690	26690	26690	26690	26690
Tracking condenser.....	.25	.25	.25	.25	.25
	26820				
R.F. Grid filter condenser.....	.20				
		26820			
1st. Det. grid filter cond.....		.20			
	26670		26670		
Oscillator grid condenser.....	.25		.25		
	30240	30240	30240	30240	30240
Diode plate condenser.....	.20	.20	.20	.20	.20

NAME OF PART	188	260	469	612	812
--------------	-----	-----	-----	-----	-----

**CONDENSERS (Cont'd)**

2nd. Detector-1st. A. F.	23250	23250	23250	23250	23250
Coupling condenser.....	.35	.35	.35	.35	.35
	17440	17440	17440	30260	30260
Phone condenser.....	.50	.50	.50	.35	.35
Compensating or stopping	16360				
condenser.....	.10				
Control bias by-pass	26550				
condenser.....	.50				
R.F.-I.F. bias by-pass	26660				
condenser.....	.25				
1st. Detector screen by-pass		26660			
condenser.....		.25			
Multiple-type by-pass	28140				
condenser.....	2.00				
Other by-pass condensers					
are listed on Page 419.					

Dry electrolytic condenser.....			23479	23479	
			.90	.90	

**FLEXIBLE AND WIRE-WOUND RESISTORS**

For tubular resistors, see Page 419.

	21420	25950	25950		
2nd. A.F. Bias resistor.....	.20	.20	.20		
R.F.-I.F. Bias resistor		20040			
No. 1 or No. 2.....		.20			
			23780		
Oscillator plate resistor.....			.20		
	24470				
Screen resistor.....	.20			16320	20380
				.20	.20
Driver bias resistor.....				20040	20040
				.20	.20
2nd. I.F. Bias resistor.....				.20	.20
				28470	
2nd. I.F. screen resistor.....				.20	.20
	28950		20040	21420	25950
R.F. I.F. Bias resistor.....	.20	.20	.20	.20	.20
	16320	25950	16320	25950	25950
1st. Detector bias resistor.....	.20	.20	.20	.20	.20
	21030	20380	16320	16320	16320
Control bias resistor No. 1.....	.20	.20	.20	.20	.20
	25850		24470	24470	
Control bias resistor No. 2.....	.20	.20	.20	.20	.20
	24450				
Bleeder resistor No. 1.....	.20				
			24470		
Bleeder resistor No. 2.....			.20		
				20380	
Bleeder resistor No. 4.....				.20	
	27930				
Filter resistor.....	1.00				
	17077	17077	17077	17077	17077
Filament shunt resistor.....	.15	.15	.15	.15	.15

TONEBEAM.....	22011	22011	22011	22011	
Tonebeam adjustment	2.00	2.00	2.00	2.00	
potentiometer.....	29020	29020	29020	29020	
	1.25	1.25	1.25	1.25	
	18534	18534	18534	23774	23774
Line fuse.....	.05	.05	.05	.05	.05
		22615*	22615*	23497	23497
		F-1008	F-1008	F-1028	F-1028
Instruction folder.....	.01 Net	.01 Net	.01 Net	.01 Net	.01 Net
		23483			
		F-1024			
Instruction and log card.....	.01 Net				
		22769*	22738*	22875*	23793
		F-986	F-993	F-994	F-1037
Panel card.....	.01 Net	.01 Net	.01 Net	.01 Net	.01 Net

\*When ordering, specify for silent tuning.

THESE PRICES SUPERSEDE ALL PREVIOUS PRICES AND ARE SUBJECT TO CHANGE WITHOUT NOTICE.

# ATWATER KENT MFG. CO.

VOLTAGE TABLE FOR MODELS 188, 260, 469, 469-D, 469-Q, 480, 558, 558-D, 558-Q, 612, 627, 812.

## TURN SILENCING ADJUSTMENT FULL CLOCKWISE, TONEBEAM ADJUSTMENT FULL COUNTER-CLOCKWISE, RANGE SWITCH AT LOCAL.

All plate, screen and grid measurements are made from cathode in heater-type tubes, and from —F in plain-filament-type tubes. Line voltage = 110 volts. Total "B" voltage on "Q" sets at time of test = 170 volts.

R. F. TUBE	2nd TYPE		3rd TYPE		480†		558		558-D 469-D		627		812	
	188	260	469	480	Local	Dist.	558	469-D	558-D	469-D	627	612	812	812
Filament Plate	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	2	2.4	2.4	2.4	2.4	2.4
Screen	225	185	190	98	65	215	83	170	220	180	215			
Grid	90	75	55	93	70	92	58	80	115	65	80			
1st DET. TUBE	1	2	1	3	3	1	1	1	1	5	2	1		
Filament Plate	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	2	2.4	2.4	2.4	2.4	2.4
Screen	220	195	205	95	65	212	80	170	220	175	217			
Grid	85	65	45	83	65	88	55	48	120	55	67			
1st I. F. TUBE	5	2	3	5	5	5	5	0	6	3	3			
Filament Plate	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	2	2.4	2.4	2.4	2.4	2.4
Screen	220	185	185	98	65	215	83	170	220	175	217			
Grid	90	80	55	93	70	92	58	80	115	65	80			
2nd I. F. TUBE	2	1	1	4	1	2	1	1	1	7	3	3		
Filament Plate	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	2	2.4	2.4	2.4	2.4	2.4
Screen	205	205	238	238	56	56	—	—	40	—	65	78		
Grid	80	4	7	3	—	—	—	—	1	—	3	4		
Filament Plate	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	2	2.4	2.4	2.4	2.4	2.4
D-1	95	80	70	—	—	—	—	—	—	70	63	85		
D-2	10	30	12	—	—	—	—	—	—	6	10	55		
Grid	4	3	2	—	—	—	—	—	—	0	0	0		
2nd DET. TUBE	—	—	—	2.4	2.4	—	—	2	—	—	—	—	—	—
Filament Plate	—	—	—	173	173	—	—	0	—	—	—	—	—	—
Grid	—	—	—	17	17	—	—	0	—	—	—	—	—	—
CONTROL TUBE	—	—	—	2.4	2.4	—	—	*	—	—	—	—	—	—
Filament Plate	—	—	—	43	43	—	—	*	—	—	—	—	—	—
Grid	—	—	—	15	15	—	—	—	—	—	—	—	—	—
1st A. F. TUBE	—	—	—	—	—	—	—	2	—	—	—	—	—	—
Filament Plate	—	—	—	—	—	—	—	105	—	—	—	—	—	—
Screen	—	—	—	—	—	—	—	50	—	—	—	—	—	—
Grid	—	—	—	—	—	—	—	—	—	—	—	—	—	—
DRIVER TUBE	—	—	—	—	—	—	—	2	—	—	—	—	—	—
Filament Plate	—	—	—	—	—	—	—	165	—	—	—	—	—	—
Screen	—	—	—	—	—	—	—	—	—	—	—	—	—	—
Grid	—	—	—	—	—	—	—	4	—	—	—	—	—	—
OUTPUT TUBES	2.4	2.4	2.4	2.4	2.4	2.4	2.4	25	2	2.4	2.4	2.4	2.4	2.4
Filament Plate	215	225	200	226	207	70	170	205	355	280	355			
Screen	225	230	205	232	217	70	—	215	0	0	0			
Grid	5	13	12	17	17	13	12	15	4	0	0			
OSC. TUBE	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	***	2.4	2.4	2.4	2.4	2.4
Filament Plate	95	27	55	123	123	93	63	***	100	63	42			
Grid	**	**	**	**	**	**	**	**	**	**	**			
SILENCING TUBE	2.4	2.4	2.4	2.4	2.4	2.4	2.4	6	—	—	—	—	—	—
Filament Plate	120	150	95	—	—	114	50	—	—	—	—	—	—	—
Screen	25	0	0	—	—	26	3	—	—	—	—	—	—	—
Grid	1	1	1	—	—	1	1	—	—	—	—	—	—	—

### VOLTAGES ACROSS RESISTORS

2nd TYPE	3rd TYPE	480†	558	558-D 469-D	627	812
Bleeder resistor No. 1	93	88	152	43	88	28
Bleeder resistor No. 2	153	9	100	—	—	60 143%
Bleeder resistor No. 3	27	87	15	—	—	123 172
Bleeder resistor No. 4	138	87	0	—	—	0 27
Bleeder resistor No. 5	0	62	30	—	—	12 0
Bleeder resistor No. 6	23	22	40	—	—	80
Bleeder resistor No. 7	—	0	—	—	—	81

### BIAS RESISTORS

Resistor Type	2nd TYPE	3rd TYPE	480†	558	558-D 469-D	627	812
R.F.-I.F. bias resistor No. 1	2	—	1	—	2	3	3
R.F.-I.F. bias resistor No. 2	—	2	—	—	—	10	—
R.F.-1st-I.F. bias resistor No. 1	—	—	—	—	5	4	6
R.F.-1st-I.F. bias resistor No. 2	5	1	2	2	4	4	1
1st-detector bias resistor	—	—	—	—	—	—	—
2nd-I.F. bias resistor No. 1	—	—	—	—	—	—	—
2nd-I.F. bias resistor No. 2	—	—	—	—	—	—	—
2nd-detector bias resistor	—	—	—	—	—	—	—
Control bias resistor No. 1	12	8	6	—	12	4	6
Control bias resistor No. 2	14	73	23	—	13	4	12
2nd-A.F. bias resistor	—	—	—	—	—	—	—
A.F. bias resistor	—	—	—	—	—	—	—
Driver bias resistor	—	—	—	—	—	—	—

### MISCELLANEOUS

Screen resistor	37	193	—	—	33	—	100	120	215
2nd-I.F. screen resistor	—	—	—	—	18	—	—	40	17
Tonebeam adjustment	—	87	47	85	—	—	—	63	93
Silencing adjustment	—	102	130	147	—	100	108	—	132 150%
Four-prong speaker field	—	—	—	—	—	—	—	—	140
Five-prong speaker field	—	—	—	—	—	—	—	—	190
Front rectifier (83) (P to F)	—	—	—	—	—	—	—	—	340
Back rectifier (83) (P to F)	—	—	—	—	—	—	—	—	290

† In early 612 and 812, the measured voltage on the driver grid is about 27 volts.


‡ In sets where bleeder No. 1 is gray, its voltage is 170, and the voltage across the silencing adjustment is 115.

\*In Models 558-Q and 469-Q, the 2nd-detector and control are combined in one tube.  
 \*\*The oscillator grid voltage varies, dependent on several factors.  
 \*\*\*In Models 558-Q and 469-Q, the 1st-detector and oscillator are combined in one tube.  
 †† It is advisable to repeat measurements of the R. F., 1st-det., and I. F. tubes in the Model 480 at each position of the frequency-band switch. The voltages on the short-wave ranges should correspond to those at the "distant broadcast" position.

# ATWATER KENT MFG. CO.

## MODEL 246 (2nd Type) and MODEL 266

Intermediate Frequency, 262½ Kilocycles



The black and red screen resistor is used only in late Model 246. In early 246, which does not use the black and red screen resistor, the voltage on the plate of the oscillator and on the screens of the 57 and 58 tubes is about 100 volts, and the drop across the gray and yellow screen resistor is about 125 volts. In late 246, the voltage across the gray and yellow screen resistor is about 145 volts, and the voltage across the black and red screen resistor is about 80 volts, thus making the oscillator plate and the 57 and 58 screens about 80 volts also.

The additional primary that is shown in dotted lines on No. 1 R.F.T. is used in some Model 246 and 266 receivers. In all Model 266, and in late Model 246, the output transformer is mounted on the speaker housing, and the connections are slightly different than shown above.

# ATWATER KENT MFG. CO.

## PARTS AND PRICE LIST FOR MODEL 246 No. 32000

For parts not listed below, please order by description or name of part and model number of set.


Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
24079	VOLUME CONTROL, complete, less leads (1/2 meg.)	\$1.25	30430	BY-PASS CONDENSER, MULTIPLE TYPE	\$2.00
23430	POWER TRANSFORMER	5.25	FLEXIBLE RESISTORS		
24113	R.F. TRANSFORMER GROUP	2.00	21030	1st. Detector bias resistor (2000 ohms)	.20
30410	NO. 1 I.F. TRANSFORMER, less trimmers	.95	21420	I.F. Bias resistor (250 ohms)	.20
30420	NO. 2 I.F. TRANSFORMER, less trimmers	.95	25840	2nd. A.F. Bias resistor (300 ohms)	.20
30440	OSCILLATOR TRANSFORMER	1.00	TUBULAR RESISTORS		
19697	OUTPUT TRANSFORMER	2.25	20980	Red and Blue (1/2 watt)	.25
19210	1st - DETECTOR PLATE FILTER CHOKE	.25	20930	Black and Purple (1/2 watt)	.25
24099	ELECTROLYTIC FILTER CONDENSER	1.60	20940	Green (1/2 watt)	.25
SMALL FIXED CONDENSERS			20950	Maroon (1/2 watt)	.25
26670	Osc. grid condenser (125 MMF)	.25	27220	Gray and Yellow (1 1/2 watt)	.30
30240	Diode plate condenser (250 MMF)	.20	SPEAKER PARTS		
27630	2nd-Det.-1st A.F. Coupling condenser (.01 MF)	.20	19465	Diaphragm	1.50
26050	Tracking condenser (800 MMF)	.20	18870	Field coil	3.00
			23657	Hum-bucking coil	.20

### VOLTAGE TABLE FOR MODEL 246

The voltages listed in this table are only approximate, and are measured values, not actual operating values.  
Use 250-volt scale of a 1000-ohm-per-volt. D. C. Voltmeter.  
All measurements made from cathode.

Line Voltage, 110 volts	
1st Det. tube	Filament . . . . . 2.4 Plate . . . . . 225 Screen . . . . . 115 Grid . . . . . 3
I.F. tube	Filament . . . . . 2.4 Plate . . . . . 225 Screen . . . . . 100 Grid . . . . . 1
Osc. tube	Filament . . . . . 2.4 Plate . . . . . 105 Grid . . . . . 8*
	Filament . . . . . 2.4 Plate . . . . . 105 D1 . . . . . 5 D2 . . . . . ** Grid . . . . . 2
	Filament . . . . . 2.4 Plate . . . . . 215 Screen . . . . . 230 Grid . . . . . 4

\*The oscillator grid voltage varies.  
\*\*The voltage from 2D to cathode is zero when no signal or noise is being picked up.




TOP VIEW OF MODEL 246, SHOWING LOCATION OF R. F. AND I. F. TRIMMER CONDENSERS



# ATWATER KENT MFG. CO.

## MODEL 448



Part No.	Name of Part	List Price
23228	VOLUME CONTROL, complete less leads	.75
21530	TONE CONTROL CONDENSER (B-11)	.65
24711	SILENCING ADJUSTMENT	.85
28680	POWER TRANSFORMER	4.75
30910	FILTER CHOKE UNIT	1.55
19210	1st. DETECTOR PLATE FILTER CHOKE	.15
22538	ELECTROLYTIC FILTER CONDENSER NO. 1	1.00
22538	ELECTROLYTIC FILTER CONDENSER NO. 2	1.00
26620	FILTER CONDENSER (K-5) paper and foil	.75
30720	MULTIPLE BY-PASS CONDENSER (J-10)	1.25
18534	LINE FUSE	.03
24211	INSTRUCTION AND LOG CARD F-1041	Net .01
24712	PANEL CARD F-1055	Net .02

Dia. Code No.	Part No.	Value	List Price
Small Fixed Condensers	C-1	26820 .05 MF	.20
	C-2	26690 1450 MMF	.35
	C-3	30240 250 MMF (2 used)	.15
	C-4	17440 .0005 MF	.15
	C-5	23250 .01 MF	.31
Flexible Resistors	R-1	20040 100 Ohms	.17
	R-2	16320 1050 Ohms	.15
	R-3	24340 8000 Ohms	.21
	R-4	16320 1050 Ohms	.15
	R-5	25950 200 Ohms	.17
	R-6	17077 10 Ohms	.12
	R-7	17077 10 Ohms	.12
	31860	1 Ohm, dial light resistor (late sets)	.17

Dia. Code No.	Part No.	Color	Value	List Price
R-8	20920	Red-yellow	250,000 Ohms	.10
R-9	20930	Black-purple	500,000 Ohms	.10
R-10	20940	Green	2,000,000 Ohms	.10
R-11	20980	Red-blue	100,000 Ohms	.10
R-12	20980	Red-blue	100,000 Ohms	.10
R-13	20940	Green	2,000,000 Ohms	.10
R-14	20970	Gray	30,000 Ohms	.10
R-15	20950	Maroon	10,000 Ohms	.10
R-16	20950	Maroon	10,000 Ohms	.10
R-17	23120	Red-black	20,000 Ohms	.10
R-18	20950	Maroon	10,000 Ohms	.10

Dia. Code No.	Part No.	Description	List Price
TRANSFORMERS			
T-1	28480	No. 1 R.F. Transformer	1.00
T-2	30810	No. 2 R.F. Transformer and oscillator	1.00
T-3	23356	No. 1 I.F. Transformer, less trimmers	.75
T-4	22059	No. 2 I.F. Transformer, less trimmers	.75
T-5	30920	Audio transformer unit	1.85
T-6	21693	Output transformer, less case	1.50


### No. 28800 TYPE 380 SPEAKER USED IN MODEL 448

Part No.	Name of Part	List Price
20737	Diaphragm	1.25
21260	Field coil	1.25

Part No.	Name of Part	List Price
20657	Cable and plug assembly	1.65

# ATWATER KENT MFG. CO.

## MODEL 469 (2nd Type)




50V 1/2 IN. DIA.  
 MODEL 469  
 TYPE 2nd




# ATWATER KENT MFG. CO.

## MODEL 469-D and 558-D



# ATWATER KENT MFG. CO.

## MODEL 469-Q and 558-Q



# ATWATER KENT MFG. CO.

## Parts and Price List for Model 469-D, 469-Q, 558-D and 558-Q

NAME OF PART	469-D	469-Q	558-D	558-Q	NAME OF PART	469-D	469-Q	558-D	558-Q
Dial lamp	23982	23832	23982	23832	2nd. I.F. Grid filter condenser		27630		27630
	.35 Net	.55 Net	.35 Net	.55 Net		.20		.20	.20
Volume Control, complete, less leads	23228	23482	23228	23482	Control filter condenser		27630		27630
	1.25	.75	1.25	.75		.20		.20	.20
Tone-control condenser	27390	21530	27390	21530	R.F. Grid filter condenser No. 1		26820		26820
	1.00	1.00	1.00	1.00		.20		.20	.20
Audio Input transformer	29380	29390	29380	29390	R.F. Grid filter condenser No. 2		27630		27630
	4.00	4.00	4.00	4.00		.20		.20	.20
R.F. Transformer group	24043	23915	24043	23915	R.F. Line by-pass condenser	26660		26660	
	2.00	2.00	2.00	2.00		.25		.25	
Silencing adjustment	28220		28220		Quality condenser	26820	21450	26820	21450
	1.25		1.25			.20	.20	.20	.20
No. 1 I.F. Transformer, less trimmers	23356	23535	23356	23535	1st. A.F. Screen by-pass condenser		26660		26660
	2.00	2.00	2.00	2.00		.25		.25	
No. 2 I.F. Transformer, less trimmers	22059	23535	22059	23535	Control Coupling Condenser		30240		30240
	2.00	2.00	2.00	2.00		.20		.20	.20
No. 3 I.F. Transformer, less trimmers		23975		23975	Control plate by-pass condenser		26660		26660
		2.00		2.00		.25		.25	.25
Filter-choke unit	29370		29370		Screen by-pass condenser	26660		26660	
	5.00		5.00			.25		.25	
R.F. Line choke	17254		17254		Diode plate condenser	30240		30240	
	.50		.50			.20		.20	
1st. A.F. Plate choke		19210		19210	Multiple-type by-pass condenser	28140		28140	
		.25		.25		2.00		2.00	
I.F. Plate filter choke	19210		19210		Dry Electrolytic condenser	23981	22472	23981	22472
	.25		.25			1.25	.80	1.25	.80
2nd. I.F. Plate filter choke		19210		19210	Range switch		13664		13664
		.25		.25		1.00		1.00	
2nd. Detector plate choke	17390	17390	17390	17390	On-off switch		21958		21958
	.60	.60	.60	.60		1.60		1.60	
Filament choke		17254		17254	<b>FLEXIBLE AND WIRE-WOUND RESISTORS</b>				
		.50		.50	For tubular resistors see Page 419.				
Oscillator plate filter condenser	26670		26670		Filament series resistor		30030		30030
	.25		.25			.15		.15	
Tracking condenser	26690	26690	26690	26690	Bleeder resistor No. 1	29220		29220	
	.25	.25	.25	.25		1.00		1.00	
Phone condenser	22220	21160	22220	21160	Control bias resistor No. 1	19820		19820	
	.35	.35	.35	.35		.20		.20	
2nd. Detector—1st. A.F. Coupling condenser	23250	23250	23250	23250	Control bias resistor No. 2	19820		19820	
	.35	.35	.35	.35		.20		.20	
110-V. Line condenser	29550		29550		R.F.-I.F. Bias resistor	20050		20050	
	1.00		1.00			.20		.20	
R.F. Grid filter condenser	26820		26820		2nd. A.F. Bias resistor	28950		28950	
	.20		.20			.20		.20	
2nd. I.F. Screen by-pass condenser		29030		29030	Battery Cable		23807		23806
		.20		.20		.75		1.25	
1st. A.F. Plate by-pass condenser		22220		22220		23603	21406	21603	23496
		.35		.35		F-1034	F-1027	F-1034	F-1027
1st. A.F.—Driver coupling condenser		27630		27630	Instruction and log-card	.01 Net	.01 Net	.01 Net	.01 Net
		.20		.20		23555	23527	23556	23484
1st. I.F. Grid filter condenser		27630		27630	Panel card	F-1030	F-1020	F-1031	F-1025
		.20		.20		.01 Net	.01 Net	.01 Net	.01 Net

### No. 31600 SPEAKER USED IN MODEL 469-D

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
20737	Diaphragm	\$2.10	30020	Output transformer, less case	\$2.25
19860	Field coil	3.00	19789	Cable and plug assembly	1.65

### No. 31500 SPEAKER USED IN MODEL 469-Q

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
19465	Diaphragm	\$1.50	23701	Output transformer, less case	\$2.25
19918	Magnet assembly	6.00	23863	Cable and plug assembly	1.00

### No. 31800 SPEAKER USED IN MODEL 558-D

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
19465	Diaphragm	\$1.50	30020	Output transformer, less case	\$2.25
19860	Field coil	3.00	19487	Cable and plug assembly	1.60

### No. 31700 SPEAKER USED IN MODEL 558-Q

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
19465	Diaphragm	\$1.50	23701	Output transformer, less case	\$2.25
19918	Magnet assembly	6.00	23764	Cable and plug assembly	1.00

THESE PRICES SUPERSEDE ALL PREVIOUS PRICES AND ARE SUBJECT TO CHANGE WITHOUT NOTICE.

# ATWATER KENT MFG. CO.

## No. 17300 TYPE S SPEAKER USED IN MODEL 558, 627

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
19465	Diaphragm.....	\$1.50	21672	Output transformer, less case.....	\$3.00
18870	Field coil.....	3.00	19487	Cable and plug assembly.....	1.60

## No. 28700 TYPE 368 SPEAKER USED IN MODEL 188

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
20737	Diaphragm.....	\$2.10	21672	Output transformer, less case.....	\$3.00
18870	Field coil.....	3.00	19789	Cable and plug assembly.....	1.65

## No. 28800 TYPE 380 SPEAKER USED IN MODEL 260, 260-F, 469, 469-F, 480


Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
20737	Diaphragm.....	\$2.10	21693	Output transformer, less case.....	\$3.00
21260	Field coil.....	3.00	20657	Cable and plug assembly.....	1.65

## PARTS AND PRICE LIST FOR SPEAKERS USED IN MODEL 612 and 812

Name of Part	Type 324 No. 30200	Type 326 No. 30300	Type 336 No. 30400	Type 338 No. 30600
DIAPHRAGM.....	23589 1.50	23589 1.50	23589 1.50	23591 2.10
FIELD COIL.....	18870 3.00	28550 3.25	18870 3.00	28550 3.25
HUM-BUCKING COIL.....	23657 .20			
CABLE AND PLUG ASSEMBLY.....	23761 1.00	23822 1.00	23761 1.00	23822 1.00

## PARTS AND PRICE LIST FOR TYPE 2-E INTERFERENCE ELIMINATOR No. 29210

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
23748	Antenna Unit.....	\$3.65	23743	Auxiliary Tube Shield.....	\$ .15
23749	Receiver Unit.....	3.55	23744	Instruction Sheet.....	Net .50/c
13222	Cable Clamp.....	.03	23745	Packing Box.....	Net .05



CIRCUIT OF TYPE 2-E INTERFERENCE ELIMINATOR.

THESE PRICES SUPERSEDE ALL PREVIOUS PRICES AND ARE SUBJECT TO CHANGE WITHOUT NOTICE.

# ATWATER KENT MFG. CO.

## TUBULAR RESISTORS

(When replacing a tubular resistor, use a resistor of the same identifying color and size)



Part No.	Color	Resistance	List Price	Part No.	Color	Resistance	List Price
20920	Red-yellow	250,000 Ohms	\$.25	21050	Blue-gray	1,000,000 Ohms	\$.25
20930	Black-purple	500,000 Ohms	.25	23120	Red-black	20,000 Ohms	.25
20940	Green	2,000,000 Ohms	.25	23130	Red-gray	800,000 Ohms	.25
20950	Maroon	10,000 Ohms	.25	23170	Green-yellow	900,000 Ohms	.25
20960	Gray-yellow	15,000 Ohms	.25	26160	White	40,000 Ohms	.25
20970	Gray	30,000 Ohms	.25	26410	Green-red	3,300 Ohms	.25
20980	Red-blue	100,000 Ohms	.25	28050	Blue-yellow	5,000 Ohms	.25
21040	Black	65,000 Ohms	.25				



Part No.	Color	Resistance	List Price	Part No.	Color	Resistance	List Price
15285	Gray	30,000 Ohms	\$.25	19346	Green-red	3,300 Ohms	\$.25
15544	Yellow	7,500 Ohms	.25	19581	Red-yellow	250,000 Ohms	.25
15545	Maroon	10,000 Ohms	.25	19649	Black-purple	500,000 Ohms	.25
15592	Black	65,000 Ohms	.25	20151	Purple	6,000 Ohms	.25
15891	Black-red	20,000 Ohms	.25	20223	Red-gray	800,000 Ohms	.25
15892	Green	2,000,000 Ohms	.25	21784	Gray-green (superseded by 22211)		
16282	Blue-red	100,000 Ohms	.25	22211	Yellow-gray	15,000 Ohms	.25
16724	White	40,000 Ohms	.25	22407	Black-yellow-red	50,000 Ohms	.25



Part No.	Color	Resistance	List Price	Part No.	Color	Resistance	List Price
27210	Maroon	10,000 Ohms	\$.30	28760	Red-blue	100,000 Ohms	\$.30
27220	Gray-yellow	15,000 Ohms	.30	28770	Purple	6,000 Ohms	.30
28030	Red-black	20,000 Ohms	.30	29710	Gray	30,000 Ohms	.30
28750	White	40,000 Ohms	.30				


## BY-PASS AND TONE-CONTROL CONDENSERS

Part No.	* Code Markings	List Price	Part No.	* Code Markings	List Price
†15262	B-1, H-1, H-9, H-20	\$1.00	20350	H-36	\$1.00
15263	B-2, H-2	.90	20830	L-B-9, J-2, J-1	2.00
15640	H-16	1.00	21170	H-37	1.00
15770	H-15	1.00	21180	H-38	1.00
15780	H-17	1.10	21250	B-9	1.00
15790	H-18, H-21	1.00	21430	H-39, L-37-A	1.00
15837	B-3 (Superseded by 16233)		21440	H-40, L-44-A	1.00
15870	B-7, L-28	1.00	21450	B-10, L-36-A	.50
16060	H-24, L-29 (304) (Superseded by 18350)	***	21530	L-42-A, B-11	1.00
16233	H-4, H-10	.90	22050	H-41	1.00
16461	H-6, H-12	.75	22570	J-3	2.00
16462	H-5, H-11	1.00	23140	J-4	2.00
16490	B-6, L-12	1.00	23310	H-42 (Superseded by 21180)	**
16745	H-7, H-8, H-13	1.00	23330	H-43	1.00
16828	B-5	.50	23590	L-55-A, H-44	1.00
16880	H-23, L-26 (439)	1.10	23610	L-57-A, H-45	1.00
16940	H-22, L-10	1.10	24250	LB-30, J-5	2.00
17360	H-27, L-32	1.10	25690	LB-34, J-6	2.00
17370	H-25, H-26, L-3, L-39	1.10	27120	H-46, L-66-A	1.00
18350	H-28, L-49	1.10	27140	H-47	1.00
19150	H-29	1.00	27390	B-14	1.00
19160	H-30	1.00	27580	H-48	1.00
19560	H-31	1.00	28140	J-7	2.00
19690	H-32	1.00	29560	H-49	1.00
19710	H-33	1.00	29690	B-15	1.00
19980	H-34	1.00	30270	B-16	1.00
19990	H-35	1.00	30310	H-51	1.00
20010	B-8	1.00			

\* For information about code markings, see Page 253. \*\* Do not use 23310 in place of 21180. \*\*\* See note on Page 243.  
 † Do not use B-1, H-1, or H-9 in place of H-20.  
 THESE PRICES SUPERSEDE ALL PREVIOUS PRICES AND ARE SUBJECT TO CHANGE WITHOUT NOTICE.

# ATWATER KENT MFG. CO. MODEL 480

(Intermediate Frequency, 472½ Kilocycles)




In some early-type Model 480 receivers the circuit arrangement and contacts of the frequency-band switch are different from that shown above. The early circuit arrangement is shown on page 411.

**IMPORTANT:** In late-type Model 480, the control-coupling condenser and the control grid leak are omitted, and there is no blue lead from No. 3 I. F. T. In these late sets, the grid of the control tube is connected to the yellow lead from No. 3 I. F. T.

# ATWATER KENT MFG. CO.





## MODEL 480 SIMPLIFIED SCHEMATIC




The frequency-range switch in Model 480 has five positions as follows:

- 1st. position — 8.2 to 21.2 megacycles.
- 2nd. position — 3.6 to 9.2 megacycles.
- 3rd. position — 1.5 to 4 megacycles.
- 4th. position — "Distance" broadcast.
- 5th. position — "Local" broadcast.

FRONT SWITCH



REAR SWITCH







# ATWATER KENT MFG. CO.

## MODEL 480 FREQUENCY-RANGE-SWITCH CIRCUIT (Early Type)

AND

## MODEL 480 R. F. TRANSFORMER CONNECTIONS





# ATWATER KENT MFG. CO.

## PARTS AND PRICE LIST

### FOR MODEL 480

Part No.	Name of Part	List Price	Part No.	Name of Part	List Price
23376	VOLUME CONTROL, complete, less leads.	\$1.25	SMALL FIXED CONDENSERS (Cont'd)		
27390	TONE-CONTROL condenser.	1.00	25650	Tracking condenser No. 2	\$ .35
22011	TONEBEAM	2.00	17440	Phone condenser	.50
27190	TONEBEAM ADJUSTMENT potentiometer	1.25	27650	Compensating or stopping condenser	.10
27720	POWER TRANSFORMER	8.25	23282	Stopping condenser (1 green dot, 2 black dots)	.30
30680	POWER TRANSFORMER, 25 cycle	10.75	FLEXIBLE AND WIRE-WOUND RESISTORS		
27760	AUDIO INPUT TRANSFORMER	3.75	(For tubular resistors, see Page 419)		
23408	R.F. TRANSFORMER GROUP	3.00	25950	R.F.-I.F. Bias resistor No. 1	.20
27670	ANTENNA TRANSFORMER	1.00	23780	R.F.-I.F. Bias resistor No. 2	.20
23271	NO. 1 I.F. TRANSFORMER, less trimmers	2.00	16320	1st. Detector bias resistor	.20
23353	NO. 2 I.F. Transformer, less trimmers	2.00	16320	2nd. I.F. Bias resistor No. 1	.20
23272	NO. 3 I.F. Transformer, less trimmers	2.00	24470	2nd. I.F. Bias resistor No. 2	.20
26970	FILTER CHOKE UNIT	5.75	25840	A.F. Bias resistor	.20
17015	1st. Detector cathode choke	.50	20380	Bleeder resistor No. 3	.20
19210	2nd. Detector plate choke	.25	23780	Oscillator plate compensating resistor	.20
17015	R.F. Plate choke	.50	17077	Filament shunt resistor	.15
19210	1st. or 2nd. I.F. Plate filter choke	.25	23107	FREQUENCY BAND SWITCH (less resistors and condensers)	3.75
26620	FILTER CONDENSER UNIT, paper and foil type	1.00	23184	WAVE GUIDE F-1013	Net .01
22538	Filter condenser No. 1 or No. 2 (electrolytic)	2.50	23279	Instruction folder F-1015	Net .01
SMALL FIXED CONDENSERS			23216	Panel card F-1012	Net .01
27130	Antenna condenser	.25	BY-PASS CONDENSERS		
27630	Control-plate by-pass condenser	.20	27580	H-48	1.00
27640	R.F.-1st. Detector stopping condenser	.25	(For other by-pass condensers, see Page 419)		
26670	Oscillator-1st. Detector coupling condenser	.25			
27630	1st. Detector grid filter condenser	.20			
23411	Tracking condenser No. 1	2.15			


## PARTS AND PRICE LIST FOR MODEL 558, 627

Name of Part	558	627	Name of Part	558	627
VOLUME CONTROL, complete, less leads.	23228	23228	Compensating or stopping condenser	16360	16360
TONE-CONTROL Condenser	1.25	1.25		.10	.10
	28040	28040	Control bias by-pass condenser	26550	26550
SILENCING ADJUSTMENT	.20	.20		.50	.50
	28220		R.F. Bias by-pass condenser	26660	
POWER TRANSFORMER, 60 cycles, 110 volts	1.25			.25	
	28150	28150	R.F.-I.F. Bias by-pass condenser		26660
	7.50	7.50		.25	
Power transformer, 60 cycles, 220 volts	28430	28430		26660	
	11.50	11.50	Screen by-pass condenser	.25	
	28290		BY-PASS CONDENSER, MULTIPLE TYPE	28140	24250
AUDIO INPUT TRANSFORMER	3.75		Other by-pass condensers are listed on Page 419.	2.00	2.00
R.F. TRANSFORMER GROUP	23643	23434	FLEXIBLE AND WIRE-WOUND RESISTORS		
	2.00	2.00	For tubular resistors, see Page 419		
NO. 1. I.F. TRANSFORMER, less trimmers	23356	23356		20040	
	2.00	2.00	R.F.-I.F. Bias resistor No. 1	.20	
NO. 2 I.F. Transformer, less trimmers	22059	22059		20380	
	2.00	2.00	R.F.-I.F. Bias resistor No. 2	.20	
1st. DETECTOR PLATE FILTER CHOKE	19210	19210		20040	
	.25	.25	R.F.-I.F. Bias resistor	.20	
	17390	17390		16320	16320
2nd. Detector plate choke	.60	.60	1st. Detector bias resistor	.20	.20
		19210		21030	
1st. A.F. Plate choke		.25	Control bias resistor No. 1	.20	
	19210	19210		25850	
R.F. Cathode Choke	.25	.25	Control bias resistor No. 2	.20	
	22538	22538		24470	
ELECTROLYTIC FILTER CONDENSER NO. 1	2.50	2.50	Screen resistor	.20	
	22538	22538		24450	
Electrolytic filter condenser No. 2	2.50	2.50	Bleeder resistor No. 1	.20	
				27930	27930
SMALL FIXED CONDENSERS	26690	26690	Filter resistor	1.00	1.00
Tracking condenser	.25	.25		17077	17077
R.F. Grid filter condenser	26820	26820	Filament Shunt resistor	.15	.15
	.20	.20		20983	
Oscillator grid condenser	26670	26670	RANGE SWITCH		1.50
	.25	.25		23393	23347
	30240	30240	INSTRUCTION AND LOG CARD	Net. 01	Net. 01
Diode plate condenser	.20	.20		23357	23339
	27630	23250	PANEL CARD	Net. 01	Net. 01
2nd. Detector—1st. A.F. Coupling condenser	.20	.35			
	17440	17440			
Phone condenser	.50	.50			

THESE PRICES SUPERSEDE ALL PREVIOUS PRICES AND ARE SUBJECT TO CHANGE WITHOUT NOTICE.

# ATWATER KENT MFG. CO.

## MODEL 555, 2nd TYPE, ABOVE SERIAL No. 5063260



For parts not listed below, please order by description or name of part and model number of set.

Part No.	Name of Part	List Price
24293	Volume control, complete, less leads, .5 meg.	\$.75
*25456	Variable condenser rotor, stator and frame (23 plates)	2.00
24558	Cabinet, complete.	6.50

\* In 1st type 555, the variable condenser is No. 24559, list price \$2.00 (21 plates).

TRANSFORMERS		
Dia. Code No.	Part No.	Description
—	24438	Power transformer
T-1	33470	R. F. transformer
T-2	33480	Oscillator transformer
T-3	31390	No. 1 I. F. transformer
T-4	31380	No. 2 I. F. transformer
T-5	24901	Output transformer

RESISTORS		
R-Code	Part No.	Description
R-1	30350	Black and purple, .5 meg., 1/3 watt.
R-2	28950	Flexible, 160 ohms.
R-3	30350	Black and purple, .5 meg., 1/3 watt.
R-4	16724	White, 40,000 ohms, 1 watt.
R-5	30380	Red and green, 3300 ohms, 1/3 watt.
R-6	30370	Green, 2 meg., 1/3 watt.
R-7	30340	Red and blue, .1 meg., 1/3 watt.
R-8	30340	Red and blue, .1 meg., 1/3 watt.
R-9	30370	Green, 2 meg., 1/3 watt.
R-10	30350	Black and purple, .5 meg., 1/3 watt.
R-11	30350	Black and purple, .5 meg., 1/3 watt.
R-12	17077	Flexible, 10 ohms.
R-13	31490	Maroon and blue, 300 ohms, 1/2 watts.
R-14	30380	Red and green, 3300 ohms, 1/3 watt.

FIXED CONDENSERS		
Dia. Code No.	Part No.	Description
C-1	30260	.50 MMF, 450-volts.
C-2	31180	.680 MMF, 100-volts.
C-2A	33660	.0022 MF, 450-volts.
C-3	29530	.03 MF, 200-volts.
C-4	26820	.05 MF, 200-volts.
C-5	30240	.250 MMF, 200-volts.
C-6	31530	.1 MF, 100-volts.
C-7	27630	.01 MF, 200-volts.
C-8	31140	.250 MMF (double), 200-volts.
C-9	27630	.01 MF, 200-volts.
C-10	31150	.3 MF, 100-volts.
C-11	27630	.01 MF, 200-volts.
C-12	29030	.02 MF, 450-volts.
C-13	22538	Electrolytic, 8 MF, 475-volts.
C-14	25184	Electrolytic, 4 MF, 475-volts.


MISCELLANEOUS PARTS		
Part No.	Description	List Price
24457	Instruction and log card (F-1045)	net \$ .01
24656	Antenna lead (20 feet)	.60
24651	Ground lead (8 feet)	.15
24649	110-volt cable	.60
24278	Knob for volume control or station selector	.10

No. 24408 SPEAKER USED IN MODEL 555

24408	Speaker, complete, less dial light assembly	\$ 4.25
24901	Output transformer (T-5)	1.00
24899	Field coil	1.00
24898	Cone assembly	2.35


# ATWATER KENT MFG. CO.

## MODEL 558



# ATWATER KENT MFG. CO.

## MODEL 612




In early Model 612, the tone-control condenser is a B-11 and the quality condensers are .02MF. Later Model 612 uses a B-15 tone-control condenser and .015MF quality condensers. The latest type Model 612 uses a B-16 tone-control condenser and .025MF quality condensers. When replacing any of these units, use the same part as the original, except in the case of the .015MF quality condensers which are superseded by .025MF. In early Model 612, an audio transformer is used to couple the 1st-A.F. and driver tubes. The power transformer has an internal shield which is connected to chassis. This shield is not shown in the above diagram. In late Model 612, the control-grid of the silencing tube connects to the green lead from No. 2 R. F. T. instead of to the black lead from No. 2 I. F. T. In early Model 612, by-pass No. 5 is an 11-20. Use H-49 for replacement.

SHOCK NO. 383  
TYPE 14

# ATWATER KENT MFG. CO.

## MODEL 627




J-5

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32	33	34	35	36
37	38	39	40	41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56	57	58	59	60

MULTIPLE BY-PASS

# ATWATER KENT MFG. CO.

## MODEL 812



In early Model 812, the tone-control condenser is a B-11 and the quality condensers are .02MF. Later Model 812 uses a B-15 tone-control condenser and .015MF quality condensers. The latest type Model 812 uses a B-16 tone-control condenser and .025MF quality condensers. When replacing any of these units, use the same part as the original, except in the case of the .015MF quality condensers which are superseded by .025MF. In early Model 812, an audio transformer is used to couple the 1st-A. F. and driver tubes. The power transformer has an internal shield which is connected to chassis. The shield is not shown in the above diagram. In late Model 812, the control-grid of the silencing tube connects to the green lead from No. 2 R. F. T. instead of to the black lead from No. 2 I. F. T. In early Model 812 by-pass condenser No. 5 is an H-20. Use H-19 for replacement.

DWG. NO.	38
MODEL	812
TYPE	1A
DATE	5-25-31

# ATWATER KENT MFG. CO.

## TYPE L-2 CHASSIS, VOLTAGE TABLE AND DIAGRAM

### VOLTAGE TABLE FOR TYPE L-2 AND P CHASSIS

Set in operation. Volume control at maximum.  
LD (or 'phono) switch up.

Use High Resistance D. C. Voltmeter (about 0-50-250) to Measure Plate and Grid Voltages.  
Use A. C. Voltmeter to Measure Filament Voltages.

#### APPROX. VOLTAGES, USING 120 V. LINE

TUBE	FILAMENT VOLTAGE	PLATE VOLTAGE	CONTROL-GRID VOLTAGE	SCREEN VOLTAGE
1st-R.F.	2.4	180	5	85
2nd-R.F.	2.35	180	4.5	86
3rd-R.F.	2.35	180	4.5	86
Detector	2.35	110	14**	—
1st-A.F.	2.35	70	2	—
2A	2.45	250	55*	—
2Aa	2.45	250	55*	—
Rectifier	5	—	—	—

\* Use 250-volt scale.

\*\* This is the voltage across the detector bias resistor; when measuring from grid to cathode, the voltage reading is only 2.

All readings made from cathode in heater-type tubes, and from —F in plain-filament-type tubes.

The Type L Chassis has three stages of screen-grid radio-frequency amplification, plate detection, one stage of resistance-coupled audio, and a "double-audio" output stage. It is designed for 110-120-volt, 50-60-cycle alternating-current operation.

Type F Chassis is similar to Type L, but it is designed for operation on 25-cycle alternating current. The filter circuit is different from the L.

Type P Chassis is similar to Type L, but instead of a "local-distance" switch, it has a "radio-phonograph" switch.




FIG. 220. DIAGRAM OF L-2 CHASSIS.

In the majority of L-2 sets, the filament shunt resistor is connected across the R.F. filaments, as shown in Fig. 219. Also, a 2-ampere fuse is connected in one side of the 110-volt line.

# ATWATER KENT MFG. CO.

## OUTPUT MEASURING CIRCUIT

### DESCRIPTION

An output measuring meter is required to ensure correct adjustment of variable condensers and trimmers. There are several satisfactory methods of connecting an output meter, but the circuit shown on page 59 has proved particularly satisfactory and popular because only one magnetic speaker is required to test any type of Atwater Kent chassis. In other words, on a chassis repair job, you do not have to "pull" the speaker; just bring in the chassis, connect it to the output meter circuit, and you can then check trimmer adjustments, sensitivity, volume and tone quality.

The output circuit includes dummy-field resistors of the correct value for each type of Atwater Kent chassis. A thermo-coupled galvanometer is used to indicate resonance when adjusting variable condensers and trimmers. The magnetic speaker provides a check on volume and tone quality. The cables and plugs provide a quick method of connecting the chassis to the output circuit.

We recommend the use of an Atwater Kent type JB inductor-dynamic speaker with this output circuit. This speaker provides good reproduction and can handle the required volume.

### LIST OF PARTS

(The meter "G," fuse "F," and 8-point switch "S-4" are not Atwater Kent parts and can not be supplied from the factory.)

- T—No. 18911 special audio output transformer.  
 S<sub>1</sub>—No. 13678 toggle switch.  
 S<sub>2</sub>, S<sub>3</sub>—No. 9991 toggle switches.  
 S<sub>4</sub>—8-point rotary switch.  
 R<sub>1</sub>—No. 16433 680-ohm resistor.  
 R<sub>2</sub>—No. 14039 535-ohm resistor (360-ohm section used).  
 R<sub>3</sub>—No. 16433 680 ohm resistor.  
 R<sub>4</sub>—No. 16434 600-ohm resistor (300-ohm section used).  
 R<sub>5</sub>—No. 14039 535-ohm resistor.  
 R<sub>6</sub>—Six No. 19180 1100-ohm resistors in series. These take the place of the 6500-ohm field coil in Models 612 and 812.  
 F— $\frac{1}{4}$  ampere fuse.  
 G—115 milliamperes thermo-coupled galvanometer.  
 Socket No. 1—No. 21337.  
 Socket No. 2—No. 21337.  
 Socket No. 3—No. 21336.  
 L<sub>1</sub>—No. 20075 110-volt, 75-watt lamp.  
 L<sub>2</sub>—No. 23982 120-volt, 3-watt lamp, miniature base.  
 L<sub>3</sub>—No. 16099 6-volt dial lamp.  
 Cable No. 1—1 No. 18582 5-prong speaker plug, and 1 No. 4259 two-conductor cord.  
 Cable No. 2—1 No. 19789 4-prong speaker cable and plug, and 1 No. 15079 4-prong plug.  
 Cable No. 3—1 No. 20657 5-prong speaker cable and plug, and 1 No. 18582 5-prong plug.  
 Cable No. 4—1 No. 23863 4-prong speaker plug and 3-conductor cable 1 No. 18582 5-prong plug.  
 Cable No. 5—1 No. 19789 4-prong speaker cable and plug. 1 No. 18582 5-prong plug.  
 Cable No. 6—1 No. 20889 2-prong speaker cable and plug. 1 No. 18582 5-prong plug.  
 Cable No. 7—1 No. 19789 4-prong speaker cable and plug. 1 No. 18582 5-prong plug.  
 Cable No. 8—1 No. 18582 5-prong plug, and resistor R<sub>6</sub>.

### OPERATION OF OUTPUT CIRCUIT

- Put switch S<sub>4</sub> in the correct position, and connect the chassis to the output circuit by means of the correct cable, as specified in the table below.
- Throw S<sub>1</sub> to the right to test for quality or volume on the magnetic speaker.  
Throw S<sub>1</sub> to the left to pick up oscillator signals on the headphones.
- Close S<sub>2</sub> and S<sub>3</sub> to secure a reading on the galvanometer. Open S<sub>3</sub> to disconnect the galvanometer when checking volume and quality.


### CONNECTION TABLE

Model Number of Set	Speaker Type No.	Resistance of Field Coil (Ohms)	Put Switch S-4 at Tap No.	Use Cable No.	Use Socket No.
43	F	2500	5	2	3
46, 47	F-2	1700	3	2	3
53 (Early)	F-3	2500	5	2	3
53 (Late)	F-3	1700	3	2	3
55	F-4	1100	2	2	3
55-F	F-2	1700	3	2	3
60	F-4	1100	2	2	3
61	F-6	700	6*	2	3
66	F-6	700	1	2	3
67	F-7	8	7**	2	3
L, F, P or H	N	1100	2	3	2
D	N-3	650	6*	3	2
Q	J	***	***	4	2
80, 82, 83, 84, 85, 86, 90, 92, 94, 96, 188, 228, 558, 567 and 627	—	2000	4	5	2
82D, 84D, 228D	—	1200	6*	3	1
82Q, 84Q, 85Q and 228Q	—	***	***	6	2
87, 89	—	1100	2	3	2
87D	—	1200	6*	3	2
99 below 4884901	—	1100	2	3	2
99 above 4884901	—	2000	4	3	2
99F	—	1100	2	3	2
99P	—	2000	4	3	2
260, 469, 480	380	1100	2	3	2
469D, 558D	—	1200	6*	7	2
469Q, 558Q	—	***	***	4	2
612	324 326	2000 6500	4	2 8	3
812	336 338	2000 6500	4	2 8	3

\*Lamp L<sub>2</sub> should light, indicating continuity of the field supply circuit.  
 \*\*Lamp L<sub>3</sub> should light, indicating continuity of the field supply circuit.  
 \*\*\*S<sub>4</sub> may be left in any position as there is no field connection in these sets.



# ATWATER KENT MFG. CO. OUTPUT MEASURING CIRCUIT



The top plug on each cable is for insertion in the correct socket on the output measuring circuit. The bottom plug on each cable is for insertion in the speaker socket on the chassis that is being tested. Follow instructions given in the table on the facing page.

In this diagram, all connections are made looking at the bottom of the sockets and plugs. When switch S4 is set at contact 8, the binding posts BP are connected in the circuit and may be used to connect an external dummy field-resistor of the correct value to take care of future models.

# ATWATER KENT MFG. CO.

## SERVICE NOTES

### SYNCHRONIZING SPEAKERS IN MODELS 612 and 812

In order to get correct tone quality from the dual-speaker sets, Models 612 and 812, it is essential that the two speakers be so connected that the diaphragms of both work in unison or synchronism. If the terminals of one speaker are reversed, the tone of the set will be flat.

To test for proper connections, remove the speakers from the cabinet (leaving them plugged in) so the movement of the diaphragms can be observed. Turn on set, but turn volume down. Connect the terminals of a 1½-volt dry cell across the voice coil-terminals of either one of the speakers. If the diaphragms move in or out together at the instant of contact, the speaker connections are O. K. If one moves out and the other moves in, they are bucking, and the remedy is to reverse the red leads of the five-prong speaker at the voice-coil terminal strip.

### TYPE '55 TUBE

The 55 tube (known as a duo-diode triode) as used by Atwater Kent in current models, serves three purposes, acting as 2nd-detector, automatic volume control, and 1st-A.F. amplifier.

The lower part of the tube has two small plates (D-2) and the cathode, forming a duo-diode. One of these small plates (D-2) and the cathode functions as a diode or half-wave 2nd-detector. The other small plate (D-1) and the cathode functions as a diode or two-element automatic volume control.

The upper part of the tube has a plate, grid, and cathode, forming a triode, with the grid brought out to a cap on the top of the tube.

The signal voltage developed across the manual volume control in the 2nd-detector plate circuit is impressed on the grid of the triode, which acts as 1st-A.F. amplifier.

The automatic volume control plate (D-1) is actuated by strong signals in such a way as to produce an increased negative bias on the control grids of the R.F. and I.F. tubes, thus reducing their amplification and tending to keep a uniform signal level. The voltage drop across control bias resistors No. 1 and 2 determines the signal level at which the automatic volume control begins to function.

The drop across control bias resistor No. 1 is the bias voltage for the 1st-A.F. grid.

There is no bias on the 2nd-detector plate.

### TYPE '85 TUBE

The 85 tube used in Models 469-D and 558-D corresponds to the 55 tube described above.

### ACTION OF SILENCING TUBE

The silencing tube is so connected in the plate circuit of the 1st-A.F. tube that when no signal is being received (that is, when the set is tuned between stations), the plate voltage and consequently the amplification of the 1st-A.F. tube is decreased. When a signal is tuned in, the silencing tube automatically restores the normal plate voltage and amplification of the 1st-A.F. tube.

The automatic action of the silencing tube is secured by having the grid of the silencing tube connected to the automatic volume control circuit.

An adjustment for selecting the desired amount of silencing between stations is provided by having the screen of the silencing tube connected to a potentiometer by means of which the screen voltage may be regulated.

### PUSH-PUSH AMPLIFICATION

"Class B" or push-push amplification is used in Atwater Kent Models 612, 812, 469-Q and 558-Q, to provide high power output with comparatively low power consumption.

Class B amplification differs from regular push-pull amplification in this way:—

In **push-pull** amplification, the grids of the two tubes are biased to a point where there is comparatively *high plate current* in each tube. When an A.C. signal voltage is impressed on the grids, the plate current of one tube decreases, and the plate current of the other tube increases in like amount. This action reverses as the impressed A.C. grid voltage reverses. Note that both tubes are functioning at all times, one pushing while the other pulls.

In class B or **push-push** amplification, the grids of the two tubes are biased to a point where there is practically *no plate current* in either tube. (The 46 tube is designed to give low plate current with zero grid bias.) When an A.C. signal voltage is impressed on the grids, one grid swings more negative, and the other grid swings positive. The plate current of the first tube cannot decrease as it is already practically zero, but the plate current of the other tube increases. This action reverses as the impressed

A.C. signal voltage reverses. Note that in class B amplification, only one tube functions at a time, the other tube being inoperative for that half-cycle of the impressed A.C. signal voltage. The name push-push is derived from this action.

### NECESSITY FOR DRIVER TUBE

In **push-pull** amplification, the grids do not swing positive, so there is practically no grid current, and very little power is required to feed the grid circuit.

However, in **push-push** amplification the grids swing positive, thus drawing grid current, and considerable power is required to feed the grids of these tubes.

This power is furnished by a "driver" tube which provides sufficient power output to swing or "drive" the grids of the push-push-tubes.

### NECESSITY FOR 83 TUBE

In **push-pull** amplification, the average plate current of the two tubes is practically constant at all times, regardless of signal strength. The current drain on the power unit is therefore practically constant, so there is no tendency for the output voltage of the power supply to vary. Under this condition the type 80 rectifier tube is satisfactory as it can supply the constant drain.

In **push-push** tubes there is practically no plate current when the volume control is turned down. But when a signal is received and the volume control is turned up, the push-push tubes alternately draw high plate current. This intermittent drain on the power supply necessitates use of a special rectifier and filter circuit to maintain constant voltage under the varying current drain. The 83 tube is designed to meet this condition as it has low internal resistance and good voltage regulation.

### ACTION OF TONEBEAM


The Atwater Kent tonebeam is a neon light-column that indicates visually when the set is tuned correctly to resonance with the incoming signal.

A typical circuit arrangement for the tonebeam is shown below. This particular circuit is used in Model 812.

The tonebeam requires an initial bias to make the short center electrode (E-2) positive with respect to the long electrode (E-1). The bias is adjustable to take care of different tonebeam tubes, the adjustment being provided by a potentiometer in series with resistors R-2 and R-3 which limit the range of adjustment. In the circuit shown below, the bias voltage across E-1 and E-2 can be adjusted from 91 to 184 volts.


When a signal is tuned in, the automatic volume control increases the negative bias on the control grids of the R.F., 1st-detector, and I.F. tubes, thus decreasing their plate current. This decrease in plate current causes a decrease in voltage across R-1 and a corresponding increase in the voltage difference between electrodes E-1 and E-2. The increase in voltage across E-1 and E-2 causes the neon glow to extend up the long electrode. When the initial bias voltage is adjusted to the correct operating point, an increase of about 20 volts across E-1 and E-2 will cause the neon glow to extend up to the top of the long electrode E-1.

The electrode E-3 and resistor R-5 are used to ensure stable operation of the tonebeam. Resistor R-4 is used to make the tonebeam action more uniform on weak and strong signals.




TONEBEAM CIRCUIT IN MODEL 812.

# BRANDES PRODUCTS CORP.



CANADIAN WESTINGHOUSE CO.

# Westinghouse Superheterodyne 53



Schematic Circuit Diagram

# CANADIAN WESTINGHOUSE CO.

## MODEL 53

### SERVICE DATA

Voltage Rating.....	105-125 Volts	Number and Types of Radiotrons....	1 UX-280, 1 W 2A5, 1 W 58, 1 W 57, 1 W 2A7.....	Total 5
Frequency Rating.....	25-60 Cycles	Undistorted Output.....	1.75 Watts	
Power Consumption.....	70 Watts	Frequency Range.....	504 K.C. to 1550 K.C.	

This receiver is a five-tube Super-Heterodyne incorporating a Dynamic Loud speaker as a part of the chassis; two-point tone control; single heater type Pentode Output tube and the inherent sensitivity, selectivity and tone quality of the Super-Heterodyne.

The circuit consists of an R.F. Stage, a combined oscillator and first detector in the Westinghouse 2A7 tube, an intermediate stage consisting of a transformer only using two tuned circuits, a second detector, an output tube and a rectifier.

Service work in conjunction with this receiver will be similar to that of other Super-Heterodyne receivers of the small compact type construction. The line-up adjustments are made in conjunction with an external oscillator and an output meter. The line-up capacitors on the gang capacitor are adjusted for maximum output when the oscillator is coupled to the antenna and the set and oscillator are both set at 1400 K.C. The I.F. frequency is 175 K.C. and the two circuits that comprise it are adjusted for maximum output at 175 K.C.

### RADIOTRON SOCKET VOLTAGES

115 Volt A. C. Line

MAXIMUM VOLUME CONTROL SETTING---NO SIGNAL

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate Volts	Plate Current M.A.	Heater Volts
1. W-58 R.F. Amplifier	3.0	95	250	5.0	2.33
2. W-2A7 First Detector Oscillator	3.0	95	250	3.0	2.33
3. W-57 Second Detector	6.0	89	170	0.3	2.33
4. W-2A5 Power Amplifier	18.0	235	220	32.0	2.33
5. W-80 Rectifier	725 Volts PLATE TO PLATE—60 M.A. TOTAL				4.82
TOTAL CATHODE CURRENT—11 M.A.					

### REPLACEMENT PARTS

Insist on genuine factory tested parts, which are readily identified and may be purchased from authorized dealers.

STYLE NO.	DESCRIPTION	LIST PRICE	NO.	DESCRIPTION	LIST PRICE
H-29391	Coil—Antenna coil assembly.....	\$1.60	H-29383	Capacitor—flat type—0.05 mfd.—300 volts.....	\$0.90
H-29392	Coil—R.F. coil assembly.....	1.40	H-29384	Capacitor—flat type—0.1 mfd.—150 volts.....	.55
H-29393	Coil—Oscillator coil assembly.....	1.10	H-29387	Capacitor—flat type—0.1 mfd.—300 volts.....	.55
H-29389	Coil—R.F. choke.....	1.00	H-29380	Capacitor—flat type—0.25 mfd.—300 volts.....	.60
H-29390	Transformer—I.F. transformer.....	2.80	H-29374	Capacitor—two 4.0 mfd. dry electrolytic units in container.....	2.45
H-29399	Transformer—Line transformer—25-60 cyc.....	7.70	H-29376	Capacitor—10 mfd.—wet electrolytic.....	2.10
H-29367	Resistor—carbon— $\frac{1}{4}$ watt—60,000 ohms.....	See RS2141	H-29394	Socket—4 contact socket.....	.50
H-27699	Resistor—carbon— $\frac{1}{2}$ watt—20,000 ohms.....		H-29409	Socket—6 contact socket.....	.80
H-29372	Resistor—carbon— $\frac{1}{2}$ watt—50,000 ohms.....		H-29410	Socket—7 contact socket.....	.60
H-29339	Resistor—carbon— $\frac{1}{2}$ watt—200,000 ohms.....		H-23786	Clip—grid connector clip—Pkg. of 5.....	.60
H-29366	Resistor—carbon— $\frac{1}{2}$ watt—250,000 ohms.....		H-29406	Knob—large control knob with set screw.....	.25
H-25519	Resistor—carbon— $\frac{1}{2}$ watt—1.0 meg.....		H-29405	Knob—small control knob with set screw.....	.25
H-29369	Resistor—carbon—1 watt—500 ohms.....		H-29388	Scale—tuning dial scale assembly.....	.75
H-27702	Resistor—carbon—1 watt—14,000 ohms.....		H-29564	Ring—R.F. or oscillator coil retaining ring.....	.12
H-29368	Resistor—carbon—3 watts—14,000 ohms.....		H-29362	Reproducer assembly complete.....	
H-29364	Volume control and operating switch.....		1.85	H-29404	Transformer—output transformer.....
H-29373	Tone control switch.....	.70	H-29363	Cone—reproducer cone.....	1.50
H-29379	Capacitor—toothpick—60 mmfd.....	.55	H-29365	Coil assembly—field coil, magnet and cone support.....	3.50
H-29378	Capacitor—toothpick—80 mmfd.....	.55	H-29401	W-53A cabinet, stripped.....	
H-29384	Capacitor—toothpick—400 mmfd.....	.45	H-29402	W-53B cabinet, stripped.....	
H-29385	Capacitor—toothpick—770 mmfd.....	.45			
H-29382	Capacitor—flat type—0.0024 mfd.—400 volts.....	.50			
H-29386	Capacitor—flat type—0.005 mfd. and 0.025 mfd.—400 volts.....	.60			



# CANADIAN WESTINGHOUSE CO.

## Meter Readings at Radiotron Sockets

110 VOLT A. C. LINE -- ANT. AND GROUND LEADS SHORTED


VOLUME CONTROL AT MINIMUM						
Radiotron No.	Cathode to Heater, Volts D.C.	Cathode or Filament to Control Grid, Volts D.C.	Cathode or Filament to Screen Grid, Volts, D.C.	Cathode or Filament to Plate, Volts, D.C.	Plate Current, M.A.	Heater or Filaments, Volts, D.C.
1—R. F.	**2.0	*1.2	110	300	0.	2.3
2—1st Det.	0	*1.3	110	290	0.	2.4
3—Osc.	—	—	—	70	7.0	2.4
4—I. F.	**2.0	*2.3	110	300	0.3	2.3
5—A. V. C.	—	0.2	—	10	0	2.3
6—2nd Det.	—	5.0	—	275	0.5	2.4
7—Pwr.	—	0.5	280	270	38.0	2.3

VOLUME CONTROL AT MAXIMUM						
Radiotron No.	Cathode to Heater, Volts D.C.	Cathode or Filament to Control Grid, Volts D.C.	Cathode or Filament to Screen Grid, Volts, D.C.	Cathode or Filament to Plate, Volts, D.C.	Plate Current, M.A.	Heater or Filaments, Volts, D.C.
1—R.F.	** 4.0	*0.2	100	275	5.5	2.3
2—1st Det.	**10.0	*0.6	95	265	2.2	2.4
3—Osc.	—	—	—	60	6.0	2.4
4—I. F.	** 4.0	*2.2	110	270	3.5	2.3
5—A. V. C.	—	0.5	—	15	0	2.3
6—2nd Det.	—	5.0	—	265	0.5	2.4
7—Pwr.	—	***0.5	270	260	30.0	2.3

\*On 5 Volt, 1000 Ohm per Volt Meter.  
 \*\*On 50 Volt, 1000 Ohm per Volt Meter.  
 \*\*\*On later sets only. See note under Fig. 2.

MODEL  
82



I. F.  
175 KC.

VIEW OF CHASSIS SHOWING R. F. AND I. F. LINE-UP ADJUSTMENT POINTS

### ADJUSTMENT OF R.F. LINE-UP AND OSCILLATOR TRIMMING CONDENSERS

Four adjustable condensers are provided for aligning the R.F. circuits, and adjusting the oscillator frequency so that it will be at a 175 K.C. difference from the incoming R.F. signal throughout the tuning range of the set. Poor quality, insensitivity and possible inoperation of the receiver may be caused by these condensers being out of adjustment.





# CANADIAN WESTINGHOUSE CO.



## MODEL 102

### RADIOTRON SOCKET VOLTAGES

120 Volt A. C. Line



(No Signal Being Received—Antenna Lead Grounded to Chassis)

Radiotron No.	Cathode to Heater Volts, D. C.	Cathode or Filament to Control Grid, Volts, D.C.	Cathode or Filament to Screen Grid, Volts, D.C.	Cathode or Filament to Plate, Volts, D. C.	Plate Current, M. A.	Heater or Filament, Volts, D. C.
<b>VOLUME CONTROL AT MINIMUM</b>						
1. R. F.	+4	1.0	90	280	0	2.4
2. 1st Det.	0	1.2	90	275	0	2.4
3. Osc.	+4	0	—	55	5.0	2.4
4. I. F.	+3	1.8	90	280	0	2.4
5. A. V. C.	0	0	—	5	0	2.4
6. 2nd Det.	+15	3.0	—	225	1.0	2.4
7. 1st A. F.	+14	10.0	—	260	5.0	2.4
8. Power	—	0	—	400	6.0	2.4
9. Power	—	0	—	400	6.0	2.4
<b>VOLUME CONTROL AT MAXIMUM</b>						
1. R. F.	+4	0	70	250	4.5	2.4
2. 1st Det.	+6	0.6	75	235	2.0	2.4
3. Osc.	+4	0	—	50	5.0	2.4
4. I. F.	+4	1.5	84	250	4.5	2.4
5. A. V. C.	0	0	—	15	0	2.4
6. 2nd Det.	+15	3.0	—	210	1.0	2.4
7. 1st A. F.	+14	10.0	—	240	5.0	2.4
8. Power	—	0	—	400	6.0	2.4
9. Power	—	0	—	400	6.0	2.4



# CANADIAN WESTINGHOUSE CO.

## MODEL 112 S.W. CONVERTER



Voltage Rating ..... 105-125 Volts and 200-250 Volts  
 Frequency Rating ..... 25-60 cycles  
 Power Consumption ..... 20 Watts  
 Recommended Antenna Length ..... 25-75 feet

DIAL SETTING  
 Approximate Calibration of Short Wave Tuning Dial  
 (with 1075 K.C. Intermediate Frequency)


### RADIOTRON SOCKET VOLTAGES-120 Volt A.C. Line

Radiotron No.	Control Grid to Cathode Volts D. C.	Screen Grid to Cathode Volts D. C.	Plate to Cathode Volts D.C.	Plate M.A.	Heater Volts A. C.
R. F.	-5	70	270	1.2	2.5
Detector	-5	70	150	1.4	2.5
Oscillator	-4	-	100	5.0	2.4

# CANADIAN WESTINGHOUSE CO.

## MODEL 122


I. F. 175 KC.



Schematic Circuit Diagram

# CANADIAN WESTINGHOUSE CO.

## MODEL 122-A



Schematic Wiring Diagram for 122A

# CANADIAN WESTINGHOUSE CO.


## MODEL 122 AND 122 A

### RADIOTRONS SOCKET VOLTAGES

120 Volt A.C. Line

No signal being received—Volume Control at minimum

Tube No.	Cathode to Heater Volts, D.C.	Cathode or Filament to Control Grid Volts, D.C.	Cathode or Filament to Screen Grid Volts, D.C.	Cathode or Filament to Plate Volts, D.C.	Plate Current M.A.	Heater or Filament Volts, A.C.
1—R.F.	7.0	0	100	210	3.0	2.5
2—1st Det.	10.0	0	95	210	1.5	2.5
3—Osc.	7.0	0	—	70	5.0	2.5
4—I.F.	8.0	0	95	210	2.5	2.5
5—A.V.C.—I.F.	7.0	0	95	210	3.0	2.5
6—A.V.C.	15.0	0	—	0	0	2.5
7—2nd Det.	12.0	12.0	—	200	1.0	2.5
8—A.F.	11.0	8.0	—	210	5.0	2.5
9—A.F.	11.0	8.0	—	210	5.0	2.5
10—Pwr.	—	0	—	400	6.0	2.5
11—Pwr.	—	0	—	400	6.0	2.5



Location of I.F. Tuning Capacitors.





Figure 7—Connections for Attaching Magnetic Pickup.

### MAGNETIC PICKUP CONNECTIONS



Due to the audio system of the receiver being designed to compensate for the radio end of the receiver, its characteristics must be altered slightly for phonograph operation. It is therefore necessary to use the auxiliary switches, resistors and capacitors shown in Figure 7 when making connections to magnetic pickups. When using these devices, the usual record volume control should be set at maximum and the volume adjusted by means of the "Radio" volume control. In some cases a slight reduction of the high frequencies by means of the tone control may prove desirable. If the degree of compensation is too great—too many highs and lows—this may be remedied by reducing the record volume control setting and advancing the radio volume control.






Amplifier Wiring Diagram

# DIRECTIONS FOR INSTALLING CARTER GENEMOTOR

Radio sets having only two B wires do not require an intermediate tap at the Eliminator as the necessary resistors are in the set. Sets having three B wires require an intermediate tap. This tap is set at the factory at 90 Volts on Eliminators of 180 Volt output and at 67½ Volts on 135 Volt output. Usually this is the proper setting for the average set, and should not be varied unless the set fails to operate properly. To change the intermediate tap voltage, loosen the screw that holds the contact on the resistance unit that is connected across the B output terminals. The tap may be then moved to a position where best results are obtained. Then tighten screw. When Eliminators with intermediate tap are used with set having 2 B wires disregard the intermediate tap, connect the 2 B wires from the set to B- and B+ on the Eliminator. The unused intermediate tap resistance unit will not interfere with the operation of the set.



## CARTER GENEMOTOR CORP.




Ground wire may be connected at either point. If Eliminator is mounted on metal bulkhead no ground wire is needed

### Carter Genemotor Corp.

361-365 WEST SUPERIOR STREET  
CHICAGO, ILL.

# CONSOLIDATED INDUSTRIES PRODS. LTD.

## MODEL 608 - A - B - C - D



I.F. 175 KC.


CIRCUIT DIAGRAM—TYPES 608-A-B-C-D (CHASSIS)

Symbol	DESCRIPTION	Part No.
C1	Tuning Condenser (3 gang)	7178
C2	R. F. by-pass condenser, .05 mfd. (200 v.)	7213
C3	Osc. by-pass condenser, .002 mfd. (M)	6755
C4	Osc. aligning condenser, (600 kes.)	6790
C5	I. F. aligning condenser, (Part of T4)	7106
C6	I. F. aligning condenser, (Part of T1)	7106
C7	I. F. aligning condenser, (Part of T5)	7105
C8	I. F. aligning condenser, (Part of T5)	7105
C9	I. F. by-pass condenser, .02 mfd. (200 v.)	6766
C10	R. F. by-pass condenser, .1 mfd. (400 v.)	6757
C11	R. F. by-pass condenser, .1 mfd. (400 v.)	6758
C12	R. F. by-pass condenser, .25 mfd. (400 v.)	6763
C13	A. F. coupling condenser, .02 mfd. (200 v.)	6766
C14	Diode by-pass condenser, .00025 mfd. (M)	6555
C15	A. F. filter condenser, .25 mfd. (400v.)	7928
C16	A. F. filter condenser, .25 mfd. (600 v.)	6845
C17	Output coupling condenser, .05 mfd. (600 v.)	6860
C18 <sup>1</sup>	A. F. resonating condenser, .005 mfd. (M)	7307
C18 <sup>2</sup>	A. F. resonating condenser, .007 mfd. (M)	6848
C19	Output filter condenser, .2 mfd. (200 v.)	6849
C20	Power filter condenser, 8. mfd. (Electrolytic)	6305
R1	Antenna resistor, 10,000 ohms (1/2 w.)	6911
R2	R. F. filter resistor, 10,000 ohms (1 w.)	7151
R3	Osc. grid leak resistor, 8,900 ohms (1/2 w.)	7316
R4	Min. (fixed) bias resistor, 140 to 185 ohms (W. W.)	6865
R5	Voltage divider resistor, 16,600 ohms (1 w.)	7153
R6	Voltage divider resistor, 14,000 ohms (2 w.)	7141
R7	Voltage divider resistor, 8,100 ohms (1/2 w.)	7148
R8	Voltage divider resistor, 80,000 ohms (1/2 w.)	7147
R9	Voltage divider resistor, 335,000 ohms (1/2 w.)	7146
R10	Voltage divider resistor, 2,500 ohms (1/2 w.)	7137
R11	Silencer resistor, 2,000,000 ohms (1 w.)	7141
R12	R. F.-I. F. filter resistor, 2,500,000 ohms (1 w.)	7140
R13	A. F. grid leak resistor, 2,000,000 ohms (1 w.)	7081
R14	A. F. filter resistor, 500,000 ohms (1/2 w.)	7142
R15	A. F. filter resistor, 60,000 ohms (1/2 w.)	7143
R16	A. F. plate resistor, 50,000 ohms (1/2 w.)	7145
R17	A. F. filter resistor, 50,000 ohms (1/2 w.)	7145
R18	Output grid leak resistor, 500,000 ohms (1/2 w.)	7145
R19	Osc. plate resistor, 800,000 ohms (1/2 w.)	7274
R20	A. F. tone control resistor, 50,000 ohms (var. c.)	6958
R21	Power filter condenser, 8. mfd. (Electrolytic)	6305
R22	Hum adjusting resistor, 20 ohms (var. w.)	7200
R23	A. V. C. resistor, 100,000 ohms (1 w.)	7190
R24	Level control resistor, 500,000 ohms (var. c.)	6887
R25	Silencer control resistor, 50,000 ohms (var. c.)	7278
R26	A. F. bleeder resistor, 25,000 ohms (1 w.)	2114
S1	I. F. filter resistor, 25,000 ohms (1/2 w.)	7187
S1	"On-off" switch (Part of R20)	6958
T1	Antenna R. F. transformer	7350
T2	Interstage R. F. transformer	7326
T3	Oscillator coil	6980
T4	First I. F. transformer	7106
T5	Second I. F. transformer	7105
T6	A. F. output transformer	7102
T7	25 cycle power transformer	7097
T7	60 cycle power transformer	6936
T8 <sup>1</sup>	Type D152C speaker	6875
T8 <sup>2</sup>	Type D154B speaker	6881
L9	Det. R. F. choke	6170

1—Consoles only—608-A and B.  
 2—Compacts only—608-C and D.  
 3—85 cycles only—608-A and C.  
 4—60 cycles only—608-B and D.  
 (M)—Indicates mica condensers.  
 (1/2 w.)—Indicates rating in watts of resistor.  
 (var. c.)—Indicates variable carbon resistor.  
 (var. w.)—Indicates variable wire resistor.  
 (400 v.)—Indicates voltage rating of condensers.

# CONSOLIDATED INDUSTRIES PRODS. LTD.

## MODEL 608-G



Symbol	DESCRIPTION	Part No.	Symbol	DESCRIPTION	Part No.
C1	Tuning Condenser (3 gang)	7178	C20	Power filter Condenser, 8. mfd. (Electrolytic)	7336
C2	R. F. by-pass Condenser, .05 mfd. (400 v.)	7613	C21	Power filter Condenser, 8. mfd. (Electrolytic)	7336
C3	Osc. by-pass Condenser, .002 mfd., (M)	6755	C22	A. F. tone control Condenser, .1 mfd. (400 v.)	6851
C4	Osc. aligning condenser, (600 kes.)	6790	C23	A. F. filter Condenser, .05 mfd. (200 v.)	7217
C5	I. F. aligning Condenser, (Part of T4)	7106	C25	Diode filter Condenser, .0001 mfd. (M)	6556
C6	I. F. aligning Condenser, (Part of T4)	7106	C26	J. F. filter Condenser, .1 mfd. (400 v.)	5218
C7	I. F. aligning Condenser, (Part of T5)	7105	C27	Diode filter Condenser, .05 mfd. (400 v.)	7556
C8	I. F. aligning Condenser, (Part of T5)	7105	C28	R. F. by-pass Condenser, .1 mfd., (400 v.)	5218
C9	I. F. by-pass Condenser, .02 mfd., (400 v.)	7014	R1	Antenna resistor, 10,000 ohms (1/2 w.)	6911
C10	R. F. by-pass Condenser, .1 mfd., (200 v.)	6757	R2	R. F. filter resistor, 10,000 ohms (1 w.)	7154
C11	R. F. by-pass Condenser, .1 mfd., (400 v.)	6758	R3	Osc. grid leak resistor, 8,900 ohms (1/2 w.)	7316
C12	R. F. by-pass Condenser, .25 mfd., (400 v.)	6763	R4	Min. (fixed) bias resistor, 115 ohms (1/2 w.)	7655
C13	A. F. coupling Condenser, .02 mfd., (200 v.)	6766	R5	Voltage divider resistor, 16,600 ohms (1 w.)	7152
C14	Diode by-pass Condenser, .00025 mfd., (M)	6555	R6	Voltage divider resistor, 14,000 ohms (2 w.)	7144
C15	A. F. filter Condenser, .25 mfd. (200 v.)	6098	R7	Voltage divider resistor, 18,000 ohms (1/2 w.)	6963
C16	A. F. filter Condenser, .25 mfd., (400 v.)	6133	R8	Voltage divider resistor, 82,000 ohms (1/2 w.)	6964
C17	Output coupling Condenser, .05 mfd., (400 v.)	7556	R9	Voltage divider resistor, 380,000 ohms (1/2 w.)	7656
C18	(*) A. F. resonating Condenser, .007 mfd., (M)	6848	R10	Silencer resistor, 1,250,000 ohms (1/2 w.)	7609
C19	Output filter Condenser, .2 mfd., (200 v.)	6849	R11	R. F.-I. F. filter resistor, 1,000,000 ohms (1/2 w.)	7196
T1	R. F. AMPL. W5B		R13	A. F. grid leak resistor, 1,500,000 ohms (1/2 w.)	6956
T2	1ST. DET. 224		R14	A. F. filter resistor, 500,000 ohms (1/2 w.)	7142
T3	I. F. AMPL. W5B		R15	A. F. filter resistor, 42,000 ohms (1 w.)	7657
T4	2ND. DET. 227		R16	A. F. plate resistor, 50,000 ohms (1/2 w.)	7145
T5	A. F. AMPL. 224		R17	A. F. filter resistor, 40,000 ohms (1/2 w.)	6901
T6	OUTPUT 247		R18	Output grid leak resistor, 500,000 ohms (1/2 w.)	7142
T7	RECTIFIER 280		R19	Osc. plate resistor, 800-900 ohms (1/2 w.)	7274
T8	SPK. T.8				


Symbol	DESCRIPTION	Part No.
R20	A. F. tone control resistor, 50,000 ohms (var. c.)	6958
R21	Hum adjusting condenser, 20 ohms (var. w.)	7200
R22	A. V. C. resistor 100,000 ohms (1 w.)	7190
R23	Level control resistor, 500,000 ohms (var. c.)	6887
R24	Silencer control resistor, 50,000 ohms (var. c.)	7278
R25	A. F. bleeder resistor, 57,000 ohms (1/2 w.)	7611
R26	I. F. filter resistor, 25,000 ohms (1/2 w.)	7187
R27	Silencer filter resistor, 250,000 ohms (1/2 w.)	7198
S1	"On-off" switch (Part of R20)	6958
T1	Antenna R. F. transformer	7350
T2	Interstage R. F. transformer	7326
T3	Oscillator coil	6980
T4	First I. F. transformer	7106
T5	Second I. F. transformer	7105
T6	A. F. output transformer	7102
T7	25 cycle power transformer	7097
T8	Type D154B speaker (field 1,200 ohms)	6881
L9	Del. R. F. choke	6170

\*Compacts only—608-G.  
 (M)—Indicates mica condensers.  
 (1/2 w.)—Indicates rating in watts of resistor.  
 (var. c.)—Indicates variable carbon resistor.  
 (var. w.)—Indicates variable wire resistor.  
 (400 v.)—Indicates voltage rating of condensers.



# CONSOLIDATED INDUSTRIES PRODS. LTD.

## MODEL 708 - A - B - F




CIRCUIT DIAGRAM—TYPES 708-A-B-F CHASSIS

Symbol	DESCRIPTION	Part No.	Symbol	DESCRIPTION	Part No.
C1	Tuning Condenser (3 gang)	7178	R19	Tone control resistor, 50,000 ohms (Var. C.)	6958
C2	R. F. by-pass condenser, .05 mfd. (400 v.)	7613	R20	Bias volt. div. resistor, 240,000 ohms (1/2 w.)	7612
C3	Osc. by-pass condenser, .002 mfd. (M)	6755	R21	Bias volt. div. resistor, 82,000 ohms (1/2 w.)	6963
C4	Osc. aligning condenser, (600 kcs.)	6790	R22	Bias volt. div. resistor, 18,000 ohms (1/2 w.)	7677
C5	I. F. aligning condenser, (Part of T4)	7106	R23	Voltage, divider resistor, 5,800 ohms (Vitreous)	7677
C6	I. F. aligning condenser, (Part of T4)	7105	R24	Voltage divider resistor, 5,000 ohms (Vitreous)	7677
C7	I. F. aligning condenser, (Part of T5)	7105	R25	Min. (fixed) bias resistor, 75 ohms (Vitreous)	7677
C8	I. F. aligning condenser, (Part of T5)	7614	R26	Hum adjusting resistor, 20 ohms (Var. W.)	7200
C9	R. F. by-pass condenser, .02 mfd. (400 v.)	6757	S1	"On-off" switch (Part of R7)	6887
C10	R. F. by-pass condenser, .1 mfd. (200 v.)	6757	T1	Antenna R. F. transformer	7850
C11	R. F. by-pass condenser, .1 mfd. (200 v.)	6757	T2	Interstage R. F.	7326
C12	R. F. by-pass condenser, .5 mfd. (400 v.)	7615	T3	Oscillator coil	6980
C13	A. F. coupling condenser, .02 mfd. (200 v.)	6766	T4	Oscillator coil	7106
C14	Diode by-pass condenser, .00025 mfd. (M)	6555	T5	First I. F. transformer	7105
C15	A. F. filter condenser, .25 mfd. (200 v.)	6038	T6	Second I. F. transformer	7654
C16	A. F. filter condenser, .25 mfd. (400 v.)	6133	L6	Det. R. F. choke coil	7604
C17	Output coupling condenser, .05 mfd. (400 v.)	7556	T7	A. F. output transformer	7605
C18	Output resonating condenser, .005 mfd. (400 v.)	7307	T8	25 cycle power transformer	7447
C19 <sup>3</sup>	Output filter condenser, .2 mfd. (200 v.)	6849	T9	60 cycle power transformer	7620
C19 <sup>4</sup>	Output filter condenser, .1 mfd. (200 v.)	7652	T10	Type D154E upper speaker (field 670 ohms)	7621
C20	Power filter condenser, 10 mfd. (Electrolytic)	7477		Type D152H lower speaker (field 670 ohms)	7621
				<sup>3</sup> Used in 708-A and F Chassis.	
				<sup>4</sup> Used in 708-B Chassis only.	

# CONSOLIDATED INDUSTRIES PRODS. LTD. MODEL 801 AND 802

CIRCUIT DIAGRAM—TYPES 801 and 802 CHASSIS.

I. F. ≈ 175 KC.



Symbol	Description	Part No.
R10	Det. filter resistor, 100,000 ohms (1/2 w)	7219
R11	Voltage divider resistor, 1,000,000 ohms (1/2 w)	6990
R12	Det. plate resistor, 175,000 ohms (1/2 w)	6973
R14	Voltage divider resistor, 40,000 ohms (1/2 w)	6975
R15	Osc. resistor, 1,000 ohms (1/2 w)	6743
R16	Tone control resistor, 500,000 ohms (Var. C.)	6993
R17	A. F. filter resistor, 11,000 ohms (1/2 w)	6957
R18	Osc. grid leak resistor, 200,000 ohms (1/2 w)	7104
R19	Current limiting resistor, 750 ohms (w.w.)	7608
R20	Current limiting resistor, 750 ohms (w.w.)	7608
R21	Bias bleeder resistor, 31,100 ohms (1/2 w)	7644
T1	Antenna R. F. transformer	6994
T2	Interstage R. F. transformer	6995
T3	First I. F. transformer	6997
T4	Second I. F. transformer	6998
L5	Det. R. F. choke	6170
T6	A. F. input transformer	7004
T7	A. F. output transformer	7005
T8	Oscillator coil	6996
L9	Filament choke	6999
T10	Speaker (P.M. 252 A) Console only	7045
T10	Speaker (P.M. 252 B) Compact only	7540

Symbol	Description	Part No.
C1	Tuning Condenser (3 gang)	6989
C2	R. F. by-pass condenser, .05 Mfd. (200 v.)	5865
C3	R. F. plate by-pass condenser .05 Mfd. (200 v.)	5865
C4	R. F. and I. F. screen by-pass condenser .1 Mfd. (200 v.)	7020
C5	Det. bias by-pass condenser .25 Mfd. (200 v.)	6134
C6	I. F. aligning condenser (part of T3)	6997
C7	I. F. aligning condenser (part of T3)	6997
C8	I. F. aligning condenser (part of T4)	6998
C9	Det. plate by-pass condenser .05 Mfd. (200 v.)	5865
C10	I. F. bias condenser .05 Mfd. (200 v.)	5865
C11	Osc. coupling condenser .01 Mfd. (200 v.)	7021
C12	Osc. series align. condenser	6790
C13	Det. screen by-pass condenser .1 Mfd. (200 v.)	7022
C14	Det. bias by-pass condenser .05 Mfd. (200 v.)	5865
C15	Det. plate by-pass condenser .005 Mfd. (M)	6176
C17	A. F. coupling condenser .05 Mfd. (400 v.)	5302
C18	Fil. by-pass condenser .5 Mfd. (200 v.)	6945
C19	"B" supply by-pass condenser 16 Mfd.	7025
C20	A. F. trap condenser .001 Mfd. (M)	4514
C21	A. F. tone control condenser .005 Mfd. (200 v.)	7026
C22	A. F. filter condenser .2 Mfd. (200 v.)	6991
C23	Osc. grid condenser .001 Mfd. (M)	7023
R1	Antenna resistor, 10,000 ohms (1/2 w)	6911
R2	R. F. filter resistor, 50,000 ohms (1/2 w)	6967
R3	I. F. filter resistor, 60,000 ohms (1/2 w)	6968
R4	Filament series resistor, 69 ohms (w.w.)	6969
R5	Voltage divider resistor, 50,000 ohms (1/2 w)	6466
R6	Voltage divider resistor, 41,000 ohms (1/2 w)	6971
R7	Voltage divider resistor, 85,000 ohms (1/2 w)	6972
R8	Minimum bias resistor, 4,000 ohms (Part of R9)	6992
R9	Volume control resistor, 86,000 ohms (Var. C.)	6992


(200 v.) —Indicates voltage rating of condenser.  
(M) —Indicates mica condenser.

(1/2 w) —Indicates rating in watts of resistor.  
(w.w.) —Indicates wire wound resistor.

(Var.C.) —Indicates variable carbon resistor.

# CONSOLIDATED INDUSTRIES PRODS. LTD.

## MODEL 855 AND 855-B




Circuit Diagram. Types 855-855 B chassis.

Symbol	DESCRIPTION	Part No.	Symbol	DESCRIPTION	Part No.
C1	Gang condenser (3 section).....	5970	C20	Electrolytic filter condenser, 8.0 mfd.	6305
C2	R. F. by-pass condenser, .05 mfd.....	5240	R15	A. F. filter resistor, 9,000 ohms	6078
C3	R. F. cathode by-pass condenser, .05 mfd.	5240	R16	A. F. tone control resistor, 1,500,000 ohms	5863
C4	Osc. cathode by-pass condenser, .0005 mfd.	5321	R17	247 bias resistor, 204,000 ohms.	6079
C5	Osc. padding (first) condenser, .00068 mfd.	5368	R18	247 bias resistor, 500,000 ohms	6080
C6	R. F. plate by-pass condenser, .25 mfd.....	5919	R19	Osc. plate resistor, 1,000 ohms.....	6130
C7	R. F. screen by-pass condenser, .05 mfd.....	5865	R20	A. F. filter resistor, 27,000 ohms.....	6358
C8	I. F. aligning condenser.....	6093 (A)	S1	On-off switch.	6067 (D)
C9	I. F. aligning condenser.....	6093 (B)	T1	Ant. stage R. F. transformer.....	6092
C10	I. F. aligning condenser.....	6094 (A)	T2	Interstage R. F. transformer.....	5416
C11	I. F. aligning condenser.....	6094 (B)	T3	Oscillator transformer.....	5462
C12	Det. (diode) cathode by-pass condenser, .00025 mfd.....	6083	T4	I. F. (1st stage) transformer.....	6093
C13	Det. (diode) R. F. by-pass condenser, .00025 mfd.....	6083	T5	I. F. (2nd stage) transformer.....	6094
C14	A. F. coupling condenser, .02 mfd.....	6085	T6	A. F. input transformer.....	6086
C15	A. F. filter condenser, .25 mfd.....	6133	T7	A. F. output.....	6087
C16	A. F. tone control condenser, .003 mfd.....	6081	T8	Filter choke.....	6088
C17	247 bias by-pass condenser, .25 mfd.....	6134	T9	Filter choke (speaker field)	6063
C18	I. F. by-pass condenser, .05 mfd.....	5240	T10	Power transformer.....	6065
C19	Output plate by-pass condenser, .003 mfd.	6081			
					(A) Part of I. F. transformer assembly Part No. 6093.
					(B) Part of I. F. transformer assembly Part No. 6094.
					(C) Level control potentiometer.
					(D) Part of level control assembly Part No. 6067.

# CONSOLIDATED INDUSTRIES PRODS. LTD.

## MODEL 905




I.F. 175 KC.

TYPE 905 CHASSIS—CIRCUIT DIAGRAM

Symbol	Description	Part No.	Symbol	Description	Part No.
C2	Gang condenser (4 section)	5246	R21	R. F. isolating resistor, 100,000 ohms	5224
C3	Osc. padding condenser, .0005 Mfd.	5074	R22	R. F. isolating resistor, 200,000 ohms	5200
C4	Osc. aligning condenser, .380 Mmfd.	5074	R23	A. F. filter resistor, 20,000 ohms	5204
C5	Osc. cathode by-pass condenser, .05 Mfd.	4513	S1	On-off Switch	5098(H)
C6	Osc. plate coupling condenser, .0001 Mfd.	3815	T1	Osc. transformer	4597
C7	Det. (1st) cathode by-pass condenser, .05 Mfd.	4679	T2	R. F. antenna transformer	5050
C8	R. F. cathode by-pass condenser, .25 Mfd.	5215(A)	T3	R. F. interstage transformer	5061
C9	R. F. Screen by-pass condenser, .50 Mfd.	5215(A)	T4	R. F. interstage transformer	5225
C10	R. F. plate by-pass condenser, .40 Mfd.	5212(B)	T5	I. F. interstage transformer	5097(D)
C11	I. F. aligning condenser	5097(D)	T6	I. F. interstage transformer	5095(E)
C12	I. F. aligning condenser	5097(D)	T7	I. F. diode stage transformer	5226
C13	I. F. aligning condenser	5095(E)	T9	A. F. input transformer	5087
C14	I. F. aligning condenser	5228	T10	A. F. output transformer	5037
C15	Det. (Diode) cathode by-pass condenser, .0007 Mfd.	3815	T11	Power (line) transformer (110 v. 25 to 60 cycles)	5036
C16	A. F. coupling condenser, .02 Mfd.	5214	T12	Power filter choke	5105
C18	A. F. filter condenser, .50 Mfd.	5213(C)	T13	Power filter choke (speaker field—2,500 ohms)	5065
C19	Power filter, condenser, 1.8 Mfd.	5212(B)	(A)	Block assembly C8-9-23-24, in some chassis contains only C8-9-23, part number 5018-C24 then separate unit part number 5240.	
C20	Electrolytic filter condenser, 8.0 Mfd.	4560	(B)	Block assembly, C10-19.	
C21	Electrolytic filter condenser, 8.0 Mfd.	4560	(C)	Block assembly, C-18-26-30—in some chassis only C18-26, part number 5072—C30 then separate unit part number 3902.	
C22	Electrolytic filter condenser, 8.0 Mfd.	4560	(D)	Part of I. F. assembly, part number 5097.	
C23	R. F. isolating condenser, .05 Mfd.	5215(A)			
C24	R. F. isolating condenser, .05 Mfd.	5215(A)			
C25	I. F. isolating condenser, .05 Mfd.	5240			

# CONSOLIDATED INDUSTRIES PRODS. LTD.

## MODEL 907



I.F. 175 KC.

TYPE 907 CHASSIS—CIRCUIT DIAGRAM

Symbol	Description	Part No.	Symbol	Description	Part No.
(E)	Part of I. F. assembly, part number 5095.		R23	A. F. filter resistor, 20,000 ohms	5204
(F)	Two section resistor.		R24	Vol. limiting resistor, 31 ohms	3686
(G)	Two section resistor.		R25	Phono. vol. control resistor, 80 ohms	4945
(H)	Radio level (vol.) control, includes on-off switch.		S1	On-off switch	5255
C2	Gang condenser (4 section)	5246	S2	Motor-radio switch	5254
C3	Osc. padding condenser, .0005 Mfd.	4654	S3	Phono-radio switch (automatic on record changer)	5253 (H)
C4	Osc. aligning condenser, 380 Mmfd.	5074	T1	Osc. transformer	4597
C5	Osc. cathode by-pass condenser, .05 Mfd.	4513	T2	R. F. antenna transformer	5050
C6	Osc. plate coupling condenser, .0001 Mfd.	3815	T3	R. F. interstage transformer	5061
C7	Det. (1st) cathode by-pass condenser, .05 Mfd.	4679	T4	R. F. interstage transformer	5097 (D)
C8	R. F. cathode by-pass condenser, .25 Mfd.	5215 (A)	T5	I. F. interstage transformer	5095 (E)
C9	R. F. screen by-pass condenser, .50 Mfd.	5215 (A)	T6	I. F. diode stage transformer	5226
C10	R. F. plate by-pass condenser, .40 Mfd.	5212 (B)	T7	Pickup transformer	4894
C11	I. F. aligning condenser	5097 (D)	T8	A. F. input transformer	5087
C12	I. F. aligning condenser	5097 (D)	T9	A. F. output transformer	5036
C13	I. F. aligning condenser	5095 (E)	T10	Power filter choke (110 v. 25 to 60 cycles)	5105
C14	I. F. aligning condenser	5228	T11	Power filter choke (speaker field—2,500 ohms)	5065
C15	Det. (Diode) cathode by-pass condenser, .0001 Mfd.	3815	(A)	Block assembly C8-9-23-24, in some chassis contains only number 5240.	
C16	A. F. coupling condenser, .02 Mfd.	5214	(B)	Block assembly, C10-19.	
C17	A. F. filter condenser, .50 Mfd.	5213 (C)	(C)	Block assembly, C18-26-30—in some chassis only C18-26, part number 5072—C30 then separate unit part number 3992.	
C18	A. F. filter condenser, 1.8 Mfd.	5212 (B)	(D)	Part of I. F. assembly, part number 5097.	
C19	Power filter, condenser, 8.0 Mfd.	4560	(E)	Two section resistor.	
C20	Electrolytic filter condenser, 8.0 Mfd.	4560	(F)	Two section resistor.	
C21	Electrolytic filter condenser, 8.0 Mfd.	4560	(G)	Two section resistor.	
C22	Electrolytic filter condenser, 8.0 Mfd.	4560	(H)	Radio level (vol.) control, includes phono-radio switch.	

# CROSLY RADIO CORP.

## CROSLY ROAMIO AUTOMOTIVE T.R.F. RECEIVER MODELS 90, 91 AND 92

(The T.R.F. series of Crosley Roamio sets; Radio Service Data Sheet No. 88 describes the superheterodyne series.)

### Model 90

Average operating potentials are given below. These values are measured with the reproducer connected and the tubes in place. For plate and grid voltages, use a high-resistance meter; measure from tube element to negative filament.

Tube Type	Fil. Volts	C.-G. Volts	S.-G. Volts	Plate Volts
V1	2.0	2.5	90	135
V2	2.0	2.5	90	135
V3	2.0	3.0	---	22.5
V4	4.7	12	---	135
V5	4.7	12	---	135

The A.V.C. potential is derived as the drop across R2. With increased signal, more current flows through the plate circuit of the combination detector and A.V.C. tube, V3, increasing the drop across R2 and thereby increasing the bias voltage applied to the control-grids of V1 and V2. This results in a reduction of the R.F. amplification, and thus maintains constant the A.F. output determined by the setting of R1.

Battery D supplies plate potential for V3. The negative "B" and positive "C" lead returns to the center-tap of two 25 ohm resistors,

to secure the same plate potentials regardless of whether the car-battery positive or negative terminal is grounded.

### Model 91

Average operating potentials are given in the tabulation below. Measure, with a high-resistance meter, to the negative filament contact.

Tube Type	Fil. Volts	C.-G. Volts	S.-G. Volts	Plate Volts
V1	2.0	1.5	100	170
V2	2.0	1.5	100	170
V3	2.0	2.5	7.5	45
V4	4.7	10*	---	170
V5	4.7	10*	---	170

\*With volume control "off."

If a signal of sufficient strength is received to cause current to flow in the grid circuit of V3 (biased by R6), the resultant drop across R2 decreases the amplification of V1, V2. Resistors R3, R4, R5 are R.F. filters.

Manual volume control R1 determines the A.F. input to the control-grid of A.F. amplifier V4.

### Model 92

Operating potentials appear in the table.


Tube Type	Fil. Volts	C.-G. Volts	S.-G. Volts	Plate Volts
V1	5.9	3	75	170
V2	5.9	3	40	170
V3	5.9	3	40	45
V4	5.9	20	---	170
V5	4.7	40	---	170
V6	5.9	---	---	3

The circuit is adjusted for zero current flow in the circuit of A.V.C. tube V6, with normal signal input; at the same time resistor R3 establishes the normal bias required by the control-grids of V1, V2. Now, an incoming signal of increased strength causes diode V6, in conjunction with load-resistor R2, to develop across R2 an increased D.C. negative potential which reduces the amplification of V1, V2. Resistors R4, R5 are R.F. filters.


The A.F. input to the first-A.F. tube, V4, is determined by the setting of the manual volume control, R1.

Manual volume control resistor R1 has a value of 0.3-meg. Since Crosley Service Bulletin No. A8 does not include the tube operating voltages for the model 92, estimated values are given.


At the present time there are no Roamio models 93 or 94 receivers.



ROAMIO MODEL 90




ROAMIO MODEL 91



ROAMIO MODEL 92

# CROSLLEY RADIO CORP.

## Model 124-1



Circuit Diagram, Model 124-1

124-1 CHASSIS ASSEMBLY  
WIRING DIAGRAM

Model 124-1 is a modified Model 124 chassis adapted to operate dual speakers. The circuit is shown in Figure 1, and the speaker connections in Figure 2. This chassis uses two -35 type tubes as radio frequency and intermediate frequency amplifiers, two -27 type tubes as oscillator, and second detector, one -24 type tube as first detector, two -47 type tubes as output tubes, and one -80 type tube as rectifier.

### Alignment

#### Alignment of I. F. Stages

Model 124-1 is designed to work with an intermediate frequency of 175 kilocycles. There are aligning condensers across the primary and secondary of the coupling transformers between the first detector and the intermediate frequency amplifier, and between the intermediate frequency amplifier and the second detector.

To align the intermediate frequency stages it is necessary to have an oscillator which tunes accurately to 175 kilocycles. Such oscillators are supplied by the Weston Electrical Instrument Co., the Jewel Co., the General Radio Company, the Radio Products Co., etc.

1. Connect the high side of the test oscillator through 0.1 mf condenser to the grid of the first detector tube. **Do not** remove the grid clip from the tube. Connect the low side of the test oscillator to chassis.

2. Turn the dial on the receiver so that the set is tuned to 550 kilocycles.

3. Adjust the condensers on either side of the coupling transformer between the first detector and the intermediate frequency amplifier to give maximum reading on the output meter.

4. Adjust the condenser on either side of the coupling transformer between the inter-

# CROSLEY RADIO CORP.

## Model 124-1

mediate frequency amplifier and the second detector tube to give maximum reading on the output meter.

After these adjustments have been made the intermediate frequency stages will be properly aligned.

### Alignment of Tuning Condensers

To align the oscillator, antenna coupling circuit, and radio frequency stage, it is necessary to have an oscillator which can be tuned to 1400 kilocycles. If no oscillator is available, the receiver may be tuned to a station of known frequency within 50 kilocycles of 1400.

1. Connect the high side of the test oscillator through a 0.00025 mf condenser (or a dummy antenna) to the antenna post on the receiving set, and connect the low side to chassis.

2. Tune the receiver to 1400 kilocycles.

3. Adjust the padding condensers on the side of the units of the ganged condenser to give maximum reading on the output meter.

After this has been done the receiver will be properly aligned.

### Voltage Limits

The voltages are to be measured with the

speakers connected, the tubes in place, and a line voltage of 117½ volts (235 volts for 220 volt receivers). All voltages should be measured with a high resistance voltmeter (600 ohms or more per volt). The plate, screen grid, and operating grid voltages are measured from the elements named to cathode.

<b>Filament Voltages</b>	
All tubes but Rectifier .....	2.2 to 2.5
Rectifier tube .....	4.6 to 5.0
<b>Plate Voltages</b>	
R. F. and I. F. Tubes .....	245 to 285
First Detector Tube .....	130 to 150
Oscillator Tube .....	80 to 100
Second Detector Tube .....	120 to 140
Output Tube .....	230 to 270
Rectifier .....	330 to 390 (A.C.)
<b>Screen Grid Voltages</b>	
R. F. and I. F. Tubes .....	80 to 100
First Detector Tube .....	75 to 85
Output Tubes .....	230 to 280
<b>Grid Voltages</b>	
R. F. and I. F. Tubes .....	-3.0 to -3.4
First Detector Tube .....	-7.0 to -9.0
Oscillator Tube .....	-10.0 to -12.0
Second Detector Tube .....	-16.0 to -20.0
Output Tubes .....	-15.0 to -17.0





Fig. 2—Diagram of Speaker Connections



# CROSLLEY RADIO CORP.

## Models 129, 129-1, Circuit Model 131



129 CHASSIS ASSEM. WIRING DIAGRAM

Circuit Diagram, Model 129

### Specifications

Models 129 and 129-1 are six-tube superheterodynes for operation from A.C. electrical circuits, differing only in that Model 129 is adapted to the operation of a single speaker, and Model 129-1 to the operation of dual speakers. The tubes used are: a -24 type oscillating first detector, a -58 type I.F. amplifier, a -57 type second detector, two -42 type push-pull output tubes, and a -80 type rectifier.

### Voltage Limits


The following are the approximate voltages which should be measured with the tubes in place, speakers connected, and a line voltage of 117½ (235 for 220 volt receivers). Measure plate and screen grid voltages with a high-resistance D.C. voltmeter (1000 ohms per volt) from plate or screen grid tube contact to emitter contact. Measure bias voltages

as shown in table. Use a low-range A.C. voltmeter for filament or heater voltages.


Heater Or Filament Voltages	
First Detector, I. F. Amplifier, and Second Detector tubes	2.3 to 2.7
Output tubes	6.0 to 7.0
Rectifier tube	4.5 to 5.5
Plate Voltages	
First Detector tube	175 to 215
I. F. Amplifier tube	260 to 320
Second Detector tube	72 to 88
Output tubes	240 to 300
Rectifier tube	335 to 365
Screen Grid Voltages	
First Detector and I. F. Amplifier tubes	85 to 105
Second Detector tube	27 to 33
Output tubes	240 to 300
Operating Grid Voltages	
First Detector tube (cathode to chassis)	7 to 9
I. F. amplifier tube (cathode to chassis)	2.7 to 3.3
Second Detector tube (across 6,000 ohm bias resistor)	6.3 to 7.7
Output tubes (cathode to chassis)	18 to 22

# CROSLY RADIO CORP.

## Models 129, 129-1, Circuit Model 131



Circuit Diagram, Model 129-1



Circuit Diagram, Model 131

# CROSLEY RADIO CORP.

## CROSLEY "CHIEF" 12-TUBE MODEL 132-1 12-TUBE SUPERHETERODYNE

(Dual reproducers, class B push-push A.F. power output fed by a class A push-pull driver stage, meter tuning, A.V.C., tone control, static control.)

The Crosley Chief, 12-tube superheterodyne console model radio receiving set, is the most recent addition to the line. This receiver incorporates the model 132-1 chassis. Although incorporating a large number of tubes, the power line current consumption is held to a minimum by use of the new tubes which consume much less current than the older types.

Resistors R1A, R1B, 1.5 megs. (per section); R2, 0.4-meg.; R3, 80,000 ohms; R4, 0.15-meg.; R5, R6, 60,000 ohms; R7, 2,000 ohms; R8, 1 meg.; R9, 7,000 ohms; R10, 40 ohms; R11, 750 ohms; R12, R13, R24, 0.5-meg.; R-14, R23, 0.3-meg.; R15, 450 ohms; R16, 3 megs.; R17, 30,000 ohms; R18, 20 ohms center-tapped; R19, 3,500 ohms; R20, 6,000 ohms; R21, 10,000 ohms; R22, 5 megs.

Condensers C1 to C4, tuning units; C5 to C8, I. F. trimmers; C9, C25, C26, .02-mf.; C10, C11, C13, C14, C16, C30, C31, C32, 0.1-mf.; C17, C15, 4 mf.; C18, 150 mmf.; C19, 100 mmf.; C20, C23, .006-mf.; C21, C22, C28, 8 mf.; C24, .05-mf.; C27, .003-mf.; C29, 12 mf.

Tube	Fil.	Bias	S.-G.	Plate
Type	Volts	Volts	Volts	Volts
V1	2.4	0.5	60	200
V2	2.4	2.5	60	200
V3	2.4	13.5	—	170
V4	2.4	0.5	60	200
V5	2.4	8	165	220
V6	2.4	—	—	—
V7	5.6	23.5	220	200
V8	5.6	23.5	220	200
V9	5.6	28.5	—	405
V10	5.6	28.5	—	405
V11	2.4	77.5	—	70
V12	2.5	—	—	415

With a line potential of 117.5 V. the above figures may be taken as average readings; for "220 V." sets a line voltage of 235 is taken as standard. Bias (unless otherwise stated), screen-grid, and plate readings are taken between these tube contacts and the emitter; bias for V3, V5, V7 to V11, cathode to chassis.

Late chassis of this model have a 1,400-ohm resistor shunted across the visual tuning meter. Also, these later chassis may have two 1 meg. resistors (total) in the manual volume control circuit, connected from the moving arms to the ground ends of R1A and R1B.

The tuning meter of this receiver has a resistance of approximately 440 ohms and the deflection is approximately 10 ma.

The A. F. output of V6 actuates tube V11 which, in turn, controls the bias on the amplifier tubes for A.V.C. operation. By manual adjustment of R2 the degree of background noise is controlled to suit individual preference of sensitivity.

Note that the transformer secondary supplying tubes V1, V2, V3 is bypassed by a dual-section condenser, C30-C31. Another unusual circuit arrangement is the use of a double choke coil arrangement comprising Ch1-Ch2. and field coils 1 and 2. The first two choke coils are connected in the positive high-voltage lead in the usual manner, while the second two chokes, the field coils of the dynamic reproducers, are connected as an "inductive voltage divider," one terminal of the two coils in series being connected to the positive output of the regular filter system, and the other end being grounded to the chassis; the center-tap of these field coils supplies voltage to the screen-grids of V1, V2, V4, and to the plate of V5.

The tone correction furnished by C25-C26 applies equally to V9 and V10, the center-tap of these two condensers being grounded to the chassis. If any portion of the tone control R3, C24, becomes grounded the A. F. portion of the receiver will become inoperative as the entire tone control operates at the potential of the plates of V7, V8.


The manual volume control operates in the input circuit of the push-pull driver stage, V7-V8. The two sections of this volume control, R1A, R1B, operate simultaneously as a dual unit.

The first A.F. stage, V7, V8, is driven by a so-called split-diode circuit furnishing A.F. voltage from both the cathode and plate circuits, which are out of phase (in push-pull relationship).

The input circuit of V1 is preceded by a band-selector which must be carefully aligned in order to maintain the required degree of selectivity at all points in the tuning band.

The A.V.C. action is obtained through the voltage drop across resistor R4. There is an initial current flowing through this unit and the 5 meg. grid leak, R22, furnishing a normal bias for the R.F. and I.F. stages. The A.V.C. tube V11 is delayed by means of a positive potential on the cathode of about 60 V. When an R.F. signal of sufficient intensity is applied to make this A.V.C. tube (D.C. amplifier) draw plate current, its plate current also flows through R4 and furnishes an additional A.V.C. bias.


The "static" control is also connected to change the current flowing through R4, thus changing the initial bias on the controlled tubes, so that the overall sensitivity of the set is reduced.



Schematic circuit of the Crosley "Chief" model 132-1, 12-tube superheterodyne. Note the unusual arrangement of the circuits of V7-V8, and also V11.

# CROSLEY RADIO CORP.

## Model 133



**Specifications**

Model 133 is a seven-tube superheterodyne for operation from A.C. electric circuits. It employs the following tubes: a -35 type R.F. tube, a -24 type first detector, a -27 type oscillator, a -35 type I.F. tube, a -27 type second detector, a -47 type output tube, and a -80 type rectifier.

**Voltage Limits**

The following are the approximate voltages which should be measured with the tubes in place, speaker connected, and a line voltage of 117½ (235 for 220 volt receivers). Measure plate and screen grid voltages with a high-resistance D.C. voltmeter (1000 ohm per volt) from plate or screen grid tube contact to emitter contact. Measure bias voltages

from cathode to chassis. Use a low-range A.C. voltmeter for filament or heater voltages.


Heater Or Filament Voltages	
All tubes but Rectifier .....	2.3 to 2.7
Rectifier tube .....	4.4 to 5.4
Plate Voltages	
R. F., First Detector, and I. F. tubes .....	265 to 325
Oscillator tube .....	80 to 100
Second Detector tube .....	125 to 155
Output tube .....	230 to 280
Rectifier tube .....	395 Volts A C
Screen Grid Voltages	
R. F., First Detector, and I. F. tubes .....	80 to 100
Output tube .....	250 to 310
Bias Voltages	
R. F. and I. F. tubes .....	2.7 to 3.3
First Detector tube .....	6 to 7
Oscillator tube .....	11 to 13
Second Detector tube .....	14 to 18
Output tube .....	16 to 20

133 CHASSIS ASSEMBLY WIRING DIAGRAM

Circuit Diagram, Model 133

# CROSLEY RADIO CORP.

## Models 134, 134-1



1	W-8406	ANTENNA COIL	30	W-2578	500.000 Ω
2	W-2713	CONDENSER COIL	31	W-2578	500.000 Ω
3	W-2564	OSCILLATOR COIL	32	W-2578	500.000 Ω
4	W-2405	I.F. TRANSFORMER	33	W-2578	500.000 Ω
5	W-2405	I.F. TRANSFORMER	34	W-2578	500.000 Ω
6	W-2405	I.F. TRANSFORMER	35	W-2578	500.000 Ω
7	W-2405	I.F. TRANSFORMER	36	W-2578	500.000 Ω
8	W-2405	I.F. TRANSFORMER	37	W-2578	500.000 Ω
9	W-2405	I.F. TRANSFORMER	38	W-2578	500.000 Ω
10	W-2405	I.F. TRANSFORMER	39	W-2578	500.000 Ω
11	W-2405	I.F. TRANSFORMER	40	W-2578	500.000 Ω
12	W-2405	I.F. TRANSFORMER	41	W-2578	500.000 Ω
13	W-2405	I.F. TRANSFORMER	42	W-2578	500.000 Ω
14	W-2405	I.F. TRANSFORMER	43	W-2578	500.000 Ω
15	W-2405	I.F. TRANSFORMER	44	W-2578	500.000 Ω
16	W-2405	I.F. TRANSFORMER	45	W-2578	500.000 Ω
17	W-2405	I.F. TRANSFORMER	46	W-2578	500.000 Ω
18	W-2405	I.F. TRANSFORMER	47	W-2578	500.000 Ω
19	W-2405	I.F. TRANSFORMER	48	W-2578	500.000 Ω
20	W-2405	I.F. TRANSFORMER	49	W-2578	500.000 Ω
21	W-2405	I.F. TRANSFORMER	50	W-2578	500.000 Ω
22	W-2405	I.F. TRANSFORMER	51	W-2578	500.000 Ω
23	W-2405	I.F. TRANSFORMER	52	W-2578	500.000 Ω
24	W-2405	I.F. TRANSFORMER	53	W-2578	500.000 Ω
25	W-2405	I.F. TRANSFORMER	54	W-2578	500.000 Ω
26	W-2405	I.F. TRANSFORMER	55	W-2578	500.000 Ω
27	W-2405	I.F. TRANSFORMER	56	W-2578	500.000 Ω
28	W-2405	I.F. TRANSFORMER	57	W-2578	500.000 Ω
29	W-2405	I.F. TRANSFORMER	58	W-2578	500.000 Ω
30	W-2405	I.F. TRANSFORMER	59	W-2578	500.000 Ω
31	W-2405	I.F. TRANSFORMER	60	W-2578	500.000 Ω
32	W-2405	I.F. TRANSFORMER	61	W-2578	500.000 Ω
33	W-2405	I.F. TRANSFORMER	62	W-2578	500.000 Ω
34	W-2405	I.F. TRANSFORMER	63	W-2578	500.000 Ω
35	W-2405	I.F. TRANSFORMER	64	W-2578	500.000 Ω
36	W-2405	I.F. TRANSFORMER	65	W-2578	500.000 Ω
37	W-2405	I.F. TRANSFORMER	66	W-2578	500.000 Ω
38	W-2405	I.F. TRANSFORMER	67	W-2578	500.000 Ω
39	W-2405	I.F. TRANSFORMER	68	W-2578	500.000 Ω
40	W-2405	I.F. TRANSFORMER	69	W-2578	500.000 Ω
41	W-2405	I.F. TRANSFORMER	70	W-2578	500.000 Ω
42	W-2405	I.F. TRANSFORMER	71	W-2578	500.000 Ω
43	W-2405	I.F. TRANSFORMER	72	W-2578	500.000 Ω
44	W-2405	I.F. TRANSFORMER	73	W-2578	500.000 Ω
45	W-2405	I.F. TRANSFORMER	74	W-2578	500.000 Ω
46	W-2405	I.F. TRANSFORMER	75	W-2578	500.000 Ω
47	W-2405	I.F. TRANSFORMER	76	W-2578	500.000 Ω
48	W-2405	I.F. TRANSFORMER	77	W-2578	500.000 Ω
49	W-2405	I.F. TRANSFORMER	78	W-2578	500.000 Ω
50	W-2405	I.F. TRANSFORMER	79	W-2578	500.000 Ω
51	W-2405	I.F. TRANSFORMER	80	W-2578	500.000 Ω
52	W-2405	I.F. TRANSFORMER	81	W-2578	500.000 Ω
53	W-2405	I.F. TRANSFORMER	82	W-2578	500.000 Ω
54	W-2405	I.F. TRANSFORMER	83	W-2578	500.000 Ω
55	W-2405	I.F. TRANSFORMER	84	W-2578	500.000 Ω
56	W-2405	I.F. TRANSFORMER	85	W-2578	500.000 Ω
57	W-2405	I.F. TRANSFORMER	86	W-2578	500.000 Ω
58	W-2405	I.F. TRANSFORMER	87	W-2578	500.000 Ω
59	W-2405	I.F. TRANSFORMER	88	W-2578	500.000 Ω
60	W-2405	I.F. TRANSFORMER	89	W-2578	500.000 Ω
61	W-2405	I.F. TRANSFORMER	90	W-2578	500.000 Ω
62	W-2405	I.F. TRANSFORMER	91	W-2578	500.000 Ω
63	W-2405	I.F. TRANSFORMER	92	W-2578	500.000 Ω
64	W-2405	I.F. TRANSFORMER	93	W-2578	500.000 Ω
65	W-2405	I.F. TRANSFORMER	94	W-2578	500.000 Ω
66	W-2405	I.F. TRANSFORMER	95	W-2578	500.000 Ω
67	W-2405	I.F. TRANSFORMER	96	W-2578	500.000 Ω
68	W-2405	I.F. TRANSFORMER	97	W-2578	500.000 Ω
69	W-2405	I.F. TRANSFORMER	98	W-2578	500.000 Ω
70	W-2405	I.F. TRANSFORMER	99	W-2578	500.000 Ω
71	W-2405	I.F. TRANSFORMER	100	W-2578	500.000 Ω

134 CHASSIS ASSEMBLY WIRING DIAGRAM

Circuit Diagram, Model 134

### Specifications


Models 134 and 134-1 are both eight-tube chassis for operation from A.C. electrical circuits. They employ similar superheterodyne circuits, the essential differences being due to the fact that Model 134 is used with a single speaker and Model 134-1 with dual speakers. Both employ a -35 or -51 type first detector tube, a -27 type oscillator tube, a -35 or -51 type first I.F. amplifier tube, a -24 type second I.F. amplifier tube, a -27 type second detector and automatic volume control tube, a -27 type first A.F. amplifier tube, a -47 type output tube, and a -80 type rectifier tube.

### Voltage Limits

The following are the approximate voltages which should be measured with the tubes in place, speakers connected, and a line voltage of 117½ (225 for 220 volt receivers). Measure plate and screen grid voltages with a high-resistance D.C. voltmeter (1000 ohms per volt) from plate or screen grid tube contact to emitter contact. Measure bias voltages from cathode contact to chassis. Use a low-range A.C. voltmeter for filament or heater voltages.

# CROSLY RADIO CORP.

Models 134, 134-1



Circuit Diagram, Model 134-1


Model 134	
<b>Heater Or Filament Voltages</b>	
All tubes but Rectifier .....	2.3 to 2.7
Rectifier tube .....	4.5 to 5.5
<b>Plate Voltages</b>	
First Detector and I. F. Amplifier tubes .....	260 to 310
Oscillator tube .....	77 to 93
First A. F. tube .....	50 to 60
Output tube .....	240 to 290
Rectifier tube .....	350 to 410
<b>Screen Grid Voltages</b>	
First Detector and I. F. Amplifier tubes .....	77 to 93
Output tube .....	260 to 310
<b>Bias Voltages</b>	
Oscillator tube .....	11 to 13
First Detector and First I. F. Amplifier tubes .....	0
Second I. F. tube .....	0.4 to 0.6
First A. F. Amplifier tube .....	4 to 6
Output tube .....	17.5 to 21.5

Model 134-1	
<b>Heater Or Filament Voltages</b>	
All tubes but Rectifier .....	2.3 to 2.7
Rectifier tube .....	4.5 to 5.5
<b>Plate Voltages</b>	
First Detector and First I. F. tubes .....	240 to 290
Oscillator tube .....	77 to 93
Second I. F. Amplifier tube .....	325 to 375
First A. F. Amplifier tube .....	125 to 155
Output Tube .....	230 to 280
Rectifier tube (measured from each plate to chassis) .....	340 to 400
<b>Screen Grid Voltages</b>	
First Detector and I. F. tubes .....	77 to 93
Output Tube .....	245 to 295
<b>Bias Voltages</b>	
Oscillator tube .....	12 to 14
First Detector and First I. F. Amplifier tubes .....	0
Second I. F. tube .....	0.5 to 0.7
First A. F. tube .....	11 to 13
Output Tube .....	14 to 18

\*SEE CHASSIS PHYSICALLY WIRING DIAGRAM

# CROSLEY RADIO CORP.

## Model 135



135 CHASSIS ASSEMBLY  
WIRING DIAGRAM

Circuit Diagram, Model 135

### Specifications

Model 135 is a five tube superheterodyne for operation from A.C. electric circuits. It employs the following tubes: a -24 type oscillating first detector, a -35 or -51 type I.F. amplifier, a -24 type second detector, a 147 output pentode, and an -80 type rectifier.

### Voltage Limits

The following are the approximate voltages which should be measured with tubes in place, speaker connected, and a line voltage of 117½ (235 for 220 volt receivers). Measure plate and screen grid voltages with a high-resistance D.C. voltmeter (1000 ohms per volt) from plate or screen grid tube contact to emitter contact. Measure bias voltages from

cathode to chassis. Use a low-range A.C. voltmeter for filament or heater voltages.

### Heater Or Filament Voltages

All tubes but Rectifier .....	2.2 to 2.8
Rectifier tube .....	4.4 to 5:4

### Plate Voltages

First Detector and I. F. tubes .....	250 to 290
Second Detector tube .....	40 to 60
Output tube .....	220 to 270
Rectifier tube .....	350 to 400

### Screen Grid Voltages

First Detector and I. F. tubes .....	70 to 90
Second Detector tube .....	20 to 35
Output tube .....	225 to 275

### Bias Voltages

First Detector tube .....	6 to 9
I. F. tube .....	2.7 to 3.5
Second Detector tube .....	4 to 6
Output tube .....	10 to 21

# CROSLEY RADIO CORP.

## Model 136-I

### Specifications

Model 136-1 is a ten tube superheterodyne for operation from A. C. electric circuits. Five sets of coils give the following frequency ranges: 550 to 1500 KC, 1500 to 3500 KC, 3500 to 6500 KC, 6500 to 12000 KC, and 12000 to 20000 KC. The intermediate frequency used is 456 KC.

### Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition, but with no signal to the antenna circuit. Use a high resistance D. C. volt-

meter (1000 ohms per volt, or more) for all but filament voltages. In measuring filament or heater voltages use a low range A. C. meter. The voltage limits are + or - 10% of values given in the following table.


Line voltage—117.5 volts (235 for 220 volt receivers).

Plate voltage measured from plate contact to cathode contact.

Suppressor grid voltage measured from suppressor grid contact to cathode contact.

Bias voltage measured from cathode contact to chassis.


Tube	Position	Plate	Screen Grid	Voltages Supp. Grid	Bias	FIL
-56	Oscillator	45			0	2.5
-58	1st Detector	275	100	0	10.0	2.5
-58	1st I. F. Amplifier	275	100	0	2.5	2.5
-58	2nd I. F. Amplifier	275	100	0	4.0	2.5
-56	Diode Detector	0			0	2.5
-56	Push Pull A. F. Amplifier	135			7.0	2.5
-56	Push Pull A. F. Amplifier	135			7.0	2.5
-42	Output	270	275		20.0	6.3
-42	Output	270	275		20.0	6.3
-80	Rectifier	370				4.8





# CROSLEY RADIO CORP.

## Model 137



Circuit Diagram, Model 137

### Specifications

Model 137 is a four-tube superheterodyne for operation from A.C. electric circuits. The tubes employed are as follows: a -24 type oscillating first detector, a -35 or -51 type I.F. amplifier, a -47 type second detector and output tube, and an -80 type rectifier.

### Voltage Limits

The following are the approximate voltages which should be measured with the tubes in place, speaker connected, and a line voltage of 117½ (235 for 220 volt receivers). Measure plate and screen grid voltages with a high-resistance D.C. voltmeter (1000 ohms per volt) from plate or screen grid tube contact to emitter contact. Measure bias voltages from


cathode to chassis. Use a low-range A.C. voltmeter for filament or heater voltages.

<b>Heater Or Filament Voltages</b>	
All tubes but Rectifier .....	2.2 to 2.6
Rectifier tube .....	4.4 to 5.2
<b>Plate Voltages</b>	
First Detector and I. F. tubes .....	220 to 260
Second Detector tube .....	210 to 250
Rectifier tube .....	380 to 430
<b>Screen Grid Voltages</b>	
First Detector and I. F. tubes .....	90 to 110
Second Detector tube .....	220 to 260
<b>Bias Voltages</b>	
First Detector tube .....	8 to 10
I. F. tube .....	2.7 to 3.3
Second Detector tube (with no signal) .....	25 to 30


137 CHASSIS ASSEMBLY WIRING DIAGRAM

# CROSLY RADIO CORP.

## Model 141



1	W-25036	ANTENNA COIL	2000-3500	-80 SOCKET	
2	W-25037	CATHODE COUPLER	27.150-27.800	-80 SOCKET	
3	W-24896	OSCILLATOR COIL	571.67-57800	-57 SOCKET	
4	W-25058	TRIMMER CONDENSER	50.00-50.00	0.005 MFD.	
5	W-25434	0.0025 MFD.	50	W-25089	I.F. TUNING COND.
6	W-25444	I.F. TRANSFORMER	30	W-25438	0.1 MFD. WITH 50
7	W-24234	R.F. GRID CHOKER	71	W-25438	0.1 MFD. WITH 50
8	W-25443	I.F. TRANSFORMER	31	W-25089	0.1 MFD. WITH 50
9	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
10	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
11	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
12	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
13	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
14	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
15	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
16	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
17	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
18	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
19	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
20	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
21	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
22	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
23	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
24	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
25	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
26	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
27	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
28	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
29	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
30	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
31	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
32	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
33	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
34	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
35	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
36	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
37	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
38	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
39	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
40	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
41	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
42	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
43	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
44	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
45	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
46	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
47	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
48	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
49	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE
50	W-25440	3/16" SPEAKER	33	W-25078	ANTENNA LEAD-SOLE



141 CHASSIS ASSEMBLY WIRING DIAGRAM

Circuit Diagram, Model 141

### Specifications

Model 141 is a five-tube superheterodyne for operation from A.C. electric circuits. It employs the following tubes: a -24 type oscillating first detector, a -58 type I.F. amplifier, a -57 type second detector, a -47 type output tube, and a -80 type rectifier.

### Voltage Limits



The following are the approximate voltages which should be measured with the tubes in place, speaker connected, and a line voltage of 117½ (235 for 220 volt receivers), Measure plate and screw grid voltages with a high-resistance D.C. voltmeter (1000 ohms per volt) from plate or screen grid tube contact to emitter contact. Measure bias voltages from

cathode to chassis. Use a low-range A.C. voltmeter for filament or heater voltages.

Heater Or Filament Voltages	
All tubes but Rectifier .....	2.2 to 2.6
Rectifier tube .....	4.3 to 5.3
Plate Voltages	
First Detector and I. F. tubes .....	230 to 270
Second Detector tube .....	30 to 50
Output tube .....	230 to 260
Rectifier tube .....	340 to 380
Screen Grid Voltages	
First Detector and I. F. tubes .....	90 to 110
Second Detector tube .....	30 to 50
Output tube .....	235 to 265
Bias Voltages	
First Detector tube .....	8 to 10
I. F. tube .....	3.1 to 3.9
Second Detector tube .....	9 to 12
Output tube .....	16 to 21

# CROSLY RADIO CORP.

## Models 146 and 146-1



146-1—Wiring Diagram

# CROSLY RADIO CORP.

## Models 146 and 146-1

### Specifications

Models 146 and 146-1 are nine tube superheterodynes for operation from A. C. electric circuits. Model 146 uses a single speaker and Model 146-1 uses two speakers. The intermediate frequency used in both models is 181.5 kilocycles.

### Tubes and Voltage Limits

The following are the voltages measured with the receiver in operating condition but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms per volt, or more) for all but filament voltages. In measuring filament or heater voltages use

a low range A. C. meter. The voltage limits are + or - 10% of values given in the following table.

Line voltage 117½ volts (235 for 220 volt receivers).

Plate voltage measured from plate contact to cathode contact.

Screen grid voltage measured from screen grid contact to cathode contact.

Suppressor grid voltage measured from suppressor grid contact to cathode contact.

Bias voltage measured from cathode contact to chassis, except in cases noted.

### Model 146

Tube	Position	Plate	Screen Grid	Voltages Supp. Grid	Bias	Fil.
-58	R. F. Amplifier	195	62	0	2.5*	2.5
-57	Osc. Detector	195	132	0	9.0	2.5
-58	1st I. F. Amplifier	200	62	0	2.0*	2.5
-58	2nd I. F. Amp. and Diode	0	105	200	5.0	2.5
-56	A. V. C.	60			70.0	2.5
-89	A. F. Amplifier	180	200	0	20.0	6.0
-46	Class B Output	350			0	2.5
-46	Class B Output	350			0	2.5
-82	Rectifier	380				2.5

\* Measured across cathode resistors of each tube.

### Model 146-1

Tube	Position	Plate	Grid Screen	Voltages Grid Supp.	Bias	Fil.
-58	R. F. Amplifier	310	130	0	4.5	2.5
-57	Osc. Detector	290	130	0	6.0	2.5
-58	1st I. F. Amplifier	310	130	0	4.5	2.5
-58	2nd I. F. Amp.	310	130	0	6.0	2.5
-56	Diode Detector and A. V. C.	80				2.0
-89	A. F. Amplifier	250	255		28.0	6.0
-46	Class B Output	365			0	2.5
-46	Class B Output	365			0	2.5
-82	Rectifier	380				2.5

# CROSLY RADIO CORP.

## Model 147

### Specifications

Model 147 is a four tube tuned radio frequency receiver designed for operation from 110 volt, 25 or 60 cycle A. C. and 110 volt D. C. electric circuits.

### Tubes And Voltage Limits

The following are the voltage limits measured with the receiver in operating condition, but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms

per volt, or more) for all voltages but filaments on A. C. operation. For heater or filament voltages on A. C. use a low range A. C. meter.

Line voltage—117.5 volts.


Plate voltage measured from plate contact to cathode contact.

Screen grid voltage measured from screen grid contact to cathode contact.

Bias voltage measured from cathode to negative of "B" supply.

Tube	Position	Plate	Screen Grid	Voltages Supp. Grid	Bias	FIL
<b>Voltages with A. C. Power Supply</b>						
-39	R. F. Amplifier	104	104		1.3	5.6
-36	Detector	5	7		1.2	5.6
-38	Output	92	95		14	5.6
-37	Rectifier				118	5.6
<b>Voltages with D. C. Power Supply</b>						
-39	R. F. Amplifier	100	100		1.2	5.6
-36	Detector	5	7		1.0	5.6
-38	Output	92	95		12.0	5.6
-37	Rectifier	3			102	5.6

- 1 W-27652 .003 MFD.
- 2 LW-27680 ANTENNA COIL
- 3 LW-27681 INTERSTAGE COIL
- 4 B-27706 TUNING CONDENSER
- 5 W-27694 VOLUME CONT. 4500 Ω
- 6 W-27694 LINE SWITCH
- 7 W-25438 1 MFD.
- 8 W-25438 1 MFD.
- 9 W-27677A 8 MFD.
- 10 W-27677A 8 MFD.
- 11 W-27677A 60,000 Ω
- 12 W-26577 3 MEG.
- 13 W-27203 .02 MFD.
- 14 W-26578 5 MEG.
- 15 W-26690 4500 Ω
- 16 W-25438 1 MFD.
- 17 W-27675 300 Ω RED DEN.
- 18 W-27675 300 Ω RED DEN.
- 19 G2-24774 FILTER CHOKE
- 20 W-27676 4 MFD.
- 21 LW-27815 CORD & PLUG
- 22 G11-27727 -36 SOCKET
- 23 G11-27727 -36 SOCKET
- 24 G15-27727 -38 SOCKET
- 25 G15-27727 -38 SOCKET
- 26 G12-27727 -37 SOCKET
- 27 27790 340 SPEAKER
- 28 W-26072 ANTENNA LEAD
- 29 W-46390 2 AMP. FUSE
- 30 W-27652 .003 MFD.
- 31 W-28100 300 Ω CATHODIA
- 32 G12-27727 -37 SOCKET
- 33 W-27652 .003 MFD.
- 34 G1-24234 FILTER CHOKE
- 35
- 36
- 37
- 38
- 39
- 40
- 41
- 42
- 43
- 44
- 45
- 46
- 47
- 48
- 49
- 50
- 51
- 52
- 53
- 54
- 55
- 56
- 57
- 58
- 59
- 60
- 61
- 62



63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94

RECORD OF CHANGES

A ITEM 16 REPLACED WITH ITEM 30 11-14-32 *W. J. B.*

B ITEM 31 ADDED AS SELECT ITEM WITH ITEM 17 11-14-32 *W. J. B.*

C ITEM 18 DELETED, ITEM 13 REPLACED BY ITEM 24 11-14-32 *W. J. B.*

D ADD ITEM 34 12-7-32 *W. J. B.*

THE CROSLY RADIO CORPORATION, CINCINNATI, OHIO

**147 WIRING DIAGRAM**

APPROVED: *[Signature]* 11-5-32 *W. J. B.* NO. B-27788 A

# CROSLY RADIO CORP.

## Model 148

### Specifications

Model 148 is a five tube superheterodyne for operation from A. C. electric circuits. The intermediate frequency used is 456 kilocycles.

### Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms per volt or more) for all but filament voltages. In measuring filament or heater voltages use a low range A. C. meter. The voltage limits are

+ or - 10% of values given in the following table.

Line voltage 117½ volts (235 for 220 volt receivers).

Plate voltage measured from plate contact to cathode contact.


Screen grid voltage measured from screen grid contact to cathode contact.

Suppressor grid voltage measured from suppressor grid contact to cathode contact.

Bias voltage measured from cathode contact to chassis, except as noted.

Tube	Position	Plate	Screen Grid	Supp. Grid	Bias	Fil.
-58	Osc. Detector	230	110	33	2.7*	2.5
-58	I. F. Amplifier	255	140	0	3.0	2.5
-57	Detector	180	40	0	5.8	2.5
-42	Output	240	255	0	17.0	7.0
-80	Rectifier	330				4.8

\*Across 275 ohm resistor in cathode circuit.



CROSLEY RADIO CORP.

Model 150

Specifications

Model 150 is a six tube superheterodyne for operation from A. C. electric circuits. The intermediate frequency used is 181.5 kilocycles.

Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms per volt or more) for all but the filament voltages. In measuring filament or heater voltages use a low range A. C. meter. The voltage

limits are + or - 10% of the values given in the following table.

Line voltage 117½ volts (235 for 220 volt receivers).

Plate voltage measured from plate contact to cathode contact.


Screen grid voltage measured from screen grid contact to cathode contact.

Suppressor grid voltage measured from suppressor grid contact to cathode contact.

Bias voltage measured from cathode contact to chassis.

Tube	Position	Plate	Screen Grid	Supp. Grid	Bias	Fil
-58	R. F. Amplifier	260	90	0	2.5	2.5
-57	Oscillating detector	240	80	0	5.0	2.5
-58	I. F. Amplifier	275	100	0	2.5	2.5
-55	Detector	95			23.0	2.5
-42	Output	255	260	0	22.0	6.3
-80	Rectifier	360				5.0

1	GT-24995	ANTENNA COIL
2	GT-25008	INTERSTAGE COIL
3	GT-25008	OSCILLATOR COIL
4	GT-25008	TUNING CONDENSER
5	GT-25008	FIRST I.F. TRANS.
6	GT-25008	SECOND I.F. TRANS.
7	GT-25008	I.F. TUNING COND.
8	GT-25008	FIRST TUNING COND. I.F.
9	GT-25008	SECOND I.F. TUNING COND.
10	GT-25008	SECOND I.F. TUNING COND.
11	W-21455	300,000 Ω
12	W-21455	300,000 Ω
13	W-22081	16,000 Ω
14	W-21875	10,000 Ω
15	W-26577	3 MEGOHMS
16	W-21455	300,000 Ω
17	W-26577	3 MEGOHMS
18	W-21875	10,000 Ω
19	W-23143	0.05 MFD.
20	W-26877	100,000 Ω
21	LC-25510	312-4 SPEAKER
22	LC-25510	FIELD COIL 1200 Ω
23	W-20265	ANT. GND. POST
24	W-25438	0.1 MFD.
25	W-20049	0.1 MFD.
26	W-24814	7,000 Ω
27	W-25437	0.0015 MFD.
28	W-21433	1 MEGOHM
29	W-26878	5 MFD.
30	W-23307	75 Ω
31	B-21497	CARD & PLUG
32	W-25504	TONE CONTROL
33	W-24049	POWER SWITCH
34	W-24049	0.1 MFD.
35	W-24049	POWER TRANS. 250V
36	W-24049	POWER TRANS. 250V
37	W-24049	POWER TRANS. 250V
38	W-24049	POWER TRANS. 250V
39	W-25542	8 MFD.
40	W-25542	4 MFD.
41	W-27589	110 Ω
42	W-27589	2,000 Ω
43	W-27589	15,000 Ω
44		
45	80-26614	-5B SOCKET
46	80-26614	-57 SOCKET
47	80-26614	-58 SOCKET
48	80-26614	-A2 SOCKET
49	80-26614	-B0 SOCKET
50	W-2722	2.7 Ω DIAL LAMP
51	W-24049	2.7 Ω DIAL LAMP
52	W-26001	SPEAKER CORD
53	W-153	500KΩ (P.A. NUMBER)
54	W-4045	0.1MFD (P.A. NUMBER)
55	W-25437	0.0015 MFD.
56	W-23143	0.05 MFD.
57	W-26878	5 MFD.
58	W-23307	75 Ω
59	W-27589	110 Ω
60	W-27589	2,000 Ω
61		
62		
63		
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		



RECORD OF CHANGES		
ITEM	BY	DATE

THE CROSLEY RADIO CORPORATION, CINCINNATI, OHIO  
 150 W. W. DINGMAN  
 B-27356

# CROSLEY RADIO CORP.

## Model 154

### Specifications

Model 154 is a midget four tube superheterodyne designed for operation from A. C. electric circuits. The intermediate frequency used is 456 KC. In addition to the combination volume control-switch and the tuning control, there is a regeneration control, a short fibre rod with a screw driver slot, located at the rear of the chassis. This should be adjusted for the most sensitive operation without oscillation in the receiver.

### Tubes and Voltage Limits

The tubes and their functions and voltages are shown in the following chart. All tube


voltages are to be measured with the set in operating condition, but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms per volt or more) for measuring all but filament voltages. Measure filament voltages with a low range A. C. meter. The voltage limits are + or - 10% of values given in the following table.

Line voltage—117.5 volts (235 for 220 volt receivers).

All voltages, except filament, measured from tube contact to chassis.

Filament voltages measured between filament contacts.

Tube	Position	Plate	Voltages				Fil.
			Screen Grid	Cathode	Control Grid		
-58	Oscillator modulator	200	100	16	-14	2.5	
-57	2nd Detector	25	20	0	0	2.5	
-42	Output	130	200	12	0	6.3	
-80	Rectifier	310				5.0	



A REPLACE ITEM 8 WITH ITEMS 30440. ADD ITEM 4 L 113-35 3330  
 B REPLACE ITEMS 14 & 216 WITH ITEMS 63-16 & 65 3555

154 WIRING DIAGRAM  
 1-20-33 B-28516



# CROSLEY RADIO CORP.

## Model 155

### Specifications

Model 155 is a four tube superheterodyne designed for operation from D. C. electric circuits. The intermediate frequency used is 456 KC.

### Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition, but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms

per volt, or more) for all voltages. The voltage limits are + or - 10% of values given in the following table.

Line voltage—117.5 volts.


Plate voltage measured from plate contact to cathode contact.

Screen grid voltage measured from screen grid contact to cathode contact.

Bias voltage measured from grid contact or negative of D. C. supply to cathode contact.

Tube	Position	Voltages			
		Plate	Screen Grid	Bias	Fil
-36	Oscillating Detector	92	50	5.0	6.3
-39	I. F. Amplifier	96	96	3.6	6.3
-37	2nd Detector	82		9.5	6.3
-48	Output	65	80	15.0	30.0

1	66-2495	ANTENNA COIL
2	WT-25444	I. F. TRANSFORMER
3	WT-25443	I. F. TRANSFORMER
4	611-24996	OSCILLATOR COIL
5	W-27752	TUNING CONDENSER
6	W-27753	.006 MFD.
7	W-27635	.006 MFD.
8	W-27269	ANT. GRID TERN.
9	W-27755	Vol. CONT. & SWITCH
10	W-27754	500,000 Ω
11	W-27687	.003 MFD.
12	W-25328	1 MFD.
13	W-27221	25 V. DIAL LIGHT
14	62-28248	I. F. CONDENSER
15	W-28008-A	I. F. CONDENSER
16	W-28008-B	I. F. CONDENSER
17	W-21485	300,000 Ω
18	W-21485	.02 MFD.
19	W-27204	.02 MFD.
20	W-23616	15,000 Ω
21	W-24784	.25 MFD.
22	W-21875	100,000 Ω
23	62-27057	A. F. TRANSFORMER
24	W-24879	5 MFD.
25	W-24007	350 Ω
26	W-27814	135 Ω
27	W-27719	5 MFD.
28	W-21489	FLAS. LAMP
29	W-21489	FLAS. LAMP
30	W-21489	FILTER CHOKE ON SPEK.
31	W-21489	SPEK. FIELD COIL 30 Ω
32	W-27813	200 Ω
33	W-27456	36 TUBE SOCKET
34	W-27456	36 TUBE SOCKET
35	W-27456	36 TUBE SOCKET
36	W-27456	36 TUBE SOCKET
37	W-27456	36 TUBE SOCKET
38	W-25316	.25 MFD.
39	W-27208	.25 MFD.
40	W-21875	100,000 Ω
41	W-21875	100,000 Ω
42	W-21875	100,000 Ω
43	W-21875	100,000 Ω
44	W-21875	100,000 Ω
45	W-27205	.02 MFD.
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		



63		79
64		80
65		81
66		82
67		83
68		84
69		85
70		86
71		87
72		88
73		89
74		90
75		91
76		92
77		93
78		94

RECORD OF CHANGES

A	2ND TUBE	AS SHOWN	W-27752
B	ITEM 10 REPLACED WITH ITEM 42		W-27752
C	ITEM 42 REPLACED WITH ITEM 44		W-27752
D	ITEM 45 ADDED		W-27752

THE CROSLEY RADIO CORPORATION, CINCINNATI, OHIO

**155 CHASSIS WIRING DIAGRAM**

APPROVED: *[Signature]* DATE: *[Date]* NO. **B-27757**

# CROSLEY RADIO CORP.

## Model 156

### Specifications

Model 156 is a five tube battery superheterodyne designed for operation from a 2 volt "A" battery, three 45 volt "B" batteries, and a 22½ "C" battery. The intermediate frequency used is 456 KC.

### Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition, but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohm

per volt, or more) for all voltages. The voltage limits are + or - 10% of values given in the following table.

Battery voltage should be that specified above.

Plate voltage measured from plate contact to filament contact, except as specified.


Screen grid voltage measured from screen grid contact to filament contact.

Bias voltage measured from grid contact to negative filament contact.

Tube	Position	Voltages			
		Plate	Screen Grid	Bias	Fil.
-34	1st Detector	135	67.5	4.0	2.0
-30	Oscillator	22.5		0	2.0
-34	I. F. Amplifier	135	67.5	4.0	2.0
-32	2nd Detector	135*	22.5	0	2.0
-33	Output	135	135		2.0

\* Measured to battery side of 300,000 ohm Plate Resistor.

1	W-20764	ANTENNA GROUND POST
2	GE-27197	INT. & Osc. Coils
3	P-271425	TUNING CONDS.
4	W-25438	0.1 MFD.
5	W-25438	0.1 MFD.
6	GE-25948	I.F. TUNING COND.
7	W-25008A	I.F. TUNING COND.
8	W-25008A	I.F. TUNING COND.
9	GE-25444	I.F. TRANS.
10	GE-25445	I.F. TRANS.
11	W-26577	3 MEG. GRID LEAK
12	W-3382	0.00025 MFD.
13	GE-71912	REGENERAT. UNIT CASE
14	W-21455	300,000
15	W-21455	0.02 MFD.
16	W-21454	1 MEGOHM GRID LEAK
17	L-27197	320-3 SPEAKER
18	M-4	EYELET CONDENSER
19	B-271930	BATTERY CABLE
20	W-25438	0.1 MFD.
22	W-27935	VOLUME CONT. 1000-Ω SWITCH
24	GA-27456	- 30 SOCKET
25	GA-27456	- 30 SOCKET
26	GA-27456	- 30 SOCKET
27	GA-27456	- 30 SOCKET
28	W-26577	3 MEG. RESIS.
29	W-27933	SPEAKER CABLE
30	GE-23500	AIR CELL RESISTOR
31	W-24077	EYELET COND.



32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		
44		
45		
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		

63		
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
92		
93		
94		

### RECORD OF CHANGES

# CROSLY RADIO CORP.

## Model 157

### Specifications

Model 157 is a ten tube superheterodyne for operation from A. C. electric circuits. The intermediate frequency used is 181.5 kilocycles.

### Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms per volt, or more) for all but filament voltages. In measuring filament or heater voltages use a low range A. C. meter. The voltage

limits are + or - 10% of values given in the following table.

Line voltage—117.5 volts (235 for 220 volt receivers).

Plate voltage measured from plate contact to cathode contact.


Screen grid voltage measured from screen grid contact to cathode contact.

Suppressor grid voltage measured from suppressor grid contact to cathode contact.

Bias voltage measured from cathode contact to chassis.

Tube	Position	Plate	Screen Grid	Voltages Supp. Grid	Bias	Fil
-58	R. F. Amplifier	240	110	0	0	2.5
-57	1st Detector	240	110	0	6.0	2.5
-56	Oscillator	110			20.0	2.5
-58	I. F. Amplifier	240	110	0	2.8	2.5
-56	Detector	0				2.5
-56	AVC Rectifier	0				2.5
-56	A. F. Amplifier	40			2.0	2.5
-42	Parallel Output	250	260		17.5	6.3
-42	Parallel Output	250	260		17.5	6.3
-80	Rectifier	350				4.8

1	G1-24295	ANTENNA COIL
2	G2-25968	INTERSTAGE COIL
3	G4-24996	OSCILLATOR COIL
4	G5-24065	FIRST I.F. TRANS.
5	G6-24065	SECOND I.F. TRANS.
6	C-26442B	TUNING CONDENSER
7	G3-25948	I.F. TUNING CONDENSER
8	N-22180	0.08 MFD.
9	N-22180	1650 Ω.
10	N-25857	8 MFD.
11	N-25970	8 MFD.
12	N-25970	15,000 Ω.
13	N-25970	10,000 Ω.
14	N-25937	275 Ω.
15	N-22215	3 MEGOHMS
16	N-21454	1 MEGOHM
17	N-21455	30,000 Ω.
18	N-22180	0.08 MFD.
19	N-26559	0.006 MFD.
20	N-25666	LEVEL CONT. 3-MEG.
21	N-23019	2000 Ω.
22	N-21237	60,000 Ω.
23	N-22180	0.08 MFD.
24	N-21455	30,000 Ω.
25	N-22214	750 Ω.
26	N-22873	220 Ω.
27	N-25517	0.008 MFD.
28	N-25594	0.05 MFD.
29	N-25594	100,000 Ω.
30	N-26118A	8 MFD.
31	N-26118A	8 MFD.
32	N-22221	2.5 PYL. LIGHT
33	N-21491A	CORD & PLUG
34	N-20264	ANT. GRID. POST
35	27869	337-4 SPEAKER-B
36	G2-26614	-58 SOCKET
37	G2-26614	-57 SOCKET
38	G2-26614	-56 SOCKET
39	G2-26614	-42 SOCKET
40	G2-26614	-80 SOCKET
41	G4-25669	PAPER TRANS. 60CY.
42	G4-25669	PAPER TRANS. 25CY.
43	G4-25669	PAPER TRANS. 220V.
44	N-22417A	10 Ω. - 10 Ω.
45	F-1870	332.5 SPEAKER - "N"
46	N-27932	.0001 MFD.
47	N-27932	.0001 MFD.
48	N-25537	.03 MFD.
49	N-25537	.001 MFD.
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		
64		
65		
66		
67		
68		
69		
70		
71		
72		
73		
74		
75		
76		
77		
78		
79		
80		
81		
82		
83		
84		
85		
86		
87		
88		
89		
90		
91		
92		
93		
94		



41 - 60 CY. - 110 VOLT  
 42 - 25 CY. - 110 VOLT  
 43 - 25 CY. - 220 VOLT

63					
64					
65					
66					
67					
68					
69					
70					
71					
72					
73					
74					
75					
76					
77					
78					

RECORD OF CHANGES

Change No.	Description	Date
A	ITEM 18 REPLACED WITH ITEM 46 & 47	5/25/32
B	ITEM 43 REPLACED WITH ITEM 40 & 45	5/26/32

THE CROSLY RADIO CORPORATION, CINCINNATI, OHIO

157 WIRING DIAGRAM

APPROVED: *[Signature]* DATE: 11-5-32 BY: R.C. [Signature] DWS NO. B-27855 A

# CROSLY RADIO CORP.

## Model 158

### Specifications

Model 158 is a seven tube superheterodyne designed for operation from A. C. electric circuits. The intermediate frequency used is 181.5 KC.

### Tubes And Voltage Limits

The following are the voltages measured with the receiver in operating condition, but with no signal to the antenna circuit. Use a high resistance D. C. Voltmeter (1000 ohms per volt, or more) for all but filament voltages. In measuring filament or heater voltages use

a low range A. C. meter. The voltage limits are + or - 10% of values given in the following table.

Line voltage—117.5 (235 for 220 volt receivers).


Plate voltage measured from plate contact to cathode contact.

Screen grid voltage measured from screen grid contact to cathode contact.

Suppressor grid voltage measured from suppressor grid contact to cathode contact.

Bias voltage measured from cathode contact to chassis.


Tube	Position	Plate	Screen Grid	Voltages Supp. Grid	Bias	FIL
-58	R. F. Amplifier	270	85	0	0	2.5
-57	Oscillating Detector	270	80	0	6.0	2.5
-58	I. F. Amplifier	275	80	0	4.0	2.5
-56	Detector	0				2.5
-56	A. F. Amplifier	40			1.6	2.5
-42	Output	245	250		22.0	6.3
-80	Rectifier	350				4.8



# CROSLY RADIO CORP.

## MODEL 160

1	G1-24995	ANTENNA COIL
2	G2-25960	INTERSTAGE COIL
3	G4-24996	OSCILLATOR COIL
4	G5-24065	1ST I.F. TRANS.
5	G10-24065	2ND I.F. TRANS.
6	C-26442B	TUNING CONDENSER
7	G3-25945	I.F. TUNING COND.
8	W-27204	.02 MFD.
9	W-25438	.02 MFD.
10	W-25937	.1 MFD.
11	W-21964	275 A.
12	W-23785	165 A.
13	W-23785	500,000 A.
14	W-21454	1 MEGOHM
15	W-23013	2000 A.
16	W-22514	150 A.
17	W-21455	300,000 A.
18	W-27540	.0005 MFD.
19		
20		
21	G3-25445	COUPLING CHOKE
22	W-21454	1 MEGOHM
23	W-23785	500,000 A.
24	W-26152	.0015 MFD.
25	W-26578	.0001 MFD.
26	W-26577	5 MEGOHM
27	W-26577	3 MEGOHM
28	W-27203	.02 MFD.
29	W-28272	LEVEL CONT. 5000 A.
30	W-25666	INDIC LEVEL CONT. 3-PHASE
31	W-26577	3 MEGOHM
32	W-23403	150,000 A.
33	W-25516	.25 MFD.
34	W-25516	.25 MFD.
35	W-27120	8500 A.
36	W-21237	25,000 A.
37	W-21237	60,000 A.
38	W-21875	100,000 A.
39	W-23142	.02 MFD.
40	W-23613	.05 MFD.
41	W-22873	200 A.
42	W-21455	300,000 A.
43	W-25857A	8 MFD. 25V.
44	W-25857A	8 MFD. 200V.
45	W-25517	.0005 MFD.
46	W-28340	100-PPH
47	W-28340	8 MFD. 250V.
48	W-28340	12 MFD. 275V.
49	W-25594A	12 MFD. 275V.
50	W-25594A	12 MFD. 275V.
51	W-21491A	337-5M. SPEAKER
52	W-22221	2.5V. DIAL LAMP
53	W-20264	ANT. GRID THERMAL
54	G5-25469	POWER TRANS. 80V.
55	G5-27849	337-4M. SPEAKER
56	G6-27456	-58 SOCKET
57	G6-27456	-56 SOCKET
58	G6-27456	-58 SOCKET
59	G6-27456	-80 SOCKET
60	G20-25669	POWER TRANS. 250V.
61	G21-25669	POWER TRANS. 220V.
62	W-21454	1 MEGOHM



110V. 60W	54
110V. 25W	60
250V. 25W	61

Item	Description	Date	By
63	W-20468	8 MFD. 250V.	
64	W-28471	12 MFD. 275V.	
65	W-28471	8500 A.	
66	W-28471	22,000 A.	
67	W-27120	337-5M. SPEAKER	
68	G5-27456	2A5 SOCKET	
69	W-28860	.003 MFD.	
70	W-28860	.15 MFD.	
71			
72			
73			
74			
75			
76			
77			
78			

Item	Description	Date	By
A	ITEM 62 ADDED	12-29-32	
B	ITEMS 63 AND 64 ADDED	1-7-33	
C	ITEMS 65 AND 66 ADDED	1-7-33	
D	ITEM 58 REPLACED BY ITEM 68	1-7-33	
E	ITEMS 45 & 46 REPLACED WITH ITEMS 65 & 70	1-7-33	

THE CROSLY RADIO CORPORATION, CINCINNATI, OHIO  
**160 WIRING DIAGRAM**  
 12-29-32 12-12-32 54407/10 NO B-28334

Tube	Position	Plate	Voltages			Fil.
			Screen Grid	Cathode		
-58	R. F. Amplifier	255	120	4	2.5	
-58	1st Detector	260	120	9	2.5	
-58	I. F. Amplifier	260	115	4	2.5	
-58	Aperiodic I. F. Amplifier	260	115	4	2.5	
-56	Oscillator	120		22	2.5	
-56	AVC diode	17		17	2.5	
-56	QAVC Tube	90		0-20*	2.5	
-56	2nd Detector	0		0	2.5	
-58	A. F. Amplifier	190		120	2.5	
-58†	Output (Class A Pentode)	250	260	17	2.5	
-58†	Output (Class A Pentode)	250	260	17	2.5	
-80	Rectifier	380			4.8	

\* Voltage dependent on position of "Q" control.  
 † May be 2A5 tubes.

### Specifications

Model 160 is a twelve tube superheterodyne for operation from A.C. electric circuits. The intermediate frequency used is 181.5 KC.

Line voltage — 117.5 volts (235 for 220 volt receivers).

All voltages, except filament, measured from tube contact to chassis. Filament voltages measured between heater contacts.

# CROSLEY RADIO CORP.

## Model 163

### Specifications

Model 163 is a five tube superheterodyne designed to operate on 100 to 130 volts, D. C. or any frequency A. C., electric circuits. The intermediate frequency is 456 KC.

### Tubes and Voltage Limits

The following chart gives the tubes, their functions, and voltages measured with the receiver in operating condition but with no signal to the antenna circuit. Use a high resistance D. C. voltmeter (1000 ohms per volt or

more) for all but filament voltages on A. C. operation. For A. C. filament voltages on A. C. operation use a low range A. C. meter. The voltage limits are + or - 10% of the values given.


Line voltage—117.5 volts D. C. or A. C.

All voltages measured from tube contact to negative line, except filament.


Filament voltages measured between filament contacts.

Tube	Position	Plate	Voltages for A. C. Operation*			Fil.
			Screen Grid	Cathode	Supp. Grid	
-78	Oscillator modulator	105	105	2.5	20	6.3
-78	I. F. Amplifier	105	105	3.0	3.0	6.3
-77	2nd Detector	5	5	4.0	4.0	6.3
-38	Output	102	105	8.0	8.0	6.3
12Z3	Rectifier	117.5AC		120		12.6

\* Voltages with D. C. operation are about 10% lower than those with A. C. operation.




# EMERSON RADIO & PHONOGRAPH CORP.



## Model B-AC-10 Model B-10 Chassis

Part No.	Description	List Price
ET-10	Antenna Coil	\$.50 each
ET-11	R. F. Coil	.50 "
ET-12	Oscillator Coil	.55 "
ET-13	R. F. Chokes	.20 "
ET-14	Power Transformer	5.25 "
ET-15	Power Choke	1.80 "
ET-16	Audio Transformer	1.85 "
ET-17	I. F. Transformer	1.15 "
ER-17	Volume Control	.85 "
ER-18	Tone Control	.60 "
ER-24	Noise Control	.55 "
	Any Carbon Resistor (specify value) (See diagram for Part No.)	.15 "
ER-23	Tapped Resistor	.55 "
EC-16	Variable Condenser	2.50 "
EC-17	12 mfd. Electrolytic Condenser	.90 "
EC-25	Dual Electrolytic Condenser	1.25 "
EC-18	1 mfd. & 1 mfd. Condensers in can.	.70 "
	Any size Tubular Condenser or Mica Condenser (See diagram for Part No.)	.15 "
	Any Socket (specify tube number)	.10 "
ES-15	Dual Speakers	10.80 pair
ED-4	Shadowgraph	1.65 each
ES-16	On-Off Switch	.40 "
ED-3	Frequency Calibrated Tuning Dial	1.05 "



### Minor Reasons For Failure Of Receiver To Function


1. Defective Tubes
2. Screen Grid Caps Off Tubes
3. Volume Control not fully on
4. Speaker Plug not in socket
5. Aerial disconnected
6. Poor Aerial
7. Fuse burnt out
8. Noise Control set too far counter-clockwise.

### Voltage Readings

	Plate	Cathode
58—R. F.	230-250	3-5
58—Det.	230-250	5-7
56—Osc.	95-115	5-7
58—I. F.	230-250	3-5
55—Duo-diode triode	75-90	40-50
46—Driver	230-250	30-35
46 } Amplifiers	310-330	
46 }		

Line Voltage—117

# EMERSON RADIO & PHONOGRAPH CORP.



**KEY TO SYMBOLS**

T-1 Ant. Coil	R-3 25M. Ohm 1/2 W	R-8 10M. Ohm 1 W	C-3 0.006 M.F.
T-2 R. F. Coil	R-4 250M. Ohm 1/2 W	R-9 500M. Ohm 1/2W	C-4 0.01 M. F.
T-3 Choke - 20 Hen.	R-5 50M. Ohm 1/2 W	R-10 750M. Ohm 1/2W	C-5 0.05 M. F.
R-1 Volume Control	R-6 50 Ohm 1 W	C-1 5-Gang Cond.	C-6 0.1 M. F.
R-2 330 Ohm. - 30 W.	R-7 30M. Ohm 1 W	C-2 Dual 1 M.F.	C-7 0.00025 M.F.
S-4 Speaker			

## Model D. C.-4

### SERVICE PRICE LIST

Part No.	Description	List Price
T-1	Antenna Coil	\$ .55
T-2	R. F. Coil	1.05
T-3	Choke-20 Hen.	1.00
R-1	Volume Control	.90
R-2	330 Ohm-30 Watt Resistor	.60
	1/2 Watt and 1 Watt Resistors	.15
C-1	Three-Gang Condenser	2.55
C-2	Dual 1 Mfd. Condenser	1.05
C-7	.00025 Mfd. Molded Mica Cond	.15
	Any Size Tubular Condenser -	.15
S-1	No. 339 Socket	.10
S-2	No. 336 Socket	.10
S-3	No. 333 Socket	.10
S-4	Dynamic Speaker	4.50
D-1	Disc Dial with Set Screws	.25

W-1	D. C. Cord Assembly 6 1/2 ft. long	.20
L-2	Pilot Light Globe .5 Amp. - 3.2 Volt	.15
K-1	Control Knob	.15
	Cabinet (Specify Serial No. of Set)	2.50
	Shipping Carton - Complete	.25

### **Voltage Readings:**

Voltages should be measured with the volume control all the way on, using a 250-volt D. C. voltmeter, with the resistance of 1,000 ohms per volt.

Approximate Voltages


	Plate	Screen	Cathode
333 Pentode Tube to Chassis	105	110	none
339 R. F. Tubes to Chassis	110	80	3
336 Detector Tube	50	20	5

The bias on the pentode is obtained by reading from pentode filament to Chassis and should be about 9 volts.




# EMERSON RADIO & PHONOGRAPH CORP.

CHASSIS NO. H-5  
 USED IN MODEL 30 SET  
 " " 250 " "  
 " " 300 " "



# EMERSON RADIO & PHONOGRAPH CORP.



KEY TO SYMBOLS			
T-7	ANTENNA COIL	R-7	30M OHM 1W
T-8	R. F. COIL	R-10	750M OHM 1/2W
T-9	POWER TRANS	R-12	25M OHM 1W
R-4	250M OHM 1/2W	R-14	1.5MEG OHM 1/2W
R-5	50M OHM 1/2W	R-15	VOL CONTROL
C-4	0.01 MFD.	C-6	0.1 MFD.
C-7	0.00025 MFD	C-10	4 MFD.
C-12	0.05 MFD	C-11	0.005 MFD.
C-14	2 GANG VAR.	S-9	SPEAKER
L-2	PILOT LAMP		

## L-AC-4

### SERVICE PRICE LIST

Part No.	Description	List Price
T-7	Antenna Coil	.36
T-8	R. F. Coil	.54
T-9	Power Transformer	2.00
R-15	Volume Control	.75
	Any 1/2 or 1 Watt Resistor (Refer to Diagram)	.15
C-14	Two-Gang Condenser	1.50
C-10	4 mfd. Dry Electrolytic Cond	.50
	Any Size Tubular Condenser No. (Refer to Diagram)	.10
C-7	.00025 Molded Mica Condenser	.10
S-9	Dynamic Speaker	4.50
	Any Socket - Specify Tube Nu on Socket and Set Serial Nu	.10
D-2	Disc Dial with Set Screws	.20
K-1	Control Knob	.10

B-2	Pilot Light Assembly	.10
L-2	Pilot Light	.15


### Voltage Readings:

Readings should be taken with volume control all the way on and tuning control set for high wave length stations. Use a 250 volt D. C. meter having a resistance of 1,000 ohms per volt.

	Plate	Screen	Cathode
347 Tube—ground to	.215	237	none
58 Tube—ground to	.237	92	2
57 Tube—ground to	.115	92	4.5
Line Voltage	.119		

The bias on the pentode cannot be read on the volt meter. These readings are approximate and will vary slightly with sets, tubes, etc.

# EMERSON RADIO & PHONOGRAPH CORP.



KEY TO SYMBOLS					
T-7	ANTENNA COIL	R-7	30M OHM 1W	C-4	0.01 MFD.
T-8	RF COIL	R-10	750M OHM 1/2W	C-6	0.1 MFD.
T-9	POWER TRANS	R-12	25M OHM 1W	C-7	0.00025 MFD
R-4	250M OHM 1/2W	R-14	1.5MEG OHM 1/2W	C-10	4 MFD.
R-5	50M OHM 1/2W	R-15	VOL CONTROL	C-11	0.005 MFD.
C-12	0.05 MFD				
C-14	2 GANG VAR.				
S-9	SPEAKER				
L-2	PILOT LAMP				

## L-AC-5

### SERVICE PRICE LIST

Part No.	Description	List Price
T-4	Antenna Coil	.50
T-5	R. F. Coils	.50
T-6	Power Transformer	2.00
R-11	Volume Control	.75
	Any Carbon Resistor Refer to Diagram)	.15
C-8	3 Gang Variable Condenser	2.25
C-9	8 mfd. Dry Electrolytic Cond	.75
C-10	4 mfd. Dry Electrolytic Cond	.50
	Any size Tubular Condenser No. Refer to Diagram)	.10
C-7	.00025 Molded Mica Condenser	.10
	Any Socket (Specify Tube Number on Socket)	.10
S-9	Dynamic Speaker	5.50
D-2	Disc Dial with Set Screws	.20
W-8	Flexible Shielding for Grid Lead	.05
B-2	Pilot Light Assembly	.10
L-2	Pilot Lamp	.15
K-1	Control Knob	.10

### Voltage Readings:

Readings should be taken with volume control all the way on and tuning control set for high wave length stations. Use a 250 volt D.C. meter having a resistance of 1,000 ohms per volt.


	Plate	Screen	Cathode
347 Pentode Tube ground to	220	240	none
58 First R. F. Tube ground to	240	90	4.5
58 Second R. F. Tube ground to	240	90	4.5
57 Detector Tube ground to	114	90	4.5

Line Voltage .....119

The bias on the 347 cannot be read with the volt meter.

These readings are approximate and will vary slightly with tubes, set, etc.

# EMERSON RADIO & PHONOGRAPH CORP.



NOMENCLATURE		
GT-20 - SHIELDED ANT. COIL	GR-31 - 20,000-ohm 1 WATT	EC-23 - .03 MFD. 300V.
GT-21 - SHIELDED R.F. INTERSTAGE COIL	GR-32 - 2,000-ohm 1/2 W.	AC-6 - .1 MFD. 200V.
GT-22 - SHIELDED R.F. OSCILLATOR COIL	GR-33 - 35,000-ohm 1/2 W.	$\Omega$ = OHMS
ET-17 - 175 KC. SHIELDED I.F. TRANSF.	GR-34 - 100,000-ohm 1/2 W.	
GT-23 - POWER TRANSFORMER	AR-9 - 500,000-ohm 1/2 W.	
EC-16 - GANGED CONDENSER	GR-34 - 600,000-ohm 1/2 W.	
GR-28 - 5000-ohm VOLUME CONTROL	BC-9 - 8-8 MFD. 500V. PEAK	
GR-29 - 300,000-ohm TONE CONTROL	AC-7 - .00025 MFD. MICA	
GR-30 - 12,500-ohm 2 WATTS	FC-29 - .02 MFD. 200 V.	


## M-A-C-7

The receiver is accurately adjusted at the factory and no adjustment should be changed except by an experienced serviceman. The intermediate frequency is 175 K.C.

### REPLACEMENT PARTS PRICE LIST

Part No.	Description	List Price
GT-20	Antenna Coil	\$.65 each
GT-21	Interstage R.F. Coil	.65 "
GT-22	Oscillator Coil	.65 "
ET-17	I. F. Transformer	1.15 "
GT-23	Power Transformer	1.95 "
GR-28	Volume Control	.80 "
GR-29	Tone Control	.60 "
GR-30	12,500 ohm 2 wt. Resistor	.25 "
EC-16	3-Gang Variable Condenser	2.45 "
BC-9	8 & 8 mfd. Electrolytic Condenser	.65 "
GD-5	Dial Assembly	.90 "
AL-2	Pilot Light	.08 "
AK-1	Knobs	.10 "
GS-19	Dynamic Speaker	5.65 "


### TUBE DIAGRAM




### Minor reasons for failure of Set to function

1. Defective Tubes
2. Grid Clips off Tubes
3. Volume Control not fully on
4. Tubes not in sockets securely
5. Aerial disconnected or grounded
6. Defective A.C. plug or poor plug connection

# FADA RADIO & ELECTRIC CORP.




# FORDSON RADIO MFG. CORP.



C1 365 mmfd. MAX.  
 C2 180 mmfd. MAX.  
 PLATE CUT FOR 456 K.C.

FORDSON RADIO MFG. CORP.  
 11702 LIVERNOIS AVE., DETROIT, MICH.  
**GOLDENTONE** MARK  
 MODEL 6T  
 SUPERHETERODYNE  
 WITH AUTOMATIC VOLUME CONTROL.



# FORDSON RADIO MFG. CORP.

## PARTS PRICE LIST MODEL 6 T GOLDENTONE SUPERHETERODYNE


<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>LIST PRICE</u>
6T72	Volume control and switch -----	\$1.50
6T58	Variable Condenser -----	2.00
6T56	Power Transformer -----	2.00
6T52	Intermediate Frequency Transformer -----	1.50
6T48	Antenna Oscillator Dowel Coil -----	1.50
6T28	Dual 6 Mfd. Filter Condenser -----	1.60
6T50	Tone Control -----	1.00
6T60	Six-inch Dynamic Speaker -----	4.00
6T62	Midget Cabinet -----	3.00
6T01	Tube Shield -----	.15
6T44	Chassis Base -----	.75
6T46	Variable Condenser Cover -----	.50
6T42	.05 Mfd. Tubular Condenser -----	.15
6T40	.002 Mfd. Tubular Condenser -----	.15
6T30	500,000 ohm Resistor -----	.20
6T32	100,000 ohm Resistor -----	.20
6T34	2,500 ohm Resistor -----	.20
6T36	300 ohm Resistor -----	.20
6T38	500 ohm Resistor -----	.20
6T26	10 Mfd. - 500 V. Electrolytic Condenser -----	.60
6T18	Type 58 Socket -----	.10
6T20	Type 55 Socket -----	.10
6T22	Type 80 Socket -----	.10
6T24	Type 2A5 Socket -----	.15
6T10	Ant. Gnd. Binding Post -----	.15
6T12	Connecting Cord (6 ft.) -----	.40
6T08	Insulated Terminal Strip -----	.10
6T14	Traveling Light Dial -----	.50
6T16	Escutcheon Plate and Scale -----	.50
6T06	Large Knob -----	.15
6T04	Small Knob -----	.15

The plate voltage on the 55 tube is about 20 to 25 volts when measured with a high resistance voltmeter, as the voltage is reached by the 100,000 ohm plate resistor.


An easy check for the audio stage can be made by removing the clip off of the 55 tube and placing the finger on the cap of the tube. If a very loud hum is received (with the volume on full) the audio circuit is undoubtedly **satisfactory**.

A continuity test of the intermediate coils can be taken. The red and blue leads are the primary and should show a closed circuit. The green lead of the secondary goes to the screen clip of the 58 tube on the center coil, but comes out underneath and chassis on the coil next to the 55 tube and connects to the two diode terminals on the socket.


# FREED-EISEMANN RADIO CORP.



## FREED-EISEMANN FE-15



## FREED EISEMANN FE-18






# GENERAL ELECTRIC COMPANY

## Automobile Radio

### MODEL B-40



Schematic Diagram

## RADIOTRON SOCKET VOLTAGES

### 6.3 Volt Battery

Radiotron No.	Cathode to Ground	Cathode to Screen Grid Volts	Cathode to Plate Volts	Plate Current M. A.	Heater Volts
RCA-78 R. F.	3.7	92	253	7.0	6.06
RCA-6A7	First Detector	92	253	12.0	6.06
	Oscillator	0	253	Total	
RCA-6B7 Second Detector	3.2	92	236	6.0	6.06
RCA-89 Power	26.5	230	217	27.5	6.06

### Suppression of Ignition Interference

1. Disconnect all wires from the spark plugs. Fasten one spark plug suppressor to the top of each plug and re-attach the wires to the free ends of the suppressors. These suppressors may be mounted either in line with or at right angles to the plugs (as shown in Figure 1) in order to avoid interference with metallic parts grounded to the engine or frame.

2. If the distributor is of the plug-in type, disconnect the center wire from the head. Plug the distributor suppressor into the distributor head and insert the wire in the free end of the suppressor.

3. Clamp the generator by-pass capacitor against the generator frame. The screw holding the cut-out ordinarily may be utilized for securing this unit. Connect the capacitor lead to the terminal on the generator side of the cut-out switch. (In some cases, interference will be reduced by connecting the capacitor lead to the opposite side of the cut-out. The most suitable position for this lead must be determined by trial.)


4. The other by-pass capacitor must be connected between the battery terminal of the ammeter and any convenient screw on the instrument panel.

# GENERAL ELECTRIC COMPANY

## B-40

### SERVICE DATA FOR VIBRATOR UNIT

The vibrator unit used in this receiver is of excellent design and sturdy construction. It functions as a combined A. C. generator and mechanical rectifier. Referring to Figure C, it will be noted that the primary and secondary of the transformer are center tapped. By connecting the outside of each winding to the contacts of the vibrator and using the arms and center taps of the windings as sources of input and output voltage, a combined generating and rectifying action is obtained.



*Schematic of Vibrator Unit*

When the switch is turned "on" the vibrator makes and breaks contact at point "A." This constitutes the driving action of the unit, and is in no way connected with the other circuits. The primary vibrator functions to connect the input low voltage current first across one-half and then across the other half of the primary of the transformer. This results in a pulsating direct current applied to the primary in an alternating direction. The result is an A. C. voltage emanating from the secondary of the transformer; as the transformer has a step-up ratio the A. C. secondary voltage is considerably greater than the primary. The secondary vibrator functions in a similar manner as that on the primary side, so that by reversing the alternations applied to the load, a pulsating D. C. is obtained. After filtering, this is used as plate and grid supply to all Radiotrons.

#### (1) Spring and Contact Adjustment Limits.

Proper adjustments of the various contacts are made in the following order and manner:

1. With 8 and 10, Figure D, firmly held against their respective stops and with 3 and 5 in contact with 8 and 10 respectively, the air gap between 1, 6 and 2, 7 shall be 0.015" plus or minus 0.005". On no particular unit however, shall the differences between the two air gaps exceed 0.005".

2. Adjust the buzzer screw, 11, Figure D, so that when the position of the armature is such that 1 and 2 are just making contact with 6 and 7 respectively, the contact between 4 and 9 shall just be breaking.

#### (2) Adjustment for the Reduction of Sparking.



If any pair of contacts show excessive sparking, the following procedure will in general reduce the sparking to a minimum.

For example, consider the case where excessive sparking is occurring between 6 and 1. Sparking will be reduced to a minimum by bending the armature spring on that side (secondary side) away from 6 and toward 8. (See Figure D.) If the bend is too small, only a small change will be noted. However, if an excessive bend is made, the sparking will be transferred from 6, 1 to 8, 3.

The same method may be applied to any pair of contacts. Usually only a slight bend will be necessary. Although after bending, no change in the position of the armature contacts may be noted, a sufficient change in the initial force requirements will have been made to reduce sparking.

#### (3) Output Voltage.

When connected to a 6 volt primary source, the output voltage across a 5,000 ohm resistor (connected in place of the receiver load at the output of the filter), must be 240 volts or greater.



*Vibrator Contacts*

# GENERAL ELECTRIC COMPANY

## MODEL-BX

### Electrical Specifications

Voltage Rating . . . 105-120 Volts, 25-133 Cycles A. C. or D. C.  
 Power Consumption . . . . . 40 Watts  
 Frequency Range . . . . . 540 K. C.-1700 K. C.  
 Type and Number of Radiotrons—  
 1 RCA-36, 1 RCA-37, 1 RCA-38, 1 RCA-39—Total 4


This receiver is an A. C.-D. C. table model tuned R. F. broadcast receiver. Features such as universal operation on both A. C. and D. C., wide tuning range, excellent performance and compact construction characterize this instrument. Figures A and B show the schematic and wiring diagrams respectively. The voltage readings and replacement parts are given below.

### RADIOTRON SOCKET VOLTAGES


Measured at Maximum Volume—115 Volt A. C. Line  
 All Voltages on D. C. will be slightly lower

Radiotron No.	Cathode or Filament to Control Grid, Volts	Cathode or Filament to Screen Grid, Volts	Cathode or Filament to Plate, Volts	Plate Current M. A.	Filament or Heater, Volts
1. RCA-39 R. F.	3.0	105.0	105	7.0	6.0
2. RCA-36 Detector	*0.75	11.0	*60	0.025	6.0
3. RCA-38 Output	11.0	100.0	95	5.0	6.0
4. RCA-37 Rectifier	—	—	115	15.0	6.0

\*Impossible to measure on ordinary voltmeter.



Schematic Circuit




Wiring Diagram

## REPLACEMENT PARTS

(Replacement parts may be purchased from authorized Distributors or Dealers only)

Stock No.	DESCRIPTION	List Price	Stock No.	DESCRIPTION	List Price
<b>RECEIVER ASSEMBLIES</b>					
2747	Cap—Contact cap—Package of 5 . . . . .	\$0.50	3709	Knob—Station selector or volume control knob—Package of 5 . . . . .	\$0.65
3076	Resistor—1 megohm—Carbon type—1/4 watt—Package of 5 . . . . .	1.00	6188	Resistor—2 megohm—Carbon type—1/4 watt—Package of 5 . . . . .	1.00
3436	Capacitor—0.05 mfd. . . . .	.44	6451	Condenser—Two gang variable tuning condenser . . . . .	2.04
3536	Capacitor—Filter capacitor—Two 5.0 mfd. capacitors . . . . .	1.10	7484	Socket—Radiotron socket—5 contact . . . . .	.35
3537	Reactor—Filter reactor . . . . .	1.10	10405	Capacitor—Antenna series capacitor—.002 mfd. . . . .	.40
3538	Capacitor—Filter capacitor—Two 4.0 mfd. . . . .	1.18	10820	Capacitor—100 mmfd. . . . .	.40
3532	Volume control—Complete with mounting nut . . . . .	1.18	G5031	Escutcheon—Station selector escutcheon—Package of 2—Brown Cabinet . . . . .	.25
3557	Capacitor—0.002 mfd. . . . .	.30	G5032	Escutcheon—Volume control escutcheon—Package of 2—Silver cabinet . . . . .	.25
3559	Resistor—31,000 ohms—Carbon type—1/4 watt—Package of 5 . . . . .	1.00	G5033	Escutcheon—Station selector escutcheon—Package of 2—Silver cabinet . . . . .	.25
3560	Resistor—1,600 ohms—Carbon type—1/4 watt—Package of 5 . . . . .	1.00	<b>LOUDSPEAKER ASSEMBLIES—MAGNETIC TYPE</b>		
3561	Capacitor—0.004 mfd. . . . .	.42	7594	Cone—Speaker cone—Package of 5 . . . . .	5.00
3562	Capacitor—0.006 mfd. . . . .	.42	7595	Support—Cone support . . . . .	.60
3635	Resistor—Filament resistor—315 ohms . . . . .	1.00	7596	Mechanism—Speaker mechanism complete with magnet . . . . .	3.00
3686	Escutcheon—Volume control escutcheon—Package of 2—Brown Cabinet . . . . .	.25	9426	Loudspeaker complete . . . . .	4.38
3714	Coil—Detector coil . . . . .	.98			
3715	Coil—R. F. coil complete . . . . .	1.08			


# GENERAL ELECTRIC COMPANY MODEL - J109









Schematic Circuit Diagram

# GENERAL ELECTRIC COMPANY


## MODEL J 109



Wiring Diagram



# GENERAL ELECTRIC COMPANY MODEL - J 109





Assembly Wiring Diagram



# GENERAL ELECTRIC COMPANY

## MODELS - K-50-P, K-51-P



### RADIOTRON SOCKET VOLTAGES



115 Volt A. C. Line

### MAXIMUM VOLUME CONTROL SETTING—NO SIGNAL

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current, M. A.	Heater Volts
1. RCA-58 R. F. Amplifier	3.0	95	250	5.0	2.33
2. RCA-2A7 First Detector Oscillator	3.0	95	250	3.0	2.33
3. RCA-57 Second Detector	6.0	89	170	0.3	2.33
4. RCA-2A5 Power Amplifier	18.0	235	220	32.0	2.33
5. RCA-80 Rectifier	275 Volts PLATE TO PLATE—60 M. A. TOTAL				4.82
TOTAL CATHODE CURRENT—11 M. A.					





# GENERAL ELECTRIC COMPANY



**RADIOTRON SOCKET VOLTAGES**  
 115 Volt A. C. Line  
 MAXIMUM VOLUME CONTROL SETTING—NO SIGNAL

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current, M. A.	Heater Volts
1. RCA-58 R. F. Amplifier	3.0	95	250	5.0	2.33
2. RCA-2A7 First Detector Oscillator	3.0	95	250	3.0	2.33
3. RCA-57 Second Detector	6.0	89	170	0.3	2.33
4. RCA-2A5 Power Amplifier	18.0	235	220	32.0	2.33
5. RCA-80 Rectifier					
275 Volts PLATE TO PLATE—60 M. A. TOTAL					4.82
TOTAL CATHODE CURRENT—11 M. A.					

# GENERAL ELECTRIC COMPANY



## RADIOTRON SOCKET VOLTAGES

115 Volts, A. C. Line—No Signal

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current, M. A.	Heater Volts
1. RCA-58 R. F.	3.0	95	255	5.0	2.31
2. RCA-2A7 1st Det. Osc.	3.0*	95*	255*	3.0*	2.31
3. RCA-58 I. F.	3.0	95	255	5.0	2.31
4. RCA-2B7 2nd Det. A. V. C.	7.5	92	60	2.0	2.31
5. RCA-2A5 Power	20.0	250	235	33.0	2.31
6. RCA-80 Rectifier	700/350 Volts—75 M. A. Total Current				4.82

\*The Voltages and current refer to the detector part of the tube. The total cathode current is 10 M. A.

# GENERAL ELECTRIC COMPANY






Figure A—Schematic Circuit

## L-50 and L-51



# GRAYBAR ELECTRIC CO.




Schematic Circuit Diagram

## SOCKET VOLTAGE READINGS GRAYBARETTE 4

These readings are obtained with the usual Set Analyzers and are not true readings of the voltages at which the Radiotrons operate.


Radiotron No.	Heater to Cathode Volts	Cathode or Filament to Control Grid Volts	Cathode or Filament to Screen Grid Volts	Cathode or Filament to Plate Volts	Plate Current M. A.	Heater Volts
1	3.0	3.0	85	225	4.0	2.2
2	7.0	7.0	65	100	0.25	2.2
3	—	2.0	225	215	30.0	2.2



Wiring Diagram

# GRIGSBY-GRUNOW CO.

## SCHEMATIC DIAGRAM MAJESTIC-MODEL 116-AUTOMOBILE RECEIVER




CONDENSER VALUES	
No. MFD.	No. MFD.
C1	.1
C2	.03
C3	.005
C4	.01
C5	.25
C6	.5
C7	.1
C8	.1
C9	.1
C10	.03
C11	.01
C12	.0005
C13	.005
C14	.01
C15	.005
C16	.5
C17	.1
C18	.1
C19	.1
C20	.5
C21	.1
C22	.01

RESISTOR VALUES	
No. Ohms	No. Ohms
R1	300
R2	3000
R3	200
R4	200
R5	150
R6	99000
R7	500,000
R8	99,000
R9	30,000
R10	15,000
R11	99,000
R12	250,000
R13	250,000
R14	4,000
R15	250,000
R16	1.5 Ohms

GRIGSBY-GRUNOW Co.  
CHICAGO, U.S.A.

## GRIGSBY-GRUNOW CO.

DURO-MUTE POWER UNIT

The Duro-Mute Power Unit of the MAJESTIC Model 116 Auto Receiver is completely housed in the large metal container located at the extreme right of the receiver (see Figure 12).

Do not tamper with this unit unless it has proven defective by causing a gradual decrease in plate voltages and power output.

Should it, at any time, become necessary to inspect or replace the vibrator armature assembly of this unit, the procedure outlined below should be followed:

If the receiver is installed in the automobile, remove it from the firewall by loosening the clamping screws and sliding it off the supporting brackets.

Take off the top and bottom covers of the chassis container.

Unsolder the red, yellow, blue and black leads from the speaker output transformer (see Figure 12).

Remove the flexible drive cable from the gang condenser drive pulley, being careful not to cause any sharp bends or kinks in the cable.

After removing the five screws from the ends of the receiver, lift the container and speaker from the chassis, being careful not to place undue strain on the antenna lead wire.

Unscrew the four screws which hold the cover of the Duro-Mute Power Unit in place. The cover is easily removed by rocking slightly and lifting upward.

The entire vibrator armature assembly is now accessible for inspection or replacement.

**WARNING!**

Do not file the contacts or tamper with any of the adjustments on the vibrator armature

## GRIGSBY-GRUNOW CO.

assembly. This unit has been carefully adjusted at the factory for utmost efficiency and any changes will seriously affect its operation.

The guarantee on the receiver will become void if the above warning is not followed.

If the vibrator armature assembly is known to be defective, remove it by disconnecting the necessary wires and unscrewing the four large screws marked "A" in Figure 11.

Replace with a new part #9367 vibrator armature assembly.

If there was a spacing washer under each of the screws at "A", they should not be used when the vibrator armature assembly is replaced with a new one.

Replace the Duro-Mute Power Unit cover, being certain that it fits snugly and properly supports the filter choke clamp.

Reassemble the outer container and speaker to the chassis and replace the bottom cover. Solder the speaker leads as indicated in Figure 12.

Assemble the flexible drive cables to the drive pulley so that with the tuning dial rotated to zero, the condenser gang will be completely unmeshed.

Turn on the receiver and test for proper operation over the entire tuning range, also noting that the drive cable operates smoothly and correctly.

Replace cover and assemble receiver to firewall.

**CAUTION!** Be sure to tighten all nuts and screws securely.

VOLTAGE CHART FOR MODEL 116 AUTO RECEIVER

TUBE	PURPOSE IN CIRCUIT	PLATE VOLTAGE	SCREEN VOLTAGE	CATHODE VOLTAGE	SUPPRESSOR VOLTAGE	GRID VOLTS
G57A-S	1st Detector Oscillator	110	110	15	0	1.4
G58A-S	1st I.F. Amplifier	180	90	3.5	3.5	...
G58A-S	2nd I.F. Amplifier	180	90	3.5	3.5	...
G75	2nd Detector and 1st Audio Amplifier	135	...	2.25	...	...
G89	Power Amplifier	170	180	0	0	...
G6-25	Rectifier	...	...	180	...	...

NOTE: All measurements made from designated points to ground with a 1000 ohm per volt, 300 volt range, D.C. voltmeter, the receiver connected storage battery delivering 6.0 volts at the battery terminals under load, the condenser gang fully meshed, and no signal supplied to the input of the receiver.

The tubes should be previously tested to assure that they are in good condition.

# GRIGSBY-GRUNOW CO.

## SCHMATIC DIAGRAM MAJESTIC-MODEL 116-A AUTOMOBILE RECEIVER




FIG. 175

REVISIONS	ISSUE	MEMO
1-25-33	1	7649
2-10-33	2	7736
4-13-33	3	7842
4-17-33	4	7851
5-4-33	5	7877

**CONDENSER VALUES**

No.	MFD.	No.	MFD.
C1	-.1	C12	-.01
C2	-.03	C13	-.005
C3	-.03	C14	-.01
C4	-.1	C15	-.01
C5	-.25	C16	8.0
C6	-.25	C17	8.0
C7	-.1	C18	-.1
C8	-.1	C19	-.1
C9	-.03	C20	.5
C10	.01	C21	.5
C11	.0005	C22	.1
C23	.005	C24	.005
C25	-.1		

**RESISTOR VALUES**

No.	OHMS	No.	OHMS
R1	500	R9	30000
R2	15000	R10	15000
R3	900	R11	50000
R4	250	R12	250000
R5	470	R13	250000
R6	99000	R14	GLOBAR
R7	500000	R15	250,000
R8	250,000	R16	10,000
R16	10,000	R17	1,000
R18	530		

GRIGSBY-GRUNOW Co.  
CHICAGO, U.S.A.

**TABLE OF VOLTAGES**

Purpose	Tube	Type	Plate Voltage	Screen Voltage	Cathode Voltage	Suppressor Voltage	Grid Volts
1st Det. Oscillator	G-57A-S		110	110	15	0	1.4
1st I. F. Amplifier	G-58A-S		180	90	3.5	3.5	..
2nd I. F. Amplifier	G-58A-S		180	90	3.5	3.5	..
2nd Det. and 1st Audio Amplifier	G-75		135	..	2.25	..	..
Power Amplifier	G-89		170	180	0	0	..
Rectifier	G-6-Z5		..	..	180	..	..

NOTE: All measurements made from designated points to ground with a 1000 ohm per volt, 300 volt range, D.C. voltmeter, the receiver connected with storage battery delivering 6.0 volts at the battery terminals under load, the condenser gang fully meshed, and no signal supplied to the input of the receiver.

The tubes should be previously tested to assure that they are in good condition.

**NOISE SUPPRESSION**

Detailed instructions for installation of sparkplug and distributor suppressors and condensers for generator are contained in Service Manual. For checking purposes keep the following points in mind.

1. Go over each spark plug suppressor.
2. Check distributor suppressor. In cars having two coils, a suppressor in each coil or high tension lead is necessary. Always install the suppressor as close to the distributor as possible.
3. Make sure that the two condensers are properly connected to the generator and ammeter respectively.
4. If noise interference still prevails, determine whether picked up by antenna or radio. Ground antenna as it leaves the radio. If interference stops, it is certain that antenna picks it up. Check all ground connections of chassis.
5. To guard against ground interference, make sure that no choke wires, speedometer cables, copper tubes, battery cables, or the like rub on the radio container.

**ALIGNMENT**

If, for any reason it becomes necessary to align the Model No. 116 Auto Radio, the following procedure should be carefully followed.

It will be necessary to remove the chassis container and cover to align the receiver.

1. Set the volume control at maximum, insert all tubes in their proper sockets and connect the battery cable to a six (6) volt storage battery.
2. Supply a 456 Kilocycle signal to the grid of the first detector tube and align for maximum output the three (3) I.F. aligning condensers that are located on the bottom right hand side of the chassis and the one (1) I.F. aligning condenser located on the upper part of the chassis behind the speaker.


The shielding is to be connected to the grounded side of the battery and the two wires emerging from the shielding are both connected to the hot side. The polarity of the battery need not be considered when making these connections. When making the ground connections, scrape away any corrosion, paint or rust so as to make a good electrical contact. TO OBTAIN BEST RESULTS FROM THIS RECEIVER, ADVANCE THE CAR GENERATOR TO KEEP THE STORAGE BATTERY FULLY CHARGED.

The cable must be securely clamped and must not come in contact with the battery in order to avoid the possibility of corrosion and shorting the battery.



# GRIGSBY-GRUNOW CO.

## SCHEMATIC DIAGRAM of MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE MODEL 300 TWIN SPEAKER



### RESISTANCE AND CONDENSER VALUES

- R1 = 230
  - R2 = 4900
  - R3 = 72
  - R4 = 20,000
  - R5 = 210
  - R6 = 110
  - R7 = 500,000
  - R8 = 50,000
  - R9 = 300,000
  - R10 = 100,000
  - R11 = 300,000
  - R12 = 100,000
  - R13 = 300,000
  - R14 = 300,000
  - R15 = 300,000
  - R16 = 30,000
  - R17 = 2,000
  - R18 = 300,000
  - R19 = 300,000
  - R20 = 100,000
  - R21 = 20 HUM CONT.
  - R22 = 20,000 SUPPRESSOR
  - R23 = 200,000 VOL. CONT.
  - R24 = 250,000 TONE CONT.
  - R25 = 500,000
  - R26 = 100,000
- C1 = 16. DRY  
 C2 = 16. DRY  
 C3 = 10. ELECTROLYTIC  
 C4 = 7  
 C5 = 20.  
 C6 = .25  
 C7 = .25  
 C8 = .10 CAN "A"  
 C9 = .10  
 C10 = .10  
 C11 = .10  
 C12 = .10  
 C13 = .02  
 C14 = .01 CAN "B"  
 C15 = .01  
 C16 = .01  
 C17 = .10-CAN "C"  
 C18 = .05-CAN "B"  
 C19 = .01  
 C20 = .01  
 C21 = .01  
 C22 = 20,000 SUPPRESSOR  
 C23 = 200,000 VOL. CONT.  
 C24 = .25 CAN "C"  
 C25 = 500,000  
 C26 = 100,000

GRIGSBY-GRUNOW CO.  
CHICAGO, U.S.A.

## GRIGSBY-GRUNOW CO.

### TECHNICAL DATA PERTAINING TO MODEL 300 CHASSIS

#### THE CIRCUIT

Model 300 Chassis is employed in the 303, 304, and 307 Receivers. Fundamentally the Model 300 circuit is similar to the 200 circuit, except that it employs synchro-silent tuning and incorporates the new MAJESTIC Reactance Resonance Indicator. Another outstanding feature is the use of true resistance coupled push-pull amplification through a novel phase rotation circuit.

#### METHOD OF BIASING

Initial bias on the R.F. and I.F. tubes is obtained from Resistor R-6. The initial bias on the First Detector tube comes from Resistor R-5. Automatic volume control bias is applied to these three tubes from Resistor R-9. The oscillator tube obtains its bias from Resistor R-17.

The fixed bias on the screen grid A.F. tube is obtained from Resistor R-3, while the bias necessary for Synchro-Silent Tuning is obtained from R-8.

Bias for the phase rotating tube is obtained from R-16.

Bias for the output tubes comes from R-1.

#### AUTOMATIC VOLUME CONTROL SYSTEM

This is the now proved MAJESTIC Duodiode circuit, which was so successfully used in the 200 and 210 chassis. The manual level control is a simple audio frequency potentiometer, R-23, in the grid circuit of the screen grid audio stage. Automatic Volume Control effect is exerted on the R.F., First Detector, and I. F. tubes, due to the voltage drop across R-9.

#### INSTRUCTIONS FOR ADJUSTING AUTOMATIC SYNCHRO-SILENT TUNER

1. Complete installation in the same manner as an ordinary broadcast receiver so far as antenna, ground, tubes, etc., are concerned.
2. Set Synchro-Silent Tuning Knob to position of no silencing. (All the way clockwise).
3. Tune receiver to a position off of the broadcasting station, preferably near the low frequency end of the dial.
4. Turn volume control full on. In this position a great deal of noise will be heard, depending upon the location.
5. Adjust Synchro-Silent Tuning Control by rotating counter-clockwise slowly until

the noise just stops. It will be found that the noise drops out quite suddenly, and it is desirable that the control be set only to the position required to take out the noise and no further counter-clockwise than necessary.

6. The set is now ready for operation, and it will be found that stations come in with just as much volume as they would if the Synchro-Silent Tuning were not used, but when tuning between stations, the set is absolutely quiet. It may be found that in some particular locations the noise is greater at one end of the dial than at the other, so that if the Synchro-Silent Tuning Control is adjusted to take out noise at the low frequency end of the dial, some noise may come in at the high frequency end. In this case, it is perfectly permissible and advisable to readjust the Synchro-Silent Tuning Control at the high frequency end of the dial.
7. If at any time it is desired to get maximum distance without regard to noise between stations, simply turn the Automatic Synchro-Silent Tuning Control knob as far clock-wise as possible.

#### MAJESTIC PUSH-PULL RESISTANCE COUPLING CIRCUIT

This is a feature which has never before appeared in a broadcast receiver. The advantages of resistance coupling are so well known that it is unnecessary to point out how good tone quality and well designed resistance coupling are synonymous. The advantages of push-pull are also well known, the chief among these being that it is possible to get greater power output with less distortion. Now, as mentioned above, for the first time we have both of these features in one chassis.

In push-pull amplification, it is necessary that the grids of the push-pull tubes be fed with voltages that are equal in magnitude, but exactly opposite in phase or polarity. When a transformer is used, this is accomplished simply by using the two extremes of the secondary winding to feed the push-pull grids, and if a center tap is provided, these voltages are bound to be equal, and opposite in polarity.

In the new MAJESTIC circuit, phase rotation is accomplished by making use of the fact that a signal in passing through a vacuum tube is rotated in phase exactly 180° (complete reversal). Following the audio channel from the duodiode, we find that the audio voltage built up across Resistor R-9 is fed to the G-57-S audio tube through potentiometer R-23. The output of this audio amplifier follows two

# GRIGSBY-GRUNOW CO.

## TECHNICAL DATA PERTAINING TO MODEL 300 CHASSIS (Cont'd)

channels; the direct and conventional channel is through condensers C-18 and C-12 to the lower of the two G-47 push-pull output pentodes and the remaining channel is through condenser C-18, and the G-58-S phase rotating tube. The signal coming out of this tube built up across R-13 is reversed in polarity over that originally built up across R-11. This reversed signal is fed to the upper of the two G-47 output pentodes. By suitable design, the G-58-S phase rotating tube and associated circuit is arranged so that no change in the magnitude of the signal takes place, the only change being a reversal of polarity or phase.

In this way, we have two voltages fed to the two G-47 output tubes which are equal in magnitude, but exactly opposite in polarity and true push-pull resistance coupled operation results.

### REACTANCE RESONANCE INDICATOR

This is an entirely new feature in radio. By referring to the wiring diagram, it will be seen that the reactor used consists of three windings on three legs respectively, of the iron core. The windings on the two end legs are connected in series with the pilot light, while the winding on the center leg is connected in series with the plates of the R.F., First Detector, and I.F. tubes. An electrolytic condenser, C-5, is connected so as to shunt the center winding. Its purpose will be explained later.

The operation of the reactor is as follows:

When the set is turned on and the tubes are warmed up, but no station is tuned in, a relatively large plate current will flow through the center winding. This saturates the iron core so that the reactance of the two outer windings is quite low, and considerable current therefore flows through the pilot light. When a station is tuned in, it operates the G-4-S Automatic Volume Control tube so that an automatic bias voltage is built up across Resistor R-9. This bias voltage is, in turn, impressed upon the control grids of the R.F., First Detector and I.F. tubes. When this bias is impressed on these amplifier tubes, the normal A.V.C. action takes place; namely, their amplification is decreased. It also happens, however, that their plate current is decreased, due to the higher negative bias on their grids. This reduced plate current flowing through the center winding of the reactor relieves the saturation in the iron core so that reactance of the out windings increases and the current flowing through

the pilot light is therefore reduced, causing the pilot light to dim when a station is tuned in.

It is, therefore, a simple and fascinating matter to adjust the dial until the pilot light is dimmest, with the perfect assurance that exact resonance will be located.

The two outer windings are connected so that they buck each other so far as the center leg of the core is concerned. Hence, there will be induced no A.C. in the center winding, which is in the plate circuit of the amplifier tubes. Because of small unbalances which may occur, it has been found necessary that we place the electrolytic condenser, C-5, across the center winding so that there is no possible chance of any A.C. getting into the plate circuit of the amplifier tubes.

### G-14-F, G-19-B AND G-19-C SPEAKERS

#### EMPLOYED IN MAJESTIC MODELS

For single speaker operation the large G-14-F speaker is used in connection with the 300 chassis. It has a field resistance of 1040 ohms and a voice coil resistance of 1.7 ohms. For dual speaker operation the G-19-B and G-19-C speakers are used simultaneously. Both of these speakers are of generous design, and handle great amounts of power. Each has a field resistance of 520 ohms and a voice coil resistance of 1.7 ohms. The frequency response represents the very latest in dynamic speaker development.

#### NOTICE

In the first run of Model 300 chassis, condenser C-13 in the #7285 "Can B" condenser assembly had a capacity of .02 mfd. while in the later run it had a capacity of .015 mfd. In cases where there is a .02 mfd. condenser a 5,000 resistor was used in series with the tone control. When replacing the #7285 condenser assembly, this resistor should be entirely removed from the circuit.

#### POWER TRANSFORMER CODE


Rectifier Filament	Terminals #1 and 3.	Black
Heater Center Tap.	Terminal #2.	Green
Tuning Light	Terminals #4 and 6.	Black
47 Filament.	Terminals #5 and 8.	Yellow
Start of Anode	Terminal #10.	Red
Center Tap of Anode	Terminal #11.	Black
Finish of Anode.	Terminal #12.	Red
Primary.	Terminal #13.	Yellow
Dummy Lug.	Terminal #14.	
Primary.	Terminal #15.	Yellow

# GRIGSBY-GRUNOW CO.

## DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE


### MODEL 310-A SINGLE SPEAKER

FOR SERIAL NUMBER 12,869 AND OVER, ON 115V-50-60 CYCLE.  
 FOR SERIAL NUMBER 10,516 AND OVER, ON UNIVERSAL MODELS.



#### RESISTANCE AND CONDENSER VALUES.


- |                              |                              |                         |                     |                |
|------------------------------|------------------------------|-------------------------|---------------------|----------------|
| $R_1 = 140$                  | } MULTIPLE WIRE WOUND        | $C_1 = 16$              | } DUAL ELECTROLYTIC |                |
| $R_2 = 2000$                 |                              | $C_2 = 8$               |                     | } ELECTROLYTIC |
| $R_3 = 500$                  |                              | $C_3 = 20$              |                     |                |
| $R_4 = 99,000$               | $C_4 = .03$                  | } BLOCK                 |                     |                |
| $R_5 = 10,000$               | $C_5 = .006$                 |                         |                     |                |
| $R_6 = 30,000$               | $C_6 = .03$                  |                         |                     |                |
| $R_7 = 200,000$ VOLUME CONT. | $C_7 = .25$                  |                         |                     |                |
| $R_8 = 50,000$ TONE CONTROL  | $C_8 = .1$                   |                         |                     |                |
| $R_9 = 20$ HUM BALANCER      | $C_9 = .1$                   | $C_{10} = .25$          | } MICA              |                |
| $R_{10} = 400$               | $C_{11} = .0005$             |                         |                     |                |
| $R_{11} = 10,000$            | $C_{12} = .004$ TUBULAR.     |                         |                     |                |
| $R_{12} = 25,000$            | $C_{13} = .5$ IN BLOCK       |                         |                     |                |
| $R_{14} = 40,000$            | $C_{14} = .01$ IN SMALL CAN. |                         |                     |                |
| $R_{15} = 99,000$            | $C_{15} = .01$ IN SMALL CAN. | $C_{16} = .11$ TUBULAR. |                     |                |



## DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE


### MODEL 310-B TWIN SPEAKER.

FOR SERIAL NUMBER 12,304 AND UNDER.




#### RESISTANCE AND CONDENSER VALUES

- |                              |                              |                         |                     |                |
|------------------------------|------------------------------|-------------------------|---------------------|----------------|
| $R_1 = 140$                  | } MULTIPLE WIRE WOUND        | $C_1 = 16$              | } DUAL ELECTROLYTIC |                |
| $R_2 = 2000$                 |                              | $C_2 = 8$               |                     | } ELECTROLYTIC |
| $R_3 = 500$                  |                              | $C_3 = 20$              |                     |                |
| $R_4 = 99,000$               | $C_4 = .03$                  | } BLOCK                 |                     |                |
| $R_5 = 10,000$               | $C_5 = .006$                 |                         |                     |                |
| $R_6 = 30,000$               | $C_6 = .03$                  |                         |                     |                |
| $R_7 = 200,000$ VOLUME CONT. | $C_7 = .25$                  |                         |                     |                |
| $R_8 = 50,000$ TONE CONTROL  | $C_8 = .5$                   |                         |                     |                |
| $R_9 = 20$ HUM BALANCER      | $C_9 = .1$                   | $C_{10} = .25$          | } MICA              |                |
| $R_{10} = 400$               | $C_{11} = .0005$             |                         |                     |                |
| $R_{11} = 10,000$            | $C_{12} = .004$ TUBULAR.     |                         |                     |                |
| $R_{12} = 25,000$            | $C_{13} = .5$ IN BLOCK       |                         |                     |                |
| $R_{13} = 25,000$ WIRE WOUND | $C_{14} = .01$ IN SMALL CAN. |                         |                     |                |
| $R_{14} = 40,000$            | $C_{15} = .01$ IN SMALL CAN. | $C_{16} = .11$ TUBULAR. |                     |                |
| $R_{15} = 99,000$            |                              |                         |                     |                |




# GRIGSBY-GRUNOW CO.

MODEL 310-B TWIN SPEAKER.  
EFFECTIVE ON SERIAL #12,304 AND OVER



## DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE MODEL 310-A SINGLE SPEAKER

FOR SERIAL NUMBERS 12,868 AND UNDER, 115V. 50-60 CYCLE.  
" " " " " " UNIVERSAL MODELS.



## GRIGSBY-GRUNOW CO.

### TECHNICAL DATA PERTAINING TO MODEL 310 CHASSIS THE CIRCUIT NOTICE

The Model 310-A is a seven-tube super-heterodyne chassis with automatic volume control, designed for single speaker operation and the 310-B is the same type chassis designed for twin speaker operation. The circuit employs the latest 2.5 volt type tubes arranged as follows: pentode radio frequency amplifier stage (G-58-S), oscillator stage (G-56), pentode first detector stage (G-58-S), high gain pentode intermediate frequency amplifier stage (G-58-S), combined duodiode second detector and triode first audio amplifier stage (G-55-S) and pentode audio output stage (G-47). The principal characteristics of the circuit are its excellent automatic volume control, high sensitivity, extreme selectivity, and carefully matched fidelity.

#### METHOD OF BIASING

In the late Model 310-B chassis, the initial bias for the R. F. and I. F. stages is provided by a 350 ohm resistor in the common cathode circuit. In the early 310-B and all 310-A chassis, this resistor has a value of 140 ohms. Initial bias for the first detector is provided by a 500 ohm resistor in its cathode circuit. Automatic bias for all three of these tubes is provided by a 10,000 ohm resistor and 40,000 ohm resistor in series in the detector circuit. This automatic bias is also applied to the triode part of the G-55-S detector tube except in the late Model 310-B chassis. This provides substantially flat automatic volume control for any input between fifty micro-volts and one volt. Bias for the output pentode is provided by plate current drop across a 400 ohm resistor in the filament circuit.

#### SPEAKERS

The Model 310-A chassis employs a single six-inch dynamic speaker having a field resistance of 1300 ohms and designated as GJ-16-B. The late Model 310-B chassis employs two ten-inch dynamic speakers each having a field resistance of 710 ohms and designated as G-19-F and G-19-G, while the early 310-B had a field resistance of 520 ohms per speaker. These speakers operating simultaneously produce an almost flat audio frequency response curve which gives these receivers a truly faithful reproduction.

#### NEW MAJESTIC TUBES

The new type G-55 tube is a combination of duodiode and triode tube concentric to one cathode. It functions as two tubes in that the duodiode part operates as a second detector and A.V.C. tube, and the triode operates as a first audio amplifier tube. It is designed for use in the detector stage of small receivers where more power is necessary to swing the grid of the output tube than is available from the ordinary duodiode detector.

There are two distinct types of R. F. coils, antenna coils, oscillator coils and gang condensers used on the Model 310 series MAJESTIC Receivers. The first type manufactured employed a #7826 antenna coil, #7830 R. F. coil, #7834 3-gang condenser and #7845 oscillator coil. The second type employed a #8160 3-gang condenser, #8367 antenna coil, #8368 oscillator coil and #8590 R. F. coil. These changes took effect as per the following:

#### MODEL 310-A:

Starting with serial #10001 there were 1,917 receivers manufactured with a 60 watt, 115 volt, 60 cycle power transformer. These are covered by serial #10001 to #11917. At this point in production the 60 watt power transformer was replaced by a 70 watt power transformer. Then, starting with serial #10001 again there were 951 manufactured with a 70 watt, 115 volt, 60 cycle power transformer. These were covered by serial #10001 to #10951. Starting with serial #10001 there were 516 receivers manufactured using a Universal power transformer. All the aforementioned receivers employed the first type of coils and gang condenser as mentioned above.

All Model 310-A chassis over serial #10951 using a 70 watt, 115 volt, 60 cycle power transformer and all over serial #10516 using a Universal power transformer employed the 2nd type of coils and gang condenser.

#### MODEL 310-B:

Between serial #10001 and #12304 the first type of coils and gang condenser were used. Over serial #12304 the 2nd type of coils and gang condenser were used.


In replacing any coils or gang condensers in these chassis it will be necessary to carefully observe the serial number and the wattage rating on the name plate so as to be able to make the correct replacements.

#### POWER TRANSFORMER COLOR CODE

Primary . . . . .	Stranded Yellow
Primary . . . . .	Stranded Yellow
High Voltage . . . . .	Stranded Red
High Voltage Center Tap . . . . .	Stranded Black
High Voltage . . . . .	Stranded Red
Heater . . . . .	Solid Black
Heater . . . . .	Solid Black
Rectifier Filament . . . . .	Solid Yellow
Rectifier Filament . . . . .	Solid Yellow

GRIGSBY-GRUNOW CO.

SCHEMATIC DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE  
MODEL-320 TWIN SPEAKER




RESISTANCE AND CONDENSER VALUES

R-1 - 110	C-1 - 16.
R-2 - 210	C-2 - 16.
R-3 - 20,000	C-12 - 20.
R-4 - 72	C-18 - 10.
R-5 - 49,000	C-20 - 7.
R-6 - 250	C-3 - .01
R-7 - 300,000	C-4 - .01
R-8 - 300,000	C-23 - .02
R-9 - 100,000	C-24 - .05
R-10 - 2,000	C-6 - .25
R-11 - 50,000	C-8 - .25
R-12 - 300,000	C-10 - .10
R-13 - 300,000	C-11 - .25
R-14 - 200,000	C-19 - .10
R-15 - 500,000	C-25 - .10
R-16 - 500,000	C-26 - .10
R-17 - 100,000	C-14 - .0005
R-18 - 250,000	C-15 - .0005
R-19 - 300,000	C-16 - .0005
R-20 - 30,000	C-22 - .0005
R-21 - 20,000	C-27 - .0005
R-22 - 100,000	C-5 - .01
R-23 - 300,000	C-7 - .01
R-24 - 300,000	C-9 - .01
R-25 - 75,000	C-13 - .01
R-26 - 5,000	C-17 - .10
R-27 - 100,000	C-21 - .25
R-28 - 20-HUM CONTS.	

# GRIGSBY-GRUNOW CO.

## SCHEMATIC DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE MODEL 330



**RESISTANCE & CONDENSER VALUES**

R <sub>1</sub> —	350	MULTIPLE W.W.
R <sub>2</sub> —	200	
R <sub>3</sub> —	500	
R <sub>4</sub> —	300,000	VOL. CONTROL
R <sub>5</sub> —	300,000	
R <sub>6</sub> —	100,000	
R <sub>7</sub> —	200,000	TONE CONTROL
R <sub>8</sub> —	250,000	
R <sub>9</sub> —	400	
R <sub>10</sub> —	100	MULTIPLE W.W.
R <sub>11</sub> —	15,000	
R <sub>12</sub> —	10,000	
R <sub>13</sub> —	100,000	20 HUM CONTROL
R <sub>14</sub> —	300,000	
R <sub>15</sub> —	300,000	
R <sub>16</sub> —	300, 600	
R <sub>17</sub> —		

C <sub>1</sub> —	16 MFD. ELECTROLYTIC
C <sub>2</sub> —	5 MFD. ELECTROLYTIC
C <sub>3</sub> —	20 MFD. ELECTROLYTIC
C <sub>4</sub> —	.05 MFD.
C <sub>5</sub> —	.005 MFD.
C <sub>6</sub> —	.05 MFD.
C <sub>7</sub> —	.01 MFD.
C <sub>8</sub> —	.01 MFD.
C <sub>9</sub> —	.1 MFD.
C <sub>10</sub> —	.25 MFD.
C <sub>11</sub> —	.05 MFD.
C <sub>12</sub> —	.25 MFD.
C <sub>13</sub> —	.01 MFD.
C <sub>14</sub> —	.01 MFD.
C <sub>15</sub> —	.0015 MFD.
C <sub>16</sub> —	.05 MFD.
C <sub>17</sub> —	.25 MFD.
C <sub>18</sub> —	.07 MFD. USED ON 6Z8A-5 RECTIFIER
C <sub>18</sub> —	.11 MFD. USED ON 6Y3A-5 RECTIFIER

TO ALL FILAMENTS  
LINE

NOTE



# GRIGSBY - GRUNOW CO.

## ALIGNMENT PROCEDURE

- 1 - The receiver must be aligned with the volume control in maximum position.
- 2 - Supply a 175 K.C. signal to the first detector grid and align all I.F. tuning condensers to give maximum sensitivity.
- 3 - Turn the gang condenser completely in mesh; set the dial at the line below 550 K.C. and lock in place.
- 4 - Set the dial at 1500 K.C. and after supplying a 1500 K.C. signal to the input of the receiver, align the three radio frequency circuits for maximum output.

## TABLE OF VOLTAGE TO GROUND

### MODEL .330 CHASSIS

TUBE PURPOSE	TYPE	FILAMENT A. C.	PLATE D. C.	SCREEN D. C.	CATHODE D. C.
R. F. Amp.	G-58-S	2.3	250	88	7.2
Modulator	G-58-S	2.3	250	88	9.3
Oscillator	G-56	2.3	90	---	18
I. F. Amp.	G-58-S	2.31	250	88	7.2
2nd Detector & 1st Audio	G-55-S	2.32	Triode 65	----	4.3
Power Output	G-59-B	2.34	254	250	19
Rectifier	G-80	4.8	352 A.C.	----	----

First Filter Condenser . . . . . 326 volts D.C.  
 Second Filter Condenser. . . . . 250 volts D.C.

Line Voltage . . . . . 115 volts  
 Volume Control . . . . . Maximum

Measurements made with a 1,000 ohm per volt D.C. voltmeter, all tubes in their sockets no signal supplied to the receiver.

## GRIGSBY-GRUNOW CO.

### TECHNICAL DATA PERTAINING TO MODEL 330 CHASSIS

#### THE CIRCUIT

The Model 330 is a seven tube chassis designed for single speaker operation in the Models 331 and 336 receivers. The tubes used and their respective stages are as follows: G-58-S, R.F. amplifier; G-56, Oscillator; G-58-S, first detector; G-58-S, I.F. amplifier; G-55-S, second detector and first audio; G-59-B pentode output; and G-80, rectifier.

This chassis is similar to the Model 310 series, except that it employs wet electrolytic condensers and a G-59-B tube connected as a pentode in the output stage.

As on the 310 series, a hum balancing potentiometer is connected in the filament circuit and should be adjusted to right or left as required, to reduce hum to a minimum after the receiver has been installed.

#### AUTOMATIC VOLUME CONTROL

Automatic volume control bias voltage is developed across resistors R-13 and R-10 and is applied to the grid of the radio frequency, first detector and intermediate frequency tubes to control their amplification.

The manual volume control is a 200,000 ohm potentiometer which is connected in the grid circuit of the G-55-S tube and works entirely independent of the automatic volume control.

#### SPEAKER


The "Best" D-65, a six and one-half inch dynamic speaker, is used in conjunction with the Model 330 chassis when used in the Model 331 receiver while the Model G-22-A, a twelve inch dynamic speaker, is used in the Model 336 receiver. The former has a field resistance of 1070 ohms hot, while the latter has a field resistance of 970 ohms at 70°F. A .07 mfd. condenser is connected across the field of each speaker in order to reduce hum.

#### POWER TRANSFORMER COLOR CODE

Primary . . . . .	. Stranded Yellow
Primary . . . . .	. Stranded Yellow
High Voltage . . . . .	. Stranded Red
High Voltage C.T. . . . .	. Stranded Black
High Voltage . . . . .	. Stranded Red
Heater . . . . .	. Solid Black
Heater . . . . .	. Solid Black
Rectifier Filament . . . . .	. Solid Yellow
Rectifier Filament . . . . .	. Solid Yellow

# GRIGSBY - GRUNOW CO.

*SCHMATIC DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL  
SUPERHETERODYNE MODEL-340-B DOUBLE SPEAKER*



**RESISTANCES**

- R-1 - 500,000 OHMS
- R-2 - 300,000 "
- R-3 - 300,000 "
- R-4 - 100,000 "
- R-5 - 500 "
- R-6 - 200,000 "
- R-7 - 150,000 "
- R-8 - 250,000 "
- R-9 - 100,000 "
- R-10 - 1,000 "
- R-11 - 4,500 "
- R-12 - 500,000 "
- R-13 - 20,000 OHMS
- R-14 - 2,000 "
- R-15 - 140 "
- R-16 - 500 "
- R-17 - 36 "
- R-18 - 1,730 "

**CAPACITIES**

- C-1 = 0.01 MFD.
- C-2 = 0.25 "
- C-3 = 0.01 "
- C-4 = 0.25 "
- C-5 = 0.0005 "
- C-6 = 0.10 "
- C-7 = 10. "
- C-8 = 7. "
- C-9 = 0.10 MFD.
- C-10 = 0.02 "
- C-11 = 0.15 "
- C-12 = 20. "
- C-13 = 0.001 "
- C-14 = 0.001 "
- C-15 = 0.005 "
- C-16 = 0.05 "
- C-17 = 0.0005 MFD.
- C-18 = 0.05 "
- C-19 = 20. "
- C-20 = 0.10 "
- C-21 = 0.01 "
- C-22 = 0.01 "
- C-23 = 8. "
- C-24 = 8. "
- C-25 = 16. MFD.
- C-26 = 1. "

## GRIGSBY-GRUNOW CO.

### TECHNICAL DATA PERTAINING TO MODEL 340 CHASSIS

#### THE CIRCUIT

The Model 340 is an eleven tube chassis designed for dual speaker operation in the Model 344 receiver. It provides reactance dimmer action, delayed automatic volume control, synchro-silent tuning and class "B" amplification.

The tubes employed and their respective stages are as follows: G-58-S, R.F. amplifier; G-56, oscillator; G-58-S, first detector; G-58-S, I.F. amplifier; G-55-S, second detector and delayed automatic volume control; G-57-S, first audio; G-57-S, suppressor; G-59, driver; two G-59's output and G-82 rectifier.

#### SYNCHRO-SILENT TUNING CONTROL

The operation of this control in the Model 340 chassis is similar to that in the 360 chassis. See page 15 for description of its operation.

#### INSTRUCTIONS FOR OPERATING AUTOMATIC SYNCHRO-SILENT TUNING CONTROL

- 1 - Complete installation of this radio in the same manner as an ordinary broadcast receiver as far as antenna, ground, tubes, etc. are concerned.
- 2 - Turn Automatic Synchro-Silent Tuning Control knob located on the side of the cabinet clockwise as far as possible - to position marked "distance".
- 3 - Turn the dial to a position between 650 and 800 kilocycles at a point on the dial where no station is heard and then turn the volume control to maximum volume position.
- 4 - FOR LOCAL STATIONS: Adjust the Automatic Synchro-Silent Tuning Control by turning the knob toward "local" position (counter-clockwise) until the noise and static is no longer heard. This noise and static will diminish suddenly and care must be taken to see that the control knob is turned toward "local" position only far enough to eliminate the noise and static and no further.
- 5 - The set is now ready for operation, and local stations will come in with just as much volume as they would if the Automatic Synchro-Silent Tuning Control was not used, but when tuning between stations the set is quiet. In practically all cases, the adjustment stated above is all that is necessary to cut out objectionable static and noises between stations.
- 6 - FOR DISTANT STATIONS: Turn the Automatic Synchro-Silent Tuning Control knob as far as possible toward "distance" position.

#### REACTANCE DIMMER OPERATION

Similar to Model 360 chassis - see page 17 for description of its operation.

#### DELAYED AUTOMATIC VOLUME CONTROL

With the ordinary type of automatic volume control circuit, the total output from the second detector is somewhat reduced by the circuit. This effect is eliminated when using the delayed automatic volume control system which allows the full output of the receiver regardless of signal strength.

## GRIGSBY-GRUNOW CO.

Delayed automatic volume control is accomplished by connecting the triode part of the G-55-S second detector so that, when a weak signal is tuned in, the bias on the grid of the G-55-S causes current to flow from the triode plate to the cathode. The flow of current causes the cathode bias to increase, which is in effect a bias on the diode plate. Hence, the rectification action and current drain properties of the diode are delayed until a point is reached in the intensity of the input signal where the peak volts are equal to the D.C. bias on the diode plates. Up to this point there is no automatic volume control.

However, beyond this point, full automatic volume control action is had because the plate current of the triode approaches zero as the intensity of the signal increases due to the fact that the grid bias on the G-55-S is obtained from the automatic volume control bias voltage that is developed across resistor R-4.

### CLASS "B" AMPLIFICATION

The Model 340 chassis provides class "B" amplification for which a type G-59 tube is employed as a driver and two tubes of the same type are used in the output stages. The screen and control grids of the output tubes are connected together to serve as a single control-grid, and the third grid is connected to the plate of the tube. No grid bias is necessary with this connection. The control-grids of the output tubes are operated sufficiently positive to cause grid current to flow in their input circuit.

### SPEAKERS

The Models G-22-B and G-22-C dynamic speakers are used in conjunction with the Model 340 chassis. They have a field resistance of 970 ohms and 2200 ohms respectively.

A seven prong plug is used to connect the speaker to the chassis. A jumper is connected across two of the prongs in such a way that no D.C. voltage is applied to any of the condensers in the chassis if the A.C. line is turned "on" when the speaker plug is removed from its socket.

### POWER TRANSFORMER CONNECTIONS

Primary . . . . .	. . . . . Yellow lead
Primary . . . . .	. . . . . Yellow lead
Heater . . . . .	Lugs #4 and #7
Heater C.T. . . . .	. . . . . Lug #1
Heater . . . . .	Lugs #5 and #8
High Voltage . . . . .	. . . . . Red lead
High Voltage C.T. . . . .	. . . . . Black lead
High Voltage . . . . .	. . . . . Red lead
Rectifier Filament . . . . .	. . . . . Blue lead
Rectifier Filament . . . . .	. . . . . Blue lead
Tuning Light . . . . .	. . . . . Lug #10
Tuning Light . . . . .	. . . . . Lug #11

## GRIGSBY - GRUNOW CO.

### ALIGNMENT PROCEDURE

- 1 - The receiver must be aligned with the volume control in **maximum** position.
- 2 - Supply a 175 K.C. signal to the first detector grid and align the four I.F. tuning condensers to give maximum sensitivity.
- 3 - Turn the gang condenser completely in mesh; set the dial at the line below 550 K.C. and lock in place.
- 4 - Set the dial at 1500 K.C. and after supplying a 1500 K.C. signal to the input of the receiver, align the three radio frequency circuits for maximum output.

### TABLE OF VOLTAGE TO GROUND

#### MODEL #340 CHASSIS

TUBE PURPOSE	TYPE	FILAMENT A. C.	PLATE D. C.	SCREEN D. C.	CATHODE D. C.	SUPPRESSOR D. C.
R.F. Amplifier	G-58-S	2.5	210	80	2.5	2.5
Modulator	G-58-S	2.5	210	80	4.5	4.5
Oscillator	G-56	2.5	80	---	18	---
I.F. Amplifier	G-58-S	2.5	210	85	2.5	2.5
2nd Detector	G-55-S	2.5	Triode 80	---	1.1	---
1st Audio	G-57-S	2.5	105	100	82.2	82.2
Suppressor	G-57-S	2.5	100	*0	0	0
Driver	G-59	2.5	225	225	22.	225.
Power Output	G-59	2.5	360	0	0	360.
Power Output	G-59	2.5	360	0	0	360.
Rectifier	G-82	2.5	---	---	---	---


First Filter Condenser . . . 400 volts D.C.	Line Voltage . . . . .115 volts
Second Filter Condenser. . . 340 volts D.C.	Volume Control . . . . .Maximum
Third Filter Condenser . . . 235 volts D.C.	Synchro Silent Tuner-Completely Clockwise

\*Will vary from 0 to 80 volts according to setting of Synchro Silent Tuning Control.

Measurements made with a 1,000 ohm per volt, D.C. voltmeter, all tubes in their sockets and no signal supplied to the receiver.

GRIGSBY - GRUNOW CO.

SCHMATIC DIAGRAM OF  
MAJESTIC MODEL 360 RECEIVER



CONDENSERS

- C1 - .01 MFD.
- C2 - .25 MFD.
- C3 - .25 MFD.
- C4 - .01 MFD.
- C5 - .001 "
- C6 - .05 "
- C7 - .1 "
- C8 - .0005 MFD.
- C9 - 10 MFD. DRY
- C10 - 7 MFD DRY
- C11 - .07 "
- C12 - .002 "
- C13 - .03 "
- C14 - .05 "
- C15 - .01 "
- C16 - .01 "
- C17 - .01 " WET
- C18 - .16 " WET
- C19 - .16 " DRY
- C20 - .20 " DRY

RESISTORS

- R1 - 300,000 OHMS
- R2 - 300,000 "
- R3 - 2,000 "
- R4 - 30,000 "
- R5 - 200,000 OHM VOL. CONT.
- R6 - 800,000 OHMS
- R7 - 150,000 "
- R8 - 250,000 OHM TONE CONTROL
- R9 - 300,000 OHMS
- R10 - 20,000 "
- R11 - 25,000 "
- R12 - 300,000 "
- R13 - 100,000 "
- R14 - 20,000 OHM SUPPRESSOR
- R15 - 300,000 OHMS
- R16 - 1500 OHMS
- R17 - 225 "
- R18 - 200 "
- R19 - 18740 "
- R20 - 125 "
- R21 - 9000 "
- R22 - 100,000 "
- R23 - 20 OHM HUM BALANCE

# GRIGSBY - GRUNOW CO.

## POWER TRANSFORMER CONNECTION

Primary . . . . .	Yellow lead
Primary . . . . .	Yellow lead
High voltage. . . . .	.Red lead
High voltage C.T. . . . .	Black lead (stranded)
High voltage. . . . .	.Red lead
Pentode Heater. . . . .	.Lug #7
Pentode Heater. . . . .	.Lug #8
R. F. Heater. . . . .	.Lug #4
R. F. Heater C.T. . . . .	.Lug #1
R. F. Heater. . . . .	.Lug #5
Tuning Light. . . . .	Lug #10
Tuning Light. . . . .	Lug #11
Rectifier filament. . . . .	.Black lead (solid)
Rectifier filament. . . . .	.Black lead (solid)

## ALIGNMENT PROCEDURE

- 1 - The receiver must be aligned with the volume control in maximum position.
- 2 - Supply a 175 K.C. signal to the first detector grid and align the three I.F. tuning condensers to give maximum sensitivity.
- 3 - Turn the gang condenser completely in mesh; set the dial at the line below 550 K.C. and lock in place.
- 4 - Set the dial at 1500 K.C. and after supplying a 1500 K.C. signal to the input of the receiver, align the three radio frequency circuits for maximum output.

## TABLE OF VOLTAGE TO GROUND

### MODEL #360 CHASSIS

TUBE PURPOSE	TYPE	FILAMENT A. C.	PLATE D. C.	SCREEN D. C.	CATHODE D. C.	SUPPRESSOR D. C.	GRID D. C.
R.F. Amplifier	G-58-S	2.35	275	105	5	5	---
Modulator	G-58-S	2.35	275	105	5	5	---
Oscillator	G-56	2.35	105	---	15	---	---
I.F. Amplifier	G-58-S	2.3	275	105	5	5	---
2nd Detector	G-56	2.3	0	---	0	---	---
First Audio	G-57-S	2.3	140	135	115	115	90
Suppressor	G-57-S	2.32	135	0	0	0	---
Phase Rotator	G-56	2.35	260	---	17	---	---
Power Output	G-59-B	2.35	280	270	---	18	---
Power Output	G-59-B	2.35	280	270	---	18	---
Rectifier	G-82	2.5	---	---	---	---	---

First Filter Condenser . . . 350 volts D.C.  
 Second Filter Condenser. . . 300 volts D.C.

Line Voltage . . . . . 115 volts  
 Volume Control . . . . . Maximum  
 Synchro Silent Tuner - Clockwise

Measurements made with a 1,000 ohm per volt D.C. voltmeter, all tubes in their sockets and no signal supplied to the receiver.



## GRIGSBY-GRUNOW CO.

### INSTRUCTIONS FOR ADJUSTING SYNCHRO-SILENT TUNING CONTROL

- 1 - Complete installation of the radio in the same manner as an ordinary broadcast receiver as far as antenna, ground, tubes, etc. are concerned.
- 2 - Turn the Synchro-Silent Tuning Control knob, which is located on the side of the cabinet, clockwise as far as possible - to position marked "distance".
- 3 - Turn the dial to a point on the dial between 650 and 800 kilocycles where no station is heard and then turn the volume control to maximum position.
- 4 - FOR LOCAL STATIONS: Adjust the Synchro-Silent Tuning Control, by turning the knob toward "local" position (counter-clockwise) until the noise and static is appreciably reduced. This noise and static will diminish suddenly and care must be taken to see that the control knob is turned toward "local" position only far enough to reduce the noise and static and no further.
- 5 - The set is now ready for operation, and local stations will come in with just as much volume as they would if the Synchro-silent Tuning Control was not used, but when tuning between stations the set is quiet. In practically all cases, the adjustment stated above is all that is necessary to cut out objectionable static and noises between stations.
- 6 - FOR DISTANT STATIONS: Turn the Synchro-Silent Tuning Control knob as far as possible toward "distance" position.

### MAJESTIC PUSH-PULL RESISTANCE COUPLING CIRCUIT

The advantages of resistance coupling are so well known that it is unnecessary to point out how good tone quality and well designed resistance coupling are synonymous. The advantages of push-pull are also well known, the chief among these being that it is possible to get greater power output with less distortion. Now, as mentioned above, we have both of these features in one chassis.


In push-pull amplification, it is necessary that the grids of the push-pull tubes be fed with voltages that are equal in magnitude, but exactly opposite in phase or polarity. When a transformer is used, this is accomplished simply by using the two extremes of the secondary winding to feed the push-pull grids, and if a center tap is provided, these voltages are bound to be equal, and opposite in phase.

In the new Majestic circuit, phase rotation is accomplished by making use of the fact that a signal in passing through a vacuum tube is rotated in phase exactly  $180^{\circ}$  (complete reversal). Following the audio channel from the detector, we find that the audio voltage built up across Resistor R-13 is fed to the G-57-S audio tube through potentiometer R-5. The output of the audio amplifier follows two channels. The direct and conventional channel is through condenser C-15 to the upper of the two G-59-B push-pull output pentodes. The remaining channel is through condenser C-15 and the G-56 phase rotating tube. The signal coming out of this tube built up across R-11 is reversed in polarity over that originally built up across R-9. This reversed signal is fed to the lower of the two G-59-B output pentodes. By suitable design, the G-56 phase rotating tube and associated circuit is arranged so that no change in the magnitude of the signal takes place, the only change being a reversal of polarity or phase.

In this way, we have two voltages fed to the two G-59-B output tubes which are equal in magnitude, but opposite in polarity and true push-pull resistance coupled operation results.

# GRIGSBY-GRUNOW CO.

## SCHMATIC DIAGRAM OF MAJESTIC MODEL 370 RECEIVER



- RESISTORS**
- R1 - 300 OHMS
  - R2 - 3000 "
  - R3 - 20,000 " } VOL. CONTROL
  - R4 - 250 "
  - R5 - 50,000 "
  - R6 - 7000 "
  - R7 - 30,000 "
  - R8 - 1,000,000 "
  - R9 - 200,000 "
  - R10 - 50,000 "
  - R11 - 400 "
  - R12 - 300,000 "

- CONDENSERS**
- C1 - .03 MFD.
  - C2 - .1 "
  - C3 - .1 "
  - C4 - .1 "
  - C5 - .25 "
  - C6 - .03 "
  - C7 - .03 "
  - C9 - .01 "
  - C10 - .1 "
  - C11 - 8. "
  - C12 - 8. " } DRY
  - C13 - .1 " } ELECTROLYTIC
  - C14 - .01 "
  - C16 - .0015 "

### ALIGNMENT PROCEDURE

- 1 - The receiver must be aligned with the volume control in maximum position.
- 2 - Supply a 456 K.C. signal to the first detector grid and align the three I.F. tuning condensers to give maximum sensitivity.
- 3 - Turn the gang condenser completely in mesh; set the dial at the line below 550 K.C. and lock in place.
- 4 - Set the dial at 1500 K.C. and after supplying a 1500 K.C. signal to the input of the receiver, align the two radio frequency circuits for maximum output.


**TABLE OF VOLTAGE TO GROUND**  
MODEL 370 CHASSIS

TUBE PURPOSE	TYPE	FILAMENT A. C.	PLATE D. C.	SCREEN D. C.	CATHODE D. C.
Modulator	G-57-S	2.4	105	105	13.5
I. F. Amp.	G-58-S	2.4	105	105	3.3
2nd Detector	G-57-S	2.4	95	53	5.4
Power Output	G-59	2.43	218	235	16.5
Rectifier	G-80	4.85	Plate to Plate A.C.620	---	---

First Filter Condenser . . . 325 volts D.C.      Line voltage . . . 115 volts  
 Second Filter Condenser . . . 235 volts D.C.      Volume Control \* \* \* \* \* Maximum  
 Measurements made with a 1,000 ohm per volt, D.C. voltmeter, all tubes in their sockets  
 and no signal supplied to the receiver.

# GRIGSBY-GRUNOW CO.

## SCHEMATIC DIAGRAM OF MAJESTIC MODEL - 380



**CONDENSER VALUES**

- C1 - .05 MFD
- C2 - .05 MFD } R.F. BY-PASS
- C3 - 0.1 MFD } COND CAN
- C4 - 0.1 MFD
- C5 - .0005 MFD
- C6 - .03 MFD
- C7 - .005 MFD } AUDIO BY-PASS
- C8 - 0.1 MFD } COND CAN
- C9 - 4 MFD } ELECTROLYTIC
- C10 - 8 MFD } FILTER UNIT
- C11 - 10 MFD - ELECTROLYTIC

**RESISTOR VALUES**

- R1 - 50,000 OHMS MAX } VOLUME
- R2 - 250 OHMS MIN } CONTROL
- R3 - 50,000 OHMS
- R4 - 500,000 OHMS
- R5 - 25,000 OHMS
- R6 - 300,000 OHMS
- R7 - 300 OHMS

**CHASSIS PARTS**

PART No.	DESCRIPTION
8881	Antenna Coil Assembly
8753	By-Pass Condenser Assembly Consisting of 1-.1, 1-.03, 1-.005 MFD
8776	By-Pass Condenser Assembly Consisting of 2-.1, 2-.05 MFD
6242	Condenser, .0005 MFD.
	Condenser, Electrolytic
8755	4-8 MFD.
8774	10 MFD.
8758	Condenser, TWO-GANG
8894	Dial Strip and Hub, Complete
8892	Power Transformer, Complete
	Resistors
8756	900 Ohm
7298	25,000 Ohm
7498	50,000 Ohm
7253	300,000 Ohm
7482	500,000 Ohm
8875	R. F. Coil Assembly
	Tube Socket
8754	Four Prong for G-84
8757	Six Prong for G-57, G-58, G-89.
8759	Volume Control and Line Switch

**TABLE OF VOLTAGES**

Tube	Heater	Cathode Ground	Plate to Ground	Screen Ground	Heater Ground
Purpose	D.C.	D.C.	D.C.	D.C.	D.C.
R. F. Amp. G-58A-S	5.9	2.5	178 D.C.		
Detector G-57A-S	5.9	1.4	80 D.C.	18.4	
Pentode Output G-89	5.9	18.4	171 D.C.	183	
Rectifier G-84	2.4		350 A.C.		285

Line Volts—115 A. C.

**COLOR CODE OF POWER TRANSFORMER**

- PRIMARY—Stranded Yellow.
- HIGH VOLTAGE—Red.
- RECTIFIER FILAMENT—Black.
- HEATERS—Solid Yellow.


**ALIGNMENT PROCEDURE**

Set the dial in a position so the gang mark below 1500 K. C. is in line with the pointer when the gang condenser is completely unmeshed.

Supply a 1500 K. C. signal to the input of the receiver and after turning the dial to 1500 K. C.. adjust both gang condenser trimmers for maximum output.

GRIGSBY-GRUNOW CO.

SCHEMATIC DIAGRAM OF MAJESTIC AUTOMATIC VOLUME CONTROL SUPERHETERODYNE  
MODEL-390



**RESISTANCE VALUES**

R1	350	OHMS
R2	2000	"
R3	500	"
R4	300,000	"
R5	300,000	"
R6	100,000	"
R7	200,000	"
R8	250,000	"
R9	2700	"
R10	2000	OHMS
R11	6000	"
R12	6000	"
R13	100,000	"
R14	300,000	"
R15	300,000	"
R16	50,000	"

{ R7 = VOLUME CONTROL  
R8 = TONE CONTROL

**CONDENSER VALUES**

C1	8 MFD. ELECTRO.
C2	16 MFD. ELECTRO.
C3	20 MFD. ELECTRO.
C4	.05 MFD.
C5	.006 "
C6	.05 "
C7	.01 "
C8	.01 "
C9	.1 "
C10	.25 "
C11	.05 MFD.
C12	.25 "
C13	.01 "
C14	.01 "
C15	.0015 "
C16	.05 "
C17	.0005 "
C18	.0005 "
C19	20 MFD ELECTRO.
C20	.25 MFD.
C21	.07 "

# GRIGSBY-GRUNOW CO.

## ALIGNMENT PROCEDURE

- 1 - The receiver must be aligned with the volume control in maximum position.
- 2 - Supply a 175 K.C. signal to the first detector grid and align all I.F. tuning condensers to give maximum sensitivity.
- 3 - Turn the gang condenser completely in mesh; set the dial at the line below 550 K.C. and lock in place.
- 4 - Set the dial at 1500 K.C. and after supplying a 1500 K.C. signal to the input of the receiver, align the three radio frequency circuits for maximum output.

### TABLE OF VOLTAGE TO GROUND

#### MODEL 390 CHASSIS

TUBE PURPOSE	TYPE	FILAMENT A. C.	PLATE D. C.	SCREEN D. C.	CATHODE D. C.	SUPPRESSOR D. C.
R.F. Amplifier	G-58-S	2.3	265	95	6.5	6.5
Modulator	G-58-S	2.35	265	95	9.5	9.5
Oscillator	G-56	2.38	98	—	13.5	—
I. F. Amplifier	G-58-S	2.28	265	95	6.5	6.5
Second Detector	G-55-S	2.4	Triode 50	—	3	—
Driver	G-56	2.41	262	—	12.5	—
Power Output	G-53	2.42	Plate #1 262	Plate #2 262	0	—
Rectifier	G-80	4.9	320 A.C.	—	—	—

First Filter Condenser . . . 305 volts D.C.  
 Second Filter Condenser. . . 265 volts D.C.

Line Voltage . . . 115  
 Volume Control-Maximum

Measurements made with a 1,000 ohm per volt D.C. voltmeter, all tubes in their sockets and no signal supplied to the receiver.

## GRIGSBY-GRUNOW CO.

### TECHNICAL DATA PERTAINING TO MODEL 390 CHASSIS

#### THE CIRCUIT

The Model 390 is an eight tube superheterodyne chassis designed for single speaker operation in the Model 393 receiver. The tubes employed and their respective stages are as follows: G-58-S, R.F. amplifier; G-56, Oscillator; G-58-S, first detector; G-58-S, I.F. amplifier; G-55-S, second detector and first audio amplifier; G-56, driver; G-53, class "B" amplifier; and G-80, rectifier. The main feature of this chassis is class "B" amplification in one output tube.

#### AUTOMATIC VOLUME CONTROL

Automatic volume control bias voltage is developed across resistors R-6 and R-10 in the second detector circuit and is applied to the grids of the radio frequency, first detector and intermediate frequency amplifier tubes to control their amplification.

The manual volume control is a 200,000 ohm potentiometer entirely independent of the automatic volume control circuit and is connected in the grid circuit of the first audio amplifier.

#### SPEAKER

The Model G-22-E speaker employed in conjunction with the Model 390 chassis is a large 12" dynamic speaker and has a field resistance of 970 ohms at 70° F. This speaker is designed to carry a tremendous amount of power without distortion.

#### CLASS "B" AMPLIFICATION

The Model 390 chassis has as a part of its circuit Class "B" Amplification for which a type G-56 tube is used as the driver and a type G-53 tube is used as the output.


This output tube is of the 2.5 volt heater type and has two plates and two grids. It does the work of two triode tubes and makes possible tremendous output.

#### POWER TRANSFORMER CODE

Primary . . . . .	.Stranded Yellow
Primary . . . . .	.Stranded Yellow
High voltage. . . . .	. Stranded Red
High voltage C.T. . . . .	. Stranded Black
High voltage. . . . .	. Stranded Red
Heater. . . . .	.Solid Black
Heater. . . . .	.Solid Black
Rectifier filament. . . . .	.Solid Yellow
Rectifier filament. . . . .	.Solid Yellow

# GRIGSBY-GRUNOW CO.

## SCHEMATIC DIAGRAM OF MAJESTIC SCREEN GRID A.C.-D.C. SUPERHETERODYNE RECEIVER MODEL - 400 USED IN 411-413 RECEIVERS.



### RESISTOR & CONDENSER VALUES

R-1 — 20,000 OHMS-V.C.	C-1 — 0.01 MFD	} DRY ELECTROLYTIC
R-2 — 250 " V.C.	C-2 — 16. "	
R-3 — 250 " "	C-3 — 8. "	} DRY ELECTROLYTIC
R-4 — 60,000 " "	C-4 — 0.01 " "	
R-5 — 50,000 " "	C-5 — 10. " "	} DRY ELECTROLYTIC
R-6 — 1,000,000 " "	C-6 — 0.10 " "	
R-7 — 500,000 " "	C-7 — 0.0005 " "	} DRY ELECTROLYTIC
R-8 — 500,000 " "	C-8 — 0.10 " "	
R-9 — 700 " "	C-9 — 0.25 " "	} DRY ELECTROLYTIC
R-10 — 500 " "	C-10 — 0.25 " "	
R-11 — 2,000 " "	C-11 — 0.25 " "	} DRY ELECTROLYTIC
	C-12 — 0.01 " "	
	C-13 — 0.25 " "	} DRY ELECTROLYTIC
	C-14 — 0.10 " "	
	C-15 — 0.01 " "	} DRY ELECTROLYTIC
	C-16 — 0.001 " "	
	C-17 — 0.10 " "	

TUBE PURPOSE	TYPE	FILAMENT A.C.-D.C.	PLATE D.C.	SCREEN D.C.	CATHODE D.C.
Modulator and Oscillator	G-57A-S	6.3	105	105	13
I.F. Amp.	G-58A-S	6.3	105	105	*3 to 30
2nd Det.	G-57A-S	6.3	18	18	2
Power Output	G-43	25.0	96	105	16
Rectifier	G-25Z5	25.0	...	...	118
Ballast	G-46A1	46.1	...	...	...

LINE VOLTAGE - 115 A.C.

\* Varies according to setting of volume control.

## GRIGSBY-GRUNOW CO.

### TECHNICAL DATA PERTAINING TO THE MODEL No. 400 CHASSIS EMPLOYED IN MODELS Nos. 411 AND 413 RECEIVERS

#### CIRCUIT

The Model #400 chassis employs the superheterodyne circuit augmented by the latest tubes designed especially for A.C. - D.C. operation. The tubes used and their respective stages are as follows:

G-57A-S	Composite oscillator and modulator
G-58A-S	Intermediate frequency amplifier
G-57A-S	Second detector
G-43	Output amplifier
G-25Z5	Rectifier
G-46A1	Ballast

The filaments of all the tubes including the ballast tube are connected in series. The sum of their required filament voltages is equal to 115 V. and they therefore, are connected directly to the line. This eliminates the necessity of dropping the voltage further through a resistor to provide proper filament supply for the tubes.

The filaments of the G-43 and G-25Z5 tubes are shunted by a 500 ohm, 5 watt resistor, due to the fact, that the current required by these filaments is only 300 milliamperes while the current required by the other four tubes is 400 milliamperes.

#### POWER SUPPLY

The Model 400 chassis will work on either an A.C. or D.C. supply and on any voltage between 100 and 125 volts.

For A.C. operation the G-25Z5 tube acts as a half-wave rectifier, thus providing the necessary D.C. voltage for operation of the tubes. On D.C. the G-25Z5 allows the current to flow from its plates to the cathodes in the same manner as an ordinary vacuum tube.

On D.C. the set will operate with the plug in one position only. It may be necessary to reverse the polarity of the line cord plug, that is, turn it half way around so that the prongs go into the opposite holes before the receiver will operate. The plug should also be tried in both positions for A.C. operation, in order to determine the position in which the least amount of noise is heard. This is especially important if no ground connection is being used.

#### ANTENNA

An antenna is provided with each Model #411 and #413 receiver. This should be stretched out to its full length by placing it around the moulding or dropping it out of a window. For best reception an antenna other than the one furnished with the receiver, should not be used.

#### SPEAKER

The Model G-26-C speaker is used in conjunction with the Model #400 chassis. The field coil of this speaker has a resistance of 2,600 ohms and is connected directly across the output of the rectifier tube. In order to minimize hum, a hum-buck coil is connected in series with the voice coil.



## GRIGSBY-GRUNOW CO.

### TUBES

The type G-43 output tube is of the Pentode type having three grids. The filament of this tube requires 25 volts at 300 mills. The maximum recommended plate voltage is 135 volts. This type of tube is especially designed for transformerless receivers.

The G-25Z5 rectifier tube is one of the latest developments in the tube industry and may be connected as a half-wave rectifier, full-wave rectifier or a voltage doubler. However, in this particular receiver it is connected as a half-wave rectifier, the positive "B" supply coming from the cathodes of the tube. The filaments of this tube require 25 volts at 300 mills.

The type G-46A1 tube employed in the Model #400 receiver as a ballast dissipates 46.1 volts. This tube is spray shielded in order to reduce the glow, however, no connection is made to the spray shield.

In some cases where noisy reception is encountered an improvement may be made by connecting a ground wire to the receiver. A screw is provided for a ground connection on the left hand side of the chassis in the rear.

The intermediate frequency is 456 kilocycles.

**WARNING** - If the receiver is of the leather carrying case type (Model #413), do not operate it without first opening the back of the carrying case to allow the heat, created by the receiver, to be dissipated.

### ALIGNMENT PROCEDURE

The Model #400 chassis is aligned for maximum sensitivity before leaving the factory and the aligning adjustments should not be altered unless it is known that they are incorrect. Whenever the radio frequency or intermediate frequency coil or tuning condenser is changed the receiver should be realigned.

1 - With the volume control in maximum volume position and the gang condenser completely out of mesh, supply a 456 K.C. signal to the grid of the modulator tube and adjust the 4 I.F. tuning condensers for maximum sensitivity.

2 - With the gang condenser and volume control in the same position, supply a 1730 K.C. signal to the input of the receiver and align the 2 R.F. trimmer condensers for maximum sensitivity.


### SPECIAL CHANGES

In some receivers the 250 ohm resistor, R-3, and the 2000 ohm resistor, R-11 have been replaced by a 160 ohm and a 2500 ohm resistor respectively. The purpose of this was to make the G-57A-S modulator tube oscillate more readily. If a 250 and 2000 ohm resistor are used in the set it may be necessary to try two or three different tubes in this stage when replacement is being made, before a tube is found that will oscillate over the entire band. If trouble is experienced along this line the changing of the value of either one or both of these resistors should eliminate the difficulty.





# HOWARD RADIO CO.



VOLTAGES AS SHOWN INDICATES POTENTIAL ABOVE GROUND AT 115V. A.C. LINE.

# HOWARD RADIO CO.

## PARTS LIST

### MODEL K RECEIVER

<u>Part No.</u>		<u>Retail List Price</u>
2313	Power Transformer	\$8.00
1832	2 Amp. Fuse	.06
1869	8 mf. Filter Condenser, single gauze	1.90
2335	8 " " " double "	2.15
2348	Volume Control .01	1.50
1962	By-pass Condenser	2.20
1964	" " "	1.55
1767	.01 mf. TC Condenser	.36
1953	Tone Control	2.50
1901	Pilot Light	.33
1897	200 M ohm Resistor	.35
1890	500 ohm Resistor	.35
1827	30 M ohm "	.35
1917	2500 ohm "	.35
SA1355	Antenna Coil	2.76
SA1356	R.F. Coil	2.20
SA1264	I.F. Coil	.80
SA1248	I.F. Coil	.80
2289	Audio Transformer	4.00
1358	Speaker	16.25
1835	3 M ohm Resistor	.35


### ALIGNING

This receiver uses 175 kcs. for the intermediate frequency, and the method of gaining these intermediate frequency stages is the same as employed in standard type receivers. There are no over-coupled stages in this intermediate frequency amplifier system and the following method is recommended for gaining this stage:

Disconnect grid cap on the 58 ist detector tube and connect between grid and ground of this tube the 175 kcs. oscillator, and by means of either the ear or a meter connected across the voice coil or plate circuit of output stage, adjust the trimming condensers associated with the two I.F. transformer systems for maximum output. We suggest that you make this adjustment with as small an input signal as can be obtained from your oscillator, in order to get away from the apparent detuning condition met with due to operation of automatic volume control system.

To align the R.F. tuning circuits, it is necessary to use an oscillator set at 1400 kcs. and connected to antenna and ground posts for this adjustment. Set receiver at 1400 kcs. on the dial and then adjust trimmer condensers of the variable condenser, adjusting first the oscillator condenser and then the antenna and R.F. tuning condensers. In cases where the receiver has seen considerable service and there is a doubt in the mind of the Service Man with respect to the condition of the receiver, it is permissible, after the 1400 kcs. adjustment has been made, to set the receiver at 600 kcs. and adjust padding condenser associated with the oscillator system. After the 600kcs. adjustment has been made, it is advisable to readjust again the oscillator at 1400 kcs.

# HOWARD RADIO CO.



VOLTAGES AS SHOWN INDICATE POTENTIAL ABOVE GROUND AT LINE VOLTAGE OF 115 V.A.C.

## HOWARD RADIO CO.

## PARTS LIST

## MODEL L RECEIVER

<u>Part No.</u>		<u>Retail List Price</u>
2352	I.F. Transformer	\$1.50
1354	Variable Tuning Condenser	5.00
1351	Dial Drive Mechanism and Scale	2.00
1562	A.C. Line cord and plug	.55
1702	Socket No. 80	.30
2358	" " 58	.30
2356	" " 56	.30
2355	" " 55	.30
2342	" " 42	.30
1890	Resistor 500 ohms 1/2 watt	.35
1897	" 200,000 ohms 1/3 watt	.35
2373	" 1,100 ohms 1/2 watt	.35
1827	" 30,000 ohms 1/2 watt	.35
1834	" 2,000 ohms 1/2 watt	.35
1835	" 3,000 ohms 1/3 watt	.35
1889	" 2 meg. 1/2 watt	.35
1873	" 100,000 ohms 1/2 watt	.35
2350	Voltage Divider, 9830 ohms	2.00
2329	" 210 ohms Candohm	.26
1747	" 50,000 ohms 1/2 watt	.35
1888	" 150,000 ohms 1/2 watt	.35
1914	" 10 ohm center tap	.19
2369	" 8,000 ohm 1/2 watt	.35
1832	Fuse 2 amp.	.06
1857	Oscillator padding Condenser	1.25
2375	By-pass Condenser Block	3.80
2319	" " .1 mf.	.25
1893	" " .05 mf.	.35
2335	Filter Cond. Double Gauze, 8 mf. 450 V.1	2.15
1869	" " Single " " " "	1.90
1964	By-pass Condenser Block	1.55
2367	Tone Control Condenser .002-	.25
1901	Pilot Light 2.5 volt	.33
2344	Power Transformer	9.00
1953	Tone Control and Power Switch, 1 1/2 meg.	2.50
2343	I.F. Transformer tuning condenser	.90
2310	Choke Coil Power Pack	4.70
2349	Volume Control 250,000 ohms	1.50
2377	Audio Transformer, 2 to 1 ratio	4.00
SA1355	Antenna Radio Frequency Transformer	2.76
SA1357	Oscillator Tuning Coil	2.20
SA1356	Radio Frequency Transformer	2.50
SA1253	Detector R.F. Choke	.35
SA2031	Tuning Meter	3.25
SA2353	Tri Coil	1.50
2353	Variator	.90
1980A	Speaker Transformer	3.60
2370	30 ohm Center Tap	.30
1366	Speaker 435 ohm	16.25
1801	.001 Type W	.41
2328	Large Knob	.30
2327	Small Knob	.25
1722	Resistor 200,000 ohms 1/2 watt	.35

# HOWARD RADIO CO.

## HOWARD MODEL M "TRIPLEX CONTROL" 14-TUBE SUPERHETERODYNE

(Parallel push-pull A. F. amplification; visual tuning meter; A.V.C.; silent-tuning control; twin 80 rectifiers; duo-diode silent-tuning tube; tone control.)

In the Howard Model M 14-tube superheterodyne, manufactured by Howard Radio Co., are incorporated several new circuit details with which the progressive Service Man must acquaint himself. Use of a "triplex control" circuit in this set results in improved performance in the reduction of station background noise, and sensitivity and inter-station noise suppression, over the "duplex control" Model K chassis.

The following tube voltages are used in this set:

Tube No.	Fil. Volts	Cath. Volts	S.G. Volts	Sup. G. Volts	Plate Volts
1	2.5	2.7	80	2.7	190
2	2.5	4.4	80	—	190
3	2.5	7.5	—	—	190
4	2.5	2.8	80	—	80
5	2.5	87.0	—	—	188
6	6.3	16.5	280	—	267
7	6.3	16.5	280	—	267
8	6.3	16.5	280	—	267
9	6.3	16.5	280	—	267
10	2.5	15.0	80	—	188
11	2.5	12.0	—	—	70
12	2.5	—	—	—	—
13	5.0	—	—	—	374**
14	5.0	—	—	—	374**

(Voltages indicated at a line potential of 115 V. \*Switch Sw. 2 closed. \*\*Read between V13, V14 filaments and chassis.)

The values of the components used in the Howard model M receiver chassis are given below.

Resistor R1, tone control, 1½ megs.; R2, manual silent tuning control, .25 meg. (liner taper); R3, manual volume control, .25-meg.; R4, R6, R8, R10, R11, R13, 0.2-meg.; R5, 2,000 ohms; R7, 1,100 ohms; R9, R12, 500 ohms; R14, R17, R28, 30,000 ohms; R15, 105 ohms; R16, 2 megs.; R18, R19, R27, 0.1-meg.; R20, 50,000 ohms; R21, R25, 10 ohms, center-tapped; R22, .15-meg.; R23, 8,000 ohms; R24, 3,000 ohms; R26, 30 ohms, center-tapped; R29, R30, R31, 2,200, 3,730 and 3,900 ohms, respectively, and on one resistor unit. The field coil has a resistance of 300 ohms.

Condensers C1 to C3, tuning units; C1A to C3A, trimmers; C4 to C7, C16, C18, I.F. trimmers; C8, C11, .001-mf.; C9, 1. mf.; C10, .002-mf.; C12, C18, C17, C24, C25, C27, C28, C29, C31, C32, C33, C35, 0.1-mf.; C14, C15, C19, C20, .05-mf.; C21, C22, C23, 8 mf.; C26, .000153-mf., padding condenser; C30, 0.5-mf.

Pilot lights V15, V16 connect to winding X, X on the power transformer, PT.

A red-lead 0.5-mf. condenser, in the same can with the blue-lead unit, C9, but not shown in the schematic circuit, bypasses the plate current supply to V5. An 11-section condenser block includes the following condensers: C12, C13, C14, C15, C17, C19, C24, C28, C30, C31, C32. The color code is as follows: brown leads, 0.1-mf.; green, .05-mf.; red, 0.5-mf.; all are rated at 200 V., as are condensers C25, C27, C29, C33.

To gang the I.F. circuits, disconnect the control-grid cap on V2 and connect the 175 kc. oscillator between the control-grid and ground (chassis); then, by means of either the ear or a meter connected across the voice coil or plate circuit output stage, adjust trimming condensers C4 to C7 for greatest output. Make the input signal as small as possible in order to eliminate the apparent detuning condition met with due to the operation of the A.V.C. system.

Due to the fact that the silent-tuning circuit (S.T.C.) and the automatic volume control (A.V.C.) system constitute a tuned unit, it will be necessary to tune the plate circuit of the type 58 "triplex control amplifier," V10, and also the tuned circuit which is associated with the type 55 tube, V12. This circuit can be readily tuned to correct resonance by use of the 175 kc. oscillator operated at the low input to the first-detector V2. All that is necessary is to first tune the plate circuit of the "triplex control amplifier," V10, until the tuning meter needle swings the greatest distance to the right. Next, tune the suppressor or type 55 tube, V12, circuit until the meter swings to the greatest distance toward the right. It may be possible that both circuits are exactly in tune so that any additional adjustment of these two tuned circuits will not effect the meter swing.

Be sure, when making this adjustment, that you snap on switch Sw.2, associated with resistor R2. If this switch is not thrown to the "on" position, the meter will not operate because switch Sw.2 opens the cathode circuit of V12 and no plate current will flow (unless V12 is gassy).


If it is not possible to obtain a sufficiently low voltage in the oscillator to "gain" this "triplex control" system, you can rotate the knob of R2 further to the right, when you will note that the meter needle swings away from

the zero or maximum right position, and when this condition is obtained, you can again check the tuning of the two circuits in order to obtain the maximum right swing of the needle on this meter. If your input signal from the oscillator is excessive, as previously stated, with the minimum right rotation of R2, you will note that when tuning to a station or to your service oscillator, the tuning meter swings to the full right position, and in such a position you cannot tune the noise-control circuits. Be sure, when tuning these circuits, that either your input signal from the oscillator is as small as possible, or if this is not obtainable, rotate R2 to the right until the meter swings away from the zero or maximum right position. The tuning of these two circuits is simple if you take precautions referred to above, and if these two circuits are properly tuned, you will note that by snapping Sw.2 the inter-station noise will disappear and you will have quiet operation between stations. This tuning operation, when correctly done, increases the apparent selectivity of the receiver and provides a beautifully operating receiver which embodies the latest development of the "duplex control" feature of previous Howard set models.

The output of V5 is fed to the parallel push-pull circuit through a step-up transformer T1 with a ratio of 2-to-1.


Associated with the plate circuit of the "triplex control," or S.T.C. and A.V.C. pre-amplifier tube V10, are three coils, L4, inductively coupled to each other. The first coil, A, is merely a coupling primary in the plate circuit of the pre-amplifier, V10; the second, B, provides voltage for the rectifier system of V11 in the A.V.C. circuit; the third coil, C, provides the noise-suppressor voltage on the control-grid of second-detector V5, through the medium of the voltage drop across resistor R23 in the plate circuit of the S.T.C. tube V12.

In the event that it is necessary to realign the R.F. circuits, connect the service oscillator to the antenna and ground post of the set and tune the oscillator to 1,400 kc. Adjust the set dial to this setting and align the trimmers, starting with C3A, then C1A and then C2A. If it is necessary to align the padding condenser C26 at 600 kc., it will be necessary to go over the adjustments of the high-frequency trimmers again. Condenser C26 is accessible through a hole in the upper part of the container which shields the variable condensers





# LANG RADIO CO.



LANG MODEL DC6

# MOTOMETER GAUGE & EQUIP. CORP.

## MOTOVOX MODELS 10A ALL-ELECTRIC AND 10E BATTERY-OPERATED "MOTO-TETRADYNES"

(The model 10A car-radio set is a superheterodyne; the model 10E receiver is a T.R.F. set incorporating a manual sensitivity control; both instruments include A.V.C.)

Latest in the car-radio line of receivers developed by Motometer Gauge & Equipment Corp. are the Motovox All-Electric model 10A, and the Battery-Operated model 10E.

The model 10A 5-tube set installation includes the following items: chassis, remote tuning control, reproducer and harness, antenna lead-in, filter bypass condensers, suppressors "B" unit and harness; a superheterodyne circuit is utilized.

The model 10E 5-tube receiver includes the following equipment: chassis, remote tuning control, reproducer and harness, antenna lead-in, filter bypass condensers, suppressors; a T.R.F. circuit is used.

### Model 10A

Tube Type	Cath.* Volts	S-G.** Volts	Plate** Volts
V1	2.0	85	180
V2	2.7	85	180
V3	2.7	85	180
V4	4.5	....	50
V5	13.5	166.5	158.5

\*Measured to ground; \*\*to cathode. Readings taken with a 1,000-ohms-per-volt meter; "no signal" setting of set. Total drain, 31 ma.

### Model 10E

Tube Type	Cath.* Volts	S.-G.** Volts	Plate** Volts	+45** Volts
V1	.....	60	135	1.9
V2	.....	59	134	3.0
V3	.....	59	134	3.0
V4	3.5	40	65	.....
V5	16.0	165	155	.....

\*Measured to ground; \*\*measured to cathode. Use a high-resistance meter. Drain, 19 ma.

Sensitivity of models 10A and 10E, ¼-micro-volt-per-meter; power output, 2.25 w.

Since the intensity of signal strength delivered by the antenna to the receiver is directly proportional to the height and effective length and inversely proportional to the resistance of the antenna, it is necessary to use every precaution to obtain an effective auto-radio antenna installation. Thus, only a low-capacity shielded lead-in should be used; also, the antenna should not come closer than 3 ins. to any

metal-work. A counterpoise antenna is used in an automobile since no actual ground is available. The height of the antenna is, therefore, equal to the distance between the flat plane of the antenna and the body of the car. Consequently, the most efficient aerial is one in which the capacity of lead-in and aerial matches the antenna stage of the receiver, covers the largest possible area and is as far removed as possible from the body of the car.

The following instructions pertain to the installation of the model 10A set. After mounting the power supply, run the separately shielded red lead, in the reproducer, to terminal No. 3. Next, connect the red lead in the radio cable to the "B+" terminal in the supply and the yellow lead to the "B-" terminal, making certain that the shield of the cable is anchored by the mounting clamp provided in the power supply. Now connect the black, yellow-tracer lead of the tuning control along with the yellow lead from the power supply terminal No. 2 to the ungrounded or "hot" post of the battery. Connect the black lead from terminal No. 1 of the power supply to the grounded battery post. Make certain that the connections to the battery are correct. Do not pull forward the switch underneath the tuning control until the receiver has been plugged into the harness, otherwise, the power unit will be operating without a load.

Installation instructions which apply to the model 10E receiver are as follows. Connect the yellow lead in the "B" harness to the negative tap of the 180 V. battery (four Burgess type 2308 batteries). Next, connect the maroon lead to the "+45" tap, and the red lead to the "+180" tap. In this line is a ¼-A. fuse.

The sensitivity control on the model 10E set is located in the bottom of the receiver. After tuning the set to a no-signal position near 1,400 kc., turn the sensitivity control right, or clockwise, to "stop," then back it, counterclockwise, until the static level becomes very high. This is the point of maximum sensitivity, to exceed this will result in lack of sensitivity and A.V.C. It is recommended that this control be set just below maximum sensitivity to reduce engine interference.

Due to the current interest in automotive radio installations the following information concerning car antennas is furnished through courtesy of Motometer Gauge & Equipment Co. Although most of the late car models are equipped at the factory with an aerial of some type, earlier cars will usually require the services of a technician acquainted both with the technique of handling car upholstery and the demands of good antenna design.


It is recommended that No. 14 or No. 16 mesh copper or galvanized screen be used. Do not forget to clear the dome-light by 3 ins. In fastening the lead-in to the screen, a No. 18 insulated wire should be used and if the aerial is copper screen it should be soldered around two adjacent sides so that a good electrical connection is assured. The screen should then be securely tacked at all points possible, making certain that it is not grounded to any metal part of the top. Conceal the lead-in and replace the top, soldering the end of the No. 18 wire to the short shielded lead-in which is provided with most sets, making sure to insulate the soldered joint well; ground the shield to some part of the metal body. Keep the unshielded portion of the lead-in, that is, the No. 18 rubber covered wire, as short as possible so that the shielded lead-in actually enters, if possible, the metal corner post, eliminating the possibility of spark pick-up by the unshielded lead.

Top construction may be divided into the following general classifications:


**Open and Convertible.** Loosen the top slightly preliminary to putting it back and weave a No. 18 insulated wire around the border between the top and the flap, giving in all a total length of about 60 ft. of wire. Then bring down the lead-in in the manner described above, and re-tighten the top.

**Screen Wire Tops.** Clip a 3 in. border around the top. Lace the center screen to the edges, using raw-hide.

**Standard Fabric Tops.** This type of top will be found most frequently. Use a wire screen, as described, removing it 3 ins. from all metals.




MotoVox, Model 10A "ALL-ELECTRIC" MOTO-TETRADYNE (Serial Nos. Above 500)




MOTOVOX MODEL 10E BATTERY-OPERATED MOTO-TETRADYNE

# PHILCO RADIO MODEL - 5



MODEL 5  
OTHER SIDE OF "A" BATTERY  
GROUNDED TO CASE - (FRAME  
OF CAR.)



## FILTER CONDENSER 30-4017

ⓐ on Figs. 1 and 2

There are five sections in this filter condenser, all terminated with wire leads. The two green leads connect to the .1 mfd. section, which is used for coupling the plate output of the 75 tube to the grid of the 41 tube.

The remaining four sections are all grounded to the can on one side. The white leads connect to two .25 mfd. sections. The first section is connected to the cathode of the 6A7 tube. The second section is connected to the screen of the 78 tube.

The red lead from the .5 mfd. section is connected to the B+ side of all the plate circuits. A 20 mfd. section terminates in a black lead, which in turn is connected to the cathode of the 41 tube.

## FILTER CONDENSER 30-4010

ⓐ on Figs. 1 and 2

This condenser consists of two sections, a 4 mfd. section and an 8 mfd. section, both of them grounded on one side.

The 4 mfd. section terminates in a red lead, which is connected to the cathode of the 84 tube. The 8 mfd. section terminates in a green lead, which is connected between the two chokes in the rectifier filter circuit.

NOTE.—The first condensers (30-4017) were made up having five sections. The .1 mfd. section has now been removed from the can and this section replaced with a .006 mfd. condenser (Part No. 30-1001). This condenser is located in the chassis adjacent to the grid terminal of the 41 tube socket.


# PHILCO RADIO & TELEVISION CORP.

## MODEL 5 PARTS LIST

No. on Fig. 1 and 2	Description	Part No.	No. on Fig. 1 and 2	Description	Part No.
1	Antenna Transformer	32-1084	38	R. F. Choke (Low voltage)	32-1083
2	Tuning Condenser	31-1019	39	Condenser (.5 mfd.)	30-4015
3	Condenser (.05 mfd.)	30-4020	40	Condenser (.05 mfd.)	30-4020
4	Filter Condenser (.25; .25; .5; 20 mfd.)	30-4017	41	Resistor (200 ohms)	7217
5	Resistor (200 ohms)	7217	42	Vibrator	38-5036
6	Resistor (1300 ohms)	8267	43	Resistor (200 ohms)	7217
7	Oscillator Coil	32-1085	44	Transformer	32-7030
8	Condenser (.00025 mfd.)	3082	45	Condenser (.006 mfd.)	30-1002
9	Resistor (15,000 ohms)	6208	46	Condenser (4 mfd.; 8 mfd.)	30-4010
10	Padder	04000-S	47	Filter Choke	32-7026
11	Padder	04000-J	48	R. F. Choke (High voltage)	32-1078
12	First I. F. Transformer	32-1086	49	Resistor (250,000 ohms)	4410
13	Padder	04000-Y		Control Shaft (Tuning)	28-8006
14	Condenser (.5 mfd.)	30-4018		Control Shaft (Volume)	28-8007
15	Resistor (1,000 ohms)	33-3017		Tube Kit	34-3006
16	Resistor (10,000 ohms)	4412		75 Tube	8002
17	Padder	04000-D		78 Tube	8315
18	Second I. F. Transformer	32-1087		41 Tube	6446
19	Resistor (1,000,000 ohms)	4409		84 Tube	34-2001
20	Padder	04000-M		6A7 Tube	34-2002
21	Condenser (.05 mfd.)	30-4020		Dial	27-5006
22	Condenser (.00025 mfd.)	3082		Antenna Lead	L-1594
23	Condenser (.0005 mfd.)	3910		Battery Cable (Bat. end)	38-5124
24	Resistor (100,000 ohms)	6099		Battery Cable (Rec. end)	38-5123
25	Volume Control and Switch	33-5009		Fuse Housing	28-1269
26	Resistor (32,000 ohms)	3525		Male Cap (Fuse)	28-1270
27	Resistor (250,000 ohms)	3768		Contact (Fuse)	27-7133
28	Resistor (500,000 ohms)	6097		Washer	27-7132
29	Resistor (700 ohms)	6443		Spring	28-8009
30	Resistor (400 ohms)	33-3016		Fuse Insulator	27-7131
31	Condenser (.006 mfd.)	30-1002		Antenna Male Cap	28-1270
32	Output Transformer	32-7005		Contact (Antenna)	28-7133
33	Cone	36-3027		Spark Plug Resistors	4531
34	Field Coil	9013		Dist. Resistors	4546
35	Pilot Lamp	6608		Screw Type	4851
36	Resistor (7 ohms)	7155		Interference Condenser (1 mfd.)	4522
37	Fuse, 15 A.	7227		Interference Condenser (1/2 mfd.)	30-4007

## MODEL EF FULL WAVE VIBRATOR

(Used With Model 6F Receiver)



The Model EF takes the place of the EB dynamotor. The cable connection between the Vibrator and the Model 6F completes the installation of the Vibrator. Terminal 1 is connected directly to the

main battery lead. Terminal 2 is the cable shield. Terminal 3 is connected to the Radio switch. Terminal 4 is the B+ high voltage lead and is connected directly to the plate circuits.

## MODEL EF—PARTS LIST

No. on Fig. 3	Description	Part No.	No. on Fig. 3	Description	Part No.
1	Condenser (.5 mfd.)	30-4015	8	Condenser (.006 mfd.)	30-1002
2	R. F. Choke (Low voltage)	32-1083	9	Condenser (4 mfd.; 8 mfd.)	30-4010
3	Condenser (.5 mfd.)	30-4015	10	Filter Choke	32-7026
4	Vibrator	38-5036	11	R. F. Choke (High voltage)	32-1078
5	Resistor (200 ohms)	7217		84 Tube	32-2001
6	Resistor (200 ohms)	7217		Battery Cable (Model 6F)	41-3017
7	Transformer	32-7030			

## PHILCO TRANSITONE MODEL 5

The Philco Transitone Model 5 is the latest Philco development in automobile radio. It is a powerful and extremely compact superheterodyne having many of the features of the larger auto radio Receivers.

The Receiver, Speaker and the new Full Wave Philco Vibrator are all housed in a single shielded container designed for quick installation on the dash of the automobile. The arrangement is particularly adaptable for small cars and for cars already equipped with a heater. The full powered, electro-dynamic speaker is mounted in the bottom of the housing so as to afford excellent tone quality and volume without the necessity of using a speaker as a separate unit.

All the tubes used are the latest Philco high-efficiency tubes, designed especially for automobile radio. Several of these tubes each perform the functions which formerly required two and three tubes, thereby effecting a great tube economy, reducing the number of tubes necessary for satisfactory operation, and reducing the amount of current taken from the car battery to the very minimum.

Philco's system of automatic volume control is used to give that smooth, elastic control which counteracts fading while driving along, and prevents blasting of local stations.

The new Receiver is All Electric, operating entirely from the car storage battery. The new Full Wave Philco Vibrator is built in as an integral part of the Receiver.

This Receiver is destined to be one of the most popular models we have ever offered to the public and will meet with instant approval from everyone as soon as it can be seen and heard. Ease of installation will enable service stations to cut their costs and speed up installations. Customers will wait for their cars while the installation is being made, since the average installation will be made in only a fraction of the time formerly required.

## THE NEW MODEL 6F

The Model 6 with the latest improvements becomes the Model 6F. The new features are entirely for your benefit. Greater ease of installation and service is accomplished, cutting the installation time practically in half.

The Model 6F is now a two-piece unit instead of having the customary three pieces. The new improved full wave EF Vibrator is securely attached to the side of the Receiver housing. Drilling three holes for the Receiver and installing it, automatically takes care of the Vibrator installation.

Connections, too, are much more simple. The battery cable plugs into the Receiver receptacle, while a leg of the cable connects by a plug to the Vibrator unit. Just one lead to connect to the battery and the antenna lead. Install the Receiver and connect the cable.

If the Vibrator requires servicing, remove four screws from the lid and the Vibrator lifts right out of the housing. The only service it should ever require will be either a replacement tube or a replacement Vibrator unit. Don't ever attempt to adjust the Vibrator.

## MODEL EG VIBRATOR

The Model EF Vibrator is a part of the Model 6F Receiver. Its counterpart for "B" battery replacement service is the Model EG Vibrator. Instead of being connected with a cable and plug, it is equipped with a terminal panel for easy installation.

When used as a replacement unit for "B" batteries, simply install in the old "B" battery box or in any place that is convenient and where the Vibrator will not be exposed to water and dirt. The installation is easy, but at the same time permanent.

Simplicity in construction insures freedom from trouble and efficient operation. Cut disc tungsten points eliminate

any possibility of troubles from contacts. Full wave rectification with the 84 rectifier tube developed especially for this type of service is used to give a smooth flow of power. Complete filtering eliminates all hum.

The terminal panel provides for the following connections:

A  $\pm$  terminal for control, connecting to the control relay.

+B terminal, 180 volts to 200 volts for the "B" lead to the Receiver.

INT+B terminal, an intermediate voltage for Receivers requiring a tap voltage.

—B terminal, for Receivers requiring this lead. Normally it is not grounded. This, however, can be accomplished by strapping to the GND terminal.

GND terminal for grounding the chassis.

## MODEL 5 ADJUSTMENTS

Become thoroughly familiar with the adjustment procedure and the location of the padding condensers before starting to adjust a Model 5 Receiver.

Furthermore, don't attempt to make the adjustments using a make-shift oscillator. The modern radio depends on critically tuned circuits for its exceptional performance. It is nothing short of gross carelessness to try to adjust these delicately tuned circuits using unstable oscillators which are incapable of being calibrated accurately.

Use a Philco 095 oscillator, or if your service department is fortunate enough to have one, the new Philco Signal Generator 048.

NOTE.—United Motors Service Stations, see U. M. S. Service Manual.

The intermediate frequency used is 460 K. C. Set up the oscillator or signal generator for this frequency.

Disconnect the grid lead from the 6A7 tube. Then connect the test lead to the grid of this tube and ground the shield on the Receiver housing. Use the fibre adjusting wrench 3164 for all adjustments.

Padder 10. Turn the adjusting nut in until tight. Then back off one full turn. Leave this condenser in this position until the last step.

Padder 11. This is the first I. F. primary condenser. With the Receiver and oscillator turned on and the oscillator set for 460 K. C., turn the Receiver volume control on full and adjust the oscillator attenuator. Then adjust the padder for maximum signal in the loud speaker.

Padder 13. This is the first I. F. secondary condenser. Adjust the attenuator so that the signal is barely audible. This should be repeated with each adjustment if necessary. Adjust the padder for maximum signal in the loud speaker. Repeat this procedure in the next two adjustments.

Padder 17. This is the second I. F. primary condenser.

Padder 20. This is the second I. F. secondary condenser.

Remove the oscillator connections from the 6A7 tube and reconnect the Receiver grid lead to this tube. The oscillator setting must now be changed to 1500 K. C.

The Receiver volume control must be turned on full, the oscillator lead connected to the antenna lead-in and the shield to the Receiver housing. To obtain the correct setting of the tuning condenser, open the plates as wide as possible. Place a piece of paper on the stator plates and then turn the rotor in until it strikes the paper.

Oscillator padder. This is the padder on the second section of the tuning condenser (section nearest drive mechanism). Adjust for maximum signal.

Antenna Padder. This is the remaining padder on the tuning condenser. Remove the paper from the tuning condenser and set the condenser and oscillator for 1400 K. C. Adjust the padder for maximum signal.

Low Frequency Padder 10. Set the oscillator for 600 K. C. and tune the Receiver to this frequency. Adjust the padder for maximum signal. After completing these operations, repad the antenna padder at 1400 K. C.

# PHILCO RADIO & TELEVISION CORP.

## PHILCO TRANSITONE MODEL 6

THE Philco Transitone Model 6 auto radio is a five-tube receiver of the superheterodyne type. Either a roof or capacity-plate aerial may be used, although the manufacturer advises the roof type.

The accessories in this receiver include the type EB dynamotor and kit of suppressors and condensers as standard equipment. No specific mounting locations have been furnished by the manufacturer, although it is recommended that the receiver be installed on the driver's side of the engine compartment on the bulkhead; as far to the right as possible; it may also be mounted on the dash. In the model A Ford, due to the location of the gas tank, the receiver must be mounted on the left side of the bulkhead in the engine compartment. The speaker should be mounted on the inside of the dash over the steering column or toward the center. In the model A Ford, the speaker should be mounted on brackets against the right kick pad.

The circuit of the Model 6 is of the superheterodyne type and uses the following tubes: One 36 as R.F. amplifier; one 36 as combination first-detector and oscillator; one 36 as I.F. amplifier (I.F. is 260 kc.); one 85 as second detector, A.V.C. and audio

amplifier; and one 41 as an output tube.

The Philco Transitone Model B6, made expressly for the Chrysler Corporation for installation in the 1933 Plymouth cars, is essentially the same in circuit design and base layout as the Model 6.

The difference between these models is in the assembly and the manner in which they are installed. In the B6, the receiver and dynamotor are located in a metal box (similar to a battery box) and the complete unit is installed in the floor of the car. The control unit is mounted in its usual place and the speaker is on the dash.

## PHILCO TRANSITONE MODEL 6F

THIS set, which incorporates the fundamental circuit of the model 6 chassis described below, is distinguished by its power supply; a vibrator-type "B" unit supplants the dynamotor and is incorporated in the receiver chassis. The model NF set is optional equipment, through United Motors Service, on the following makes of cars: Auburn, Chrysler, Cord, DeSoto, Dodge, Essex, Franklin, Hudson, Hupmobile, Nash, Rockne and Studebaker. (A special set is available for Packards.) The installation time for a model 6F job is only about 1 hour.



## PHILCO TRANSITONE MODEL 7

THE Transitone Model 7 receiver is a five-tube auto-radio receiver. The accessories in this set include ignition noise suppression equipment and the type EA dynamotor.

Installation of this receiver is made on the inside of the dash, as high and far to the right as possible. Clinch-on nuts are provided so that the receiver may be mounted on the dash in either position. In the model A Ford, the set should be placed on the left side of the dash on the engine side of the bulkhead because of the location of the gas tank. The speaker should be mounted on the inside of the dash either over the steering column or near the center. In the model A Ford, the speaker should be mounted on brackets against the right kick pad. The control unit is mounted on the steering column.

The circuit of the Model 7 is of the superheterodyne type and uses the following tubes: One 36 as an R.F. amplifier; one 36 as a combination first detector and oscillator; one 36 as an I.F. amplifier (I.F. is 175 kc.); one 38 as a second detector and A.V.C.; and one 41 in the output stage.

The model EA dynamotor, or batteries, (180 volts) may be used with this receiver. Terminal connections and a diagram of the EA dynamotor are shown here.



# PHILCO RADIO & TELEVISION CORP.

## PHILCO TRANSITONE MODELS 8 AND 12

THESE two receivers are identical except for the fact that the Model 12 is designed for operation from a 12-volt storage battery. The filament connections of the Model 12 are shown here.

The installation data for these receivers are the same as for the Model 7 receiver except for the cable connections: in the Models 8 and 12, the speaker and battery cables and the antenna lead are all formed in a one-piece cable which is totally shielded. The Model EA dynamotor is supplied

as standard equipment on the Model 8 set, and the Model EC dynamotor is supplied as standard equipment with the model 12 receiver. The size of these dynamotors is approximately 6½ x 8-7/16 inches.

These receivers are six-tube superheterodynes using the following tubes: one 36 as an R.F. amplifier; one 36 as a combination detector-oscillator; one 36 as an I.F. amplifier (I.F. is 175 kc.); one 38 as a second detector and A. V. C.; two type 41 tubes in the push-pull output stage. The "B" supply is 180 volts. A dynamic speaker is employed. As in other Philco Transitone auto receivers, ignition-noise sup-






pression equipment is supplied as an accessory.

All Philco Transitone Model 12's manufactured after January 1, 1933, are similar to the Model 9, except that they are designed for operation on 12-volt bus and boat batteries.


## PHILCO TRANSITONE MODEL 9

THE Model 9 receiver is a six-tube superheterodyne receiver. The mechanical details are essentially the same as for the Models 7, 8, and 12. The electrical characteristics of this receiver are the same for the Model 6 discussed previously, and, therefore, reference should be made to that description. The tubes used are as follows: One 36 as an R.F. amplifier; one 36 as a combination first-detector and oscillator; one 36 as I.F. amplifier (I.F. is 260 kc.); one 85 as second-detector, A.V.C., and audio amplifier; one 37 in an audio stage; and one 79 in the output stage.

The "B" supply is furnished by a type ED dynamotor which supplies 220 volts.



# PHILCO RADIO & TELEVISION CORP.



Schematic Wiring Diagram

NOTE: FIGURES INDICATE RELATIVE POSITION OF SECTIONS FROM FRONT OF CHASSIS.



# PHILCO RADIO & TELEVISION CORP.

## Model 16

THE PHILCO RADIO MODEL 16 is an eleven-tube superheterodyne broadcast and short-wave receiver, operating upon alternating current and employing the high-efficiency 6.3 volt tubes, automatic interstation noise suppression, and a frequency (wave-band) coverage that permits reception of the short-wave (high-frequency) broadcast programs. The same superheterodyne circuit is used for all reception. The Receiver is equipped with a five-point wave-band switch. The ranges are—

- (1) 520 K. C. to 1500 K. C.
- (2) 1.5 M. C. to 4.0 M. C.
- (3) 3.2 M. C. to 6.0 M. C.
- (4) 5.8 M. C. to 12.0 M. C.
- (5) 11.0 M. C. to 23.0 M. C.

The Receiver employs a Philco Type 77 tube for first detector, a Type 76 for oscillator, a Type 78 for first I. F., a Type 78 for second I. F., and a Type 37 for second detector. The automatic interstation noise suppression circuit uses a Type 78, the first A. F., a Type 77. The driver (second A. F.) is a Type 42; the class "A" amplification is accomplished with two Type 42 tubes as triodes; the rectifier is a Type 5-Z-3. The intermediate frequency is 460 kilocycles. The power consumption of Model 16-122 is 130 watts; of Model 16-121, 120 watts.

Table 1—Tube Socket Data\*—A. C. Line Voltage 115 Volts

Circuit	1st Det.	Osc.	1st. I. F.	2nd I. F.	2nd Det.	Inter-Station Noise Supr. Circuit	1st A. F.	2nd A. F. (Driver)	Output		Rectifier
Type Tube	77	76	78	78	37	78	77	42	42	42	5-Z-3
Filament Volts—F to F.....	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	4.7
Plate Volts—P to K.....	220	53	225	230	0	1.8	130	220	340	340	400
Screen Grid Volts—SG to K....	80	—	80	80	—	1.8	1.8	220	340	340	—
Control Grid Volts—CG to K...	1.6	6.4	0	0	.2	1.6	.4	.6	34	34	—
Cathode Volts—K to F.....	4.2	1.9	2.2	2.5	0	0	0	0	0	0	—

NOTE—These values are for Model 16-122. Model 16-121 uses a Type 80 Rectifier Tube. See Note, page 4, at end of Replacement Parts List.

\* All of the above readings were taken from the underside of the chassis, using test prods and leads, with a suitable A. C. voltmeter for filament voltages, and a high-resistance multi-range D. C. voltmeter for other readings. The Philco Model 048 All-Purpose Set Tester is highly recommended for this use. Volume control set at maximum and station selector turned to low frequency end; interstation noise suppression circuit potentiometer turned all the way to the right; and toggle switch (interstation noise suppression circuit) in "ON" ("S") position. Readings taken with a plug-in adapter will NOT be satisfactory.





Table 2—Power Transformer Data

Terminal	A. C. Volts	Circuit	Color
1—2	105—125	Primary	White
3—5	6.3	Filament	Black
6—7	5.0	Filament of 5-Z-3	Blue
8—10	800	Plates of 5-Z-3	Yellow
4	—	Center Tap of 3—5	Black—Yellow Tracer
9	—	Center Tap of 8—10	Yellow—Green Tracer



Terminal Arrangement of Tube Sockets Viewed from Underside of Chassis

## PHILCO RADIO & TELEVISION CORP.



Bottom View of Chassis, Showing Parts

Inability of a suitable radio receiver to pick up signals upon the shorter waves (higher frequencies) frequently can be traced to the aerial itself. A relatively short, but efficiently designed, aerial will give better results on the short waves than one which has a long and involved lead-in. Extreme care should be exercised in the installation of the Model 16, that it may have every opportunity to bring in *all* the frequencies. Instruction should be given the customer in tuning in the shorter waves, which are characteristically difficult for a novice. Attention should be called to the time-difference existing, that the listener may not listen at such hours as a desired station is *not* transmitting. Much good will be accomplished by a thorough instruction of the customer. Philco distributors are prepared to supply special aerial equipment, especially designed for reception of the short waves.

### ADJUSTMENT OF MODEL 16 SERIES

These receivers are adjusted accurately at the factory prior to shipment. Under normal conditions it is not necessary to readjust the compensating condensers. If such adjustment becomes necessary, it should not be attempted without first making sure that proper instructions and suitable equipment are at hand. Philco distributors are in a position to supply both. The Philco Model 048 All-Purpose Set Tester contains a variable-frequency signal generator covering all frequencies between 105 K. C., and 2000 K. C., and is highly recommended for all required adjustments.

# PHILCO RADIO & TELEVISION CORP.

## REPLACEMENT PARTS FOR MODEL 16


No. on Figs.	Description	Part No.	List Price	No. on Figs.	Description	Part No.	List Price
①	Wave Band Switch	42-1037		④⑤	Compensating Cond'ser (3d, I. F. Primary)	31-6003	
②	Tuning Condenser Assembly	31-1039		④⑥	3d, I. F. Transformer	32-1188	
③	Compensating Condenser (Wave-trap)	38-5190		④⑦	Compensating Cond'r (3d, I. F. Secondary)	Common with ④⑤	
④	Inductance (Wave-trap)			{ Assembly }	④⑧	Condenser	3615-AS
⑤	Condenser	5858	.16	④⑨	Resistor (Part of ④⑨)		
⑥	Compensating Condenser (Ant.; H. F.; Part of ②)			⑤①	Resistor (White-White-Orange)	4411	.20
⑦	Compensating Condenser (Ant.; Broadcast and Police; Part of ②)			⑤②	Condenser	4519	.18
⑧	Antenna Transformer (H. F. Bands)	32-1183		⑤②a	Condenser	4519	.18
⑨	Antenna Transformer (B'dc't & Police B'ds)	32-1182		⑥②	Condenser (Double)	7296-G	
⑩	Resistor (Brown-Black-Orange)	4412	.20	⑥③	Resistor (Yellow-Black-Green)	6010	.20
⑪	Compensating Condenser (Range 3)	04000-V	.16	⑥④	Switch (Toggle); Interstation Noise Suppression Circuit	42-1036	.40
⑫	Condenser	30-1000	.20	⑥⑤	Volume Control and "On-Off" Switch	33-5013	1.00
⑬	Compensating Condenser (Range 2; series)	04000-R	.35	⑥⑥	Resistor (Green-Black-Red)	5310	.20
⑭	Compensating Condenser (Range 1; series)	04000-R	.35	⑥⑦	Condenser	3903-J	.20
⑮	Condenser	3615-L	.16	⑥⑧	Condenser	4519	.18
⑯	Resistor (Green-Black-Red)	5310	.20	⑥⑨	Condenser	3615-AD	.20
⑰	Condenser	5886	.25	⑥⑩	Resistor (White-White-Orange)	4411	.20
⑱	Resistor (Brown-Black-Orange)	4412	.20	⑥⑪	Resistor (Violet-Black-Orange)	5385	.20
⑲	Oscillator Coil (H. F.)	32-1185		⑥⑫	Filter Condenser Bank	30-4026	3.00
⑳	Condenser	7301	.35	⑥⑬	Resistor (Brown-Blue-Yellow)	5331	.20
㉑	Resistor (Brown-Black-Orange)	4412	.20	⑥⑭	Resistor (White-White-Orange)	4411	.20
㉒	Compensating Condenser (Range 1; Shunt)	0-4000-A	.12	⑥⑮	Condenser (Double)	6287-J	
㉓	Oscillator Coil (Broadcast and Police)	32-1184		⑥⑯	Input Transformer	32-7057	2.25
㉔	Compensating Condenser (Osc.; H. F.; Part of ②)			⑥⑰	Resistor (Brown-Black-Orange)	3524	.20
㉕	Compensating Condenser (Osc.; Police; Part of ②)			⑥⑱	Condenser	3903-F	.15
㉖	Resistor (Flexible Wire-wound; Green-Black-Brown)	6977	.20	⑥⑲	Output Transformer	32-7052	
㉗	Condenser	5863	.18	⑦①	Voice Coil and Cone Assembly	36-3061	.75
㉘	Resistor (Green-Brown-Orange)	4237	.25	⑦②	Speaker Field, Assembled with Pot (U-2)	36-3088	
㉙	Compensating Cond'ser (1st, I. F. Primary)	31-6002		⑦③	Resistor (Brown-Black-Green)	4409	.20
㉚	1st, I. F. Transformer	32-1186		⑦④	Resistor (Wire-wound)	33-3020	.30
㉛	Compensating Cond'r (1st, I. F. Secondary)	Common with ㉚		⑦⑤	Resistor (Brown-Black-Green)	4409	.20
㉜	Condenser	3615-AB	.20	⑦⑥	Condenser (Electrolytic)	30-2003	.70
㉝	Resistor (Flexible Wire-wound; Orange-Black-Brown)	33-3010	.15	⑦⑦	Resistor (Yellow-White-Yellow)	4517	.20
㉞a	Condenser	3615-AT	.20	⑦⑧	Condenser (Internal to ⑦⑨)		
㉞b	Resistor (Red-Black-Green)	5872	.20	⑦⑨	Tone Control	30-4033	
㉟	Condenser	3615-D	.18	⑧①	Condensers (External to ⑦⑨)	06713	.45
㊱	Resistor (Brown-Green-Green)	7009	.20	⑧②	Voltage Divider Resistor (Wire-wound)	33-3021	.16
㊲a	Resistor (White-White-Orange)	4411	.20	⑧③	Potentiometer (Interstation Noise Suppression Circuit)	33-5015	.80
㊲b	Resistor (Yellow-White-Yellow)	4517	.20	⑧④	Resistor (Brown-Black-Orange)	3524	.20
㊲c	Compensating Cond'ser (2d, I. F. Primary)	31-6002		⑧⑤	Resistor (Brown-Orange-Orange)	6450	.35
㊲d	2d, I. F. Transformer	32-1186		⑧⑥	Filter Choke	32-7056	1.85
㊲e	Compensating Cond'r (2d, I. F. Secondary)	Common with ㊲c		⑧⑦	Condenser	6287-F	.12
㊲f	Condenser	3615-AT	.20	⑧⑧	Condenser (Electrolytic)	30-2011	1.25
㊲g	Resistor (Flexible Wire-wound; Green-Black-Brown)	6977	.20	⑧⑨	Condenser (Electrolytic)	30-2011	1.25
㊲h	Pilot Lamp (Station Selector)	6608	.12	⑧⑩	Power Transformer (50-60 ~)	32-7058	5.00
㊲i	Shadow Tuning Meter	6497	2.25	⑧⑪	Condenser (Double)	3793-E	.20
㊲j	Pilot Lamp (Shadow Tuning Meter; Part of ㊲h)			⑧⑫	Resistor (Brown-Green-Orange)	5718	.40
					Tube Shield	28-1107	.10
					Four-prong Socket	7545	.08
					Five-prong Socket	7546	.10
					Six-prong Socket	7547	.10
					Knob (Large)	03063	.08
					Knob (Small)	03064	.06

NOTE.—Model 16-121 uses a Type 80 tube in lieu of 5-Z-3. Parts used in the 16-121 chassis that differ from the 16-122 parts above listed are:

⑧⑬	Power Transformer (50-60 ~)	32-7080		Speaker	K-17	
⑧⑭	Condenser (Electrolytic) (8.0 Mfd.)	6706	1.50	Speaker Socket	7084	
⑧⑮	Condenser (Electrolytic) (8.0 Mfd.)	7464	1.25	Speaker Cable	L1632	

# PHILCO RADIO & TELEVISION CORP.


## Model 37



Schematic Wiring Diagram

Table 1—Tube Socket Data

Tube Type	Circuit	Filament Volts F to F	Plate Volts P to K	Screen Grid Volts SG to F	Control Grid Volts CG to F	Cathode Volts K to F
15	Det.-Osc.	1.9	120(P to K)	60(SG to K)	2.5(CG to K)	5.5
32	I.F.	1.9	120	60	2.5	...
32	2nd Det.	1.9	2.0	45	2.5	...
30	1st Audio	1.9	110	..	4	...
19	Output	2.0	120/Plate	..	.4/Grid	...



PHILCO RADIO & TELEVISION CORP.

PHILCO

REG. U.S. PAT. OFF.

Service Bulletin — No. 138


Model 43

The Philco Radio of the 43 Series is an eight tube superheterodyne short wave and broadcast wave combination, employing the high efficiency 6.3 volt filament tubes, automatic volume control and pentode output. The same superheterodyne circuit is employed for both short wave and broadcast wave ranges, with an intermediate frequency of 450 kilocycles. Four tuning ranges on the dial are provided, these being controlled by the wave change switch. The ranges are as follows:

- Position 1.....550 KC to 1400 KC
- Position 2.....1.4 MC to 3.4 MC
- Position 3.....3.3 MC to 9.0 MC
- Position 4.....8.5 MC to 20.0 MC

The chassis is made in two different types, one known as the 121 code, employing a single dynamic speaker, and the other known as the 221 code, employing twin dynamic speakers. These code numbers appear on the radio chassis as a part of the model number. Chassis of one code are not interchangeable with those of another. The power consumption of the various models is as follows:

Chassis	Volts	Cycles	Watts
43-121	115	50-60	65
43-221	115	50-60	88
43-121	115	25-40	67
43-121	230	50-60	65
43-221	230	50-60	88



F—Filament  
P—Plate  
SG—Screen Grid  
CG—Control Grid  
K—Cathode

Tube Sockets, Under Side of Chassis

Caution:—Never connect the chassis to the power supply unless the speakers are connected and all tubes are in place.

Table 1—Tube Socket Data\*—A. C. Line Voltage 115 Volts

Type	Tube	Circuit	Filament Volts F to F	Plate Volts P to K	Screen Grid Volts SG to K	Control Grid Volts CG to K	Cathode Volts K to F
37	Osc.		6.3	175	—	6.	—
36	1st Det.		6.3	235	80	3.0	12.0
44	1st I. F.		6.3	235	80	.2	3.0
44	2nd I. F.		6.3	235	80	3.5	3.5
37	2nd Det.		6.3	0	—	0	0
44	1st Audio		6.3	45	45	.2	2.0
42	Output		6.3	215	240	.4	15.0
80	Rectifier		5.0	350/Plate			

\*All of the above readings were taken from the under side of the chassis, using test prods and leads with a suitable A. C. voltmeter for filament voltages and a high resistance, multi-range D. C. voltmeter for all other readings. Volume control at maximum and switch and station selector set for 550 KC. Readings taken with a radio set tester and plug-in adaptor will not be satisfactory.

Table 2—Power Transformer Data

Terminals	A. C. Volts	Circuit	Color
1-2	105 to 125	Primary	White
3-5	6.3	Filaments	Black
6-7	5.0	Filament of 80	Blue
8-10	685	Plates of 80	Yellow
4	....	Center Tap of 3-5	Black Yellow Tracer
9	....	Center Tap of 8-10	Yellow Green Tracer


Table 3—Resistor Data

No. on Figs.	Power (Watts)	Resistance (ohms)	COLOR		
			Body	Tip	Dot
			Flexible Wire		
26	.5	500	Brown	Black	Red
33	.5	1,000	Red	Black	Red
43	.5	2,000	Green	Black	Red
58	1.0	5,000	Green	Black	Red
59	...	5,620	Long	Tubular	
62	1.0	10,000	Brown	Black	Orange
37	.5	10,000	Brown	Black	Orange
74	.5	13,000	Brown	Orange	Orange
60	.5	25,000	Red	Green	Orange
27	.5	25,000	Red	Green	Orange
64	.5	70,000	Violet	Black	Orange
62	.5	99,000	White	White	Orange
22	.5	490,000	Yellow	White	Yellow
62	.5	1,000,000	Brown	Black	Green
26	.5	2,000,000	Red	Black	Green
58					
55					

# PHILCO RADIO & TELEVISION CORP.

## PHILCO Service Bulletin


### Model 43




Schematic Wiring Diagram

# PHILCO RADIO & TELEVISION CORP.

## Model 43



Parts Diagram



Twin Speaker Connections—221 Code




Fig. 5—Speaker Connections—121 Code

### Adjustment of Model 43 Series

These receivers are accurately adjusted at the factory prior to shipment. Under normal conditions it will never be necessary to re-adjust the compensating condensers. If for any reason such adjustment should be required, it should not be attempted without first receiving the proper instruction and equipment from your distributor. The Philco Oscillator equipment has been especially designed for use in this work and will be found the most inexpensive and most reliable for the purpose.

# PHILCO RADIO & TELEVISION CORP.

## PHILCO Service Bulletin

### Replacement Parts Model 43

No. on Figs. 2 and 3	Description	Part No.	List Price	No. on Figs. 2 and 3	Description	Part No.	List Price
①	Wave Change Switch	05617		⑥1	Condenser (110 mmf.)	4519	.18
②	Condenser (410 mmf.)	5120	.18	⑥2	Resistor (99,000 ohms)	4411	.25
③	Compensating Condenser—450 K. C. Wave Trap	04000B	.18	⑥3	Condenser (110 mmf.)	4519	.18
④	R. F. Choke	05191	.15	⑥4	Volume Control and On-Off Switch	6892	1.25
⑤	Resistor (2,000 ohms)	6984	.25	⑥5	Condenser (.01 mfd.)	3903F	.15
⑥	Condenser (1000 mmf.)	5215	.20	⑥6	Resistor (1,000,000 ohms)	4409	.25
⑦	Antenna Coupling Coil	05189	.50	⑥7	Wire Wound Resistor (185 and 245 ohms)	6452	.16
⑧	Antenna Transformer*	06404		⑥8	Resistor (5,000 ohms)	3526	.25
⑧a	Condenser (3,000 mmf.)	6009	.30	⑥8	Resistor (5,000 ohms)	3526	.25
⑨	Resistor (1,000 ohms)	5837	.25	⑥8	Resistor (13,000 ohms)	6450	.35
⑩	Oscillator Coil*	05624		⑥1	Condenser (.01 mfd.)	3903N	.16
⑪	Condenser (1,650 mmf.)	5877	.30	⑥2	Resistor (70,000 ohms)	5385	.25
⑫	Condenser (1,250 mmf.)	5886	.25	⑥3	Resistor (490,000 ohms)	4517	.25
⑬	Compensating Condenser—1400 K. C. End of Second Band	04000F	.16	⑥4	Resistor (25,000 ohms)	4516	.25
⑭	Condenser (250 mmf.)	3082	.20	⑥5	Condenser (.01 mfd.)	3903AA	.14
⑮	Compensating Condenser—600 K. C. End of First Band	04000F	.16	⑥6	Tone Control	05174	.16
⑯	Condenser (250 mmf.)	3082	.20	⑥7	Output Transformer	2580	1.25
⑰	Compensating Condenser—8 Megacycle End Third Band	04000V		⑥8	Voice Coil and Cone Assembly	02823	.45
⑱	Tuning Condenser Assembly	05154		⑥9	Speaker Field and Bucking Coil Assembled with Pot (K-7)	02761	2.25
⑲	Grid Coil (Top of Chassis)	05190	.25	⑦0	Condenser (.015 mfd. Double)	3793K	.20
⑳	Compensating Condenser (Part of Tuning Cond. Assembly)			⑦1	Power Transformer—50-60 Cycles, 115 Volts, Single Speaker Models	7074	3.50
㉑	Compensating Condenser (3.5 Megacycle End of Second Band)	04000V			25-40 Cycles, 115 Volts, Single Speaker Models	7075	6.75
㉒	Resistor (99,000 ohms)	4411	.25		50-60 Cycles, 230 Volts, " " "	7076	4.00
㉓	Neutralizing Condenser (Top of Chassis)	04000V			50-60 Cycles, 115 Volts, Twin Speaker Models	6985	4.50
㉔	Condenser (1000 mmf.)	5837	.25		50-60 Cycles, 230 Volts, " " "	6986	5.25
㉕	Condenser (50 mmf.) (Top of Chassis)	3774	.25	㉗	Electrolytic Condenser (6 mfd.) 50-60 Cycles	4916	1.75
㉖	Resistor (490,000 ohms)	4517	.25		Electrolytic Condenser (8 mfd.) 25-40 Cycles	6707	1.50
㉖a	Compensating Condenser (1400 K. C. End of First Band)	04000F	.16	㉘	Resistor (10,000 ohms)	4412	.25
㉗	Resistor (25,000 ohms)	4516	.25	㉙	Condenser (.05 mfd.)	3615AD	.20
㉘	Condenser (.05 mfd.)	3615E	.20	㉚	Electrolytic Condenser (6 mfd.) 50-60 Cycles	4916	1.75
㉙	Resistor (500 ohms)	6977	.20		Electrolytic Condenser (8 mfd.) 25-40 Cycles	6706	1.50
㉚	Compensating Condenser	04000C	.08	㉛	Output Transformer—Twin Speaker	2564	1.35
㉛	Compensating Condenser—1st I. F. Primary	04000M	.16	㉜	Voice Coil and Cone Assembly	02823	.45
㉜	First I. F. Transformer	05185	.55	㉝	Voice Coil and Cone Assembly	02823	.45
㉝	Compensating Condenser—1st I. F. Secondary	04000M	.16	㉞	Speaker Field and Bucking Coil Assembled with Pot (K-9)	02762	2.75
㉞	Condenser (.05 mfd.)	3615W	.16	㉟	Speaker Field and Bucking Coil Assembled with Pot (K-10)	02767	2.25
㉟	Resistor (2,000,000 ohms)	5872	.25	㊱	Condenser (.5 mfd.)	05150	.50
㊱	Condenser (.05 mfd.)	3615J	.18	㊲	Wire Wound Resistor (5,620 ohms) Twin Speaker	6451	.30
㊲	Resistor (10,000 ohms)	3524	.25		Tube Shield	5387	.05
㊳	Resistor (500 ohms)	6977	.20		Knob (Large)	03063	.08
㊴	Compensating Condenser—2nd I. F. Primary	04000M	.16		Knob (Medium)	03064	.06
㊵	Second I. F. Transformer	05185	.55		Knob (Small)	03437	.02
㊶	Compensating Condenser—2nd I. F. Secondary	04000X	.16		Knob Spring (Large)	5262	.35 per C
㊷	Condenser (.05 mfd.)	3615W	.16		Knob Spring (Small)	4147	.01
㊸	Resistor (500 ohms)	6977	.20		Grid Clip	4897	.30 per C
㊹	Filter Condenser Bank (.25, 2-.5 mfd.)	05239	1.00		Four Prong Socket Assembly	5026	.08
㊺	Filter Choke	5930	1.40		Five Prong Socket Assembly	4956	.10
㊻	Condenser (.05 mfd. and Resistor 250 ohms)	3615AS	.25		Six Prong Socket Assembly	6417	.10
㊼	Electrolytic Condenser	7556	1.25		Dial Complete	05418	.55
㊽	Compensating Condenser—3rd I. F. Primary	04000M	.16		Bezel	6826	.20
㊾	Third I. F. Transformer	05185	.55		Tuning Condenser Drive Cord	04834	.12
㊿	Compensating Condenser—3rd I. F. Secondary	04000M	.16		Spring	6508	1.60 per C
					Chassis Mounting Screw	W-468	3.50 per C
					Mounting Washer	W-315	.40 per C
					Rubber Washer	5189	.03

\*Supplied in matched pair—Antenna and oscillator coils.

## PHILCO RADIO & TELEVISION CORPORATION




# PHILCO RADIO & TELEVISION CORP.

## Model 48

The Model 48 is a four tube, 115 volt direct current operated superheterodyne receiver, designed for operation on 540 to 1500 kilocycles.

This model contains a type 36 screen grid tube for combination first detector and oscillator, a type 44 r. f. pentode tube as intermediate frequency amplifier, a type 36 screen grid tube as second detector, and a type 43 pentode tube as output. A type 9 ballast tube is used for automatic voltage regulation. All of these tubes are the new Philco high efficiency type which consume a minimum of current.

The intermediate frequency of this model is 175 kilocycles. The power consumption is 40 watts.



F—Filament  
P—Plate  
SG—Screen Grid  
CG—Control Grid  
K—Cathode

### Tube Sockets, Under Side of Chassis


Caution.—Never connect the chassis to the power supply unless the speaker is connected and all tubes are in place.

Table 1—Tube Socket Data—D.C. Line Voltage 125 Volts

Valve		Filament Volts F to F	Plate Volts P to K	Screen Grid Volts SG to K	Control Grid Volts CG to K	Cathode Volts K to F
Type	Circuit					
36	Det.-Osc.	6.3	100	55	3.0	.5
44	I.F.	6.3	70	70	4.5	10.
36	2nd Det.	6.3	37	35	3.0	.5
43	Output	25.0	100	105	.4	.4
9	Ballast	50	...	...	...	...

Table 2—Resistor Data


Nos. on Figs. 3 and 4	Resistance (Ohms)	Power (Watts)	Color		
			Body	Tip	Dot
(26)	30 & 140	...	Wire	Wound	
(21)	250	...	Combined with	.05 Mfd: Condenser	
(20)	1000	.5	Brown	Black	Red
(14)	8000	.5	Gray	Black	Red
(34)	25,000	1.	Red	Green	Orange
(35)	32,000	1.	Orange	Red	Orange
(29) (31)	51,000	.5	Green	Brown	Orange
(25)	10,000	2.	Brown	Black	Orange
(32) (33) (41)	99,000	.5	White	White	Orange
(36)	240,000	.5	Red	Yellow	Yellow
(40)	490,000	.5	Yellow	White	Yellow
(9)	1,000,000	.5	Brown	Black	Green



Internal Connections Filter Condenser

# PHILCO RADIO & TELEVISION CORP.


## Model 48



Schematic Wiring Diagram

# PHILCO RADIO & TELEVISION CORP.

## Model 48



Under Side of Chassis Showing Parts

# PHILCO RADIO & TELEVISION CORP.

## ADJUSTMENT OF MODEL 48

These receivers are accurately adjusted at the factory prior to shipment. Under no circumstances are the compensating condensers to be changed in the field unless the proper instructions and equipment are available. This adjustment requires special oscillator equipment which can be obtained from all Philco distributors.

## Replacement Parts for Model 48

No. on Figs. 3 and 4	Description	Part No.	No. on Figs. 3 and 4	Description	Part No.
①	Condenser (.01 Mfd.)	3903-T	②⑧	Resistor (51,000 Ohms)	4518
②	Volume Control (5,000 Ohms)	5839	③⑨	Condenser (250 Mmf.)	3082
③	Condenser (.01 Mfd.)	3903-AK	④⑩	Resistor (51,000 Ohms)	4518
④	Condenser (2 Mfd.)	05518	⑤⑪	Resistor (99,000 Ohms)	4411
⑤	Antenna Transformer	05848	⑥⑫	Resistor (99,000 Ohms)	4411
⑥	Tuning Condenser Assembly	05885	⑦⑬	Resistor (25,000 Ohms)	3656
⑦	Compensating Cond.—Antenna—Part of Tuning Condenser Assembly		⑧⑭	Resistor (32,000 Ohms)	3525
⑧	Detector Transformer	05849	⑨⑮	Pilot Light	6608
⑨	Resistor (1,000,000 Ohms)	4409	⑩⑯	Condenser (250 Mmf.)	3082
⑩	Condenser (.05 Mfd.)	3615-J	⑪⑰	Condenser (.01 Mfd.)	3903-F
⑪	Compensating Cond.—Detector, Part of Tuning Condenser Assembly		⑫⑱	Resistor (240,000 Ohms)	4410
⑫	Comp. Cond. First I.F. Primary	04000-A	⑬⑲	Resistor (490,000 Ohms)	4517
⑬	Oscillator Coil		⑭⑳	Resistor (99,000 Ohms)	4411
⑭	Resistor (6,000 Ohms)		⑮㉑	Condenser (.01 Mfd.)	3903-F
⑮	Condenser (710 Mmf.)	5863	⑯㉒	Condenser .01 Mmf. (assembled with ⑳)	3903AK
⑯	Condenser (.05 Mfd.)	3615-AC	⑰㉓	Condenser (1 Mfd.)	05518
⑰	Compensating Cond.—High Frequency —Part of Tuning Condenser Assembly		⑱㉔	Output Transformer	2660
⑱	Comp. Condenser Low Frequency	04000-F	㉑	Choke	4951
⑲	Condenser (710 Mmf.)	5863	⑳	Voice Coil and Cone Assembly	02861
⑳	Resistor (1000 Ohms)	5837	㉒	Speaker Field Assembly with Pot	02671
㉑	Condenser (.05 Mfd. and Resistor 250 Ohms)	3615-C	㉓	On-Off Switch Assembly with Volume Control	5839
㉒	First I.F. Transformer	04887	㉔	Condenser (.015 Mfd. Twin)	3793-P
㉓	Comp. Cond. First I.F. Secondary	04000-A		Tube Shield	03169
㉔	Second I.F. Transformer	03887		Knob	03064
㉕	Resistor (10,000 Ohms)	4237		Knob Spring	5262
㉖	Resistor—Wire Wound—(140 Ohms and 30 Ohms)	06200		Grid Clip	4897
㉗	Compensating Condenser, Second I.F. Secondary	04000-A		Four Prong Socket	5026
㉘	Filter Condenser Bank (.1, .15, .25, 2-.5 Mfd.)	05569		Five Prong Socket	4956
				Six Prong Socket	6417
				Pilot Light Bracket Complete	05603
				Dial Complete	05811
				Bezel	6413

**PHILCO RADIO & TELEVISION CORPORATION**


Service Department

PHILCO RADIO & TELEVISION CORP.

PHILCO  
REG. U.S. PAT. OFF


Service Bulletin — No. 147

Adjusting Models 48, 89 and 19




Back of Model 48 Chassis, showing location of Compensating Condensers

NOTE:—The 2nd I.F. Secondary Condenser is mounted on the front of the Chassis, but accessible through the opening in the back as shown




Tuning Condenser, Model 48 Chassis, showing location of additional Compensating Condensers



Back of Model 89 and 19 Chassis, showing location of Compensating Condensers

NOTE:—I.F. Frequency in 89 and 19 is 260 K.C.



Top View of Chassis showing Tuning Condensers, Models 89 and 19, also additional Compensating Condensers

The general method of adjusting the Philco Models 48, 89 and 19 is the same as that for other models as outlined in Service Bulletin No. 120-C. The adjustment of the I.F. Compensating Condensers is completed first. This adjustment is then followed by the adjustment of the high frequency and Antenna Condensers, and finally the low frequency condenser.

It is necessary to have an accurately calibrated oscillator signal at 175 K.C. and 260 K.C. for adjusting the I.F. Compensating Condensers on the above Models 48, 89 and 19. The Philco Oscillators Models 095 or 095B are accurately calibrated for these frequencies.

Use Philco replacement parts and tubes for every make of radio. Get a complete catalogue from your Distributor.

PHILCO RADIO & TELEVISION CORPORATION

Service Department


PHILCO RADIO & TELEVISION CORP.

PHILCO  
REG. U.S. PAT. OFF.

Service Bulletin—No. 149

Model 53

The Philco Radio Model 53 is a four tube superheterodyne, employing the new Philco high efficiency tubes with pentode output and a permanent Field Dynamic Speaker. The set uses a Philco Type 77 tube as a first detector and oscillator, a Type 77 tube as second detector, a Type 43 tube as output, and a Type 12-Z-3 as a rectifier. The set will operate universally on either alternating or direct current, 105-125 Volts. The intermediate frequency for tuning the I.F. transformer is 450 kilocycles. The power consumption on both A. C. and D. C. is approximately 45 watts.



F Filament                      SG Screen Grid                      K Cathode  
P Plate                              CG Control Grid                      SP Suppressor Grid

Tube Sockets, Under Side of Chassis

Table 1—Tube Socket Data\*—A.C. Line Voltage 115 Volts

Circuit	Det. Osc.	2nd Det.	Out-put	Rectifier
Type Tube	77	77	43	12-Z-3
Filament—Total 49.9 Volts A. C.	Refer	to Note.		
Plate Volts—P to K.....	95	15	94	112
Screen Grid Volts—SG to K...	94	34	102	....
Control Grid Volts—CG to K...	7	4	4	....
Cathode Volts—K to F.....	18	12	10	112

NOTE:—Refer to Fig. 3. Due to filaments in series, test with suitable A. C. voltmeter across the two points indicated.


\*All of the readings above in Table 1 were taken from the under side of chassis, using test prods and leads with a suitable A. C. voltmeter for filament voltage and a high resistance, multi-range D. C. voltmeter for all other readings. Volume control at maximum and station selector set for 550 KC. Readings taken with a radio set tester and plug-in adapter will not be satisfactory.

Table 2—Tube Socket Data\*—D.C. Line Voltage 120 Volts


Circuit	Det. Osc.	2nd Det.	Out-put	Rectifier
Type Tube	77	77	43	12-Z-3
Filament—Total 51 Volts D.C.	Refer	to Note.		
Plate Volts—P to K.....	95	14	94	10
Screen Grid Volts—SG to K...	93	34	100	....
Control Grid Volts—CG to K...	8	3	4	....
Cathode Volts—K to F.....	7-14	6-12	3-26	58-73

NOTE:—Refer to Fig. 3. Due to filaments in series, test with suitable D.C. Voltmeter across the two points indicated.

\*All of the readings above in Table 2 were taken from the under side of chassis, using test prods and leads with a suitable high resistance, multi-range D. C. voltmeter for all readings. Volume control at maximum and station selector set for 550 KC. Readings taken with a radio set tester and plug-in adapter will not be satisfactory.



Top View of Chassis, Showing Parts




Bottom View of Chassis, Showing Parts

NOTE:—Place test prods across the two points indicated to test filament voltage.

# PHILCO RADIO & TELEVISION CORP.

## PHILCO Service Bulletin

### Model 53



-Schematic Wiring Diagram

NOTE ④—This capacity obtained by pair twisted wires

### Replacement Parts for Model 53


No. on Figs. 2, 3 and 4	Description	Part No.	No. on Figs. 2, 3 and 4	Description	Part No.
①	Volume Control	33-5001	㉓	Condenser (.01 Mfd.)	3903-AM
②	Antenna Transformer	32-1000	㉔	Resistor (240,000 ohms) Red-Yellow-Yellow	4410
③	Tuning Condenser Assembly	31-1000	㉕	Resistor (490,000 ohms) Yellow-White-Yellow	4517
④	Compensating Condenser (Part of Tuning Condenser Assembly)		㉖	Resistor (51,000 ohms) Green-Brown-Orange	4518
⑤	Filter Condenser Block (.05-.09-.25-.75-.2 Mfd.)	30-4000	㉗	Resistor (99,000 ohms) White-White-Orange	4411
⑥	Condenser (.0014 Mfd.)	7007	㉘	Condenser (.015 Mfd.)	3793-S
⑦	Resistor (8,000 ohms) Gray-Black-Red	5838	㉙	Output Transformer	32-7000
⑧	Oscillator Transformer	32-1001	㉚	Voice Coil and Cone Assembly	36-3000
⑨	Compensating Condenser (I.F. Primary)	04000-A	㉛	A. C. Switch (Part of Volume Control Assembly)	33-5001
⑩	Compensating Cond. (Low Frequency)	04000-S	㉜	Resistors (2 Wire Wound-108 ohms each)	{ 33-3000 33-3001
⑪	Condenser (10.0 Mfd.)	7440	㉝	Electrolytic Condenser (8 Mfd.)	30-2000
⑫	Compensating Condenser (Part of Tuning Condenser Assembly)		㉞	Electrolytic Condenser (8 Mfd.)	30-2000
⑬	I.F. Transformer	32-1002	㉟	Condenser (.05 Mfd.)	3615-E
⑭	Compensating Cond. (I.F. Secondary)	04000-A	㊱	Filter Choke	32-7000
⑮	Resistor (10,000 ohms) Brown-Black-Orange	4412	㊲	Tube Shield	7172
⑯	Resistor (490,000 ohms) Yellow-White-Yellow	4517	㊳	Knobs (Both Controls)	03064
⑰	Resistor (10,000 ohms) Brown-Black-Orange	4412	㊴	Four Prong Socket	7544
⑱	Compensating Condenser (Regeneration)	04000	㊵	Six Prong Socket	7547
⑲	Condenser (.00025 Mfd.)	3082	㊶	Pointer for Station Selector Dial	28-1019 28-1021

USE PHILCO REPLACEMENT PARTS AND TUBES FOR EVERY MAKE RADIO  
 GET COMPLETE CATALOGUE FROM YOUR DISTRIBUTOR

**PHILCO RADIO & TELEVISION CORPORATION**

# PHILCO RADIO & TELEVISION CORP.

## Model 54



Schematic Wiring Diagram

THE PHILCO RADIO MODEL 54 is a five-tube superheterodyne, designed for operation on 110 volts, alternating current, 25, 60 cycles, and 110 volts direct current, employing the new Philco high efficiency tubes with pentode output and an Electro Dynamic Speaker. The set uses a Philco Type 6A7 tube as a first detector and oscillator; a Type 78 tube as intermediate frequency; a Type 75 tube as a second detector; a Type 43 tube as pentode output and a Type 25-Z-5 tube as a rectifier and voltage doubler. The intermediate frequency for tuning the I. F. transformers is 460 kilocycles. The power consumption on both A. C. and D. C. is approximately 50 watts.

Table 1—Tube Socket Data\*—A.C. Line Voltage 115 Volts

Circuit	Det. Osc.	I. F.	2nd Det.	Out-put	Rectifier
Type Tube	6A7	78	75	43	25-Z-5
Filament—Total 68—Refer to	Note.				
Plate Volts—P to K	84	84	38	84	146
Screen Grid Volts—SG to K	K to G 3/5 65	52	..	90	..
Control Grid Volts—CG to K	.15	.15	.25	.5	..
Cathode Volts—K to F	12	12	10	10	..

NOTE—Due to filaments in series, test with suitable A. C. voltmeter across the two points on Resistor (2) marked with an X in Fig. 3.

\* All of the readings above in Table 1 were taken from the under side of chassis, using test prods and leads with a suitable A. C. voltmeter for filament voltage and a high resistance, multi-range D. C. voltmeter for all other readings. Volume control at maximum and station selector set for 550 KC. Readings taken with a radio set tester and plug-in adapter will not be satisfactory.

Table 2—Tube Socket Data\*—D.C. Line Voltage 120 Volts

Circuit	Det. Osc.	I. F.	2nd Det.	Out-put	Rectifier
Type Tube	6A7	78	75	43	25-Z-5
Filament—Total 70—Refer to	Note.				
Plate Volts—P to K	90	90	40	90	..
Screen Grid Volts—SG to K	70	70	..	92	..
Control Grid Volts—CG to K	.15	.15	.25	.5	..
Cathode Volts—K to F	7.5	7.5	10	10	..

NOTE—Due to filaments in series, test with suitable D. C. voltmeter across the two points on Resistor (2) marked with an X in Fig. 3.

\* All of the readings above in Table 2 were taken from the under side of chassis, using test prods and leads with a suitable high resistance, multi-range D. C. voltmeter for all readings. Volume control at maximum and station selector set for 550 KC. Readings taken with a radio set tester and plug-in adapter will not be satisfactory.



# PHILCO RADIO & TELEVISION CORP.

## Changes in Models

**It is unnecessary to alter receivers in your stock to comply with these changes.**

In order to facilitate supplying correct replacement parts to dealers, it is our intention to supply you with production change information, such as that outlined below, at regular intervals. These minor changes are made in the factory in accordance with our policy of constant research and improvement in Philco products. To make it possible for you to furnish dealers with correct parts, it will be necessary for you to have the model number, code number, and run number. The main purpose of these change bulletins is to enable you to order and sell the correct parts. This information is intended for your service department only. Your orders for parts from Philco will be filled as specified on your order. It is suggested that you mark up your copies of Service Bulletins so as to agree with the latest production. The changes noted can be easily understood if a bulletin is marked up in this manner.

### Speakers

H-9 and H-10, speaker cones changed from old part number 02807 to a new part number 02625.

### Models 71 and 22L

Refer to Service Bulletins 128-128A

Below run No. 3 on 71-125B, run No. 2 on both 71-125 and 71-225; tone control ③ part number 05153 was changed to part number 04787. A part number 3903AH condenser was connected from plate of output tube type ④ to ground on chassis.

The tube shield used on detector amplifier tube was changed to new shield part number 8005.

Condenser ⑤ part number 3793-H was changed to part number 3793-R.

### Models 91, 91A and 14

Refer to Service Bulletins 129-129A

On model 14LZX; the grille silk part number 8140 was changed to new grille silk part number 8139.

On models 19-121-122; a felt pad to eliminate the possibility of buzzing of the shadow tuning meter was placed on the back of the bezel.

On model 14-221; only 6497G shadow meters can be used.

On models 91-14; tone control ④ part number 04787 was changed to new tone control part number 06698.

Volume control ③ part number 7049 was changed to new volume control part number 8054.

The following parts have been added:

Part number 7625B, plate condenser; part number 6984, resistor 2,000 ohms; part number 4516, resistor 25,000 ohms; two part number 4411, resistor 99,000 ohms; part number 06713, by-pass condenser—this change effective on run No. 1 for models 91-125 and 91-225; run No. 2 for models 14-221.

# PHILCO RADIO & TELEVISION CORP.

## Model 80

### Refer to Service Bulletin 140

The following changes made on sets above run No. 12.

All tube shields were changed to new shield part number 8005.

Coil shield (square type) part number 7406 was changed to (round type) part number 7830. The following additional changes were made at the same time. Antenna coil ② part number 05831 changed to new coil part number 06888, and the oscillator coil ③ part number 05832 changed to new coil part number 06887; resistor ⑤ (10,000 ohms) part number 4412 and condenser ⑥ (710 Mmfd.) part number 4520 becomes part of coil assembly—(part number 06887).

Resistor ⑩ part number 4412 should be as far away from the I. F. coils as possible. The black and white lead from ⑭ I. F. coil should be placed as near the chassis as possible over the oscillator coil.

## Model 48 and 48E

### Refer to Service Bulletins 143 and 143-S

Volume control ② part number 5839 was changed to new volume control part number 6415.

## Model 43

### Refer to Service Bulletins 138 and 138A

Grid inductance coil ⑩ part number 05190 changed to new type, bearing same part number, identified by black paint.

Resistors (700 ohms) ③ and ④ part number 6443 changed to new resistors (500 ohms) part number 6977.

Resistor (10,000 ohms) ⑩ part number 4412 changed to new resistor (25,000 ohms) part number 4516.

A half plate compensating condenser part number 04000-C added; this is mounted on top of ⑦ compensating condenser part number 04000-V. An extra collar part number 3098 and a longer screw part number W443 are used for mounting. The solid plate of this new compensating condenser is connected to the plate of the first detector tube and the movable plate to a new (500 ohm) resistor part number 6977; the other end of this resistor is connected to the cathode of the first detector tube.

The first detector tube changed from type 44 to type 36.

The I. F. compensating condensers are re-adjusted in the usual manner, but with the new one half plate compensating condenser (04000-C) open. After the set has been re-adjusted and placed in operation, oscillation in the broadcast band is corrected by increasing the capacity of the new one-half plate compensating condenser with the dial set slightly off the frequency of a strong signal at the low frequency end of the band until the oscillation disappears. The primary compensating condenser ⑩ of the first I. F. is then readjusted by decreasing capacity.

If oscillation still persists the above adjusting procedure is repeated until the sensitivity is strong and no oscillation is present.


**Be sure to order your requirements of the above parts at once.**

**PHILCO RADIO & TELEVISION CORPORATION**

**Service Department**

# PHILCO RADIO & TELEVISION CORP.

## Model 80



Schematic Wiring Diagram

Table 2—Power Transformer Data

Terminals	A.C. Volts	Circuit	Color
1-2	105 to 125	Primary	White
3-5	6.3	Filament	Black
6-7	5.0	Filament	Blue
8-10	630	Plates of 80	Yellow
4		Center Tap of 80	Black Yellow
9		Center Tap of 3-5 (Center Tap of 8-10)	Tracer Tracer Yellow Green Tracer

Table 1—Tube Socket Data\*—Power Line Voltage 115 Volts

Tube		Filament	Plate	Screen Grid	Control Grid	Cathode
Type	Circuit	Volts F to F	Volts P to K	Volts SG to K	Volts CG to K	Volts K to F
36	Det.—Osc.	6.3	245	165	6.4	8.4
36	2nd Det.	6.3	40	15	.4	0
42	Output	6.3	240	255	4	0
80	Rectifier	5.0	340/Plate			

# PHILCO RADIO & TELEVISION CORP.

## Model 81

The Philco Radio Model 81 is a four tube superheterodyne receiver combining Standard broadcast and police reception and employs the new Philco high efficiency tubes with pentode output and electro dynamic speaker. The same superheterodyne circuit is used for Standard broadcast and police reception. The intermediate frequency for tuning the I. F. transformer is 460 kilocycles. The power consumption of the Model 81 is 46 watts.


**Table 1—Tube Socket Data\***  
Power Line Voltage 115 Volts

Circuit	Det. Osc.	2nd Det.	Out-put	Rec-tifier
Type Tube	77	77	42	80
Filament Volts—F to K	6.3	6.3	6.3	5.0
Plate Volts—P to K	240	75	240	425
Screen Grid Volts—SG to K	85	40	250	..
Control Grid Volts—CG to K	5.6	.6	2.3	..
Cathode Volts—K to F	24.5	16	16.2	..

**Table 2—Power Transformer Data**

Terminal	A. C. Volts	Circuit	Color
1-2	105-125	Primary	White
3-5	6.3	Filament	Black
6-7	5.0	Filament of 80	Blue
8-10	630	Plates of 80	Yellow
4	..	Center Tap of 3-5	Black-Yellow
9	..	Center Tap of 8-10	Tracer Yellow-Green Tracer

\*All of the above readings were taken from the underside of the chassis, using test prods and leads with a suitable A. C. voltmeter for filament voltages and a high resistance multirange D. C. voltmeter for all other readings. Volume control at maximum and station selector turned to low frequency end. Readings taken with a radio set tester and plug in adapter will not be satisfactory.



Parts Diagram



77 Sockets




42 Socket



80 Socket

Terminal Arrangement of Tube Sockets Viewed from Under Side of Chassis.

# PHILCO RADIO & TELEVISION CORP.



Schematic Wiring Diagram

Note ④—This capacity obtained by pair twisted wires.

RESISTOR VALUES IN (OHMS)	FIXED CONDENSER VALUES (MFD)
⑩ 6,000	⑤ .0014
⑭ 9,000	⑦ .00041
⑯ 18,000	⑮ .09-.09
⑲ 4,000,000	⑳ .001-.015
㉒ 1,000,000	㉔ .006
㉓ 10,000	㉖ .015-.015
㉕ 240,000	
㉗ 490,000	
㉘ 325 (WIRE WOUND)	

## REPLACEMENT PARTS MODEL 81

No. on Figs.	Description	Part No.	List Price	No. on Figs.	Description	Part No.	List Price
①	Volume Control*	33-5002	.75	㉔	Resistor (Yellow-White-Yellow)	4517	.25
②	Antenna Transformer	32-1030	.50	㉕	Condenser	7625-B	.12
③	Tuning Cond. Assembly	31-1006		㉖	Output Transformer	2660	1.25
④	Compensating Condenser (Part of ③)			㉗	Voice Coil and Cone Assembly	02861	.60
⑤	Cond. (Red and Black)	7007	.25	㉘	Speaker Field and Bucking Coil (with Pot)	02867	2.00
⑥	Frequency Switch	42-1000		㉙	Pilot Light	6608	.14
⑦	Cond. (Orange and Yellow)	30-1000	.20	㉚	"On-Off" Switch*	6416-W	.40
⑧	Compensating Condenser	04000-S	.25	㉛	Power Transformer—50-60 Cycles	7421	2.75
⑨	Compensating Condenser	04000-X	.16	㉜	Power Transformer—25-40 Cycles	7422	4.00
⑩	Resistor (Blue-Black-Red)	7352	.25	㉝	Power Transformer—50-60 Cycles, 250 Volts	7423	2.75
⑪	Compensating Condenser (I.F. Primary)	04000-A	.12	㉞	Condenser (Double)	3793-R	.25
⑫	Oscillator Coil	32-1031	.75	㉟	Resistor (Wire Wound)	7465	.12
⑬	Compensating Condenser (Low Frequency)	04000-S	.25	㊱	Electrolytic Condenser (8 Mfd.)	7558	1.25
⑭	Resistor (White-Black-Red)	7501	.25	㊲	Electrolytic Condenser (4 Mfd.)	7467	1.25
⑮	Condenser	4989-B	.22	㊳	Bezel	7417	
⑯	Resistor (Brown-Blue-Orange)	7500	.40	㊴	Tube Shield	7172	.12
⑰	Compensating Condenser (Part of ③)			㊵	Knob (Large)	03063	.08
⑱	I.F. Transformer	06100	1.25	㊶	Knob (Small)	03064	.06
⑳	Resistor (Mounted on I.F. Transformer)	6010	.25	㊷	Knob Spring	5262	.35 per C
㉑	Compensating Condenser (I.F. Secondary)	04000-D	.10	㊸	Grid Clip	4897	.30 per C
㉒	Compensating Condenser	04000	.16	㊹	Four Prong Socket Assembly	5026	.08
㉓	Resistor (Brown-Black-Green)	4409	.25	㊺	Six Prong Socket Assembly	6417	.10
㉔	Resistor (Brown-Black-Orange)	4412	.25	㊻	Chassis Mounting Screw	W-567	2.40 per C
㉕	Condenser (Double)	7762-B	.20	㊼	Chassis Mounting Washer	W-315	.40 per C
㉖	Resistor (Red-Yellow-Yellow)	4410	.25	㊽	Pilot Lamp Shield	5760	

\*On later production (run No. 3 and above, rubber stamped in a star on back of chassis) volume control ① and on-off switch ㉚ was combined. This new volume control and on-off switch is Part Number 7439.

**PHILCO RADIO & TELEVISION CORPORATION**  
Service Department

# PHILCO RADIO & TELEVISION CORP.

## Models 89 and 19

The Philco Radio of the 89 and 19 Series is a 6 tube super-heterodyne, employing the high efficiency 6.3 volt filament tubes, automatic volume control and pentode output. The intermediate frequency used in adjusting the super-heterodyne circuit is 260 kilocycles. The power consumption of the models 89 and 19 is 60 watts.


**Table 1—Tube Socket Data\*—A. C. Line Voltage 115 Volts**

Circuit	RF	Det. Oac.	IF	2nd Det.	Out-put	Rectifier
Type Tube	44	36	44	75	42	80
Filament Volts—F to F	6.3	6.3	6.3	6.3	6.3	5.0
Plate Volts—P to K	235	230	240	175	235	350/Plate
Screen Grid Volts—SG to K	90	90	90	90	245	
Control Grid Volts—CG to K						
Cathode Volts—K to F	.3	7.5	.3	.3	.15	
Diode Plate Volts—K to DP	3.5	7.8	3.5		14	
				.2		

\*All of the readings above in Table 1 were taken from the under side of chassis, using test prods and leads with a suitable A. C. voltmeter, for filament voltages and a high resistance, multi-range D. C. voltmeter for all other readings. Volume control at maximum and switch and station selector set for 550 KC. Readings taken with a radio set tester and plug-in adapter will not be satisfactory.

**Table 2—Power Transformer Data**


Terminal	A. C. Volts	Circuit	Color
1-2	105-125	Primary	White
3-4	6.3	Filaments	Black
6-7	5.0	Filament of 80	Blue
9-10	670	Plates of 80	Yellow
5		Center Tap of 3-4	Black-Yellow Tracer
8		Center Tap of 9-10	Yellow-Green Tracer




F Filament                      SG Screen Grid                      K Cathode  
P Plate                              CG Control Grid                      DP Diode Plate

Tube Socket, Under Side of Chassis

**Caution:** Never connect the chassis to the power supply unless the speaker is connected and all tubes are in place.



Bottom View of Chassis, Showing Parts




Internal Connections Filter Condenser.

# PHILCO RADIO & TELEVISION CORP.

## Adjustment of Models 89 and 19

These receivers are accurately adjusted at the factory prior to shipment. Under normal conditions it will never be necessary to readjust the compensating condensers. If for any reason such adjustment should be required, it should not be attempted without first receiving the proper instruction and equipment from your Distributor. The Philco Oscillator equipment has been designed for use in this work and will be found the most inexpensive and most reliable for the purpose.

### Models 89 and 19




--Schematic Wiring Diagram

## Replacement Parts for Models 89 and 19

① Resistor (10,000 Ohms) Brown—Black—Orange	4412	②② Resistor (70,000 Ohms) Violet—Black—Orange	5385
② Antenna Transformer	06619	③③ Condenser (.01 Mfd.)	3903-T
③ Tuning Condenser Assembly	06577	③④ Resistor (490,000 Ohms) Yellow—White—Yellow	4517
④ Compensating Condenser—(R.F. Part of Tuning Condenser Assembly)		③⑤ Bezel	8055
⑤ Condenser and Resistor—(.09 Mfd. and 200Ω)	4989-W	③⑥ Tone Control	06764
⑥ Interstage Transformer	06662	③⑦ Output Transformer	2580
⑦ Filter Cond. Bank (.09—09—.05—.05—.25)	06624	③⑧ Voice Coil and Cone Assembly	02823
⑧ Condenser (Double—.09 and .0007 Mfd.)	8174-B	③⑨ Speaker Field and Bucking Coil Assembled with Pot (K-7)	02761
⑨ Compensating Condenser—(R.F. Part of Tuning Condenser Assembly)		③⑩ Switch (A.C.) Part of Vol. Control Assembly	
⑩ Resistor (15,000 Ohms) Brown—Green—Orange	6208	③⑪ Power Transformer (50-60 Cycles, 115 Volts)	8046
⑪ Pilot Lamp	6608	③⑫ Power Transformer (25-40 Cycles—115 Volts)	8047
⑬ Dial Scale	7882	③⑬ Power Transformer (50-60 Cycles—230 Volts)	8048
⑬ Pilot Lamp—(Shadow Tuning)	6608	③⑭ Condenser (Double—.015 and .015 Mfd.)	3793-E
⑭ Oscillator Transformer	06620	④① Shadow Tuning	6497-G
⑮ Compensating Condenser — (1st I.F. Primary)	04000-M	④② Resistor (99,000 Ohms) White—White—Orange	4411
⑯ Compensating Condenser — (Low Frequency)	04000-S	④③ Resistor (1,000,000 Ohms) Brown—Black—Green	4409
⑰ Compensating Condenser—(R.F. Part of Tuning Condenser Assembly)		④④ B.C. Resistor (235 Ohms and 32 Ohms—Wire Wound)	7998
⑰ First I.F. Transformer	06621	④⑤ Electrolytic Condenser—6 Mfd.	8165
⑱ Compensating Condenser (1st I.F. Secondary)	04000-M	④⑥ Condenser (.05 Mfd.)	3615-E
⑳ Resistor (5,000 Ohms) Green—Black—Red	3526	④⑦ Electrolytic Condenser—6 Mfd.	8166
㉑ Resistor (2,000,000 Ohms) Red—Black—Green	5872	④⑧ Resistor (51,000 Ohms) Green—Brown—Orange	4518
㉒ Compensating Cond. (2nd I.F. Primary)	04000-A	④⑨ Resistor (32,000 Ohms) Orange—Red—Orange	3525
㉓ Second I.F. Transformer	06622	④⑩ Tube Shield	8005
㉔ Resistor (51,000 Ohms) Green—Brown—Orange	6098	④⑪ Knob (Large)	03063
㉕ Volume Control and A.C. Switch	8003	④⑫ Knob (Small)	03064
㉖ Condenser (Double—.00011 & .00011 Mfd.)	8035-C	④⑬ Knob Spring	5262
㉖ Condenser (.01 Mfd.)	3903-AB	④⑭ Grid Clip	4897
㉗ Resistor (70,000 Ohms) Violet—Black—Orange	5385	④⑮ Four Prong Socket	7544
		④⑯ Five Prong Socket	7546
		④⑰ Six Prong Socket	7547
		④⑱ Pilot Lamp Shield	5760

# PILOT RADIO & TUBE CORP.



VOLTAGES AT SOCKETS AS MEASURED WITH MODEL 536 WESTON TESTER

Line Voltage -- 220 D. C. -- .34 Amperes									Line Voltage -- 110 D. C.								
Type of Tube	Position	Fil.	Plate to Cath.	Screen+ to Cath.	Screen- to Cath.	Screen Cur- rent	Cath. to Fil.	Plate Cur- rent	Type of Tube	Position	Fil.	Plate to Cath.	Screen+ to Grid-	Screen- to Cath.	Screen Cur- rent	Cath. to Fil.	Plate Cur- rent
237	Osc. A	6.2	128.	-5.			19.3	9.2	Osc. A	6.2	93	-1.3	-	-	-	12.0	7.3
	B	6.3	78.	0			64.0	7.0		B	6.3	55	-0.1	-	-	-	55.0
236	1st Det. A	5.2	120.	-9.6	70.	.05	18.8	5.0	1st Det. A	6.2	93	-3.8	52	1.2	7.0	3.6	
	B	5.3	130.	-7.3	93.	.03	14.0	3.7		B	6.3	96	-3.9	67	1.2	5.7	3.4
239	I.F. A	6.2	130.	-4.8	130.	4.8	.8	10.0	IF A	6.2	95	-2.4	95	1.33	-0.3	5.5	
	B	3.3	90.	-50.	90.	.01	52.0	.01		B	6.3	62	-37	60	.0	+33	*
236	2nd A	6.7	94.	-5.	75.	.05	1.7	.3	2nd A	6.2	26	-9.8	65	1.0	-4.5	0.18	
	Det. B	6.8	100.	-6.	92.	.15	2.8	.26		Det. B	6.3	26	-10.7	51	1.3	-4.8	0.2
238	Out-A	7.2	118.	-	140.	1.5	-9.4	7.5	Out-A	6.2	85	-	100	2.0	-15.1	5.0	
	put B	7.3	115.	-	143.	2.8	-11.8	10.0		put B	6.3	85	-	103	1.55	-15.7	6.5

A - Vol. control maximum. B.- Vol. control minimum. Vm return on K. Readings all taken at approximately 1400 kilocycles.

### RE-ALIGNMENT

The sensitivity and selectivity of the Pilot DRAGON largely depend upon the proper adjustment of the various trimmer condensers. Before sets leave the factory, these trimmers are carefully tuned and every precaution is taken to insure the permanence of the adjustments.

The best method of adjusting the I.F. trimmers is by means of a signal generator (or modulated oscillator) tuned to 115 KC. The output of the oscillator is connected across the grid circuit of the first detector and the two I.F. transformers are lined up to resonance with the 115 KC. signal. Many service stations, however may not be equipped with a 115 KC. oscillator, in which case the I.F. transformers can be adjusted at the same time as the broadcast band trimmers, using an oscillator tuned to broadcast frequencies. This method can be used successfully when the I.F. transformers are slightly out of adjustment. However, if the factory adjustments have been changed with a screw driver and the I.F. amplifier thrown completely out of line, a 115 KC. generator must be used to re-adjust the trimmers.


## D. C. Dragon Receiver

For Table and Console Sets Bearing the Following Chassis Model Numbers

- Chassis No. 11-R 110-125 volts D.C.
- Chassis No. 11-A 220 volts D.C.



# PILOT RADIO & TUBE CORP.




- CONDENSERS**  
 C1 - .0005  
 C2 - .0005  
 C3 - .0005  
 C4 - .01  
 C5 - .01  
 C6 - .01  
 C7 - .01  
 C8 - .01  
 C9 - .0001  
 C10 - .0001  
 C11 - .0001  
 C12 - .0001  
 C13 - .0001  
 C14 - .0001  
 C15 - .0001  
 C16 - .0001  
 C17 - .0001  
 C18 - .0001  
 C19 - .0001  
 C20 - .05
- RESISTORS**  
 R1 - 10000 ohms-1/2 W  
 R2 - 10000 ohms-1/2 W  
 R3 - 10000 ohms-1/2 W  
 R4 - 10000 ohms-1/2 W  
 R5 - 10000 ohms-1/2 W  
 R6 - 10000 ohms-1/2 W  
 R7 - 10000 ohms-1/2 W  
 R8 - 10000 ohms-1/2 W  
 R9 - 10000 ohms-1/2 W  
 R10 - 10000 ohms-1/2 W  
 R11 - 10000 ohms-1/2 W  
 R12 - 10000 ohms-1/2 W  
 R13 - 10000 ohms-1/2 W  
 R14 - 10000 ohms-1/2 W  
 R15 - 10000 ohms-1/2 W  
 R16 - 10000 ohms-1/2 W  
 R17 - 10000 ohms-1/2 W

**SCHEMATIC DIAGRAM MODEL 35  
 PILOT HIGH BAND SUPER HET**

**VOLTAGE TABLE FOR CHASSIS MODEL NO. 35 (A-B-F & FJ)**

Type Tube	Tube Position	Fil. A.C.	Cath. + to Screen		Plate Cath. Current
			Control Grid -	Grid - Cath. -	
227	Osc. (a)	2.3	73	3.4*	3.2
	Osc. (b)	2.3	68	2.4*	36
224-A	1st (a)	2.3	225	8.4	.1
	Det. (b)	2.3	234	8.7	9.6
235	R.F. (a)	2.3	237	1.7	1.5
	(b)	2.3	214	34	34.
235	I.F. (a)	2.3	234	3.3	3.5
	(b)	2.3	216	36.	.11
224-A	2nd (a)	2.3	200+	4.1	30
	Det. (b)	2.3	200+	4.9	50
247	Power (a)	2.3	214	7.5†	240
	(b)	2.3	218	7.5†	255
280	Rect. (a)	4.9	590		32.0 per anode
	(b)	4.9	590		29 per anode




- CONDENSERS**  
 C1 - .25 mf.  
 C2 - .0005  
 C3 - .0005  
 C4 - .01  
 C5 - .01  
 C6 - .01  
 C7 - .01  
 C8 - .01

- CONDENSERS**  
 C9 - .0001  
 C10 - .0001  
 C11 - .0001  
 C12 - .0001  
 C13 - .0001  
 C14 - .0001  
 C15 - .001480  
 C16 - .0001  
 C17 - .01  
 C18 - .01  
 C19 - .01  
 C20 - .05


- RESISTORS**  
 R1 - 10000 ohms-1/2 W  
 R2 - 10000 ohms-1/2 W  
 R3 - 10000 ohms-1/2 W  
 R4 - 10000 ohms-1/2 W  
 R5 - 10000 ohms-1/2 W  
 R6 - 10000 ohms-1/2 W  
 R7 - Center Tap Resistor  
 R8 - 10000 ohms-1/2 W  
 R9 - 10000 ohms-1/2 W  
 R10 - 10000 ohms-1/2 W  
 R11 - 10000 ohms-1/2 W  
 R12 - 10000 ohms-1/2 W  
 R13 - 10000 ohms-1/2 W  
 R14 - 10000 ohms-1/2 W  
 R15 - 10000 ohms-1/2 W  
 R16 - 10000 ohms-1/2 W  
 R17 - 10000 ohms-1/2 W

- RESISTORS**  
 R9 - 10000 ohms-1/2 W  
 R10 - 10000 ohms-1/2 W  
 R11 - 10000 ohms-1/2 W  
 R12 - 10000 ohms-1/2 W  
 R13 - 10000 ohms-1/2 W  
 R14 - 10000 ohms-1/2 W  
 R15 - 10000 ohms-1/2 W  
 R16 - 10000 ohms-1/2 W  
 R17 - 10000 ohms-1/2 W



**PILOT MODEL 39 SUPER HET**

# PILOT RADIO & TUBE CORP.



- |                   |             |                      |                           |
|-------------------|-------------|----------------------|---------------------------|
| <b>CONDENSERS</b> | C10 .1      | <b>RESISTORS</b>     | R10 200 ohms 1/2 w        |
| C1 .01 mfd        | C11 .1      | R1 30,000 ohms 1/2 w | R11 400                   |
| C2 .0005          | C12 .25     | R2 10,000            | R12 10,000                |
| C3 .0005          | C13 .25     | R3 10,000            | R13 10,000                |
| C4 .1             | C14 .1      | R4 500,000           | R14 40,000                |
| C5 .005           | C15 .1      | R5 500,000           | R15 300                   |
| C6 .25            | C16 .0001   | R6 30                | R16 10,000                |
| C7 .3             | C17 .0014#0 | R7 6,000             | R17 0-50,000 TONE CONTROL |
| C8 .25            | C18 .001500 | R8 10,000            |                           |
| C9 .25            | C19 .1      | R9 150               |                           |
|                   | C20 .25     |                      |                           |
|                   | C21 .05     |                      |                           |

SPEAKER WIRING - 220V 5 ONLY

**SCHEMATIC DIAGRAM  
PILOT MODEL 41 SUPER HET**

Chassis No. 41-R 110-125 volts D.C.

Chassis No. 41-A

220 volts D.C.

VOLTAGES AT SOCKETS AS MEASURED WITH MODEL 566 WESTON TESTER

Line Voltage -- 220 D. C. -- .34 Amperes

Line Voltage -- 110 D. C.

Type of Tube	Tube Position	Fil.	Plate+ to Cath.-	Cath.+ to Grid-	Screen+ to Cath.-	Screen- to Cur- rent	Cath.+ to Fil.-	Plate to Cur- rent	Tube Position	Fil.	Plate+ to Cath.-	Cath.+ to Grid-	Screen+ to Cath.-	Screen- to Cur- rent	Cath.+ to Fil.-	Plate to Cur- rent
237	Osc. A	6.2	128.	-5.	-	-	19.3	9.2	Osc. A	6.2	93	-1.3	-	-	12.0	7.3
		B	6.3	78.	0	-	-	64.0		7.0	B	6.3	55	-0.1	-	55.0
236	1st Det.	5.2	120.	-9.8	70.	.05	18.8	5.0	1st Det.	6.2	93	-3.8	52	1.2	7.0	3.6
		B	5.3	130.	-7.3	93.	.03	14.0		3.7	B	6.3	96	-3.9	67	1.2
239	I.F. A	6.2	130.	-4.8	130.	4.8	.8	10.0	IF A	6.2	95	-2.4	95	1.33	-0.3	5.5
		B	5.3	90.	-50.	90.	.01	52.0		.01	B	6.3	62	-37	60	.0
236	2nd A	6.7	94.	-5.	75.	.05	1.7	.3	2nd A	6.2	26	-9.8	65	1.0	-4.5	0.18
		Det. B	6.8	100.	-6.	92.	.15	2.8		.26	Det. B	6.3	26	-10.7	51	1.3
238	Out-A put B	7.2	118.	-	140.	1.5	-9.4	7.5	Out-A put B	6.2	85	-	100	2.0	-15.1	5.0
		7.3	115.	-	143.	2.8	-11.8	10.0		6.3	85	-	103	1.55	-15.7	6.5

A - Vol. control maximum. B - Vol. control minimum. Vm return on K. Readings all taken at approximately 1400 kilocycles.

### RE-ALIGNMENT

The sensitivity and selectivity of the PILOT DX Super-Heterodyne largely depend upon the proper adjustment of the various trimmer condensers. Before sets leave the factory, these trimmers are carefully tuned and every precaution is taken to insure the permanence of the adjustments.


If a set appears to be insensitive, it is possible that rough handling in transit has changed the positions of some of the trimmers. In this case, the sensitivity can be restored by re-aligning the set. It is understood, of course, that the tubes have been checked and other tests made as suggested in the foregoing sections, to make sure that the insensitivity is not due to other causes.

The best method of adjusting the I.F. trimmers is by means of a signal generator (or modulated oscillator) tuned to 115 KC. The output of the oscillator is connected across the grid circuit of the first detector and the two I.F. transformers are lined up to resonance with the 115 KC signal. Many service stations, however, may not be equipped with a 115 KC oscillator in which case the I.F. transformers can be adjusted at the same time as the broadcast band trimmers, using an oscillator tuned to broadcast frequencies. This method can be used successfully when the I.F. transformers are slightly out of adjustment. However, if the factory adjustments have been changed with a screw driver and the I.F. amplifier thrown completely out of line, a 115 KC generator must be used to re-adjust the trimmers.


# RCA-VICTOR, INC.

## M-34









### Automobile Receiver



# RCA-VICTOR, INC.




Radiotron No.	Cathode to Ground	Cathode to Screen Grid Volts	Cathode to Plate Volts	Plate Current M. A.	Heater Volts
RCA-78 R. F.	3.7	92	253	7.0	6.06
RCA-6A7	First Detector	3.7	253	12.0	6.06
	Oscillator	0	253	Total	
RCA-6B7 Second Detector	3.2	92	236	6.0	6.06
RCA-89 Power	26.5	230	217	27.5	6.06



# RCA-VICTOR, INC.


## SERVICE DATA FOR VIBRATOR UNIT

The vibrator unit used in this receiver is of excellent design and sturdy construction. It functions as a combined A. C. generator and mechanical rectifier. Referring to Figure C, it will be noted that the primary and secondary of the transformer are center tapped. By connecting the outside of each winding to the contacts of the vibrator and using the arms and center taps of the windings as sources of input and output voltage, a combined generating and rectifying action is obtained.



*Schematic of Vibrator Unit*

When the switch is turned "on" the vibrator makes and breaks contact at point "A." This constitutes the driving action of the unit, and is in no way connected with the other circuits. The primary vibrator functions to connect the input low voltage current first across one-half and then across the other half of the primary of the transformer. This results in a pulsating direct current applied to the primary in an alternating direction. The result is an A. C. voltage emanating from the secondary of the transformer; as the transformer has a step-up ratio the A. C. secondary voltage is considerably greater than the primary. The secondary vibrator functions in a similar manner as that on the primary side, so that by reversing the alternations applied to the load, a pulsating D. C. is obtained. After filtering, this is used as plate and grid supply to all Radiotrons.



*Vibrator Contacts*

**Fuses**—This installation is protected by one fuse (rated 20 amperes) which is mounted in the fuse receptacle contained in the power input lead. If the set fails to operate and the dial lamp does not light, this fuse should be removed for examination. If found to be burned out, the wiring should be inspected for short-circuits or grounds and all tubes tested prior to insertion of a new fuse. The replacement fuse must be of the same ampere rating.

### (1) Spring and Contact Adjustment Limits.

Proper adjustments of the various contacts are made in the following order and manner:

1. With 8 and 10, Figure D, firmly held against their respective stops and with 3 and 5 in contact with 8 and 10 respectively, the air gap between 1, 6 and 2, 7 shall be 0.015" plus or minus 0.005". On no particular unit however, shall the differences between the two air gaps exceed 0.005".

2. Adjust the buzzer screw, 11, Figure D, so that when the position of the armature is such that 1 and 2 are just making contact with 6 and 7 respectively, the contact between 4 and 9 shall just be breaking.

### (2) Adjustment for the Reduction of Sparking.



If any pair of contacts show excessive sparking, the following procedure will in general reduce the sparking to a minimum.

For example, consider the case where excessive sparking is occurring between 6 and 1. Sparking will be reduced to a minimum by bending the armature spring on that side (secondary side) away from 6 and toward 8. (See Figure D.) If the bend is too small, only a small change will be noted. However, if an excessive bend is made, the sparking will be transferred from 6, 1 to 8, 3.

The same method may be applied to any pair of contacts. Usually only a slight bend will be necessary. Although after bending, no change in the position of the armature contacts may be noted, a sufficient change in the initial force requirements will have been made to reduce sparking.

### (3) Output Voltage.

When connected to a 6 volt primary source, the output voltage across a 5,000 ohm resistor (connected in place of the receiver load at the output of the filter), must be 240 volts or greater.



**Ignition System**—The ignition system of the car must be kept in good condition. Fouled plugs or plugs with improperly adjusted gaps will affect the operation of the receiver as well as of the automobile. Burned or improperly adjusted breaker points will also impair the performance. It will be advisable to advance the generator charging rate in order to compensate for the additional drain on the car storage battery imposed by this instrument.

# RCA-VICTOR, INC.

## Portable Public Address System Type PG-62

### Instructions for Operation and Service

#### ELECTRICAL SPECIFICATIONS

Voltage Rating.....	105-125 Volts
Frequency Rating.....	50-60 Cycles
Power Consumption.....	110 Watts
Number and Type of Radiotrons.....	1 RCA-57, 2 RCA-56, 3 RCA-59, 1 RCA-83
Number of Voltage Amplifier Stages.....	Three
Number of Power Amplifier Stages.....	Two
Overall Gain.....	95 db.
Type of Loudspeaker.....	Electro-Dynamic
Wattage Dissipation in Loudspeaker Fields.....	9 Watts
Number of Loudspeakers.....	Two
Maximum Undistorted Audio Output.....	20 Watts

#### RADIOTRON SOCKET VOLTAGES

The Radiotron socket voltages given in the following tabulation are the actual values at which each Radiotron should operate. In circuits containing high resistance, voltages read on a set analyzer will not agree with the values in the table, due to the relatively low resistance of the meter employed. Therefore, a correction must be applied to the meter reading to obtain the correct voltage at each socket. Usually, an application of Ohms Law will give an approximate value of the voltages at which each Radiotron is operating, assuming that the resistance of the meter is known.

#### RADIOTRON SOCKET VOLTAGES

##### 115 VOLT A. C. LINE — NO INPUT SIGNAL VOLTAGE


Radiotron No.	Control Grid to Cathode or Filament Volts	Screen Grid to Cathode or Filament Volts	Plate to Cathode or Filament Volts	Plate Current M. A.	Filament or Heater Volts
1. RCA-57	1.0	80	145	.25	2.5
2. RCA-56	3.5	—	120	1.2	2.5
3. RCA-56	4.0	—	165	1.6	2.5
4. RCA-59	2.8	—	242	23.0	2.5
5. RCA-59	0	—	390	13.0	2.5
6. RCA-59	0	—	390	13.0	2.5

**CAUTION:** Whenever the Radiotron RCA-83 rectifier is removed from or installed in its socket, the A. C. power control switch should be in the "off" position.

The amplifier consists of two units; the voltage amplifier and the power amplifier, both mounted in a carrying case. The loudspeakers, two of which are supplied with the equipment, are mounted in the cover of the carrying case. A velocity type microphone, the latest type developed by the RCA Victor engineers, is also supplied as a standard part of the equipment. Provision is made for placing the microphone and stand together with the interconnecting cables in the carrying case when the equipment is to be transported. The weight of the complete equipment packed in the carrying case is 75 pounds.

# RCA-VICTOR, INC.

## MODEL P.G-62




Schematic Circuit Diagram

# RCA-VICTOR, INC.

## Portable Phonograph Turntable


### Type PT-15



*Wiring and Schematic Diagrams*




# RCA-VICTOR, INC.




Schematic Diagram of Receiver Assembly

# Intravario Model R-24 and SW-3

# RCA-VICTOR, Inc.



Schematic Circuit Diagram of Short Wave Converter



Wiring Diagram of Short Wave Converter



## RCA-VICTOR, INC.

### LINE-UP CAPACITOR ADJUSTMENTS

The detector and oscillator trimming capacitors may be correctly aligned in the following manner:

The oscillator frequencies should be the following values for the taps indicated:

<i>Band</i>	<i>Oscillator Frequency</i>	<i>Trimming Capacitor</i>
19 Meter	14100 K. C.	C-2
25 Meter	12900 K. C.	C-3
31 Meter	8450 K. C.	C-4
49 Meter	7250 K. C.	C-5

If a frequency meter or a calibrated receiver is available, either will be suitable for checking or adjusting these capacitors. If such equipment is not available then the following method may be used:

The frequency of the oscillator may be checked by adding or subtracting the dial reading in kilocycles from the operating frequency of the station being received. The instruction book lists a number of stations with their correct operating frequency. The dial reading should be added or subtracted as follows:

19 Meter Tap	..... Subtract dial reading.
25 Meter Tap	..... Add dial reading.
31 Meter Tap	..... Subtract dial reading.
49 Meter Tap	..... Add dial reading.

The adjustment of the detector trimming capacitor may be checked as follows:

Unless the set is operating poorly in comparison with similar receivers do not attempt to make these adjustments.

- (a) Remove the Short Wave Converter chassis from the cabinet without disturbing its wiring, and remove mounting plates so that access to C-1 is obtained. See Figure 1.
- (b) Set the switch at the 49 meter position and tune in W8XK (6140 K. C.). Then detune the receiver to a higher frequency, 50-70 K. C., *at which no station is being received.*
- (c) Turn the tone control clockwise for maximum highs and advance the volume control toward maximum so that background noise is readily discernible.
- (d) Then with a non-metallic screw driver, rotate C-1 back and forth until the noise is at its loudest value. This is the correct adjustment and detector will be accurately tuned to the center of the 49 meter band.
- (e) Carefully note the position of the screw head of the trimming capacitor. It is suggested that a pencil mark be made opposite one end of the slot on the chassis and a corresponding mark at the end of the slot on the trimmer.
- (f) Then turn the switch to the 31 meter position and tune in W2XAF at 9530 K. C. Detune the receiver to a slightly higher frequency, 10-30 K. C., *at which no station is being received.*
- (g) Repeat adjustments given in (c), (d) and (e), and again note very carefully the position of the screw head. It should not be necessary to turn the screw more than one half turn.

Note this down in terms of  $\frac{1}{2}$  or  $\frac{1}{4}$  turns in or out from previous setting. Then return the trimming capacitor to the position marked for the 49 meter position.

- (h) Turn the switch to the 25 meter position and tune in W8XK at 11870 K. C. Tune out the station by turning the dial to a higher frequency (60-80 K. C.) *at which no station is heard.*

## RCA-VICTOR, INC.

- (i) Again check the trimming capacitor for maximum noise as in (c), (d), and (e), and note the amount of change in the screw from the 49 meter position marking.
- (j) Turn to the 19 meter position. Tune in W2XAD at 15330 K. C. and then set the dial at a lower frequency (90-110 K. C.) *at which no station is heard*. Find the position of the detector trimmer for maximum noise and note it in terms of relation to the 49 meter position.
- (k) Tabulate the results as per the following example:

Band	Aligning Frequency	Trimmer Change
49 Meter	6080 K. C.	0—Adjustment marked
31 Meter	9550 K. C.	Out— $\frac{1}{2}$ turn
25 Meter	11800 K. C.	In + $\frac{1}{4}$ turn
19 Meter	15220 K. C.	Out— $\frac{1}{4}$ turn
		4 )— $\frac{1}{2}$ turn
		— $\frac{1}{8}$ turn out

By taking the average of the four adjustments, it is found that the best adjustment for all four bands is— $\frac{1}{8}$  turn out from the 49 meter position for this particular example.

In general, it will be found that if the proper adjustment is made for the 49 meter band, the corrections for the other three bands will be negligible and the single adjustment is sufficient.

If it is found that any of the bands require readjustment of more than one full turn of the detector trimmer, the circuit wiring should be investigated for a poor contact or misplaced tap on the switch or inductance coil. The wiring of the detector coil must be with the shortest possible leads.

### GENERAL NOTES

1. Keep the antenna lead from the converter as far as possible from the broadcast chassis.
2. Do not connect the SW-3 to a receiver having the antenna coil grounded.
3. Keep leads from the SW-3 to the receiver as short as possible but do not shield.
4. If modulation hum is encountered connect a 5,000 MMFD. Capacitor from either heater lead to ground.


### RADIOTRON SOCKET VOLTAGES

#### 120 VOLT A. C. LINE

Radiotron No.	Cathode to Heater, Volts, D. C.	Cathode or Filament to Control Grid, Volts, D. C.	Cathode or Filament to Screen Grid, Volts, D. C.	Cathode or Filament to Plate, Volts, D. C.	Plate Current M. A.	Heater or Filament, Volts, D. C.
<b>VOLUME CONTROL AT MINIMUM</b>						
1—R. F.	**2.0	*1.2	110	280	0	2.5
2—1st Det.	0	*1.5	110	280	0	2.5
3—Osc.	—	—	—	90	5.5	2.5
4—I. F.	**2.0	*2.0	110	280	0	2.5
5—A. V. C.	—	1.0	—	10	0	2.5
6—2nd Det.	—	6.0	—	260	1.0	2.5
7—Power	—	20.0	275	265	35.0	2.5
Conv. Det.	—	—	—	—	—	2.5
Conv. Osc.	—	—	—	—	—	2.5
<b>VOLUME CONTROL AT MAXIMUM</b>						
1—R. F.	**4.0	*0.1	100	260	5.0	2.5
2—1st Det.	**10.0	*1.0	95	250	2.0	2.5
3—Osc.	—	—	—	75	4.5	2.5
4—I. F.	**4.0	*1.8	100	260	3.0	2.5
5—A. V. C.	—	2.0	—	20	0	2.5
6—2nd Det.	—	7.0	—	240	1.0	2.5
7—Power	—	20.0	275	265	30.0	2.5
Conv. Det.	—	2.1	60.0	255	0.15	2.5
Conv. Osc.	—	2.1	—	60	4.0	2.5


\*On 5 Volt, 1000 Ohm per Volt Meter.  
 \*\*On 50 Volt, 1000 Ohms per Volt Meter.

# RCA-VICTOR, INC.



## MODEL R-27

Schematic Circuit



Wiring Diagram

# RCA-VICTOR, INC.

## MODEL R-27

### SERVICE DATA

#### Electrical Specifications

Voltage Rating . . . 105-120 Volts, 25-133 Cycles A. C. or D. C.  
 Power Consumption . . . . . 40 Watts  
 Frequency Range . . . . . 540 K. C.-1710 K. C.  
 Type and Number of Radiotrons—  
 1 RCA-36, 1 RCA-37, 1 RCA-38, 1 RCA-39—Total 4

This receiver is an A. C.-D. C. table model tuned R. F. broadcast receiver. Features such as universal operation on both A. C. and D. C., wide tuning range, excellent performance and compact construction characterize this instrument. Figures A and B show the schematic and wiring diagrams respectively. The voltage readings and replacement parts are given below.

### RADIOTRON SOCKET VOLTAGES

Measured at Maximum Volume—115 Volt A. C. Line  
 All Voltages on D. C. will be slightly lower

Radiotron No.	Cathode or Filament to Control Grid Volts	Cathode or Filament to Screen Grid, Volts	Cathode or Filament to Plate, Volts	Plate Current M. A.	Filament or Heater Volts
1. RCA-39 R. F.	3.0	105	105	7.0	6.0
2. RCA-36 Det.	*0.75	11.0	*60	.025	6.0
3. RCA-38 Output	11.0	100	95	5	6.0
4. RCA-37 Rect.	—	—	115	15	6.0

\*Impossible to measure on ordinary voltmeter

### REPLACEMENT PARTS

Insist on genuine factory tested parts, which are readily identified and may be purchased from authorized dealers.

Stock No.	DESCRIPTION	List Price	Stock No.	DESCRIPTION	List Price
<b>RECEIVER ASSEMBLIES</b>					
3076	Resistor—1 megohm—Carbon type—Package of 5 . . . . .	\$2.50	3568	Escutcheon — Volume control escutcheon Package of 2 . . . . .	\$0.42
3456	Capacitor—.05 mfd. . . . .	.44	3569	Knob—Station selector or volume control knob—Package of 5 . . . . .	.65
3536	Capacitor—Filter capacitor—Two 5.0 mfd. capacitors . . . . .	1.10	3635	Resistor—Filament resistor—315 ohms . . . . .	1.00
3537	Reactor—Filter reactor . . . . .	1.10	6188	Resistor—2 megohm—Carbon type—½ watt Package of 5 . . . . .	2.00
3538	Capacitor—Filter capacitor—Two 4.0 mfd. . . . .	1.18	6451	Condenser—Two gang variable tuning condenser . . . . .	2.04
3539	Coil—R. F. coil complete . . . . .	1.08	7484	Socket—Radiotron socket—5 contact . . . . .	.65
3540	Coil—Detector coil . . . . .	.98	10405	Capacitor—Antenna series capacitor—.002 mfd. . . . .	.50
3542	Volume control—Complete with mounting nut . . . . .	1.18	10820	Capacitor—100 mfd. . . . .	.50
3557	Capacitor—0.002 mfd. . . . .	.30	<b>REPRODUCER ASSEMBLIES DYNAMIC TYPE</b>		
3559	Resistor—31,000 ohms—Carbon type—½ watt—Package of 5 . . . . .	1.00	3610	Magnet . . . . .	1.04
3560	Resistor — 1,600 ohms — Carbon type — ½ watt—Package of 5 . . . . .	1.00	6477	Transformer—Output transformer . . . . .	1.32
3561	Capacitor—0.004 mfd. . . . .	.42	7598	Cone—Reproducer cone complete—Package of 5 . . . . .	4.35
3562	Capacitor—0.006 mfd. . . . .	.42	7599	Housing—Cone housing and core assembly . . . . .	1.16
3567	Escutcheon — Station selector escutcheon Package of 2 . . . . .	.42	9429	Reproducer—Complete . . . . .	4.85

# RCA-VICTOR, Inc.

## R-28

### SERVICE DATA

Voltage Rating . . . . . 105-125 Volts  
 Frequency Rating . . . . . 25-40 Cycles and 50-60 Cycles  
 Power Consumption . . . . . 70 Watts  
 Number and Types of Radiotrons . . . . . 1 UX-280,  
 1 RCA-2A5, 1 RCA-58, 1 RCA-57, 1 RCA-2A7—Total 5  
 Undistorted Output . . . . . 1.75 Watts  
 Frequency Range . . . . . 540 K. C. to 1500 K. C.

This receiver is a five-tube Super-Heterodyne incorporating a Dynamic Loudspeaker as a part of the chassis; two-point tone control; single heater type Pentode Output tube and the inherent sensitivity, selectivity and tone quality of the Super-Heterodyne.

The circuit consists of an R. F. stage, a combined oscillator and first detector in the RCA-2A7 tube, an intermediate stage consisting of a transformer only using two tuned circuits, a second detector, an output tube and a rectifier.

Service work in conjunction with this receiver will be similar to that of other Super-Heterodyne receivers of the small compact type construction. The line-up adjustments are made in conjunction with an external oscillator and an output meter. The line-up capacitors on the gang capacitor are adjusted for maximum output when the oscillator is coupled to the antenna and the set and oscillator are both set at 1400 K. C. The I. F. frequency is 175 K. C. and the two circuits that comprise it are adjusted for maximum output at 175 K. C.

### RADIOTRON SOCKET VOLTAGES

115 Volt A. C. Line

#### MAXIMUM VOLUME CONTROL SETTING—NO SIGNAL

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current, M. A.	Heater Volts
1. RCA-58 R. F. Amplifier	3.0	95	250	5.0	2.33
2. RCA-2A7 First Detector Oscillator	3.0	95	250	3.0	2.33
3. RCA-57 Second Detector	6.0	89	170	0.3	2.33
4. RCA-2A5 Power Amplifier	18.0	235	220	32.0	2.33
5. RCA-80 Rectifier	275 Volts PLATE TO PLATE—60 M. A. TOTAL				4.82
TOTAL CATHODE CURRENT—11 M. A.					


### REPLACEMENT PARTS

Stock No.	DESCRIPTION	List Price	Stock No.	DESCRIPTION	List Price
<b>RECEIVER ASSEMBLIES</b>					
2747	Contact cap—Package of 5 . . . . .	\$0.50	6143	Resistor—40,000 ohms—Carbon type— $\frac{1}{4}$ watt—Package of 5 . . . . .	\$2.00
2749	Capacitor—2,400 mmfd. . . . .	1.60	6228	Resistor—200,000 ohms—Carbon type— $\frac{1}{4}$ watt—Package of 5 . . . . .	2.50
3050	Resistor—14,000 ohms—Carbon type—3 watts . . . . .	.60	6303	Resistor—20,000 ohms—Carbon type— $\frac{1}{4}$ watt—Package of 5 . . . . .	2.50
3456	Capacitor—0.05 mfd. . . . .	.44	6306	Resistor—14,000 ohms—Carbon type—1 watt—Package of 5 . . . . .	2.50
3459	Capacitor—80 mmfd. . . . .	.44	6464	Transformer—I. F. transformer . . . . .	1.88
3472	Capacitor—0.0024 mfd. . . . .	.32	6465	Volume control—Complete with mounting nut . . . . .	1.22
3514	Resistor—250,000 ohms—Carbon type— $\frac{1}{4}$ watt—Package of 5 . . . . .	1.00	6466	Switch—Tone control switch . . . . .	.45
3572	Socket—Radiotron 7 contact socket . . . . .	.38	6470	Coil—Antenna coil . . . . .	1.08
3573	Socket—Radiotron 4 contact socket . . . . .	.32	6471	Coil—Oscillator coil assembly . . . . .	.74
3574	Coil—Choke coil . . . . .	.68	6472	Coil—R. F. coil assembly . . . . .	.94
3575	Socket—Dial lamp socket and bracket . . . . .	.34	6473	Scale—Dial scale assembly . . . . .	.50
3584	Ring—R. F. or oscillator coil retaining ring—Package of 5 . . . . .	.40	7485	Socket—Radiotron 6 contact socket . . . . .	.70
3590	Escutcheon—Station selector escutcheon—Package of 5 . . . . .	1.40	7487	Shield—Radiotron tube shield . . . . .	.50
3591	Escutcheon—Name plate escutcheon—Package of 5 . . . . .	1.40	7588	Condenser—3 gang variable tuning condenser . . . . .	2.85
3592	Knob—Station selector, operating switch or volume control knob—Package of 5 . . . . .	.80	7589	Capacitor—Filter capacitor—Two 4.0 mfd. in container . . . . .	1.64
3593	Screw—Chassis mounting screw—Package of 10 . . . . .	.30	7590	Capacitor—10 mfd. . . . .	1.40
3594	Resistor—50,000 ohms—Carbon type— $\frac{1}{2}$ watt—Package of 5 . . . . .	1.00	8985	Transformer—Power transformer—105-120 volts—50-60 cycles . . . . .	4.26
3596	Capacitor—60 mmfd. . . . .	.36	8986	Transformer—Power transformer—200-250 volts—60 cycles . . . . .	4.38
3597	Capacitor—0.25 mfd. . . . .	.40	9002	Transformer—Power transformer—105-125 volts—25-50 cycles . . . . .	6.00
3598	Capacitor—0.1 mfd. . . . .	.36	<b>REPRODUCER ASSEMBLIES</b>		
3601	Coil—Choke coil . . . . .	.68	6467	Transformer—Output transformer . . . . .	1.44
3602	Resistor—60,000 ohms—Carbon type— $\frac{1}{4}$ watt—Package of 5 . . . . .	1.00	8987	Cone—Reproducer cone—Package of 5 . . . . .	5.00
3603	Resistor—500 ohms—Carbon type—1 watt—Package of 5 . . . . .	1.10	8988	Coil assembly—Comprising field coil, magnet and cone support . . . . .	2.35
3604	Capacitor—400 mmfd. . . . .	.30			
3605	Capacitor—770 mmfd. . . . .	.30			
3606	Capacitor—Comprising one 0.005 mfd. and one 0.25 mfd. capacitors . . . . .	.40			




# RCA-VICTOR, Inc.

## R-28




Schematic Circuit Diagram




Wiring Diagram

# RCA-VICTOR, Inc.



Schematic Circuit Diagram



Wiring Diagram

# RCA-VICTOR, Inc.

## R-28 BW

### SERVICE DATA

Voltage Rating . . . . . 105-125 Volts  
 Frequency Rating . . . . . 25-40 Cycles and 50-60 Cycles  
 Power Consumption . . . . . 70 Watts  
 Number and Types of Radiotrons . . . . . 1 UX-280,  
 1 RCA-2A5, 1 RCA-58, 1 RCA-57, 1 RCA-2A7—Total, 5  
 Undistorted Output . . . . . 1.75 Watts  
 Frequency Range . . . . . 540 K. C. to 1500 K. C.

The circuit consists of an R. F. stage, a combined oscillator and first detector in the RCA-2A7 tube, an intermediate stage consisting of a transformer only using two tuned circuits, a second detector, an output tube and a rectifier.

Service work in conjunction with this receiver will be similar to that of other Super-Heterodyne receivers of the small compact type construction. The line-up adjustments are made in conjunction with an external oscillator and an output meter. The line-up capacitors on the gang capacitor are adjusted for maximum output when the oscillator is coupled to the antenna and the set and oscillator are both set at 1400 K. C. The I. F. frequency is 175 K. C. and the two circuits that comprise it are adjusted for maximum output at 175 K. C.

This receiver is a five-tube Super-Heterodyne incorporating a Dynamic Loudspeaker as a part of the chassis; two-point tone control; single heater type Pentode Output and the inherent sensitivity, selectivity and tone quality of the Super-Heterodyne.

### RADIOTRON SOCKET VOLTAGES

115 Volt A. C. Line

#### MAXIMUM VOLUME CONTROL SETTING—NO SIGNAL


Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current, M. A.	Heater Volts
1. RCA-58 R. F. Amplifier	3.0	95	250	5.0	2.33
2. RCA-2A7 First Detector Oscillator	3.0	95	250	5.0	2.33
3. RCA-57 Second Detector	6.0	89	170	0.3	2.33
4. RCA-2A5 Power Amplifier	18.0	235	220	32.0	2.33
5. RCA-80 Rectifier	725 Volts PLATE TO PLATE—60 M. A. TOTAL				4.82
TOTAL CATHODE CURRENT—11 M. A.					

### REPLACEMENT PARTS

Insist on genuine factory tested parts, which are readily identified and may be purchased from authorized dealers.

Stock No.	DESCRIPTION	List Price	Stock No.	DESCRIPTION	List Price
<b>RECEIVER ASSEMBLIES</b>					
2747	Contact cap—Package of 5 . . . . .	\$0.50	3605	Capacitor—770 mmfd. . . . .	\$0.30
2749	Capacitor—2,400 mmfd. . . . .	1.50	3606	Capacitor—Comprising one 0.005 mfd. and one .025 mfd. capacitors . . . . .	.40
3050	Resistor—14,000 ohms—Carbon type—3 watts . . . . .	.60	6143	Resistor—40,000 ohms—Carbon type—¼ watt—Package of 5 . . . . .	2.00
3456	Capacitor—0.05 mfd. . . . .	.44	6228	Resistor—200,000 ohms—Carbon type—½ watt—Package of 5 . . . . .	2.50
3459	Capacitor—80 mmfd. . . . .	.44	6303	Resistor—20,000 ohms—Carbon type—½ watt—Package of 5 . . . . .	2.50
3472	Capacitor—0.0024 mfd. . . . .	.32	6306	Resistor—14,000 ohms—Carbon type—1 watt—Package of 5 . . . . .	2.50
3514	Resistor—250,000 ohms—Carbon type—½ watt—Package of 5 . . . . .	1.00	6443	Capacitor—10 mfd. . . . .	1.50
3555	Capacitor—0.1 mfd. . . . .	.36	6464	Transformer—I. F. transformer . . . . .	1.88
3572	Socket—Radiotron 7 contact socket . . . . .	.38	6470	Coil—Antenna coil . . . . .	1.08
3573	Socket—Radiotron 4 contact socket . . . . .	.32	6471	Coil—Oscillator coil assembly . . . . .	.74
3574	Coil—Choke coil . . . . .	.68	6472	Coil—R. F. coil assembly . . . . .	.94
3584	Ring—R. F. or oscillator coil retaining ring—Package of 5 . . . . .	.40	7485	Socket—Radiotron 6 contact socket . . . . .	.70
3586	Scale—Dial scale . . . . .	.50	7487	Shield—Radiotron tube shield . . . . .	.50
3587	Socket—Dial lamp socket and bracket . . . . .	.32	7589	Capacitor—Filter capacitor—Two 4.0 mfd. in container . . . . .	1.64
3588	Volume control—Complete with mounting nut . . . . .	1.40	7592	Condenser—3 gang variable tuning condenser . . . . .	3.35
3589	Switch—Tone control switch . . . . .	.54	8985	Transformer—Power transformer—105-125 volts—50-60 cycles . . . . .	4.26
3592	Knob—Station selector, operating switch or volume control knob—Package of 5 . . . . .	.80	8986	Transformer—Power transformer—200-250 volts—60 cycles . . . . .	4.38
3593	Screw—Chassis mounting screw—Package of 10 . . . . .	.30	9002	Transformer—Power transformer—105-125 volts—25-50 cycles . . . . .	6.00
3594	Resistor—50,000 ohms—Carbon type—½ watt—Package of 5 . . . . .	1.00	<b>REPRODUCER ASSEMBLIES</b>		
3596	Capacitor—60 mmfd. . . . .	.36	6467	Transformer—Output transformer . . . . .	1.44
3597	Capacitor—0.25 mfd. . . . .	.40	8987	Cone—Reproducer cone—Package of 5 . . . . .	5.00
3598	Capacitor—0.1 mfd. . . . .	.36	9004	Coil assembly—Comprising field coil, magnet and cone support . . . . .	2.35
3601	Coil—Choke coil . . . . .	.68			
3602	Resistor—60,000 ohms—Carbon type—¼ watt—Package of 5 . . . . .	1.00			
3603	Resistor—500 ohms—Carbon type—1 watt—Package of 5 . . . . .	1.10			
3604	Capacitor—400 mmfd. . . . .	.30			


# RCA-VICTOR, Inc.



Schematic Diagram

R-37

R-38



Wiring Diagram

# RCA-VICTOR, INC.

## R-37 R-38


### SERVICE DATA

#### Electrical Specifications

Voltage Rating . . . . .	115 Volts
Frequency Rating . . . . .	25-60 and 50-60 Cycles
Power Consumption . . . . .	60 Cycle 75 Watts, 25 Cycle 80 Watts
Number and Types of Radiotrons . . . . .	2 RCA-58, 1 RCA-2A7, 1 RCA-2B7, 1 RCA-2A5, 1 RCA-80—Total 6
Undistorted Output . . . . .	1.75 Watts
Frequency Range . . . . .	540 K. C. to 1500 K. C.

This receiver is a six tube Superheterodyne incorporating a Dynamic Loudspeaker as a part of the chassis, automatic volume control, single heater type Pentode output tube, continuously variable type tone control and the inherent sensitivity, selectivity and tone quality of the Superheterodyne.

The circuit consists of an R. F. stage using Radiotron RCA-58, a combined oscillator and first detector in the RCA-2A7 tube, an intermediate stage using Radiotron RCA-58, an RCA-2B7 functioning a combined second detector and automatic volume control, an output stage using the new heater Pentode RCA-2A5 and the RCA-80 functioning as a rectifier.



Location of I. F. Line-up Adjustment Screws

Service work in conjunction with this receiver will be similar to that of other Superheterodyne receivers incorporating a similar type automatic volume control.

#### Line-up Adjustments

**I. F. Tuning Adjustments**—Two transformers comprising three tuned circuits (the secondary of the second transformer is untuned) are used in the intermediate amplifier. These are tuned to 175 K. C. and the adjustment screws are accessible as shown in Figure C. Proceed as follows:

- (a) Procure a modulated oscillator giving a signal at 175 K. C., a non-metallic screw driver such as Stock No. 7065 and an output meter.
- (b) Short-circuit the antenna and ground leads and tune the receiver so that no signal is heard. Set the volume control at maximum and connect a ground to the chassis.
- (c) Connect the oscillator output between the 1st detector control grid and chassis ground. Connect the output meter across the voice coil of the loudspeaker and adjust the oscillator output so that with the receiver volume control at maximum, a slight deflection is obtained in the output meter.
- (d) Adjust the primary of the second, and the secondary and primary of the first I. F. transformers until a maximum deflection is obtained. Keep the oscillator output at a low value so that only a slight deflection is obtained on the output meter at all times. Go over these adjustments a second time as there is a slight interlocking of adjustments. This completes the I. F. Adjustments.

**R. F. and Oscillator Adjustments**—The three gang capacitor screws are accessible at the top of the chassis. Proceed as follows:

- (a) Procure a modulated oscillator giving a signal at 1400 K. C., a non-metallic screw driver such as Stock No. 7065 and an output meter.
- (b) Connect the output of the oscillator to the antenna and ground lead of the receiver. Check the dial at the extreme maximum position of the tuning capacitor. The indicator should be at the last division. Then set the dial at 140, the oscillator at 1400 K. C. and connect the output meter across the cone coil. Adjust the oscillator output so that a slight deflection is obtained when the receiver volume control is at maximum.
- (c) Adjust the three tuning condenser line-up capacitors until maximum deflection is obtained in the output meter.

When making both the I. F. and R. F. adjustments, the important point to remember is that the receiver volume control must be at its maximum position and the minimum input signal necessary from the oscillator must be used.


### RADIOTRON SOCKET VOLTAGES

115 Volts. A. C. Line—No Signal

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current M. A.	Heater Volts
1. RCA-58 R. F.	3.0	95	255	5.0	2.31
2. RCA-2A7 1st Det. Osc.	3.0*	95*	255*	3.0*	2.31
3. RCA-58 I. F.	3.0	95	255	5.0	2.31
4. RCA-2B7 2nd Det. A. V. C.	7.5	92	60	2.0	2.31
5. RCA-2A5 Power	20.0	250	235	33.0	2.31
6. RCA-80 Rect.	700/350 Volts - 75 M. A. Total Current				4.82

\*The Voltages and current refer to the detector part of the tube. The total cathode current is 10 M. A.

# RCA-VICTOR, INC.




Schematic Wiring Diagram

## R-70

### RADIOTRON SOCKET VOLTAGES

All Voltages Measured at Maximum Volume with no Signal Impressed on Input. 120 Volt 60 Cycle A. C. Source Used

Radiotron No.	Cathode or Filament to Control Grid Volts	Cathode or Filament to Screen Grid Volts	Cathode or Filament to Plate Volts	Plate Current M. A.	Heater or Filament Volts
1. R. F. RCA-58	4.5	100	245	6.0	2.37
2. Oscillator RCA-56	—	—	60	4.5	2.37
3. First Detector RCA-58	13.0	90	235	1.3	2.37
4. I. F. RCA-58	4.5	100	245	6.0	2.37
5. Second Detector RCA-56	18.0	—	230	1.0	2.37
6. Power RCA-247	16.5	250	210	30.0	2.37
7. Rectifier UX-280	370 Volts R. M. S. each plate			70.0	5.0



Chassis Wiring Diagram

# RCA-VICTOR, INC.

## SERVICE NOTES

for

# RCA Victor Model R-71-B

### ELECTRICAL SPECIFICATIONS

"A" Batteries Required.....	Eveready Aircell "A" Battery
"B" Batteries Required.....	Four 45 Volt Blocks, Preferably of Heavy Duty Type
"A" Battery Current.....	0.48 Amperes
Average "B" Battery Current.....	18 M. A.
Type of Circuit.....	Super-Heterodyne with A. V. C., Class "B" Output Stage and Compensated Volume Control
Type and Number of Radiotrons.....	3 RCA-234, 1 RCA-232, 4 RCA-230—Total 8
Number of R. F. Stages.....	One
Number of I. F. Stages.....	One
Type of Second Detector.....	Pentode, Combining Detector, A. V. C. and Audio Amplification
Number of Audio Stages.....	Two
Undistorted Output.....	1.00 Watt

### PHYSICAL SPECIFICATIONS

Height.....	18 11/16 Inches
Depth.....	10 21/32 Inches
Width.....	14 Inches
Weight Alone.....	34 Pounds
Weight Packed for Shipment.....	40 Pounds

RCA Victor Model R-71-B is an eight tube battery operated Super-Heterodyne radio receiver incorporating such features as Super-Control R. F. Amplifier Pentode Radiotrons in the R. F. and I. F. stages, automatic volume control, combination Pentode second detector, compensated Class "B" audio amplifier and the inherent sensitivity, selectivity and tone quality of the RCA Victor Super-Heterodyne. The chassis and permanent magnet dynamic loudspeaker are enclosed in a standard R-71 cabinet. The performance of this receiver is comparable in all respects to the A. C. model of the same designation, except in output volume.

### SERVICE DATA


Except for different chassis design the circuit used in the R-71-B is very similar to that of the P-31 Portable Radiola. A reference to this Service Note should therefore be made for a description of the circuit and manner of making adjustments. The voltage readings are given below and the replacement parts on page 3. Figure 1 shows the schematic circuit diagram and Figure 2 the chassis wiring diagram.

### RADIOTRON SOCKET VOLTAGES

(No signal being received)

Radiotron No.	Control Grid to Filament Volts	Screen Grid to Filament Volts	Plate to Filament Volts	Screen Current M. A.	Plate Current M. A.	Filament Volts
1. R. F.	0.2	65	157	1.0	3.0	2.0
2. 1st Detector	0.5	65	157	0.1	0.2	2.0
3. Oscillator	1.0	—	65	—	4.0	2.0
4. I. F.	0.5	65	157	1.0	3.0	2.0
5. 2d Detector	2.0	155	0	4.0	0	2.0
6. 1st A. F.	1.0	—	155	—	2.5	2.0
7. Power	14.0	—	155	—	1.2	2.0
8. Power	14.0	—	155	—	1.2	2.0

# RCA-VICTOR, INC.



*Schematic Wiring Diagram of R-71-B*



# RCA-VICTOR, INC.


## R-73

### SERVICE DATA

#### Electrical Specifications

Voltage Rating . . . . . 105-125 Volts  
 Power Consumption . . . . . 100 Watts  
 Type and Number of Radiotrons . . . . . 3 RCA-58, 1 RCA-56,  
 1 RCA-55, 2 RCA-247, 1 UX-280—Total, 8  
 Type of Circuit . . . . . Super-Heterodyne  
 with A. V. C., tone control and push-pull Pentode Output  
 Undistorted Output . . . . . 3 Watts  
 R. F. and Oscillator Alignment Frequency  
 600 K. C. and 1400 K. C.  
 Intermediate Frequency . . . . . 175 K. C.

This receiver is an eight tube Super-Heterodyne incorporating Automatic volume control, tone control and Push-Pull Pentode Output. Service Data will be found to be similar to that of other Super-Heterodyne receivers incorporating similar features.



I. F. Alignment Location

#### Line-up Adjustments


**I. F. Tuning Adjustments**—Two transformers comprising four tuned circuits are used in the intermediate amplifier. These are tuned to 175 K. C. and the adjustment screws are accessible from the rear of the chassis. See Figure 5 for location of the adjustment screws and proceed as follows:

- Procure a modulated oscillator giving a signal at 175 K. C., a non-metallic screw driver such as Stock No. 7065 and an output meter.
- Remove the oscillator tube and connect a ground to the chassis.
- Connect the oscillator output between the 1st detector control grid and chassis ground. Connect the output meter across the voice coil of the loudspeaker and adjust the oscillator output so that with the receiver volume control at maximum, a slight deflection is obtained in the output meter.
- Adjust the secondary and then the primary of the second and then the first I. F. transformers until a

maximum deflection is obtained. Keep the oscillator output at a low value so that only a slight deflection is obtained on the output meter at all times. Go over these adjustments a second time as there is a slight interlocking of adjustments. This completes the I. F. Adjustments.

**R. F. and Oscillator Adjustments**—The three gang capacitor screws are accessible through the bottom cover and the 600 K. C. oscillator trimmer through the top of the chassis adjacent to the R. F. coil. Proceed as follows:

- Procure a modulated oscillator giving a signal at 1400 K. C. and 600 K. C., a non-metallic screw driver such as Stock No. 7065 and an output meter.



Loudspeaker Wiring

- Connect the output of the oscillator to the antenna and ground lead of the receiver. Check the dial at the extreme maximum position of the tuning capacitor. The indicator should be at the short line on the dial. Then set the dial at 1400 K. C., the oscillator at 1400 K. C. and connect the output meter across the cone coil. Adjust the oscillator output so that a slight deflection is obtained when the receiver volume control is at maximum.
- Adjust the three line-up capacitors accessible at the bottom of the receiver until maximum deflection is obtained in the output meter.
- Shift the oscillator frequency to 600 K. C. and tune the signal. Then adjust the 600 K. C. capacitor, accessible through the top, until maximum deflection is obtained. The main tuning capacitor must be rocked back and forth while making this adjustment.
- Then realign at 1400 K. C. This completes the adjustments.

When making both the I. F. and R. F. adjustments, the important point to remember is that the receiver volume control must be at its maximum position and the minimum input signal necessary from the oscillator must be used.

#### RADIOTRON SOCKET VOLTAGES

120 Volts, 60 Cycles A. C. Line—V. C. At Maximum and no Signal


Radiotron No.	Control Grid to Filament or Cathode Volts	Screen Grid to Filament or Cathode Volts	Plate to Filament or Cathode Volts	Plate Current M. A.	Heater or Filament Volts
1. R. F. RCA-58	4.5	100	165	6.0	2.37
2. 1st Det. RCA-58	11.0	95	155	1.5	2.37
3. Oscillator RCA-56	—	—	70	4.5	2.37
4. I. F. RCA-58	4.5	100	165	6.0	2.37
5. 2nd Det. RCA-55 and A.V.C.	—	—	55	4.7	2.37
6. Power RCA-247	19.0	235	225	20.0	2.37
7. Power RCA-247	19.0	235	225	20.0	2.37

#### OTHER IMPORTANT VOLTAGES

2nd Detector and A.V.C. Cathode to Low Side of Field . 105 Volts  
 Chassis to Low Side of Field . . . . . 90 Volts

Voltage Across Field . . . . . 120 Volts  
 Rectifier . . 370 Volts R.M.S. Each Plate—80 M.A. Each Plate


# RCA-VICTOR, INC. R-73



**RESISTANCE AND CAPACITOR VALUES**

- C-17—25 Cycles, 8.0 Mfd.
- C-17—60 Cycles, 1.0 Mfd.
- C-25—25 Cycles, 4.0 Mfd.
- C-25—60 Cycles, 1.0 Mfd.
- L-11—3,000 Ohms
- L-12—3,000 Ohms
- Interstage Primary—1,650 Ohms
- Interstage Secondary—7,900 Ohms
- Output Primary—875 Ohms
- Output Secondary—0.375 Ohm
- Power High Voltage—60 Cycles, 375 Ohms
- 25 Cycles, 590 Ohms
- Field—1,300 Ohms

Schematic Circuit



Chassis Wiring Diagram


# RCA-VICTOR, INC.

## R-74, R-76, R-77.

### SERVICE DATA

Service data in conjunction with these receivers will be found to be similar to that of other RCA Victor Super-Heterodyne receivers employing automatic volume control. A dummy Radiotron RCA-56 should replace the tube normally in the A. V. C. socket when making R. F., oscillator and I. F. adjustments. The Radiotron socket voltages are given below and the Replacement Parts on Pages 7 and 8.

Figure 1 shows the schematic diagram for all models. Figures 2 and 4 show the wiring diagrams while Figure 3 shows the loudspeaker wiring. Figures 5, 6, and 7 show various magnetic pickup connections and Figure 8 gives the correct manner of attaching the RCA Victor Short Wave Adaptor.




### RADIOTRON SOCKET VOLTAGES

120 Volt A. C. Line

(No Signal Being Received—Antenna Lead Grounded to Chassis)

Radiotron No.	Cathode to Heater Volts, D. C.	Cathode or Filament to Control Grid Volts, D. C.	Cathode or Filament to Screen Grid Volts, D. C.	Cathode or Filament to Plate Volts, D. C.	Plate Current, M. A.	Heater or Filament Volts, D. C.
<b>VOLUME CONTROL AT MINIMUM</b>						
1. R. F.	+4	1.0	90	280	0	2.4
2. 1st Det.	0	1.2	90	275	0	2.4
3. Osc.	+4	0	—	55	5.0	2.4
4. I. F.	+3	1.8	90	280	0	2.4
5. A. V. C.	0	0	—	5	0	2.4
6. 2nd Det.	+15	3.0	—	225	1.0	2.4
7. 1st A. F.	+14	10.0	—	260	5.0	2.4
8. Power	—	0	—	400	6.0	2.4
9. Power	—	0	—	400	6.0	2.4
<b>VOLUME CONTROL AT MAXIMUM</b>						
1. R. F.	+4	0	70	250	4.5	2.4
2. 1st Det.	+6	0.6	75	235	2.0	2.4
3. Osc.	+4	0	—	50	5.0	2.4
4. I. F.	+4	1.5	84	250	4.5	2.4
5. A. V. C.	0	0	—	15	0	2.4
6. 2nd Det.	+15	3.0	—	210	1.0	2.4
7. 1st A. F.	+14	10.0	—	240	5.0	2.4
8. Power	—	0	—	400	6.0	2.4
9. Power	—	0	—	400	6.0	2.4

# RCA-VICTOR, INC.




Change in Wiring of Console Models

Schematic Circuit Diagram




# RCA-VICTOR, INC.




R-76 and R-77 Wiring Diagram

# RCA-VICTOR, INC.



Schematic Circuit

## R-75




Chassis Wiring Diagram

Radiotron No.	Control Grid to Cathode, Volts	Screen Grid to Filament or Cathode, Volts	Plate to Filament or Cathode, Volts	Plate Current, M. A.	Heater or Filament, Volts
1. R. F. RCA-58	4.0	100	240	6.0	2.4
2. 1st Det. RCA-58	10.0	90	230	2.0	2.4
3. Osc. RCA-56	—	—	75	4.5	2.4
4. I. F. RCA-58	4.0	100	240	6.0	2.4
5. 2nd Det. RCA-55 and A.V.C.	5.8	—	100	4.0	2.4
6. P.W.R. RCA-2A5	19.0	230	220	20.0	2.4
7. P.W.R. RCA-2A5	19.0	230	220	20.0	2.4

Rectifier—370 Volts R.M.S. Each Plate

# RCA-VICTOR, INC.




**RESISTANCE AND CAPACITOR VALUES**

C-17—25 Cycles, 8.0 Mfd.  
 C-17—60 Cycles, 1.0 Mfd.  
 C-25—25 Cycles, 4.0 Mfd.  
 C-25—60 Cycles, 1.0 Mfd.  
 L-11—3,000 Ohms  
 L-12—3,000 Ohms  
 Interstage Primary—1,650 Ohms  
 Interstage Secondary—7,900 Ohms  
 Output Primary—875 Ohms  
 Output Secondary—0.375 Ohm  
 Power High Voltage—  
 60 Cycles, 375 Ohms  
 25 Cycles, 590 Ohms  
 Field—1,300 Ohms

Schematic Circuit

## Radiola R-75



Radiotron No.	Control Grid to Filament or Cathode Volts	Screen Grid to Filament or Cathode Volts	Plate to Filament or Cathode Volts	Plate Current M. A.	Heater or Filament* Volts
1. R. F. RCA-58	4.5	100	165	6.0	2.37
2. 1st Det. RCA-58	11.0	95	155	1.5	2.37
3. Oscillator RCA-56	—	—	70	4.5	2.37
4. I. F. RCA-58	4.5	100	165	6.0	2.37
5. 2nd Det. RCA-55 and A.V.C.	—	—	55	4.7	2.37
6. Power RCA-247	19.0	235	225	20.0	2.37
7. Power RCA-247	19.0	235	225	20.0	2.37

### OTHER IMPORTANT VOLTAGES

2nd Detector and A.V.C. Cathode to Low Side of Field. 105 Volts  
 Chassis to Low Side of Field. . . . . 90 Volts  
 Voltage Across Field. . . . . 120 Volts  
 Rectifier. . . 370 Volts R.M.S. Each Plate—80 M.A. Each Plate



# RCA-VICTOR, INC.

## R-90


### SERVICE DATA

#### Electrical Specifications

Voltage Rating.....	105-125 Volts
Power Consumption.....	120 Watts
Type and Number of Radiotrons.....	3 RCA-56, 4 RCA-58, 1 UX-280, 2 RCA-2A5—Total, 10
Frequency Range.....	540 K. C.—1500 K. C.
Undistorted Output.....	4.0 Watts

This receiver is a ten tube Super-Heterodyne radio receiver. Features such as illuminated control, improved automatic volume control, noise suppressor, compensated volume control, heater pentode output tubes operated as a push-pull stage, acoustically correct cabinets and the inherent sensitivity, selectivity and tone quality of the Super-Heterodyne are included in this instrument.

Figure A shows the schematic circuit, Figure B the wiring diagram, Figure C the location of the adjustable capacitors and Figure D, the loud-speaker wiring. The Radiotron socket voltages, the line-up procedure and the replacement parts are given on the following pages.



Location of Adjustable Capacitors


#### R. F. And Oscillator Line - Up Capacitor Adjustments

Four adjustable capacitors are provided for aligning the R. F. circuits and adjusting the oscillator frequency so that the oscillator will maintain a constant frequency—175 K. C.—difference from that of the incoming signal. Poor quality, insensitivity, poor A. V. C. action and possible inoperation of the receiver may be caused by these capacitors being out of adjustment.

If the other adjustments have not been tampered with—the intermediate transformer tuning capacitors—the following procedure may be used for aligning these capacitors.

- (a) Procure an R. F. Oscillator giving a modulated signal at 600 K. C. and 1400 K. C. Also procure a non-metallic screw driver such as Stock No. 7065.
- (b) An output meter is necessary. This may be a current squared galvanometer connected to the secondary of the output transformer instead of the cone coil, a 0.5 milliammeter connected in series with the plate supply to the second detector or a low range A. C. voltmeter connected across the reproducer unit cone coil.
- (c) A dummy Radiotron RCA-56 is necessary to substitute for the one normally used in the A. V. C. socket. This should be a tube that is otherwise normal in all respects but having one heater prong removed. Insert this tube in the A. V. C. socket.
- (d) First check the chassis and carefully ascertain that the dial pointer reads exactly at the first line on the scale when the tuning capacitor rotor plates are fully meshed with the stator plates.
- (e) Place the oscillator in operation at exactly 1400 K. C. and couple its output to the antenna. Set the dial scale at exactly 1400. Connect the output meter to the set and place the volume control and suppressor control, if noise level will permit, at its maximum position. Adjust the oscillator input so that an excessive reading on the output meter is not obtained.

- (f) With a suitable socket wrench—the nuts are at ground potential—adjust the oscillator, first detector and R. F. line-up capacitors, until a maximum deflection is obtained in the output meter.
- (g) Set the oscillator at 600 K. C. Tune in the signal with the receiver until a maximum deflection is obtained in the output meter. Now adjust the 600 K. C. series capacitor, Figure C, until a maximum deflection is obtained in the output meter. Rock the tuning capacitor back and forth while making this adjustment as the tuning capacitor and oscillator series capacitor adjustments interlock.



Loudspeaker Wiring

- (b) Change the frequency of the oscillator to 1400 K. C. and set the dial at 1400. Again make the adjustments given under (f) and (g). So adjusted, the R. F. circuits are properly aligned and the oscillator will maintain a constant frequency difference from the incoming R. F. signal.

#### I. F. Tuning Capacitor Adjustments

Although this receiver has two I. F. stages, one for the second detector and one for the A. V. C., only two of the three I. F. transformers are tuned by adjustable capacitors and require adjustment. The stage used for the A. V. C. is broadly tuned and does not require any adjustment.

The transformers are all tuned to 175 K. C. and the circuits broadly peaked.

A detailed procedure for making this adjustment follows:

- (a) Procure a modulated R. F. Oscillator that gives a modulated 175 K. C. signal. Also procure a non-metallic screw driver such as Stock No. 7065.
- (b) An output meter is necessary. This may be a current squared galvanometer connected to the secondary of the output transformer instead of the cone coil, a 0.5 milliammeter connected in series with the plate supply to the second detector or a low range A. C. voltmeter connected across the reproducer unit cone coil.
- (c) A dummy Radiotron RCA-56 is necessary to substitute for the one normally used in the A. V. C. socket.
- (d) Remove the oscillator tube and make a good ground connection to the chassis. Place the oscillator in operation and couple its output from the control grid of the first detector to ground. Adjust the oscillator output, with the receiver volume control at maximum, until a deflection is obtained in the output meter.
- (e) Refer to Figure C. Adjust the secondary and primary of the second and then the first I. F. transformer until a maximum deflection is obtained in the output meter. Go through these adjustments a second time as a slight readjustment may be necessary.

When the adjustments are made the set should perform at its maximum efficiency. However, due to the interlocking of adjustments, it is good practice to follow the I. F. adjustments with the R. F. and oscillator line-up capacitor adjustments. The correct method of doing this is given in the preceding section.


#### RADIOTRON SOCKET VOLTAGES

120 Volt, A. C. Line—No signal being received—Volume Control at minimum

Radiotron No.	Cathode or Control Grid Volts, D. C.	Cathode or Filament to Screen Grid Volts, D. C.	Cathode or Filament to Plate Volts, D. C.	Plate Current, M. A.	Heater or Filament Volts, A. C.
1. R. F.	3.0	100	230	7.0	2.4
2. 1st Detector	8.0	95	220	2.5	2.4
3. Oscillator	—	—	105	6.0	2.4
4. I. F.	7.5	100	225	2.5	2.4
5. A. V. C.—I. F.	7.5	100	225	2.5	2.4
6. A. V. C.	20.0	—	0	—	2.4
7. 2nd Detector	17.0	—	250	1.2	2.4
8. Power	18.0	255	245	33.0	2.4
9. Power	18.0	255	245	33.0	2.4


# RCA-VICTOR, INC.

## R-90




# RCA-VICTOR, INC.

## Radiola Automatic Electrola Model RAE-84




Schematic Wiring Diagram of RAE-84

# RCA-VICTOR, INC.



# RCA-VICTOR, INC.

## RAE-84




Amplifier Wiring Diagram of RAE-84

### RADIOTRON SOCKET VOLTAGES

120 Volt Line—Fuse at 120 Volt Tap—Antenna Shorted to Ground—No Signal

Radiotron No.	Cathode or Filament to Control Grid Volts, D. C.	Cathode or Filament to Screen Grid Volts D. C.	Cathode or Filament to Plate Volts D. C.	Diode Plate No. 1 to Cathode Volts D. C.	Diode Plate No. 2 to Cathode Volts D. C.	Plate Current M. A.	Heater or Filament Volts D. C.
1. RCA-58—R. F.	— 3.5	106	212	—	—	6.5	2.5
2. RCA-56—Osc.	—	—	65	—	—	4.5	2.5
3. RCA-58—1st Det.	9	101	206	—	—	1.8	2.5
4. RCA-58—I. F.	— 12	98	203	—	—	2.0	2.5
5. RCA-58—A. V. C. I. F.	— 5	106	210	—	—	4.0	2.5
6. RCA-55—A. V. C. Sup. (Sensitivity Control At Minimum)	0	—	0	0	— 12	0	2.5
6. RCA-55—A. V. C. Sup. (Sensitivity Control At Maximum)	0	—	69	0	36	8.0	2.5
7. RCA-56—2nd Det.	— 15	—	200	—	—	1.0	2.5
8. RCA-56—Driver	— 11	—	204	—	—	5.0	2.5
9. RCA-56—Power	0	—	204	—	—	5.0	2.5
10. RCA-46—Power	0	—	400	—	—	6.0	2.5
11. RCA-46—Power	0	—	400	—	—	6.0	2.5
12. RCA-82—Rectifier	—	—	—	—	—	—	—

462.5 Volts R. M. S. Each Plate—72 M. A. Total Plate Current.



Location of I. F. Capacitors

# RCA-VICTOR, INC.

## RE-40

### SERVICE DATA

Voltage Rating . . . . . 105-125 Volts  
 Frequency Rating . . . . . 25, 30, 40, 50 and 60 Cycles  
 Power Consumption . . . . . 60 Cycles, 95 Watts  
 Number and Types of Radiotrons . . . . . 1 UX-280,  
 1 RCA-2A5, 1 RCA-58, 1 RCA-57, 1 RCA-2A7—Total 5  
 Undistorted Output . . . . . 1.75 Watts  
 Frequency Range . . . . . 540 K. C. to 1500 K. C.

This combination radio-phonograph instrument uses a five-tube Super-Heterodyne receiver incorporating a dynamic loudspeaker, two-point tone control, single heater type Pentode Output tube and the inherent sensitivity, selectivity and tone quality of the Super-Heterodyne.

The standard RCA Victor two speed motor board equipment is used and the entire assembly enclosed in a table type cabinet.

The circuit consists of an R. F. stage, a combined oscillator and first detector in the RCA-2A7 tube, an intermediate stage consisting of a transformer only, using two tuned circuits, a second detector, an output tube and a rectifier.

Service work in conjunction with this receiver will be similar to that of other Super-Heterodyne receivers of the small compact type construction. The line-up adjustments are made in conjunction with an external oscillator and an output meter. The line-up capacitors on the gang capacitor are adjusted for maximum output when the oscillator is coupled to the antenna and the set and oscillator are both set at 1400 K. C. The I. F. frequency is 175 K. C. and the two circuits that comprise it are adjusted for maximum output at 175 K. C.

Service data for the magnetic pickup is included below.

### RADIOTRON SOCKET VOLTAGES

115 Volt A. C. Line

#### MAXIMUM VOLUME CONTROL SETTING—NO SIGNAL

Radiotron No.	Cathode to Control Grid, Volts	Cathode to Screen Grid, Volts	Cathode to Plate, Volts	Plate Current, M. A.	Heater Volts
1. RCA-58 R. F. Amplifier	3.0	95	250	5.0	2.33
2. RCA-2A7 First Detector Oscillator	3.0	95	250	3.0	2.33
3. RCA-57 Second Detector	6.0	89	170	0.3	2.33
4. RCA-2A5 Power Amplifier	18.0	235	220	32.0	2.33
5. RCA-80 Rectifier	275 Volts PLATE TO PLATE—60 M. A. TOTAL				4.82
TOTAL CATHODE CURRENT—11 M. A.					

### SERVICE DATA ON MAGNETIC PICKUP


This magnetic pickup is of a new design that results in excellent reproduction. While in physical appearance, it is similar to that of the older type, details of construction are considerably different. It consists of essentially a chromium steel magnet, two thin pole pieces, a mechanism support and bracket, a coil, and an armature.

#### REPLACING MAGNET COIL, PIVOT RUBBERS, OR ARMATURE

In order to replace a defective magnet coil or hardened pivot rubbers, it is necessary to proceed as follows:

- (a) Remove the pickup cover by removing the center holding screw and needle screw.
- (b) Remove the pickup magnet and the magnet clamp by pulling them forward.
- (c) Unsolder the coil leads and remove the mechanism assembly from the back plate by releasing the two mounting screws.
- (d) Remove screws A and B, Figure A, and then remove the mechanism assembly from the pole pieces.
- (e) The coil or the front pivot rubber may now be removed and replaced. If it is desired to replace the rear pivot rubber, then the end of the armature soldered to the mechanism support must be unsoldered.
- (f) The mechanism should now be reassembled except for the magnet which must be magnetized. After being magnetized the mechanism—with the pole pieces upward, should be placed so that the magnet may be slid from the magnetizer onto the pole pieces without breaking physical contact. After placing the pole pieces on the magnet, the entire assembly should be remagnetized thoroughly, being careful not to change polarity.

- (g) After reassembling to the mechanism, the entire assembly should be fastened to the back plate by means of the two screws provided, making sure support is down against pads on back. At the same time, the metal dust cover must be placed in position.




*View of Pickup showing parts*

- (h) After remagnetizing, it is necessary to correctly center the armature. This may be done quite accurately by feeling its play after the needle is inserted. A little practice will quickly show which way an adjustment is necessary to have the armature centered properly. The adjustment is made by loosening screws A and B (Figure A), and sliding the mechanism slightly in relation to the pole pieces.
- (i) The cover may be now replaced over the entire assembly, and the pickup returned to the tone arm.


Only rosin core solder should be used for any soldering in conjunction with the pickup. However, if great care to wipe clean and use as small amount as possible is exercised, paste or liquid flux may be used for soldering the end of the spring.

# RCA-VICTOR, INC.




Schematic Circuit

## RE - 40




Wiring Diagram

# RCA-VICTOR, INC. RE-80




Schematic Wiring Diagram



Chassis Wiring Diagram



# RCA-VICTOR, INC.



Radiotron No.	Control Grid to Filament or Cathode Volts	Screen Grid to Filament or Cathode Volts	Plate to Filament or Cathode Volts	Plate Current M. A.	Heater or Filament Volts
1. R. F. RCA-58	4.5	100	165	6.0	2.37
2. 1st Det. RCA-58	11.0	95	155	1.5	2.37
3. Oscillator RCA-56	—	—	70	4.5	2.37
4. I. F. RCA-58	4.5	100	165	6.0	2.37
5. 2nd Det. RCA-55 and A.V.C.	—	—	55	4.7	2.37
6. Power RCA-247	19.0	235	225	20.0	2.37
7. Power RCA-247	19.0	235	225	20.0	2.37

### OTHER IMPORTANT VOLTAGES


2nd Detector and A.V.C. Cathode to Low Side of Field . . . . .120 Volts  
 Chassis to Low Side of Field . . . . .90 Volts

Voltage Across Field . . . . .120 Volts  
 Rectifier . .370 Volts R.M.S. Each Plate—80 M.A. Each Plate

# RCA-VICTOR, INC.

## RE-81


# Radiola Electrola, Model RE-81



Schematic Diagram of RE-81


# RCA-VICTOR, INC.

## RE - 81



# RCA-VICTOR, INC.


## Centralized Radio Rack Model ER-1240-A2



Schematic and Assembly Wiring Diagram

# RCA-VICTOR, INC.

## ER 1240-A2



Wiring Diagram of Receiver Assembly

# RCA-VICTOR, INC.

## MODEL ER-1240-A2

### VOLTAGE READINGS AT RADIOTRON SOCKETS

The following voltages taken at each Radiotron socket with the receiver in operating condition should prove of value when checking with test sets such as the Weston Model 547, Type 3, or others giving similar readings. The plate currents shown are not necessarily accurate for each tube, as the cable in the test set will cause some circuits to oscillate, due to its added capacity. Small variations of voltages will be caused by different tubes and line voltages. Therefore, the following values must be taken as approximately those that will be found under varying conditions. The numbers in column 1 indicate the tube socket numbers shown in Figure 3.

### RADIOTRON SOCKET VOLTAGES—RECEIVER ASSEMBLY 120 VOLT LINE

Tube No.	Cathode to Heater Volts, D. C.	Cathode or Filament to Control Grid Volts, D. C.	Cathode to Screen Grid Volts, D. C.	Cathode or Filament to Plate Volts, D. C.	Plate Current M. A.	Screen Grid Current M. A.	Heater or Filament Volts, A. C.
<b>VOLUME CONTROL AT MINIMUM</b>							
1	40	40	55	200	0	0	2.4
2	40	0	—	50	4.0	—	2.4
3	8.0	7.0	90	240	0.5	0.25	2.4
4	40	40	55	200	0	0	2.4
5	25	*5.0	—	220	0.5	—	2.4
6	—	*30.0	—	245	30.0	—	2.4
7	—	*30.0	—	245	30.0	—	2.4
<b>VOLUME CONTROL AT MAXIMUM</b>							
1	3.5	3.5	70	240	5.0	**0.7	2.4
2	2.5	0	—	65	5.5	—	2.4
3	5.0	5.0	70	235	0.5	0.25	2.4
4	3.5	3.5	70	240	5.0	**0.7	2.4
5	25	*5.0	—	220	0.5	—	2.4
6	—	*30	—	245	25.0	—	2.4
7	—	*30	—	245	25.0	—	2.4

\*Not true reading due to resistance in circuit.


\*\*This reading may be + or - depending on age of tube.

### RADIOTRON SOCKET VOLTAGES—POWER AMPLIFIER 120 VOLT LINE

<b>VOLUME CONTROL AT ZERO—NO STATION TUNED IN</b>				
Tube	Cathode or Filament to Grid—Volts	Cathode or Filament to Plate—Volts	Plate Current Milliamperes	Filament or Heater—Volts
Either UX-250	86.5	460	55.0	7.5
Either UX-281	—	630	75.0	7.5

# SENTINEL RADIO CORP.

## MODEL 108-A AND 109



Type of Tube	Position of Tube	Filament Volts	B Volts	C Volts	Normal Plate M.A.	Screen Volts
227	Oscillator	2.4	62.5		4.75	27
235	Radio Frequency	2.4	240	2.15	2.75	65
224	1st Detector	2.4	230	4.35	.5	72
235	Intermediate	2.4	237	2.15	2.75	35*
224	2nd Detector	2.4	100*	2.1*	2.5	250
247	Pentode	2.4	220	16.5**	32.5	250
247	Pentode	2.4	220	16.5**	32.5	250
280	Rectifier	4.95			47.5 ea. plate	

115 V. Line Volume Control Full On

\*These readings are only comparative and are not true voltages applied. The volt meter, when the readings are taken at these points, is in series with a very high resistance.


\*\*To read the 247 bias, read between H.K. speaker socket and ground.





# SENTINEL RADIO CORP.

## MODEL 513



**TUBE VOLTAGES**

Type of Tube	Position of tube	Filament volts	Plate volts	C volts	Normal Plate-M.A.	Screen volts
257	Composite oscillator and modulator	2.4	240	6	3.5	85
258	Intermediate frequency	2.4	240	3	7	85
255	Detector and audio	2.4	30*			
247	Output	2.4	220	5**	32.5	240
280	Rectifier	4.9	30 M.A. each plate			

\* These readings are only comparative and are not true voltages applied. The voltmeter, when readings are taken at these points, is in series with a very high resistance.  
 \*\* To read 247 bias, read between 247 control grid and ground.

- NOTE:
1. DOTTED LINES DENOTE SHIELDING
  2. ALL NUMBERS SHOWN RELATIVE TO PARTS ARE OUR PART NOS.
  3. NUMBERS SHOWN WITH PREFIX "A" ARE COMPLETE ASSEMBLIES.
  4. WHEN PHONO-JKS ARE USED CATHODE OF 55 TUBE IS CONNECTED TO POINT MARKED "X"





# SILVER-MARSHALL MFG. CO.

## SILVER-MARSHALL MODEL Z-13 ALL-WAVE 13-TUBE SUPERHETERODYNE

(The Z-13 Round-the-World receiver incorporates automatic volume control, silent tuning control, beat-tuning oscillator, parallel type 56 driver tubes, push-pull type 59 A. F. output, tone control, and a diode second-detector. The wavelength range is 15 to 545 meters, in four steps.)

Technicians and, particularly, Mr. Consumer, are acquainted with the tedious technique of short-wave tuning, as compared with the operation at the "broadcast" wavelength range of 200 to 545 meters. It is to overcome this objection that the model Z-13 receiver was designed, in an effort to popularize short-wave reception. A full-vision tuning dial, with color bands to correspond with the setting of the frequency-band selector switch, Sw.1 to Sw.4, a ganged unit, gives accurate indication of the frequency to which the receiver is tuned. On each color band the position of police, television, aviation, amateur, and broadcast channels are marked.

Instant location of even the weakest stations is accomplished by means of an electron-coupled heterodyne oscillator; this beat-tuning oscillator is designated in the diagram as V10. The action of this tube is controlled by a pendant push-button, Sw.7.

The use of a silent-tuning control circuit results in quite operation during the period of tuning from one station to another, but at the expense of sensitivity; therefore, switch Sw.5, a panel-operated unit, is provided to control the operation of the silent-tuning tube, V12.

Resistor R1, a tapered manual volume control, 5,000 ohms; R2, tone control, log taper, 0.5-meg.; R3, 2 W., 3,000 ohms; R4, 0.23-meg.; R5, 60,000 ohms; R6, 11,000 ohms; R7, R21, 0.1-meg.; R8, R9, 0.5-meg.; R10, 0.25-meg.; R11, R14, 1 meg.; R12, 2 meg.; R13, 0.3-meg.; R15, 6,000 ohms; R16, 8,000 ohms; R17, R18, R19, R20, 2,600, 340, 1,840 and 5,750 ohms, respectively, wire wound; R22, 150 ohms.

Condensers C1, C4, C5, C15, .01-mf.; C2, .25-mf.; C3, C7, C8, C9, .5-mf.; C6, C14, 0.1-mf.; C10, mica dielectric, .01-mf.; C11, .15-mf.; C12, C19, mica dielectric, 100 mmf.; C13, .0-25-mf.; C16, C32, mica dielectric, 250 mmf.; C17, mica dielectric, 50 mmf.; C18, C33, mica dielectric, .002-mf.; C20, dry electrolytic, 450 V., 8 mf.; C21, dry electrolytic, 450 V., 12 mf.; C22, .002-mf.; C23, mica-dielectric trimmers, 20 to 65 mmf.; C24, mica-dielectric trimmer, 6 to 30 mmf.; C25, mica-dielectric trimmer, 25 to 65 mmf.; C26; C29, tuning condensers, 410 mmf.; C27, C30, trimmers; C28, mica dielectric, 350 to 500 mmf.; C31, mica dielectric, 70

to 125 mmf.

Instead of operating voltage and current figures for the tubes in this receiver the following voltage figures, measured on a high-resistance meter, connected from chassis to the points indicated, are given. Point A, 250 V.; B, 100 V.; C, 5 V.; D, 150 to 180 V.; E, 3 V.; F, 3 V.; G, 60 V.; H, 18 V.; I, 3 V.; J, 40 V.; K, 47 V.; L, 100 V.; M, 250 V.; N, 250 V.; O, 250 V.

In the center, directly below the tuning knob, is the switch controlling the silent tuning or quiet A.V.C. circuit. When this knob is turned to the left, or counterclockwise, the S.T.C. circuit is in operation. Only the louder broadcast stations are now heard. When the tuning dial is rotated off the local station, the inter-carrier noise usually heard on A.V.C.-equipped receivers is muffled or entirely silent. Thus, the listener is not bothered with static and other spurious noises when only reception from the louder stations is desired.

When distant broadcast or short-wave reception is desired, this switch should be turned to the right and the S.T.C. circuit will be inoperative. It is imperative that the switch be turned to this position for short-wave reception, otherwise it is very possible to miss stations in tuning, due to the sharpness of tuning.

The electron-coupled beat-oscillator is weak-coupled to the I.F. amplifier section of the receiver in such a way that when the pushbutton on the pendant cord is depressed the oscillator is connected in circuit. If any station carrier is crossed during the turning of the tuning dial while the oscillator is in operation, there will be heard, from the reproducer, a musical note, or whistle, of varying pitch. When this note is tuned to the lowest possible pitch, "zero

beat," the receiver will be very closely adjusted to the distant station signal and the pendant switch should be released. If the signal is that of a radiophone station, the voice or music will now be heard and only the slightest readjustment will be necessary to bring it in at its maximum volume. For code reception, continue to press button.



The tuning dial should be operated very slowly when tuning for short-wave stations, particularly when in the green and purple bands, for the receiver is extremely selective and faint signals may be passed.

This receiver is designed to be used on an antenna with a length of about 40 to 100 ft. It is imperative that a good ground connection be used with this receiver in order to obtain stable operation.

The receiver is shipped with a kit of selected tubes. If it becomes necessary to replace tubes, carefully select the oscillator. Test two or three tubes until a type 56 for V2 is found which will operate satisfactorily in the purple band.


The model Z-13 receiver has a sensitivity of .45-microvolt-per-meter, a power output of 6.9 W., and power consumption of 120 W.

The first R.F. and oscillator input circuits of this receiver are unusual. The antenna circuit includes three primaries in series: L2, L5, and L7; L2 feeds two secondaries, L1 and L3, while primaries L5 and L7 feed only one apiece, L4 and L6, respectively. The latter primary and secondary are used for tuning in the 200 to 550 meter band, and it is only in this range that trimming condenser C27 is to be aligned; trimmers for each of the other ranges are provided in shunt to the individual secondaries. Since the two gang tuning condenser has sections of equal capacity, a padding circuit is required; condenser C28 is the padding condenser for this circuit and is to be aligned at the highest wavelength to which the receiver will tune, or about 545 meters. Since, at the shortest wavelength to which the receiver will tune the frequency tracking of the oscillator tuning condenser is close to that of the signal-frequency tuning condenser, padding condenser C28 is not required on the first two short-wave bands and, therefore, is shorted out of the circuit by one of the sections, Sw.3, of the band-selector switch.





# SIMPLEX RADIO CO.




**MODEL P**

**CAUTION: DO NOT ATTEMPT TO OPERATE ON CURRENT OTHER THAN THAT NOTED ON INSTRUMENT.**

**INSTALLATION:** "Ant" lead may be fed from "BLT-IN-ANT" lead, indoor or out door aerial, radiator, bed springs or any large metal object, if desired.  
**BALANCING:** The intermediate stage is carefully phased and sealed to 175 K.C. and should not be tampered with.  
**TO RECEIVE ON 1500 TO 4000 KILO-CYCLES:** Turn tone control knob to end of range until switch throws to 4000 k. c. band. To throw back to broadcast band turn tone control in opposite direction until switch throws.

**PHONOGRAPH:** Use a single pole switch mounted as near as possible to second detector socket, connect in series with lead from ground end of grid coil of second detector tube. Solder phonograph pickup leads to switch terminals  
**GUARANTEE:** This instrument is guaranteed for ninety days, within which period any part showing electrical or mechanical defect will be replaced without charge when returned prepaid to the factory, but if the complete instrument is returned a nominal charge will be made for such labor




**MODEL Q**

**CAUTION: Do not attempt to operate on current other than that noted on instrument.**


**INSTALLATION:** "ANT" may be fed from "BLT-IN-ANT" lead, indoor or outdoor aerial, radiator, bed springs, or any large metal object, if desired.  
**BALANCING:** The intermediate stage is carefully phased and sealed to 175 K.C. and should not be tampered with.  
**PHONOGRAPH:** Use a single pole switch mounted as near as possible to the second detector socket, connect in series with lead from ground end of the grid coil of second detector tube. Solder phonograph pick-up leads to switch terminals.  
**GUARANTEE:** This instrument is guaranteed for ninety days, within which period any part showing electrical or mechanical defect will be replaced without charge when returned prepaid to the factory, but if the complete instrument is returned a nominal charge will be made for such labor

# SPARKS - WITHINGTON, INC.



# STEWART-WARNER SPEEDOMETER CORP.

## CIRCUIT DIAGRAM OF SERIES 105 CHASSIS



### PARTS LIST


Diagram No.	Part No.	Description	List Price
1	81274	Tuning coil	1.70
2	81274	I.F. transformer coils	1.00
3	81274	I.F. tuning coil transformer	1.00
4	81274	R.F. choke coil	0.75
5	81274	R.F. choke coil	0.75
6	81274	Lead-distant switch	.40
7	81274	2.5 V pilot lamp	.25
8	81274	.05 mfd. 200v. condenser	.15
9	81274	Power transformer, 115 V. 25 typ.	15.75
10	81274	Power transformer, 250 V. 60 typ.	15.75
11	81274	8 Mfd. 400 V. Electrolytic cond.	1.75
12	81274	10 Mfd. 450 V. Electrolytic cond.	2.00
13	81274	Output transformer, twin speaker	1.75
14	81274	Output transformer, single speaker	1.50
15	81274	Speaker socket	.15
16	81274	Speaker socket	.15
17	81274	Power supply terminal socket	.45
18	81274	Speaker cord and plug	.60
19	81274	Speaker cord and plug	.60
20	81274	Speaker plug only	.35
21	81274	Field coil Model R-30L-A (60 ohm)	3.50
22	81274	Field coil Model R-30L-A (120 ohm)	3.50
23	81274	Field coil Model R-30L-A (250 ohm)	3.50
24	81274	Diagram Assembly (Model R-30L-A)	2.75
25	81274	Diagram Assembly (Model R-30L-A)	2.75
26	81274	Diagram Assembly (Model R-30L-A)	2.75
27	81274	Diagram Assembly (Model R-30L-A)	2.75
28	81274	Diagram Assembly (Model R-30L-A)	2.75
29	81274	Diagram Assembly (Model R-30L-A)	2.75
30	81274	Diagram Assembly (Model R-30L-A)	2.75
31	81274	Diagram Assembly (Model R-30L-A)	2.75
32	81274	Diagram Assembly (Model R-30L-A)	2.75
33	81274	Diagram Assembly (Model R-30L-A)	2.75
34	81274	Diagram Assembly (Model R-30L-A)	2.75
35	81274	Diagram Assembly (Model R-30L-A)	2.75
36	81274	Diagram Assembly (Model R-30L-A)	2.75
37	81274	Diagram Assembly (Model R-30L-A)	2.75
38	81274	Diagram Assembly (Model R-30L-A)	2.75
39	81274	Diagram Assembly (Model R-30L-A)	2.75
40	81274	Diagram Assembly (Model R-30L-A)	2.75
41	81274	Diagram Assembly (Model R-30L-A)	2.75
42	81274	Diagram Assembly (Model R-30L-A)	2.75
43	81274	Diagram Assembly (Model R-30L-A)	2.75
44	81274	Diagram Assembly (Model R-30L-A)	2.75
45	81274	Diagram Assembly (Model R-30L-A)	2.75
46	81274	Diagram Assembly (Model R-30L-A)	2.75
47	81274	Diagram Assembly (Model R-30L-A)	2.75
48	81274	Diagram Assembly (Model R-30L-A)	2.75
49	81274	Diagram Assembly (Model R-30L-A)	2.75
50	81274	Diagram Assembly (Model R-30L-A)	2.75
51	81274	Diagram Assembly (Model R-30L-A)	2.75
52	81274	Diagram Assembly (Model R-30L-A)	2.75
53	81274	Diagram Assembly (Model R-30L-A)	2.75
54	81274	Diagram Assembly (Model R-30L-A)	2.75
55	81274	Diagram Assembly (Model R-30L-A)	2.75
56	81274	Diagram Assembly (Model R-30L-A)	2.75
57	81274	Diagram Assembly (Model R-30L-A)	2.75
58	81274	Diagram Assembly (Model R-30L-A)	2.75
59	81274	Diagram Assembly (Model R-30L-A)	2.75
60	81274	Diagram Assembly (Model R-30L-A)	2.75
61	81274	Diagram Assembly (Model R-30L-A)	2.75
62	81274	Diagram Assembly (Model R-30L-A)	2.75
63	81274	Diagram Assembly (Model R-30L-A)	2.75
64	81274	Diagram Assembly (Model R-30L-A)	2.75
65	81274	Diagram Assembly (Model R-30L-A)	2.75
66	81274	Diagram Assembly (Model R-30L-A)	2.75
67	81274	Diagram Assembly (Model R-30L-A)	2.75
68	81274	Diagram Assembly (Model R-30L-A)	2.75
69	81274	Diagram Assembly (Model R-30L-A)	2.75
70	81274	Diagram Assembly (Model R-30L-A)	2.75
71	81274	Diagram Assembly (Model R-30L-A)	2.75
72	81274	Diagram Assembly (Model R-30L-A)	2.75
73	81274	Diagram Assembly (Model R-30L-A)	2.75
74	81274	Diagram Assembly (Model R-30L-A)	2.75
75	81274	Diagram Assembly (Model R-30L-A)	2.75
76	81274	Diagram Assembly (Model R-30L-A)	2.75
77	81274	Diagram Assembly (Model R-30L-A)	2.75
78	81274	Diagram Assembly (Model R-30L-A)	2.75
79	81274	Diagram Assembly (Model R-30L-A)	2.75
80	81274	Diagram Assembly (Model R-30L-A)	2.75
81	81274	Diagram Assembly (Model R-30L-A)	2.75
82	81274	Diagram Assembly (Model R-30L-A)	2.75
83	81274	Diagram Assembly (Model R-30L-A)	2.75
84	81274	Diagram Assembly (Model R-30L-A)	2.75
85	81274	Diagram Assembly (Model R-30L-A)	2.75
86	81274	Diagram Assembly (Model R-30L-A)	2.75
87	81274	Diagram Assembly (Model R-30L-A)	2.75
88	81274	Diagram Assembly (Model R-30L-A)	2.75
89	81274	Diagram Assembly (Model R-30L-A)	2.75
90	81274	Diagram Assembly (Model R-30L-A)	2.75
91	81274	Diagram Assembly (Model R-30L-A)	2.75
92	81274	Diagram Assembly (Model R-30L-A)	2.75
93	81274	Diagram Assembly (Model R-30L-A)	2.75
94	81274	Diagram Assembly (Model R-30L-A)	2.75
95	81274	Diagram Assembly (Model R-30L-A)	2.75
96	81274	Diagram Assembly (Model R-30L-A)	2.75
97	81274	Diagram Assembly (Model R-30L-A)	2.75
98	81274	Diagram Assembly (Model R-30L-A)	2.75
99	81274	Diagram Assembly (Model R-30L-A)	2.75
100	81274	Diagram Assembly (Model R-30L-A)	2.75

### VOLTAGE TABLE

Tube	Type of Tube	Filament Voltage	Plate to Chassis	Screen Grid to Chassis	Line Voltage
57	Short Wave Oscillator	2.4	81	5.2	5.2
56	Short Wave Detector	2.4	21	2	1.9
55	R. F.	2.4	148	102	2.4
54	Broadband Oscillator	2.4	102	0	0
53	First Detector	2.4	118	102	0
52	I. F.	2.42	118	102	2.2
51	A. V. C.	2.44	0	0	-89
50	Second Detector	2.42	70	0	-92
47	Output Rectifier	2.4	377	188	110
80		4.3			

**CAUTION**  
Reading must be taken with the set tuned to a station, and the load distance switch pulled out. All D.C. voltages are measured between the tube socket terminal and chassis, using a high resistance voltmeter of 1000 ohms per volt. Readings will vary depending upon voltage range of meter. Reading higher for high range. Voltmeter must be marked for all detector and oscillator D.C. voltages.  
Readings taken with set testers plugged into tube sockets may deviate considerably from the values given in this table, due to their internal circuit arrangements.

### TUBE LOCATIONS




FRONT OF SET  
NOTE: Use an 80 tube in the Power Unit.



# STEWART-WARNER SPEEDOMETER CORP.

## Chassis Series 108 and 108-X

Used on Models 10 to 20 Inclusive



**NOTE:** In some receivers, a 140 ohm, ¼ watt carbon resistor, part 81646 is connected in series with the volume control; in other sets this resistor is built into the volume control.


**LINE VOLTAGE \* Voltage Table \* VOLUME CONTROL**  
115 VOLTS A. C. FULL ON

Type of Tube	Tube Circuit	Filament to Condenser	Plate to Condenser	Screen Grid to Condenser	Cathode to Condenser
39	R. F.	**	107	107	1.5
36	Det.	**	1.3 †	9	1.3
38	Output	**	103	107	9
12Z3	Rect.	**	.....	.....	122

**IMPORTANT NOTE**

\*These voltages will be obtained when the set is operated at 115 volts, 60 cycles A. C. For D. C. operation, voltages will be somewhat lower. All voltage readings have been taken between tube prongs and the variable condenser frame, not the chassis. The chassis cannot be used in this receiver as a reference point for voltage readings. \*\*Filament voltage readings will vary widely, depending upon the resistance of the A. C. voltmeter. With high resistance rectifier type meters, voltage readings will be approximately 6.3 for the detector and amplifier tubes, and 12.6 for the 12Z3 rectifier. With ordinary A. C. Voltmeters, readings will be very much less. †This reading is obtained with a 30-volt scale, one thousand ohms per volt instrument. Higher resistance meters or higher scale readings will give greater voltage readings.

**FRONT OF CHASSIS**



**TUBE LOCATIONS**

### PARTS LIST

Diag. No.	Part No.	Description	List Price
1	67298	.01 mfd. 600 V cartridge condenser	\$0.30
2	81158	.0001 mfd. mica condenser	.22
3	81630	.1 mfd. 100 V cartridge condenser	.30
4	81644	2.1 meg. ¼ W. carbon resistor	.20
	81646	140 ohm ¼ W. carbon resistor	.20
5	81657	.003 mfd. mica condenser	.35
6	81662	Variable condenser	3.00
7	81664	Antenna Coil	.90
8	81666	Detector Coil	1.20
9A	81678	4 mfd. 150 V dry electrolytic condensers (in one unit)	1.35
9B			
10	81679	250,000 ohm volume control and switch	1.50
11	81680	Speaker	5.00
12	81681	29,000 ohm ¼ W. carbon resistor	.20
13	81682	1.1 meg. ¼ W. carbon resistor	.20
14	81683	1600 ohm ½ W. carbon resistor	.20
15	81694	Filter choke	2.00
16A	81698	5 mfd. 20 V dry electrolytic condensers (in one unit)	1.20
16B			
17	81785	Power cord assembly	1.30
18	81834	Battery cable socket	.10
19	81861	6 volt battery cable	.90
	81863	12 volt battery cable	1.15
	81865	32 volt battery cable	1.15
20	.....	Switch on back of 81679	.....

**PARTS NOT LISTED ON DIAGRAM**

81885	Bronze tuning knob	.35
81886	Bronze volume control knob	.35
81887	Gold tuning knob	.35
81888	Gold volume control knob	.35
81889	Silver tuning knob	.35
81890	Silver volume control knob	.35
81891	Book model knob	.35
81824	Antenna reel	.25
81841	Antenna reel clip	.02
81712	Bronze receiver housing	4.00
81713	Bronze housing back	.60
81731	Gold receiver housing	4.00
81728	Gold housing back	.60
81735	Silver cabinet housing	4.00
81732	Silver housing back	.60
81884	Automobile mounting bracket	.30

# STEWART-WARNER SPEEDOMETER CORP.

## SERVICE DATA FOR MODEL 109 CHASSIS

### CIRCUIT DESCRIPTION OF 109 CHASSIS

The Model 109 Stewart-Warner Radio Chassis makes use of a six-tube superheterodyne circuit embodying automatic volume control (A.V.C.) through the action of its type 55 detector tube. An incoming signal is tuned first by a pre-selector circuit to increase selectivity and reduce image frequency interference and then fed into a tuned first detector stage, where it beats with the output of a local oscillator to produce a 177.5 K.C. intermediate frequency signal. This odd frequency is chosen to reduce further any image frequency interference.

The I.F. signal is amplified in an exceptionally high gain stage, and then fed to the diode section of the 55 tube where it is rectified. This rectified signal appears across the 500,000 ohm potentiometer (No. 12 in the diagram) not only at radio frequencies but also as an audio voltage. Any desired portion of this audio voltage is picked up by the sliding arm of the potentiometer and fed to the triode section of the 55 tube, which functions purely as a standard A.F. amplifier. Thus this potentiometer is made to act as the volume control.

The necessary A.V.C. operating potential is developed by virtue of the radio frequency drop across the potentiometer resistance. This potential is smoothed out by an appropriate resistance-capacity filter and applied as a bias to the grids of the first detector and I.F. tubes. Thus as the incoming signal increases or decreases in strength the bias is raised or lowered proportionately and the audio output of the set maintained constant.

Excellent tone quality is realized in this set because of the superior design of the resistance network coupling the triode section of the 55 to the output pentode.

### ALIGNING THE 109 CHASSIS

Alignment can be carried out intelligently only if the service man knows the general layout of the set, and how each circuit is affected during the process of alignment. The simplified top view of the chassis appearing on the other side of this sheet gives the layout of the receiver and indicates the names and locations of the various aligning adjustments. The following brief discussion of what actually happens during alignment should be carefully read, using the sketch as a basis before commencing the actual work.

### LOCATION AND FUNCTION OF ALIGNING ADJUSTMENTS

The incoming signal is tuned first by the pre-selector "A" stage and then fed into the first detector "B" circuit, where it is tuned again to improve selectivity. These circuits are brought into exact alignment by the two trimmer condensers "A" and "B," pointed out in the attached sketch. The tuned oscillator circuit is so designed that it tunes to a frequency exactly 177.5 K.C. higher than the incoming signal. This circuit is kept in exact step with the other two by means of the oscillator condenser trimmer "O."

The two intermediate frequency (I.F.) transformers are of the tuned input-tuned output type and each winding is tuned by a separate trimmer condenser, making a total of four additional adjustments. The first I.F. transformer is in the steel shield at the right side of the set, while the second I.F. transformer is at the rear of the chassis. The I.F. trimmer adjusting screws can easily be reached through two small holes at the base of each shield, the primary circuit adjustment in each case being at the left and the secondary adjustment at the right.

### PRELIMINARY STEPS IN ALIGNING

In aligning the Model 109 it is essential to use a high grade oscillator and sensitive output meter. The R.F. signal fed into the receiver must be very weak or it will cause the A.V.C. circuit to function, making correct alignment impossible. The output meter must be sufficiently sensitive to give a satisfactory reading with this low signal.

Before starting the alignment procedure see that the volume control is full on, and the output meter connected either between the pentode plate and ground **through a .25 mfd condenser** or across the voice coil, depending upon its sensitivity.

### ALIGNING PROCEDURE

With this preliminary discussion clearly in mind, the actual alignment can be started. The following step-by-step routine should be followed for satisfactory results.

1. Set up the oscillator, and tune it to exactly 177.5 K.C. (This frequency can be accurately determined by tuning in a station at either 710 or 1420 K.C. and beating the 4th or 8th harmonic of the oscillator 177.5 K.C. signal against it. To be sure that you have the harmonic of the 177.5 K.C. signal, instead of some other frequency, tune in the other 177.5 harmonics on the broadcast dial. These should come in 177.5 K.C. on either side of the original setting. **Do not use the oscillator calibration curve to determine this intermediate frequency.**)

2. Connect the oscillator output between the grid cap of first detector tube and chassis.

### Adjusting R. F. and Oscillator Circuits

1. Twist the aerial and ground wires of the set together to reduce noise pick-up. Connect the aerial wire to the output of the oscillator and **ground both set and oscillator**. Adjust the oscillator frequency to 1400 K.C. and carefully tune the receiver to give maximum output. Adjust the oscillator output to produce about one-half full scale deflection of the output meter.

2. Carefully tune the "A" trimmer till the output meter reading reaches a maximum.

Due to the fact that the variable condenser is mounted on rubber cushion supports, pressure of the aligning tool will usually cause it to shift slightly and throw it out of tune. **It is therefore necessary to retune the set repeatedly while adjusting any variable condenser trimmer.**

3. Retune the set and adjust the "B" trimmer for maximum output.


The third, or "O" trimmer should not be touched unless the set is badly out of calibration at the high frequency end of the dial.

If the set is out of calibration, it can be re-calibrated as follows: Set the tuning dial at the frequency reading of some station **between 1200 and 1500 kilocycles only**, whose exact frequency is known and which can be picked up without any difficulty. Adjust the oscillator trimmer "O" until this station is brought in with maximum volume. **Re-adjust the "A" and "B" trimmers again**, since these are always affected by any change in the oscillator tuned circuit.

The receiver should now be perfectly aligned.

# STEWART-WARNER SPEEDOMETER CORP.

## CHASSIS MODEL 109 (RECEIVER MODELS 1090 TO 1099)



### 109 PARTS LIST

Diag. Part No.	Description	List Price
1	500 ohm, 1/2 watt resistor	.40
2	100,000 mfd, 500 volt condenser	.25
3	100,000 mfd, 500 volt condenser	.25
4	2.5 volt pilot light	.25
5	150,000 ohm, 1/2 watt resistor	.25
6	150,000 ohm, 1/2 watt resistor	.25
7	230 volt 60 cy. powertransf. (see 81800)	6.25
8	Line Switch. (Separate unit used in phonograph chassis only. Part of volume control on standard chassis)	.40
9	Phono chassis type volume control (See 81722)	2.00
10	Phonograph pickup	.....
11	Phonograph switch, mounted on back volume control in phonograph models.	.....
12	10,000 ohm, resistor (round in 10,500 ohm, resistor)	.60
13A	315 ohm, wire wound resistor	.30
13B	1000 ohm, 1/2 watt resistor	.35
14	.04 mfd, 600 volt condenser with bracket	.....
15	.25 mfd, 200 volt	1.50
16	.25 mfd, 100 volt	2.00
17A	First I. F. Transformer	2.00
17B	Second I. F. Transformer	2.00
18	First detector tuning coil	1.20
19	First detector tuning coil	1.20
20	5-prong socket	1.35
21	6-prong socket	1.35
22	Rectifier coil	3.00
23	Speaker field coil	4.00
24	110 volt 60 cy. power transformer	6.00
25	230 volt 60 cy. power transformer	6.25
26	980,000 ohm 1/2 watt resistor	.20
27	160,000 ohm 1/2 watt resistor	.20
28	110,000 ohm 1 watt resistor	.20
29	100,000 mfd, 500 volt condenser	.25
30	2.5 volt pilot light	.25
31	150,000 ohm, 1/2 watt resistor	.25
32	150,000 ohm, 1/2 watt resistor	.25
33	230 volt 60 cy. powertransf. (see 81800)	6.25
34	Line Switch. (Separate unit used in phonograph chassis only. Part of volume control on standard chassis)	.40
35	Phono chassis type volume control (See 81722)	2.00

### VOLUME CONTROL FULL ON

LINE	TYPE OF TUBE	TUBE CIRCUIT	FILAMENT VOLTAGE	SCREEN GRID VOLTAGE	PLATE VOLTAGE	BIAS VOLTAGE
56	Osc.		2.40		88	9.6
58	1st Det.		2.40	92	208	5
58	I. F.		2.40	92	208	3.4
55	2nd Det.		2.42		18	
95 or 2A5	Output		2.38	208	200	16.5*
80	Rect.		5.00			


All D. C. voltages measured with respect to ground, using high resistance voltmeter of 1000 ohm per volt. Reading will change if meter being used has lower internal resistance. This variation is most marked for second detector plate voltages.

\*This reading taken across metal clad bias resistor.

### MISCELLANEOUS PARTS NOT SHOWN IN DIAGRAM

Diag. Part No.	Description	List Price
67236	Rubber tuning drive bushing	.02
81039	4-prong socket	.12
81040	5-prong socket	.12
81043	6-prong socket	.20
81608	R. F. coil shield	.50
81625	Tube shield	.20
81870	Ground clip	.10
81875	Tuning dial and gear assembly (see 81879)	.50
81876	First I. F. coil shield	.50
81879	Steel I. F. coil shield	.50
81879	Celluloid tuning dial	.30
35459	Steel washer	.10 dz.
39393	Lock washer	.50 per C
67711	Rubber washer mounting vari-	.05
67712	Rubber bushing	.05
67713	Steel bushing	.05

# STEWART-WARNER SPEEDOMETER CORP.



Intermediate Frequency Transformers Tuned to 177.5 K. C.

LINE VOLTAGE 115 VOLUME CONTROL FULL ON


Type of Tube	Tube Circuit	Filament Voltage	Plate Voltage	Screen Grid Voltage	Bias Voltage
'24	1st Det.	2.45	250	95	6.5
'27	Osc.	2.45	95		9
'51	I. F.	2.40	250	95	3
'24	2nd Det.	2.45	70	30	7
P. Z. or '47	Output	2.45	230	250	15 †
'80	Rect.	4.8	170		

All D. C. voltages measured with respect to ground, using high resistance voltmeter of 1000 ohms per volt. Readings will vary, depending upon voltage range of meter, being higher for higher range instruments. This variation is most marked for second detector screen grid and plate voltages.  
 † This reading obtained between ground and yellow speaker lead. Direct reading from grid to ground or reading taken with a set tester will show about 3 volts because of high resistance in grid circuit.

\*This data sheet applies to the following serial numbers only:  
 Model 102-A, 34,000 upwards  
 Model 102-B, 10,500 upwards  
 Model 102-E, 10,200 upwards

See Form 5535 for lower serial numbers

Models R-102-A, B & E.\*



TUBE LOCATIONS

# STEWART-WARNER SPEEDOMETER CORP.

## SERVICE DATA ON MODEL 104 CHASSIS

### CIRCUIT DESCRIPTION OF 104 CHASSIS

The Model 104 Stewart-Warner Radio Chassis makes use of a six-tube superheterodyne circuit embodying automatic volume control (A.V.C.) thru the action of its Wunderlich-type detector tube. An incoming signal is tuned first by a pre-selector circuit to increase selectivity and reduce image frequency interference and then fed into a tuned first detector stage, where it beats with the output of a local oscillator to produce a 177.5 K. C. intermediate frequency signal. This odd frequency is chosen to reduce further any image frequency interference. The I.F. signal is amplified in an exceptionally high gain stage and then fed into the Wunderlich tube which performs the triple functions of detection, amplification, and automatic volume control. As a result of the A.V.C. action of this tube a voltage varying in value in direct relationship to the strength of the incoming signal, appears across the 1 megohm resistor connected between one of its grids and ground. This resistor is also in the grid return circuit of both the first detector and I.F. tubes, so that their biases increase in direct relationship to the strength of the incoming signal. This action results in an automatic control of sensitivity.

The plate circuit audio output of the detector tube is impressed across the 400,000 ohm variable resistor in the grid circuit of the pentode tube. Volume is controlled by using this variable resistor as a voltage divider to feed any desired audio voltage from zero to the maximum available across the pentode grid circuit.

### ALIGNING THE 104 CHASSIS

Alignment can be carried out intelligently only if the service man knows the general layout of the set, and how each circuit is affected during the process of alignment. The simplified top view of the chassis appearing on the other side of this sheet gives the layout of the receiver and indicates the names and locations of the various aligning adjustments. The following brief discussion of what actually happens during alignment should be carefully read, using the sketch as a basis before commencing the actual work.

### LOCATION AND FUNCTION OF ALIGNING ADJUSTMENTS

The incoming signal is tuned first by the pre-selector "A" stage and then fed into the first detector "B" circuit, where it is tuned again to improve selectivity. These circuits are brought into exact alignment by the two trimmer condensers "A" and "B," pointed out in the attached sketch. The tuned oscillator circuit is so designed that it tunes to a frequency exactly 177.5 K.C. higher than the incoming signal. This circuit is kept in exact step by means of two adjustments, the oscillator condenser trimmer "O," and the padding condenser "P," which can be reached thru a small hole in the chassis base just in front of the "O" condenser.

THE "O" TRIMMER IS MAINLY EFFECTIVE AT THE HIGH FREQUENCY END OF THE DIAL, AND THE PADDING CONDENSER "P" AT THE LOW FREQUENCY END. The alignment routine which will be outlined takes this into consideration.

The two intermediate frequency (I. F.) transformers are of the tuned input,—tuned output type and each winding is tuned by a separate trimmer condenser, making a total of four additional adjustments. The first I. F. transformer is in the steel shield at the right side of the set, while the second I. F. transformer is at the rear of the chassis. The I. F. trimmer adjusting screws can easily be reached thru two small holes at the base of each shield, the primary circuit adjustment in each case being at the left and the secondary adjustment at the right.

### PRELIMINARY STEPS IN ALIGNING

In aligning the Model 104 it is essential to use a high grade oscillator and sensitive output meter. The R. F. signal fed into

the receiver must be very weak or it will cause the A. V. C. circuit to function, making correct alignment impossible. The output meter must be sufficiently sensitive to give a satisfactory reading with this low signal.

Before starting the alignment procedure see that the volume control is full on, and the output meter connected either between the pentode plate and ground thru a .25 mfd condenser or across the voice coil, depending upon its sensitivity.

### ALIGNING PROCEDURE

With this preliminary discussion clearly in mind, the actual alignment can be started. The following step-by-step routine should be followed for satisfactory results.

1. Remove the grid clip leading from the variable condenser to the cap of the first detector tube.

2. Set up the oscillator, and tune it to exactly 177.5 K.C. (This frequency can be accurately determined by tuning in a station at either 710 or 1420 K.C. and beating the 4th or 8th harmonic of the oscillator 177.5 K.C. signal against it. To be sure that you have the harmonic of the 177.5 K.C. signal, instead of some other frequency, tune in the other 177.5 K.C. harmonics on the broadcast dial. These should come in 177.5 K.C. on either side of the original setting. Do not use the oscillator calibration curve to determine this intermediate frequency.) Connect the oscillator output between the grid cap and grid clip of the first detector tube.

3. Adjust the oscillator output to give about one-half full scale deflection of the output meter.

#### Adjusting the I. F. Circuits

1. Adjust all four I. F. trimmer condensers, in each case tuning carefully to make sure that maximum deflection is obtained on the output meter.

IT IS VERY IMPORTANT THAT ABSOLUTELY NO INWARD PRESSURE BE APPLIED TO THE ALIGNMENT TOOL, OR THE CONDENSER MAY SPRING BACK TO A DIFFERENT SETTING AS SOON AS THE TOOL IS REMOVED.

2. Go back and repeat all four adjustments since the adjustment of each I. F. trimmer affects the others to a certain extent, thus necessitating readjustment.

#### Adjusting R. F. and Oscillator Circuits

1. Replace the grid cap on the first detector tube.

2. Twist the aerial and ground wires of the set together to reduce noise pick-up. Connect the aerial wire to the output of the oscillator and ground both set and oscillator. Adjust the oscillator frequency to 1400 K.C. and carefully tune the receiver to give maximum output. Adjust the oscillator output to produce about one-half full scale deflection of the output meter.

3. Carefully tune the "A" trimmer till the output meter reading reaches a maximum.

4. Note the wire leading from the grid cap of the 57 first detector tube (see tube layout diagram on the reverse side of this sheet), to the tuning condenser. The section of the condenser gang to which this lead is soldered is the "B" section. Altho this "B" section is shown as the center condenser section on the diagram, some sets were manufactured with the "B" section in the rear.

Retune the set and adjust the "B" trimmer for maximum output. The third, or "O" trimmer should not be touched unless the set is badly out of calibration at the high frequency end of the dial.

5. Set the oscillator at 600 K.C. and tune the set carefully to this frequency.

6. Adjust the oscillator padding condenser "P" for maximum output, RETUNING THE SET AFTER EACH CHANGE IN ADJUSTMENT. This is important.

7. Turn back the oscillator to 1400 K.C., tune the set to the same frequency, and very carefully readjust the "A" and "B" trimmer condensers to produce maximum output.


The receiver should now be perfectly aligned.

## 104 PARTS LIST


Part No.	Description	List Price	Part No.	Description	List Price	Part No.	Description	List Price
38261	.00025 mfd. condenser	\$0.35	67328	8 mfd. 440 volt electrolytic condenser	1.75	67946	1st I.F. transformer	2.00
67240	Speaker diaphragm and voice coil assembly	1.85	67329	5000 ohm vitreous resistor	.50	67481	coil only	.75
67242	I.F. coil shield	.25	67330	6000 ohm vitreous resistor	.50	67536	trimmer only	.65
67248	Main tuning condenser	5.50	67517	1 mfd. 100 volt condenser	.75	67951	Oscillator coil shield	.75
67259	45000 ohm, ½ watt resistor	.25	67535	Oscillator pad trimmer condenser	.45	67974	700 ohm, 1 watt resistor	.25
67260	100,000 ohm, ½ watt resistor	.25	67551	2.5 volt pilot light	.25	67976	67976 2nd I.F. transformer	2.00
67294	.1 mfd. 200 volt condenser	.30	67556	115 volt 60 cycle power transformer	5.50	67976	67481 coil only	.75
67296	.1 mfd. 400 volt condenser	.40	67580	6000 ohm, ½ watt resistor	.25	81042	67536 trimmer only	.65
67298	.01 mfd. 600 volt condenser	.30	67581	Speaker field coil	3.50	81042	Speaker socket	.20
67299	.02 mfd. 400 volt condenser	.30	67584	Filter choke coil	2.00	81092	81092 Speaker plug only	.20
67303	2000 ohm, ½ watt resistor	.25	67588	8 mfd. 500 volt electrolytic condenser	1.80	81092	67972 Cable and plug	.60
67304	.0009 mfd. padding condenser	.30	67671	115 volt 25 cycle power transformer	8.00	81092	67971 Cable only	.40
67309	60,000 ohm tone control	1.50	67937	400,000 ohm volume control	.95	81459	230 volt 60 cycle power transformer	10.00
67318	Oscillator tuning coil	1.25	67938	100,000 ohm, 1 watt resistor	.25	PARTS NOT SHOWN ON DIAGRAM		
67321	"A" tuning coil	1.00	67939	1 megohm, ½ watt resistor	.25	67532	Rubber dial drive bushing	.02
67326	R.F. coil shield	.50	67942	"B" tuning coil	.75	67953	Escutcheon plate	.50
						81412	Volume or tone control knob	.25
						81413	Tuning knob	.25

# STEWART-WARNER SPEEDOMETER CORP.

## Circuit Data for Stewart-Warner A. C. Series R-104



FRONT OF SET



TUBE LOCATIONS

LINE VOLTAGE 115 VOLUME CONTROL FULL ON


Type of Tube	Tube Circuit	Filament Voltage	Plate Voltage	Screen Grid Voltage	Bias Voltage
'57	1st Det.	2.57	256	100	4.5
'56	Osc.	2.57	100		7.8
'58	I. F.	2.56	256	100	3.9
Wunderlich	2nd Det.	2.56	37		
P. Z. or '47	Output	2.56	239	256	15.75 †
'80	Rect.	4.9			

All D. C. voltages measured with respect to ground, using high resistance voltmeter of 1000 ohms per volt. Readings will vary, depending upon voltage range of meter, being higher for higher range instruments. This variation is most marked for second detector plate voltages.

†This reading obtained between ground and that prong of speaker socket situated furthest from other three. Direct reading from grid to ground or reading taken with a set tester will show about 3 volts because of high resistance in grid circuit.

# TRANSFORMER CORPORATION OF AMERICA

## MODEL 300



CIRCUIT RESISTANCE ANALYSIS  
Model 300 Socket to ground

Stage	Grid	Cathode	Heater	Plate	Screen	Suppr.
R. F. . . . .	Infini-ty	1,450	.1	6,100	3,350	1,480
1st. Det. . . . .	Infini-ty	5,000	.1	6,600	3,350	6,000
1st. I. F. . . . .	Infini-ty	500	.1	6,600	3,350	500
2nd. I. F. . . . .	Infini-ty	500	.1	6,100	3,350	500
Oscillator . . . . .	100,000	.07	.1	3,400	.....	.....
A.V.C. . . . .	500,000	500	.1	500	.....	.....
1st. diode . . . . .	100,000	500	.1	500	.....	.....
2nd. diode . . . . .	100,000	500	.1	500	.....	.....
A. F. . . . .	500,000	350	.1	8,600	.....	.....
Driver 1. . . . .	68,000	1,500	.1	6,400	.....	.....
Driver 2. . . . .	68,000	1,500	.1	6,400	.....	.....
1 Class "B" . . . . .	3,250	.....	3,250	6,300	.....	.....
2 Class "B" . . . . .	3,250	.....	3,250	6,300	.....	.....
Rectifier . . . . .	.....	.....	6,100	3,400	.....	.....

Note: Readings of one megohm and over are given as "infinity". The first three significant figures, only are interpreted from the ohm meter in each reading, the individual resistance in the circuit can be readily checked upon removal of chassis.

VOLTAGE OF ANALYSIS  
Model 300

No.	Stage	Tube	A	B	C	K	Sc.G	Ip.	St.G.
1	R.F.	58	2.2	180	.5	7.	85	.7	7.
2	1st. Det.	58	2.2	180	1.	7.	85	1.2	7.
3	Oscillator	56	2.2	100	0	0	10.	0	..
4	1st. i.f.	58	2.1	190	.4	4.	90	3.	4.
5	2nd. i.f.	58	2.0	190	.2	4.	90	2.	4.
6	A.V.C.	56	2.0	0	0	4.	..	0	..
7	Diode	56	2.1	0	0	4.	..	0	..
8	Diode	56	2.1	0	0	4.	..	0	..
9	A.F.	56	2.2	180	0	10.	..	2.	..
10	Driver 1	56	2.3	185	0	8.	..	3.	..
11	Driver 2	56	2.3	185	0	8.	..	3.5	..
12	Class "B" 1	46	2.2	400	0	0	..	5.	..
13	Class "B" 2	46	2.2	400	0	0	..	5.	..
14	Rectifier	82	2.3	300	..	..	..	..	..

Vol. control "full on".  
Noise suppressor "full open".  
Tested with Weston model 565 analyzer.  
Line: 115 volts.

# STEWART-WARNER SPEEDOMETER CORP.

## SERVICE DATA FOR MODEL 106 CHASSIS

### CIRCUIT DESCRIPTION

The Model 106 Stewart-Warner Radio Chassis is a seven tube superheterodyne receiver embodying three important features: (1) Interstation Noise Suppression; (2) "Q" or "Squelch" Circuit; (3) Delayed Automatic Volume Control Action. These desirable features are obtained thru the use of a 55 detector tube which functions as three tubes in one—two diode rectifiers and a triode amplifier. One diode is used for detection, the detected signal obtained in this way being then passed on to the grid of the triode part of the same tube where it is amplified at audio frequencies and fed into the pentode output tube. A constant negative bias is provided on this diode by means of a cathode resistor which prevents detection of signal or noise unless the incoming signal is above a certain minimum value, thus providing the "squelcher" or "Q" circuit. This circuit, in combination with a manually operated sensitivity control (No. 32 on the diagram) makes it possible to eliminate objectionable noise when tuning between stations, resulting in interstation noise suppression.

Delayed A. V. C. is obtained thru the second diode section of the 55 tube, which is coupled to the first by a .001 mfd. condenser. However, this diode plate is about 15 volts negative with respect to the cathode, so that no rectification and consequently no A. V. C. action can take place in this circuit unless the incoming signal builds up to this value, which represents the minimum signal capable of giving full audio output. Consequently no fading will be noticed throughout the range where the A. V. C. has hold. Furthermore, any station not capable of producing full output in the speaker, is not further reduced in volume by the action of the A.V.C. circuit, as is the case in normal A.V.C., so that with delayed A.V.C. weak stations come in with much better volume and the effects of severe fading are greatly minimized.

### ALIGNING THE 106 CHASSIS

Alignment can be carried out intelligently only if the service man knows the general layout of the set, and how each circuit is affected during the process of alignment. The simplified top view of the chassis appearing on the other side of this sheet gives the layout of the receiver and locations of the various aligning adjustments. The following brief discussion of what actually happens during alignment should be carefully read, using the sketch as a basis before commencing the actual work.

### LOCATION AND FUNCTION OF ALIGNING ADJUSTMENTS

The incoming signal is tuned first by the radio-frequency stage and then fed into the first detector circuit, where it is tuned again to improve selectivity. These circuits are brought into exact alignment by the two trimmer condensers "A" and "B," pointed out in the attached sketch. The tuned oscillator circuit is so designed that it tunes to a frequency exactly 177.5 K.C. higher than the incoming signal. This circuit is kept in exact step by means of two adjustments, the oscillator condenser trimmer "O," and the padding condenser "P," which can be reached thru a small hole in the chassis base just in back of the "O" condenser.

THE "O" TRIMMER IS MAINLY EFFECTIVE AT THE HIGH FREQUENCY END OF THE DIAL, AND THE PADDING CONDENSER "P" AT THE LOW FREQUENCY END. The alignment routine which will be outlined takes this into consideration.

The two intermediate frequency (I.F.) transformers are of the tuned input,—tuned output type and each winding is tuned by a separate trimmer condenser, making a total of four additional adjustments. The first I.F. transformer is in the shield at the right side of the set, while the second I.F. transformer is at the rear of the chassis. The I.F. trimmer adjusting screws can easily be reached thru two small holes at the top of each shield.

### PRELIMINARY STEPS IN ALIGNING

In aligning the Model 106 it is essential to use a high grade oscillator and sensitive output meter. The R.F. signal fed into the receiver must be very weak or it will cause the A.V.C. circuit to function, making correct alignment impossible. The output meter must be sufficiently sensitive to give a satisfactory reading with this low signal.

Before starting the alignment procedure see that the volume control and inter-station noise suppressor are full on, and the output meter connected either between the pentode plate and ground thru a .25 mfd condenser or across the voice coil, depending upon its sensitivity.

### ALIGNING PROCEDURE

With this preliminary discussion clearly in mind, the actual alignment can be started. The following step-by-step routine should be followed for satisfactory results:

1. Set up the oscillator, and tune it to exactly 177.5 K.C. (This frequency can be accurately determined by tuning in a station at either 710 or 1420 K.C. and beating the 4th or 8th harmonic of the oscillator 177.5 K.C. signal against it. To be sure that you have the harmonic of the 177.5 K.C. signal, instead of some other frequency, tune in the other 177.5 harmonics on the broadcast dial. These should come in 177.5 K.C. on either side of the original setting. Do not use the oscillator calibration curve to determine this intermediate frequency.)
2. Connect the oscillator output across the grid clip of the first detector tube and ground.
3. Adjust the oscillator output to give about one-half full scale deflection of the output meter.

### Adjusting the I. F. Circuits

1. Adjust all four I.F. trimmer condensers, in each case tuning carefully to make sure that maximum deflection is obtained on the output meter.

IT IS VERY IMPORTANT THAT ABSOLUTELY NO INWARD PRESSURE BE APPLIED TO THE ALIGNMENT TOOL, OR THE CONDENSER MAY SPRING BACK TO A DIFFERENT SETTING AS SOON AS THE TOOL IS REMOVED.

2. Go back and repeat all four adjustments since the adjustment of each I.F. trimmer affects the others to a certain extent, thus necessitating readjustment.

### Adjusting R. F. and Oscillator Circuits

1. Twist the aerial and ground wires of the set together for their entire length to reduce noise pick-up. Connect the aerial wire to the output of the oscillator and ground both set and oscillator. Adjust the oscillator frequency to 1400 K.C. and carefully tune the receiver to give maximum output. Adjust the oscillator output to produce about one-half full scale deflection of the output meter.

2. Carefully tune the radio frequency stage "A" trimmer till the output meter reading reaches a maximum.

3. Retune the set and adjust the "B" first detector trimmer for maximum output. The oscillator, or "O" trimmer should not be touched unless the set is badly out of calibration at the high frequency end of the dial.

4. Set the oscillator at 600 K.C. and tune the set carefully to this frequency.

5. Adjust the oscillator padding condenser "P" for maximum output, **RETUNING THE SET AFTER EACH CHANGE IN ADJUSTMENT.** This is important.


6. Turn back the oscillator to 1400 K.C., tune the set to the same frequency, and very carefully readjust the "A" and "B" trimmer condensers to produce maximum output.

The receiver should now be perfectly aligned.



# STEWART-WARNER SPEEDOMETER CORP.

## Circuit Data for Stewart-Warner A. C. Series R-106



### 106 PARTS LIST

Diag. No.	Part No.	Description	Price
1	67248	3 gang tuning condenser	\$5.50
2	67259	45,000 ohm, 1/2 w. carbon res.	.25
3	67294	1 mf., 200 v. tubular cond.	.30
4	67297	.25 mf., 200 v. tubular cond.	.40
5	67298	.01 mf., 600 v. tubular cond.	.30
6	67299	.02 mf., 400 v. tubular cond.	.30
7	67303	2,000 ohm, 1/2 w. carbon res.	.25
8	67328	8 mf., 440 v. electrolytic cond.	.75
9	67551	2.5 volt pilot lamp	.25
10	67584	Filter choke coil	2.00
11	67588	8 mf., 500 v. electrolytic cond. (For 25 cycle sets only)	1.80
12	67762	.05 mf., 200 v. tubular cond.	.25
13	67938	100,000 ohm, 1 w. carbon res.	.25
14	67939	1 megohm, 1/2 w. carbon res.	.40
15	67972	Speaker cable and plug	.60
16	81042	Speaker plug only	.20
17	81151	4,000 ohm, 1/2 w. carbon res.	.25
18	81155	.0005 mf. pigtail mica cond.	.25
19	81156	.001 mf. pigtail mica cond.	.30
20	81157	.00025 mf. pigtail mica cond.	.30
21	81190	1 mf., 200 v. tubular cond. & bracket	.35
22	81251	Celluloid pad trimmer control	1.00
23	81279	Diaphragm (R210) or (R1211A)	2.75
24	81361	150,000 ohm, 1/2 w. carbon res.	2.75
25	81382	500,000 ohm, 1/2 w. carbon res.	.25
26	81484	500,000 ohm volume control	.95
27	81510	1st I. F. trans. assembly	2.00
28	81254	Double I. F. trans. cond. only	1.00
29	81254	I. F. transformer coils only	1.00
30	81254	2nd I. F. trans. assembly	2.00
31	81254	Double I. F. trim. cond. only	1.00
32	81254	I. F. trim. cond. only	1.00
33	81254	Single speaker output trans.	1.00
34	81513	Twin speaker output trans.	2.75
35	81596	115 v., 60 cy. power trans.	8.00
36	81571	115 v., 25 cy. power trans.	10.00
37	81574	10-250 v., 50-60 cy. power trans.	10.00
38	81530	Voltage divider vitreous res.	1.25
39	81534	8,000 ohm sensitivity control & switch.	2.50
40	81534	8,000 ohm speaker field coil (1000 ohm)	3.50
41	81265	211 A vacuum tube	3.50
42	81538	R. F. tuning coil (160 ohms)	1.00
43	81539	Oscillator tuning coil	1.00
44	81548	200 ohm, 1/2 w. resistor	.25
45	81548	First detector tuning coil	1.50
46	81580	.25 mf., 100 v. shielded cond. in can	1.50
47	81593	1 mf., 100 v. shielded cond. in can	.25
48	81616	1000 ohm, 1/2 w. tubular cond.	.40
49	81618	1000 ohm, 1/2 w. tubular cond.	.40
50	81618	1000 ohm, 1/2 w. tubular cond.	.40
51	81618	1000 ohm, 1/2 w. tubular cond.	.40
52	81618	1000 ohm, 1/2 w. tubular cond.	.40
53	81618	1000 ohm, 1/2 w. tubular cond.	.40
54	81618	1000 ohm, 1/2 w. tubular cond.	.40
55	81618	1000 ohm, 1/2 w. tubular cond.	.40
56	81618	1000 ohm, 1/2 w. tubular cond.	.40
57	81618	1000 ohm, 1/2 w. tubular cond.	.40
58	81618	1000 ohm, 1/2 w. tubular cond.	.40
59	81618	1000 ohm, 1/2 w. tubular cond.	.40
60	81618	1000 ohm, 1/2 w. tubular cond.	.40
61	81618	1000 ohm, 1/2 w. tubular cond.	.40
62	81618	1000 ohm, 1/2 w. tubular cond.	.40
63	81618	1000 ohm, 1/2 w. tubular cond.	.40
64	81618	1000 ohm, 1/2 w. tubular cond.	.40
65	81618	1000 ohm, 1/2 w. tubular cond.	.40
66	81618	1000 ohm, 1/2 w. tubular cond.	.40
67	81618	1000 ohm, 1/2 w. tubular cond.	.40
68	81618	1000 ohm, 1/2 w. tubular cond.	.40
69	81618	1000 ohm, 1/2 w. tubular cond.	.40
70	81618	1000 ohm, 1/2 w. tubular cond.	.40
71	81618	1000 ohm, 1/2 w. tubular cond.	.40
72	81618	1000 ohm, 1/2 w. tubular cond.	.40
73	81618	1000 ohm, 1/2 w. tubular cond.	.40
74	81618	1000 ohm, 1/2 w. tubular cond.	.40
75	81618	1000 ohm, 1/2 w. tubular cond.	.40
76	81618	1000 ohm, 1/2 w. tubular cond.	.40
77	81618	1000 ohm, 1/2 w. tubular cond.	.40
78	81618	1000 ohm, 1/2 w. tubular cond.	.40
79	81618	1000 ohm, 1/2 w. tubular cond.	.40
80	81618	1000 ohm, 1/2 w. tubular cond.	.40
81	81618	1000 ohm, 1/2 w. tubular cond.	.40
82	81618	1000 ohm, 1/2 w. tubular cond.	.40
83	81618	1000 ohm, 1/2 w. tubular cond.	.40
84	81618	1000 ohm, 1/2 w. tubular cond.	.40
85	81618	1000 ohm, 1/2 w. tubular cond.	.40
86	81618	1000 ohm, 1/2 w. tubular cond.	.40
87	81618	1000 ohm, 1/2 w. tubular cond.	.40
88	81618	1000 ohm, 1/2 w. tubular cond.	.40
89	81618	1000 ohm, 1/2 w. tubular cond.	.40
90	81618	1000 ohm, 1/2 w. tubular cond.	.40
91	81618	1000 ohm, 1/2 w. tubular cond.	.40
92	81618	1000 ohm, 1/2 w. tubular cond.	.40
93	81618	1000 ohm, 1/2 w. tubular cond.	.40
94	81618	1000 ohm, 1/2 w. tubular cond.	.40
95	81618	1000 ohm, 1/2 w. tubular cond.	.40
96	81618	1000 ohm, 1/2 w. tubular cond.	.40
97	81618	1000 ohm, 1/2 w. tubular cond.	.40
98	81618	1000 ohm, 1/2 w. tubular cond.	.40
99	81618	1000 ohm, 1/2 w. tubular cond.	.40
100	81618	1000 ohm, 1/2 w. tubular cond.	.40
101	81618	1000 ohm, 1/2 w. tubular cond.	.40
102	81618	1000 ohm, 1/2 w. tubular cond.	.40
103	81618	1000 ohm, 1/2 w. tubular cond.	.40
104	81618	1000 ohm, 1/2 w. tubular cond.	.40
105	81618	1000 ohm, 1/2 w. tubular cond.	.40
106	81618	1000 ohm, 1/2 w. tubular cond.	.40

LINE	TUBE	VOLUME TABLE	VOLUME AND SENSITIVITY CONTROLS FULL ON
58	R. F.	Filament Voltage: 2.29	Plate Voltage: 245
56	Osc.	Filament Voltage: 2.28	Plate Voltage: 97
58	1st Det.	Filament Voltage: 2.26	Plate Voltage: 245
55	2nd Det.	Filament Voltage: 2.24	Plate Voltage: 66
59	Output	Filament Voltage: 2.24	Plate Voltage: 229
80	Rect.	Filament Voltage: 4.78	Plate Voltage: 245

All D. C. voltages measured with respect to ground, using high resistance voltmeter of 1000 ohms per volt. Readings will vary, depending upon voltage range of meter, being higher for higher range instruments. This variation is most marked for second detector plate voltages.

\*This reading taken between negative end of voltage divider and chassis.

# STROMBERG-CARLSON TELEPHONE MFG. CO.

## Engineering Data Stromberg-Carlson Nos. 48, 49, 50, and 51 Radio Receivers

STROMBERG-CARLSON TELEPHONE MANUFACTURING COMPANY  
Rochester, New York

### ELECTRICAL SPECIFICATIONS

Type of Circuit.....	Superheterodyne
Type and Number of Tubes.....	3 No. 58, 1 No. 57, 3 No. 56, 1 No. 55, 2 No. 2A3, 1 No. 5Z3
Voltage Rating.....	105-125 Volts
Frequency Rating.....	60 Cycles and 25-60 Cycles
Power Consumption (Maximum at 125 Volts).....	160 watts

### CIRCUIT DESCRIPTION

The three No. 58 tubes are used as R. F. amplifier, mixer, and I. F. amplifier. The No. 57 is used as the "relay" tube in the "Q" circuit. One No. 56 tube is used as the oscillator and the other two as the push-pull first audio amplifier. The No. 55 tube is used as the demodulator. The two No. 2A3 super-triode tubes are used in the push-pull power output stage. The No. 5Z3 rectifier is used in the power supply.

A Bi-resonator is used to couple the antenna to the R. F. amplifier to prevent cross modulation. The R. F. amplifier is coupled to the mixer by a regular tuned R. F. transformer. This gives three tuning circuits (four-gang tuning capacitor) for R. F. selectivity ahead of the mixer, thus the image response ratio is extremely high. The oscillator is coupled to the cathode circuit of the mixer tube in the regular manner. The I. F. output of the mixer tube is fed into Tetro-resonator (four-tuned circuit transformer) and thence to the I. F. amplifier tube. This tube is coupled to the No. 55 demodulator tube by a single-tuned circuit transformer.

The resistor unit of the volume control potentiometer forms part of the load of the "audio" diode of the No. 55 tube, and the audio voltage is applied to the triode portion of this tube through the movable contact of this potentiometer. The potentiometer is double, the rear unit being used in the low level tone compensation circuit, which increases the response to bass frequencies and high frequencies in proper amount as the volume level is reduced. The output of the triode portion of the No. 55 tube is fed through a transformer to the push-pull first audio stage. The "Bass Control" circuit apparatus is connected across the primary of this transformer. The "Bass Control" switch is provided to remove the bass compensation by opening this circuit when it is desired to secure extremely high levels of sound output for dancing, etc. The AVC voltage is obtained from the other diode of the No. 55 tube, and is fed back to the first two tubes through a suitable filter.

The "Q" circuit for providing quiet operation for tuning between stations consists of the No. 57 relay tube connected to the "AVC" diode of the No. 55 tube. When there is no carrier coming in, the action of this circuit is to put high negative potentials on the "audio" diode and the control grid of the triode of the No. 55 tube, thus preventing reception of inter-carrier noise when tuning. When a carrier of suitable strength comes in, these negative potentials are removed and the signal is received. A switch in the rear of the chassis is provided, so that this "Q" circuit can be rendered inoperative if it is desired to use the maximum sensitivity of the receiver.

From the push-pull first audio stage the signal is coupled by a transformer to the super-triode push-pull power output stage. The "Adjustable Treble Control" circuit apparatus is connected across the primary of this coupling transformer to enable the user to adjust the proportion of high frequencies in the reproduction as he desires. Used in conjunction with the "Bass Control" a wide range of variation in the response characteristics can be obtained.

A large output transformer, large on account of the high audio power available in the system, is used to couple the super-triode tubes to the high quality electro-dynamic speaker.

The power supply employs three stages of filter; the first being of the resistance type, and the other two of the choke type. The speaker field is used as the choke in the third stage. The plate supply for the output tube is tapped off between the second and third stages of filter, while the remainder of the voltages are supplied from the voltage divider resistor.

(The servicing instructions for the Multi-Record Phonograph in the No. 51 Radio-Phonograph are in P-23221 Data Sheet.)

### CONTROLS

The accompanying cut shows the location and purpose of the controls on the front panel of the receiver, and the following paragraphs explain their use.

#### Station Selector

No description of this control is necessary as its operation is usual and normal.


#### On-Off Switch and Adjustable Treble Control

The On-Off switch is turned to "On" by clockwise rotation. Further rotation in a clockwise direction gradually reduces the response to the high audio or treble frequencies. When in a full clockwise position the minimum response to the highs is obtained. The full audio range is again obtained by turning the knob counter-clockwise until just before the On-Off switch turns "Off".

#### Volume Control

This control is operated in the usual manner, turning clockwise for higher volume levels. Operated simultaneously with this Volume Control is the low level tone compensation circuit, which increases the relative response to low and high audio frequencies as the volume level is reduced. This gives the effect of "constant fidelity" to the ear.

# STROMBERG-CARLSON TELEPHONE MFG. CO.



Location of Controls.

### Phonograph Switch and Bass Control

When this knob is turned counter-clockwise from the normal position, the input of the audio system is switched to the phonograph circuits in such a manner that the Volume Control knob is used for controlling the level of reproduction of phonograph recordings. When turned clockwise from the normal position, this control reduces the response at the low audio or bass frequencies. This position is used when it is desired to obtain extremely high sound levels from the receiver without over-loading.

### "Q" Switch

This control is a toggle switch located on the rear of the chassis. When the lever is in the "Down" position the "Q" circuit is operating.

### Hum Balancer

This is a potentiometer located on the rear of the chassis with means for adjusting by a screwdriver. It should be adjusted only when the Volume Control is at minimum and the "Q" Switch is in the "Up" position.


### ALIGNMENT OF RECEIVERS

Realignment of the R. F. and Oscillator Tuning circuits when necessary may be accomplished in the following manner:

If a test oscillator and output meter are used, the signal strength applied to the receiver should be low enough so that the automatic volume control is not operated in order to avoid apparent broad adjustment. If broadcast signals are used, moderately strong signals which swing the meter pointer about half the distance back toward the "Off" position should be used.

With whichever method is used, the receiver should be tuned to a 1400 kc. signal first, and the Antenna, R. F. and Oscillator Shunt Aligners adjusted for best setting. Next the receiver should be set at 600 kc. on the dial, and the Oscillator Series Aligner ONLY adjusted for best position for maximum background noise. After this is done re-check the Oscillator Shunt Aligner at 1400 kc., using same dial setting as previously. The receiver should be left turned "On" for about fifteen minutes before aligning.

The Intermediate Amplifier circuits are aligned on oscillographs to obtain the proper shape of resonance curves having "steep" sides to get proper selectivity and fidelity. "Peak" methods of alignment (with oscillator and meter) do not give the desired curve, as it may be broad and unsymmetrical although a high peak is indicated. The adjustment of these circuits is very stable as shown by field experience and Proving Division tests. Therefore, as these adjustments cannot be duplicated exactly without the oscillograph equipment, it is recommended that the I. F. circuits never be adjusted by a service man.



Schematic Circuit of Receiver.

# STROMBERG-CARLSON TELEPHONE MFG. CO.

## NORMAL VOLTAGE READINGS

These voltage readings correspond to a line voltage at 120 volts. When voltages are measured, proper allowances should be made for a difference in line voltage above or below 120 volts. Be sure to make these readings with the Meter and Scale indicated, otherwise the results will not agree with those tabulated. Alternating voltages are indicated in italics. The dial should be set at about 1000 kc. The "Q" switch should be set in the "Up" position so that the "Q" circuit is not operating.


Voltage	Meter	Scale	Where Measured	Approx. Value in Volts
Heater Voltages Nos. 55, 56, 57, and 58 Tubes	A. C.	0-4	Across Heater Terminals of Sockets	2.5
Filament Voltages Nos. 2A3 Tubes	A. C.	0-4	Across Filament Terminals of Audio Output Sockets	2.5
Filament Voltage No. 5Z3 Tube	A. C.	0-8	Across Filament Terminals of No. 2B0 Rectifier Socket	5.
Plate Voltage Radio Amplifier Tube	D. C.	0-250	Between Plate Terminal of R. F. Amplifier Socket (+) and Chassis Base (-)	200
Plate Voltage Mixer Tube	D. C.	0-250	Between Plate Terminal of Mixer Socket (+) and Chassis Base (-)	200
Plate Voltage Oscillator Tube	D. C.	0-250	Between Plate Terminal of Oscillator Socket (+) and Chassis Base (-)	95
Plate Voltage I. F. Tube	D. C.	0-250	Between Plate Terminal of I. F. Socket (+) and Chassis Base (-)	200
Plate Voltage Demodulator Tube	D. C.	0-250	Between Plate Terminal and Demodulator Socket (+) and Chassis Base (-)	170
Plate Voltage First Audio Tubes	D. C.	0-250	Between Plate Terminal of First Audio Socket (+) and Chassis Base (-)	220
Plate Voltages Audio Output Tubes	D. C.	0-750	Between Plate Terminals of Audio Output Sockets (+) and Chassis Base (-)	345
"C" Voltage R. F. Amplifier Tube	D. C.	0-10	Between Cathode Terminal of R. F. Amplifier Socket (+) and Chassis Base (-)	4
"C" Voltage Mixer Tube	D. C.	0-10	Between Cathode Terminal of Mixer Socket (+) and Chassis Base (-)	8
"C" Voltage Oscillator Tube	D. C.	0-250	Between Cathode Terminal of Oscillator Socket (+) and Chassis Base (-)	25
"C" Voltage I. F. Tube	D. C.	0-10	Between Cathode Terminal of I. F. Socket (+) and Chassis Base (-)	4
"C" Voltage First Audio Tubes	D. C.	0-250	Between Cathode Terminal of First Audio Sockets (+) and Chassis Base (-)	12
"C" Voltage Audio Output Tube	D. C.	0-250	Across 775-ohm Biasing Resistor	60
Grid Voltage Triode of Demodulator Tube	D. C.	0-250	Between Cathode Terminals of Demodulator Socket (+) and Green-White Wire on "B" Stick (-)	8
Screen Voltages R. F. Mixer and I. F. Tubes	D. C.	0-250	Between Screen Terminals on Sockets (+) and Chassis Base (-)	95
"B" Voltage R. F. Mixer, I. F. First Audio and Demodulator Tube	D. C.	0-250	Between High Side of Voltage Divider (+) and Chassis Base (-)	200
"B" Voltage Audio Output Tubes	D. C.	0-750	Between Mid-Tap of Output Transformer (+) and Chassis Base (-)	350
Speaker Field Volts	D. C.	0-250	Across Small Pins on Speaker Connector Socket	145
Plate Voltage A. C. per Anode No. 5Z3 Rectifier Tube	A. C.		Between Plate Terminals of No. 5Z3 Rectifier Socket and Chassis Base	380

## CONTINUITY READINGS OF CHASSIS

All readings taken from designated terminal to chassis base unless otherwise specified and are indicated in ohms as read on a Weston Model 663 Ohmmeter. The G terminals of the Nos. 55, 57, and 58 tubes are connected to the top caps.


Tube	H	H	K	SU	S	P	G	Remarks
R. F. (58)	0	0	600	600	20,000	5,000	1,450,000	SU and S terminals of Demodulator Socket are diode plates.
Mix (58)	0	0	2000	2000	20,000	5,000	1,450,000	
Osc (56)	0	0	6500			20,000	600	NOTE A With phono switch on, Res. is from 1 megohm to 400,000 ohms, varying with volume control.
I. F. (58)	0	0	600	600	20,000	5,000	70	NOTE B Open when switch is in up position, 600 ohms when switch is in down position and relay tube is operating.
Demod. (55)	0	0	600	100,000	1,000,000	10,450	2,100,000	
Relay (57)	0	0	{ See Note B } Open=0		100,800	100,425	{ See Note A } 1,500,000	NOTE C Readings taken from designated terminal to either "H" terminal of rectifier (5Z3) socket.
1st Aud. (56) 1st	0	0	1200			{ See Note C } 11,085	5,000	
1st Aud. (56) 2nd	0	0	1200			{ See Note C } 11,690	6,500	NOTE D Taken from H-H terminals to either P terminal of 2nd audio (output) sockets.
2nd Aud. (2A3) 1st	F	F	975	975		{ See Note C } 340	1,100	
2nd Aud. (2A3) 2nd	975	975				{ See Note C } 420	1,100	
Rect. (5Z3)	{ See Note D } 340	{ See Note D } 420				27	27	

# STROMBERG-CARLSON TELEPHONE MFG. CO.



Wiring Diagram of Chassis.

# STROMBERG-CARLSON TELEPHONE MFG. CO.



Chassis Assembly.


# THORDARSON ELECTRIC MFG. CO.

## A CLASS "B" AMPLIFIER USING TYPE 46 TUBES

The release of the type 46 double grid tube and the type 82 mercury vapor rectifier makes possible the construction of an amplifier that will deliver 20 watts of audio power at a very reasonable cost. In order that full power may be obtained with negligible distortion, it is important that carefully designed coupling transformers be used and that the power supply unit have extremely good regulation.

We recommend that the filaments be lighted from a separate transformer as shown in the circuit diagram. This, with the unusually heavy plate supply transformer, assists greatly in improving the regulation over that obtained with the ordinary power supply. In addition, a swinging filter choke, T-2353-A, so designed that the inductance decreases with an increase in current, has the effect of raising the output voltage of the rectifier system at the heavier current drains and tends to make the voltage output of the power supply constant over the required range. This is extremely important for a class "B" amplifier since the plate current of the power tubes varies over a wide range with each signal impulse.

The grids of the power output tubes of class "B" amplifiers draw considerable current. The coupling transformer used to feed the grids must be designed with care in order that maximum power transfer may be accomplished with a minimum of signal distortion. A driver stage of sufficient capacity to properly excite the class "B" stage is, of course, necessary.



## THORDARSON ELECTRIC MFG. CO.

A schematic diagram of the complete amplifier is shown in Figure "A". The input is designed so that it is possible to fade from an electric pick-up or a radio set to the microphone. A type T-2876 transformer was used to couple the pick-up to the fader. It is important that this coupling transformer have a low resistance primary in order that the full voltage developed by the pick-up be available. It should be noted that the pick-up is connected to the secondary of the transformer, the terminals of which are marked "speaker", and the primary is connected to the fader. This gives a step-up ratio of 1.7. The circuit shows the use of the T-3020 transformer to couple the double button microphone to the fader. In case a single button microphone is used, the type T-2357 transformer may be substituted. The fader also serves as a volume control for the amplifier.


A type 56 tube is used in the first audio or voltage amplifier stage. This has practically the same characteristics as the type 27 tube with the exception that the amplification factor is 13.8 compared with 8.2 for the type 27. The type 27 tube can be substituted for the type 56 tube without any change in the circuit constants if the voltage input from the pick-up and microphone is sufficiently high.

The type 56 tube is coupled to a type 46 tube in the driver stage operating as a class "A" amplifier. The 46 has two grids, one close to the plate and the other next to the filament. In class "A" operation, the grid closest to the plate is tied to the plate. An R-300 transformer is used to couple the voltage amplifier stage to the driver stage and a low pass filter is placed across the secondary of the R-300. The low pass filter is adjustable so that the response of the amplifier to the higher frequencies can be reduced. Adjusting the low pass filter will eliminate objectionable high notes. If a greater cut off of the high frequencies is desired, this can be obtained by using a condenser larger than the .003 mfd. recommended. The filter also cuts down needle scratch and microphone hiss.

The driver stage is coupled through a type T-5289 transformer into the grids of the 46 tubes in the class "B" power output stage. This is a transformer of generous design with the secondary center tapped and designed to carry the heavy grid currents. For class "B" operation, the two grids of the 46 tube are tied together.

A cheap and fairly good volume indicator consists of a 0-25 milliamperere D.C. meter placed in the circuit between the center tap of the T-5289 transformer secondary and ground. This measures the grid current drawn by the class "B" power output tubes which varies with the strength of signal. For full power the meter will swing to about 20 milliamperes on signal peaks.

The output transformer shown in Figure "A" couples the power stage to a 500 ohm line. If the speakers are placed at any distance from the amplifier, it is recommended that this method of coupling to the speakers be used, since considerable loss of power will result if long leads are connected direct to the voice coils.






# THORDARSON ELECTRIC MFG. CO.

At the speaker end of the line, the type T-5381 transformer should be used. The primary of this transformer is designed to match the 500 ohm line and has a tap for 250 ohms. The secondary is designed for an 8 ohm voice coil (which is almost standard for dynamic speakers) and has a tap at 4 ohms if two are to be used in parallel. Figure "B" shows the circuit for two speakers with the connections for one speaker dotted in. The 4 and the 8 ohm taps should not both be used at the same time.

Figure "C" shows the method of coupling recommended where it is desired to operate two groups of speakers which may be some distance apart. Two of the T-5381 transformers are used and should be placed as close as possible to the speakers. Using the 250 ohm taps, the primaries of the two transformers are connected in series to match the 500 ohm line. Either one or two voice coils may be connected to the secondaries as explained above.



If the speakers are close to the amplifier, the type T-5356 transformer can be used as the output transformer in the amplifier and the secondary coupled directly to the voice coils of the speakers. Figure "D" shows this method of connection. If one speaker is used it should be connected to terminals 1 and 3 which is the 8 ohm output. If four speakers are to be used, they should be connected in series-parallel to the 8 ohm terminals. If two speakers are to be used, the four ohm secondary should be used with the speakers in parallel.





Figure "E" shows the overall response curve of the amplifier from the grid of the 56 tube to the secondary of the output transformer.



## THORDARSON ELECTRIC MFG. CO.

The average gain of the amplifier is approximately 42 decibels, which does not include the amplification of the input transformer. The dotted curve shows the effect of the low pass filter in attenuating the high frequencies.

There are no tricks to the circuit and it is only necessary to observe ordinary precautions in the construction and operation of the amplifier. The cases of all the coupling transformers should be connected to the ground (B-) of the amplifier. The pick-up, the frame of the turntable motor, and the center tap of the microphone transformer should be grounded as well. If it is not convenient to connect the ground post of the amplifier to a good ground, a 1.0 mfd. condenser connected to the ground side of the incoming power line may be used to ground the amplifier. All grid leads should be kept as short as possible. The leads carrying A.C. should be twisted together and kept as far as possible from the other wiring. The coupling transformers should be placed outside the magnetic field of the power supply to keep the hum at a low level. It is often times possible to reduce hum by rotating the input transformers until a most advantageous position is found.

The amplifier should never be operated without a load connected to the secondary of the output transformer as it might cause the destruction of either the tubes or the output transformer, or both. If the amplifier is operated with only one or two speakers the volume should be kept low or the speakers may be permanently injured by the tremendous power available.

For amateur phone transmitters the same circuit may be used, the type T-5291 output transformer being used to modulate one or two 210 tubes. A choke and condenser should be used to isolate the plate current of the modulated tubes from the secondary of the transformer.


### List of Transformers to be Used

T-5303	Plate Transformer - 400 volts D.C. - 200 m.a.	\$8.00 list
T-5338	Filament Transformer	6.00 list
T-2353-A	Swinging Filter Choke	5.00 list
T-5289	Input Transformer - 46 to 46's Class "B"	5.00 list
T-5339	Output 46's Class "B" to 500 ohms	5.00 list
T-5356	Output 46's Class "B" to 8 or 4 ohms	5.00 list
T-5381	Line transformer 500 to 8 or 4 ohms	4.50 list
T-5291	Output 46's Class "B" to 10,000 or 5,000 ohms	5.00 list
T-3020	Double Button Microphone to Grid	5.00 list
T-2876	Coupling Transformer	3.00 list
R-300	Audio Transformer	4.00 list
R-196	Filter Choke	3.00 list

# TRANSFORMER CORPORATION OF AMERICA

## MODEL 300

### SUPERHETERODYNE



**ADJUSTING TRIMMERS:** The model 300 receiver has nine trimmer condensers. The setting must be accurate, although with tolerance enough to permit exchange of tubes without ruining sensitivity. Rough handling in shipment will not ordinarily jar these condensers and cause the set to lose sensitivity.



To adjust the trimmers connect your 175 K. C. oscillator to the first detector type 58 grid cap, and in the following order, readjust trimmers numbers five, six, seven, eight and nine for maximum output; next, disconnect your 175 K. C. oscillator and connect to the antenna binding post of the receiver the output lead from your broadcast test oscillator or tune in a broadcast signal from a known frequency, crystal controlled, station at 1400 K. C., then reset trimmers two and one respectively for maximum output. This adjustment will track the first detector and r. i. stage.

To check the calibration of the receiver, whether it be high or low, trimmer, number three (oscillator) should be reset until a station of known high frequency is brought in at the correct dial marking with peak volume. If your broadcast test oscillator is accurately calibrated, it might be used in place of the broadcast station signal. In this adjustment a signal at about 1400 K. C. should be chosen. The setting of the trimmers at 1400 K. C. is more critical than it would be at 600 K. C., therefore more accurate.

The next adjustment is important and not easily explained in writing, so pay close attention to the following instructions. We will now balance the oscillator to the r. i. and first detector stages. Tune the external broadcast test oscillator and the receiver both to 600 K. C., then slowly increase or decrease the capacity of No. 4 (oscillator padding trimmer) at the same time and continuously tuning back and forth across the signal with the receiver tuning condenser gang. The output meter needle will now be swinging up and down in step with the variation in tuning. Watch the peak of this swinging closely and readjust No. 4 trimmer until the swinging needle reaches its highest peak. Your output meter mentioned in this test is not to be confused with the tuning meter incorporated in the set.

Return the receiver and broadcast test oscillator to 1400 K. C., and recheck trimmer No. 3 to make sure that the adjustment of No. 4 has not thrown the receiver out of calibration. If it has, then readjust No. 3 until the calibration is correct, as previously explained, and check on trimmers No. 2 and No. 1 to make sure that the adjustment of No. 4 has not reduced the sensitivity.

# TRANSFORMER CORPORATION OF AMERICA



VOLTAGE ANALYSIS

Model 320

No.	Stage	Tube	A	B	C	K	SoG	Ip	Su.C
1	Autodyne . . . . .	57	2.0	230	3.0	3.0	75	3.5	....
2	I.F. . . . .	58	2.0	245	1.5	1.5	65	4.5	1.5
3	2nd. det. . . . .	57	2.0	125	1.0	2.0	45	.2	2.0
4	Output. . . . .	47	2.0	260	14	...	270	27.	....
5	Rectifier . . . . .	80	4.4	280	...	...	...	....	....

Vol. control "full on".  
Line: 115 volts.




BREAKDOWN ANALYSIS

## MODEL 320


### SUPERHETERODYNE

*Clarion Radio*

# TRANSFORMER CORPORATION OF AMERICA TYPE 340



# TRANSFORMER CORPORATION OF AMERICA



CIRCUIT RESISTANCE ANALYSIS  
MODEL 340 SOCKET TO GROUND

Stage	Grid	Cathode	Heater	Plate	Screen G	Suppr. G	Space G
R.F.	Infinity	0	.1	18,750	1,000	0	.....
Autodyne	1,000	8,000	.1	18,750	7,500	0	.....
I.F.	75	500	.1	18,750	7,500	0	.....
Diode det.	250,000	500	.1	500	.....	.....	.....
Audio	750,000	1,000	.1	18,750	.....	.....	.....
Output	500,000	.....	.1	18,750	.....	.....	18,750
Output	500,000	.....	.1	18,750	.....	.....	18,750
Rectifier	.....	.....	18,750	1,800	.....	.....	.....


\* Volume control "full on".  
NOTE: Readings of one megohm and over are given as "infinity". The first three significant figures, only are interpreted from the ohmmeter in each reading. The individual resistance in the circuit can be readily checked upon removal of chassis.

VOLTAGE ANALYSIS \*ACTUAL  
MODEL 340

No.	Stage	Tubes		A	B	C	K	S <sub>c</sub>	S <sub>p</sub>	I <sub>p</sub>	Su. G
		58	57								
1	r.f.	58	57	2.4	260	.4	0	12	.6	0	0
2	Autodyne	58	57	2.4	260	0	7	90	.5	0	0
3	i.f.	58	56	2.4	260	0	3	90	5.	0	0
4	Diode det.	56	56	2.4	3	0	3	.....	0	.....	.....
5	Audio	56	56	2.4	180	0	12	.....	5	.....	.....
6	Output	47	47	2.4	250	1	.....	260	20	.....	.....
7	Output	47	47	2.4	250	1	.....	260	20	.....	.....
8	Rectifier	80	80	4.8	.....	.....	.....	.....	.....	.....	.....

Volume control full on.  
\*Tested from socket to chassis with 1000 ohm per volt meter.  
Line 115 volts.

# TRANSFORMER CORPORATION OF AMERICA




SCHEMATIC DIAGRAM  
CLARION  
MODEL-360

# UNITED AMERICAN BOSCH CORP.

## ESSEX RADIO

Service Instructions for the Models 4 and 10 Receivers



Schematic Wiring Diagram - Model 4 Receiver


R1 - Volume Control  
 R2 - 600 ohms  
 R3 - 50,000 ohms  
 R4 - 1 megohm  
 R5 - 1/2 megohm  
 R6 - 100,000 ohms  
 R7 - 400 )  
 R8 - 11,500)ohms  
 R9 - 19,000)  
 R10 - 2 megohms  
 R11 - Center Tap  
 C1 - Antenna Trimmer  
 C2 - Condenser Gang

C3 - Condenser Gang  
 C4 - Condenser Gang  
 C5 - Coupling Capacity  
 C6 - .0001 mfd. mica  
 C7 - .005 3 ply  
 C8 - .25 2 ply  
 C9 - .25 2 ply  
 C10 - .05 2 ply  
 C11 - .05 2 ply  
 C12 - .05 2 ply  
 C13 - .01 3 ply  
 C14 - 8 mfd.)  
 C15 - 4 mfd.)

By-pass unit  
 Filter unit



# UNITED AMERICAN BOSCH CORP. MODEL 10



Schematic Wiring Diagram - Model 10 Receiver

- |                      |                     |                       |
|----------------------|---------------------|-----------------------|
| R1 - 100,000 ohms    | R19 - 20,000 ohms   | C18 - .05 mfd 3 ply   |
| R2 - 1000 ohms       | C1 - Condenser Gang | C19 - .05 mfd 2 ply   |
| R3 - 2000 ohms       | C2 - Condenser Gang | C20 - .0001 mfd. mica |
| R4 - 100,000 ohms    | C3 - Condenser Gang | C21 - 8 mfd.          |
| R5 - 20,000 ohms     | C4 - Condenser Gang | C22 - 8 mfd.          |
| R6 - 100,000 ohms    | C5 - Condenser Gang | C23 - 4 mfd.          |
| R7 - 500,000 ohms    | C6 - Condenser Gang | C24 - .01 mfd 4 ply   |
| R8 - 1 megohm        | C7 - .04 mfd. 3 ply | C25 - .0001 mica      |
| R9 - 500,000 ohms    | C8 - .05 mfd. 3 ply | C26 - .1 mfd 3 ply    |
| R10 - 500,000 ohms   |                     |                       |
| R11 - 500,000 ohms   |                     |                       |
| R12 - 12,000 ) ohms  |                     |                       |
| R13 - 8000 ) ohms    |                     |                       |
| R14 - 6000 ) ohms    |                     |                       |
| R15 - 30 ) ohms      |                     |                       |
| R16 - 200 ) ohms     |                     |                       |
| R17 - 300 ) ohms     |                     |                       |
| R18 - Center Tap     |                     |                       |
| C9 - 7 to 70 mmf.    |                     |                       |
| C10 - 7 to 70 mmf.   |                     |                       |
| C11 - .5 mfd.        |                     |                       |
| C12 - .0005 mfd.     |                     |                       |
| C13 - 7 to 70 mmf.   |                     |                       |
| C14 - .05 mfd. 2 ply |                     |                       |
| C15 - .0001 mfd mica |                     |                       |
| C16 - .0001 mfd mica |                     |                       |
| C17 - .05 mfd 2 ply  |                     |                       |

# UNITED AMERICAN BOSCH CORP.

## Socket Voltage Readings - Model 4 Receiver

	224 1st RF	224 Det.	247 Audio	280 Rect.
Filament	2.2	2.2	2.2	4.5
Plate	250	250	250	
Screen	90	90	250	
Bias	2.5	-	45	

## Socket Voltage Readings - Model 10 Receiver

	227 Osc.	1st Det. 551	1st I.F. 58	2nd IF 58	AVC 227	2ND DET 227	AF 227	AF 245	Rect. 280
Filament	2.5	2.2	2.2	2.2	2.3	2.3	2.3	2.3	4.5
Plate	85	228	105	232	36	-	225	225	-
Screen	-	85	85	85	-	-	-	-	-
Bias	7	2.6	2.6	-	-	-	19	45	-

## ALIGNMENT INSTRUCTIONS FOR MODEL 10

### I. F. ADJUSTMENT


1. Connect the five leads to the loud speaker.
2. Set volume control at maximum, tone control on base, and ground antenna lead.
3. Connect the 175 KC oscillator to the grid of the 2nd I. F. tube.
  - a) Align the second I. F. transformer, for max. sensitivity. 20,000 u.v.
4. Connect the 175 KC oscillator to the grid of the 1st I.F. tube.
  - a) Align the first and second I.F. coils for max. sens. Limit: 500 u.v.
5. Check the I. F. stability.

### OSCILLATOR ADJUSTMENT

1. Adjust scale so that the indicator will be on the second line from the left, when the gang is entirely closed.
2. Connect ant. lead of the R. F. Oscillator to the grid of the 1st Detector.
3. Set the oscillator and set scale at 1400 Kilocycles.
  - a) Peak the oscillator condenser on the second signal heard, when turning the condenser out. The osc. condenser is the front align. cond. on the variable condenser gang.
4. Connect ant. lead of the R. F. oscillator to the antennae lead of the set.
  - a) Without touching the oscillator condenser, align the R. F. and ant. alignment condensers to the 1400 Kilocycle signal, until maximum sensitivity is obtained.
5. Check sensitivity at 1400 Kilocycles. Limit is 20 microvolts.  
Check sensitivity at 1000 Kilocycles. Limit is 20 microvolts.  
Check sensitivity at 550 Kilocycles. Limit is 20 microvolts.
6. If set lacks sensitivity at 600 or 550, the plates of the condenser gang should be adjusted until the set will reach the sensitivity limits.
7. If set does not track at 600, readjust plates of osc. section of gang condenser.

# UNITED AMERICAN BOSCH CORP.

## MODEL 31



Wiring Diagram of Model 31 Receiver

# UNITED AMERICAN BOSCH CORP.

## MODEL - 31

### NOMENCLATURE

R1—Volume Control—10,000 ohms  
 R2—Coupling Resistor—1000 ohms  
 R3—1st Det. Cathode Resistor 5000 ohms  
 R4—1st. Det. Plate Resistor 1000 ohms  
 R5—2nd Det. Cathode Resistor—50,000 ohms  
 R6—2nd Det. Screen Resistor—2 megohms  
 R7—2nd Det. Plate Resistor—10,000 ohms  
 R8—2nd Det. Plate Resistor—1 megohm  
 R9—Audio Grid Resistor— $\frac{1}{2}$  megohm  
 R10—Audio Grid Resistor—100,000 ohms  
 R11—Divider Resistor—20,000 ohms  
 R12—Screen Supply Resistor—30,000 ohms  
 R13—Cathode Resistor—300 ohms  
 R14—Oscillator Grid Resistor—100,000 ohms  
 R15—Audio Bias Resistor—350 ohms  
 R16—Mid Tap Resistor

C1—Antenna Trimmer  
 C2—Tuning Condenser  
 C3—Tuning Condenser  
 C4—Oscillator Tuning Condenser  
 C5—Alignment Condenser  
 C6—Oscillator Tuning Alignment  
 C7—I. F. Alignment Condenser  
 C8—I. F. Alignment Condenser  
 C9—Alignment Condenser  
 C10—Oscillator Alignment  
 C11—RF Coupling Condenser .05 mfd.  
 C12—1st Det. Plate By-pass .05 mfd.  
 C13—I. F. Cathode By-pass .05 mfd.  
 C14—I. F. Plate By-pass .05 mfd.  
 C15—2nd Det. Cathode By-pass 1. mfd.

C16—2nd Det. Screen By-pass .25 mfd.  
 C17—2nd Det. Plate By-pass 0001 mfd.  
 C18—Audio De-coupling Condenser .02 mfd.  
 C19—Audio Coupling Condenser .006 mfd.  
 C20—Audio Plate Condenser .05 mfd.  
 C21—Tone Selector Condenser .05 mfd.  
 C22—Cathode By-pass Condenser .05 mfd.  
 C23—Oscillator Grid Condenser .0001 mfd.  
 C24—Oscillator Tuning Condenser .0011 mfd.  
 C25—Screen By-pass Condenser 8. mfd.  
 C26—Buffer Condenser .08 mfd.  
 C27—Filter Condenser 3.5 mfd.  
 C28—Field Coil Tuning Condenser .08 mfd.  
 C29—Filter Condenser 3.5 mfd.

S1—Tone Selector Switch  
 S2—Main Switch

T1—Power Transformer  
 T2—Output Transformer

L1—RF Coil  
 L2—RF Coil  
 L3—I.F. Coil (Primary)  
 L4—I.F. Coil (Secondary)  
 L5—I.F. Coil (Primary)  
 L6—I.F. Coil (Secondary)  
 L7—Speaker Field  
 L8—Speaker Voice Coil  
 L9—Oscillator Coupling Coil  
 L10—Oscillator Grid Coil  
 L11—Oscillator Plate Coil

### SOCKET VOLTAGES


Stage	Tube	Plate	Screen	Cathode	Grid	Fil.	Plate MA
1st Det.	551	260	80	10	7	2.2	2
Oscillator	227	75	..	*0	*0	2.2	5
I.F.	551	260	80	3	3	2.2	4
2nd Det.	224	50	*5	3	1	2.2	*.1
Audio	247	250	250	..	*3	2.2	32
Rectifier	280					4.8	22-22

Line voltage—115 volts

Volume control fully "on"

\* These values will vary considerably with the type of test kit employed, due to the high resistance in the circuit.

# UNITED AMERICAN BOSCH CORP. MODEL - 36



Schematic Wiring Diagram of Model 36 Receiver

## UNITED AMERICAN BOSCH CORP.

### MODEL - 36

#### Loud Speaker

The electro-dynamic speaker consists of four principal assemblies, diaphragm with moving coil and centering spring—frame—field magnet and pole—field coil.

The construction of the speaker is so simple that the method of replacing any part is self evident. The pole of the field magnet is centered exactly in the opening of the frame by four small steel dowel pins which accurately relocate these two parts after the speaker has been disassembled. It is essential that the air gap around the pole piece is exactly uniform. The moving coil must also be centered exactly in the air gap. If the diaphragm is replaced this adjustment is best made by placing four strips of thick paper or card in the space between the outside of the moving coil and the frame before tightening the screw holding the bronze diaphragm centering spring against the end of the pole piece.

A rattle in the speaker may be the result of a wire touching against the diaphragm, a loose part in the receiver, or the diaphragm incorrectly centered. In the latter case it must be centralized as described in the preceding paragraph.

#### Alignment Instructions:

The following instructions for the alignment of the condensers in the models 36 and 37 describe the operation as done with any type of special oscillator designed for the adjustment of superheterodyne receivers. Such an oscillator is essential for anyone who handles more than a small amount of service work. Such oscillators are designed to provide ordinary broadcast frequencies, and in addition, a 175 kilocycle for the alignment of the intermediate frequency (I. F.) stages.

There are seven alignment adjustments on the receiver. The location, together with the schematic diagram reference numbers, are given below.

Antenna Alignment (C1)—on rear of condenser gang.

Oscillator Shunt Condenser (C6)—on front stator of condenser gang.

Oscillator Series Condenser (C8)—on side of base, near front.

Preselector Alignment (C5)—on middle stator of condenser gang.

1st IF Alignment (Plate) (C11)—on side of base, lower rear.

1st IF Alignment (Grid) (C12)—on side of base, upper rear.

2nd IF Alignment (C14)—on coil can over speaker.

1—Connect 175 KC output of oscillator to grid terminal of 1st detector (unshielded type 551 tube) and set dial at 55. Align 2nd IF condenser C14.

2—With input and dial setting as above, align 1st IF condensers C11 and C12.

3—With input and dial setting as above, recheck step No. 1.


4—With input on grid of 1st detector set dial at 140 and align oscillator shunt condenser C6. Align on the second peak out from maximum capacity of condenser.

5—Connect input of oscillator to antenna. Align antenna trimmer C1 and preselector condenser alignment C5.

6—Set receiver at 60 and tune in oscillator input. Adjust oscillator series condenser C8 by "max-max" method. (Move condenser gang slowly back and forth and at the same time adjust oscillator series condenser C8 for maximum response).

7—Set dial at 1400 and tune oscillator to set. Align oscillator shunt condenser C6, preselector condenser C5, and antenna trimmer.


# UNITED AMERICAN BOSCH CORP.



Schematic Diagram — Model 40

## DUO DIODE DETECTOR

The type 227 detector utilizes the elements (cathode, grid, and plate) for two very distinct functions, namely detection and automatic volume control. The grid to cathode circuit (L 6 and C 19 is the tuned IF circuit, C 20 imposes the signal on the grid, and R 11 and R 12 provide a voltage drop for the rectified audio voltage.) acts as the detector and the AVC action is furnished by the plate to cathode circuit (R 10 controls the bias of the 1st detector and 1st IF tubes, and R 24 and R 25 furnish the delay action.) This type of control provides high output on weak signals and controls over a wide range of signal strengths.



# UNITED AMERICAN BOSCH CORP.

## NOMENCLATURE — MODEL 40

R 1—Grid Resistor—10,000 ohms	C 9—IF Grid—.05 mfd.
R 2—Grid Resistor—10,000 ohms	C 10—IF Cathode By-pass—.05 mfd.
R 3—Cathode Resistor—750 ohms	C 11—Screen By-pass—.05 mfd.
R 4—IF Plate Resistor—25,000 ohms	C 12—Screen By-pass—.05 mfd.
R 5—IF Grid Resistor—.1 megohm	C 13—IF Cathode By-pass—.05 mfd.
R 6—Cathode Resistor—750 ohms	C 14—IF Coupling—1100 mmf.
R 7—Screen Resistor—1,000 ohms	C 15—IF Plate By-pass—.05 mfd.
R 8—Plate Resistor—1,000 ohms	C 16—2nd Det. Cathode—.05 mfd.
R 9—Divider Resistor—.5 megohm	C 17—1st Det. Alignment
R 10—Divider Resistor—.1 megohm	C 18—1st IF Alignment
R 11—2nd Det. Screen Resistor—10,000 ohms	C 19—2nd Det. Alignment
R 12—2nd Det. Screen Resistor—.5 megohm	C 20—Blocking Condenser—100 mmf.
R 13—Volume Control—.5 megohm	C 21—By-pass Condenser—.05 mfd.
R 14—Audio Grid Resistor—.1 megohm	C 22—2nd Det. Screen By-pass—100 mmf.
R 15—Audio Plate Resistor—25,000 ohms	C 23—Audio Coupling—.05 mfd.
R 16—Audio Grid Resistor—.5 megohm	C 24—Audio Coupling—.05 mfd.
R 17—Audio Grid Resistor—.1 megohm	C 25—Audio Plate By-pass—.01 mfd.
R 18—Tone Control—.5 megohm	C 26—Tone Control Condenser—.05 mfd.
R 19—Audio Plate Resistor—5,000 ohms	C 27—1st Det. Cathode—.05 mfd.
R 20—1st Det. Cathode Resistor—5,000 ohms	C 28—Osc. Grid Condenser—100 mmf.
R 21—Osc. Grid Resistor—.1 megohm	C 29—Oscillator Condenser—1100 mmf.
R 22—Screen Supply Resistor—5,000 ohms	C 30—Oscillator Series Alignment
R 23—Divider Resistor—1,830 ohms	C 31—By-pass Condenser—.05 mfd.
R 24—Divider Resistor—235 ohms	C 32—Filter Condenser—8 mfd.
R 25—Divider Resistor—850 ohms	C 33—Filter Condenser—8 mfd.
R 26—Bias Resistor—300 ohms	C 34—Filter Condenser—4 mfd.
R 27—Bias Resistor—200 ohms	C 35—Buffer Condenser—.05 mfd.
R 28—Mid Tap Resistor	C 36—Field Tuning Condenser—.05 mfd.
C 1—Antenna Trimmer	C 37—1st Audio Plate By-pass—.25 mfd.
C 2—Tuning	L 1—RF Coil
C 3—Tuning	L 2—RF Coil
C 4—Alignment	L 3—Primary
C 5—Tuning	L 4—Secondary
C 6—Alignment	L 5—Primary
C 7—RF Coupling—.05 mfd.	L 6—Secondary
C 8—Plate By-pass—.05 mfd.	L 7—Cathode Winding
	L 8—Grid Winding
	L 9—Plate Winding
	L 10—Speaker Field
	L 11—Voice Coil

Condenser Gang

1st IF coil

2nd IF coil

Osc. coil


## SOCKET VOLTAGES

Stage	Tube	Plate	Screen	Cathode	Grid	Fil.	Plate MA
1st Det.	551	250	75	10	2	2.2	2
Osc.	227	75	....	0	0	2.2	7
1st IF	551	140	85	4	.2	2.2	4
2nd IF	551	260	85	5	.4	2.2	5
2nd Det.	227	—5	....	35	1	2.2	.1
1st Audio	227	110	....	35	1	2.2	4
2nd Audio	247	250	250	....	16	2.2	30
Rect.	280	.....	.....	....	....	5.0	30

NOTE: These are average readings obtained by an ordinary set analyzer.




# UNITED AMERICAN BOSCH CORP.



Schematic Diagram — Model 91

## LOCATION OF PARTS

- R 9, R 11, R 13, R 17, C 11, C 19, C 22, C 23, C 28, C 32 on Chassis Base.
- R 3, R 4, R 5, R 6, R 15, R 16, C 14, C 25, C 27 on Resistor Strip.
- R 7, R 8, R 10, R 12, C 17, C 18, C 20, C 21 on Resistor Strip.
- R 1, R 14, R 19, R 20, R 21, C 24, C 29 on Resistor Strip.
- C 10, C 26, L 7, L 8, L 9 on Oscillator Coil Assembly.
- R 2, C 7, C 8, C 12, C 13, L 3, L 4 on 1st IF Coil Assembly.
- R 22, C 9, C 15, C 16, L 5, L 6 on 2nd IF Coil Assembly.
- C 30, C 31 in Housed Filter Assembly.
- C 1, C 2, C 3, C 4, C 5, C 6 on Main Tuning Condenser Gang.



# UNITED AMERICAN BOSCH CORP.

## NOMENCLATURE — MODEL 91

R 1—500,000 ohms—Grid Resistor	C 1—Variable—Antenna Trimmer
R 2—10,000 ohms—Grid Resistor	C 2—Variable
R 3—1,000 ohms—Plate Resistor	C 3—Variable
R 4—300 ohms—Cathode Divider Resistor	C 4—Variable
R 5—20,000 ohms—Cathode Divider Resistor	C 5—Alignment
R 6—15,000 ohms—Screen Supply Resistor	C 6—Alignment
R 7—20,000 ohms—Screen Resistor	C 7—Variable
R 8—25,000 ohms—Cathode Resistor	C 8—Variable
R 9—50,000 ohms—Screen Resistor	C 9—Variable—2nd IF alignment condenser
R 10—500,000 ohms—Plate Resistor	C 10—Variable—Oscillator Series Condenser
R 11—500,000 ohms—Volume Control	C 11—.05 mfd.—RF coupling condenser
R 12—100,000 ohms—Grid Resistor	C 12—.05 mfd.—Plate by-pass condenser
R 13—500,000 ohms—Tone Control	C 13—.05 mfd.—Grid Condenser
R 14—2 megohms—AVC Resistor	C 14—.05 mfd.—Cathode by-pass condenser
R 15—5,000 ohms—Cathode Resistor	C 15—.05 mfd.—Plate by pass condenser
R 16—100,000 ohms—Grid Resistor	C 16—.0001 mfd.—AVC condenser
R 17—Mid Tap Resistor	C 17—.5 mfd.—Cathode by-pass
R 18—750 ohms—25 cycle only	C 18—.25 mfd.—Screen by-pass
R 19—200 ohms—Bias Resistor	C 19—.00025 mfd.—Plate by-pass
R 20—750 ohms—Bias Resistor	C 20—.006 mfd.—Audio coupling condenser
R 21—350 ohms—Bias Resistor	C 21—.25 mfd.—Grid by-pass
R 22—2 megohms—Bias Resistor	C 22—.01 mfd.—Plate by-pass
L 1—Antenna Coil	C 23—.05 mfd.—Tone Control Condenser
L 2—1st R.F. Coil	C 24—.05 mfd.—Grid condenser
L 3—Primary } 1st IF Coil	C 25—.05 mfd.—Cathode by-pass
L 4—Secondary } 1st IF Coil	C 26—.0011 mfd.—Oscillator series condenser
L 5—Primary } 2nd IF Coil	C 27—.0001 mfd.—Oscillator grid condenser
L 6—Secondary } 2nd IF Coil	C 28—8 mfd.—Screen by-pass
L 7—Cathode Winding } Oscillator Coil	C 29—.01 mfd.—Buffer condenser
L 8—Plate Winding } Oscillator Coil	C 30—16 mfd.—Filter condenser
L 9—Grid Winding } Oscillator Coil	C 31—4 mfd.—Filter condenser
L 10—Primary } Output Transformer T 2	C 32—.01 mfd.—Field shunt condenser
L 11—Secondary } Output Transformer T 2	
L 12—Field Coil } Loud Speaker	
L 13—Voice Coil } Loud Speaker	

## SOCKET VOLTAGES


Stage	Tube	Plate	Screen	Cathode	Grid	Fil.	Plate MA
Osc.	227	100	....	0	5	2.2	4
1st Det.	551	240	85	0	3.5	2.2	.1
IF	551	240	90	3	.5	2.2	2
2nd Det.	224	90	45	5	4	2.2	.1
AVC	224	10	50	60	.5	2.2	.1
Audio	247	240	240	....	16	2.2	30
Rect.	280	.....	.....	....	....	4.8	25

NOTE: These are average readings obtained with an ordinary set analyzer.

# UNITED AMERICAN BOSCH CORP.

## MODEL - 100

Schematic Diagram of Model 100 Motor Car Radio Receiver




### Symbols and Electrical Values

- |   |  |   |
|---|--|---|
| <p>R1 — 10,000 ohms<br/>                 R2 — 3,000 ohms<br/>                 R3 — 5,000 ohms<br/>                 R4 — 10,000 ohms<br/>                 R5 — 1,000 ohms<br/>                 R6 — 1,000 ohms<br/>                 R7 — 3,000 ohms<br/>                 R8 — 1,500 ohms<br/>                 R9 — 5,000 ohms<br/>                 R10 — .5 megohm<br/>                 R11 — 100,000 ohms<br/>                 R12 — .5 megohm<br/>                 R13 — .1 megohm</p> | <p>R14 — 2,000 ohms<br/>                 R15 — 1,500 ohms<br/>                 R16 — 1,000 ohms<br/>                 C1 — Condenser<br/>                 C2 — Gang with Alignment<br/>                 C3 — Condensers<br/>                 C4 — .100 to 200 mmf.<br/>                 C7 — 75 to 140 mmf.<br/>                 C8 — 75 to 140 mmf.<br/>                 C9 — 75 to 140 mmf.<br/>                 C10 — 75 to 140 mmf.</p>   | <p>C11 — .05 mfd.<br/>                 C12 — .05 mfd.<br/>                 C13 — .05 mfd.<br/>                 C14 — .05 mfd.<br/>                 C15 — .05 mfd.<br/>                 C16 — .0025 mfd.<br/>                 C17 — .0001 mfd.<br/>                 C18 — .01 mfd.<br/>                 C19 — .5 mfd.<br/>                 C20 — .0011 mfd.<br/>                 C21 — .004 mfd.<br/>                 C22 — .05 mfd.<br/>                 C23 — .05 mfd.</p> |
| <p>L1 — Antenna Coil<br/>                 L2 — Oscillator Coil<br/>                 L3 — Radio Frequency Coil<br/>                 L4 — Filter</p>  | <p>L5 — Intermediate Coil<br/>                 L6 — Intermediate Coil<br/>                 L7 — Intermediate Coil<br/>                 L8 — Intermediate Coil<br/>                 L9 — Audio Input Transformer<br/>                 L10 — Audio Output Transformer<br/>                 L11 — Audio Output Transformer<br/>                 L12 — Audio Output Transformer<br/>                 L13 — Oscillator Coil<br/>                 L14 — Radio Frequency Coil<br/>                 L15 — Radio Frequency Coil<br/>                 L16 — Filter</p> | <p>C24 — .25 mfd.<br/>                 C25 — 1100 mmf.<br/>                 C26 — .05 mfd.<br/>                 C27 — .25 mfd.<br/>                 C28 — .25 mfd.<br/>                 C29 — .05 mfd.<br/>                 C30 — .25 mfd.<br/>                 C31 — .05 mfd.</p>  |

# UNITED AMERICAN BOSCH CORP.

## VIBRO-POWER CAR RADIO MODEL 150



- 1 - CHASSIS ASSEMBLY - SA-104,564
- 2 - RESISTOR STRIP ASS'Y. - SA-105,068
- 3 - RESISTOR STRIP ASS'Y. - SA-105,070
- 4 - RESISTOR STRIP ASS'Y. - SA-105,078
- 5 - POWER PACK ASS'Y. - SA-104,618
- 6 - VAR. COND. & SHIELD ASS'Y. - SA-105,091

INTERMEDIATE FREQUENCY 175 K.C.


3	R1	100,000 $\Omega$	1/2 WATT	SA-100,727
3	R2	1,000 $\Omega$	"	SA-100,729
1	R3	75,000 $\Omega$	"	SA-104,824
3	R4	1,000 $\Omega$	"	SA-100,726
3	R5	100,000 $\Omega$	"	SA-100,727
4	R6	5,000 $\Omega$	"	SA-100,824
4	R7	0.5 MEG.	"	SA-100,194
2	R8	1,000 $\Omega$	"	SA-100,729
4	R9	0.5 MEG.	"	SA-100,194
6	R11	0.5 MEG. VOL. CONT.	"	SA-104,605
4	R12	1,000 $\Omega$	1/2 WATT	SA-102,961
1	R13	6,000 $\Omega$	1 WATT	SA-105,004
4	R14	5,000 $\Omega$	1/2 WATT	SA-99,583
2	R15	1 MEG.	"	SA-100,115
2	R16	50,000 $\Omega$	"	SA-100,512

2	R17	40,000 $\Omega$	"	SA-103,410
3	R18	75,000 $\Omega$	"	SA-101,163
5	R19	5,000 $\Omega$ - 10 WATT	"	SA-104,704
1	C10	.0001 MFD.	"	SA-R1,143
3	C1	.05 - 2-PLY	"	SA-102,493
3	C2	.05 - 3-PLY	"	SA-102,492
1	C3	.002 - 4-PLY	"	SA-103,852
3	C4	.05 - 3-PLY	"	SA-102,492
3	C5	.05 - 2-PLY	"	SA-102,493
4	C6	.1 - 2-PLY	"	SA-102,495
4	C7	.05 - 2-PLY	"	SA-102,493
2	C8	.05 - 3-PLY	"	SA-102,492
2	C9	.0001 MFD.	"	SA-101,143
2	C10	.01 - 3-PLY	"	SA-102,500
2	C11	.0001 MFD.	"	SA-101,143

1	C12	.5 - 2-PLY	"	SA-102,499
1	C13	.5 - 2-PLY	"	SA-102,499
4	C14	.25 - 2-PLY	"	SA-102,497
1	C15	.002 - 4-PLY	"	SA-103,852
4	C16	.05 - 2-PLY	"	SA-102,493
1	C17	.002 - 4-PLY	"	SA-103,852
5	C18	.002 - 4-PLY	"	SA-103,852
5	C19	.01 MF - 1600 V	"	SA-104,837
5	C20	8 MFD	"	SA-104,614
5	C21	8 MFD	"	SA-104,614
5	C22	.002 - 4-PLY	"	SA-103,852
5	C23	.5 -	"	SA-104,601
5	C24	.01 -	"	SA-104,601
5	C25	.5 - 2-PLY	"	SA-102,499
1	C26	.002 - 4-PLY	"	SA-103,852

# UNITED AMERICAN BOSCH CORP.

SERVICE INSTRUCTIONS - MODELS 200-201



Schematic Diagram of Model 200 Receiver

### ELECTRICAL VALUES

R1 - 10,000 ohms	R11 - 10,000 ohms	C9 - .006 mfd.	C19 - 8. mfd.
R2 - 200 ohms	R12 - 400 ohms	C10 - .0001 mfd.	C20 - .01 mfd.
R3 - 50,000 ohms	C1 - Trimmer	C11 - .05 mfd.	C21 - 4 mfd.
R4 - 2 megohms	C2 - Tuning	C12 - .05 mfd.	L1 - Ant. Coil
R5 - 1 megohm	C3 - Tuning	C13 - .25 mfd.	L2 - Primary
R6 - 500,000 ohms	C4 - Tuning	C14 - .01 mfd.	L3 - Secondary
R7 - 100,000 ohms	C5 - Alignment	C15 - 1. mfd.	L4 - Primary
R8 - Center Tap	C6 - Alignment	C16 - .25 mfd.	L5 - Secondary
R9 - 20,000 ohms	C7 - Coupling	C17 - .05 mfd.	L6 - Voice Coil
R10 - 15,000 ohms	C8 - Coupling	C18 - .01 mfd.	L7 - Field Coil

Note: Electrolytic filter condensers C19 and C21 are a single assembly. Condensers C11 to C18 inclusive are also a single assembly contained in the square can underneath the base plate.

# UNITED AMERICAN BOSCH CORP.

STAGE	TUBE	FIL.	PLATE	SCREEN	CATHODE	GRID	PLATE MA
1st RF	551	2.3	250	90	2.5	3.0	4.5
2nd RF	551	2.3	250	90	2.5	3.0	4.5
Det.	224	2.3	*150	*20	3.0	1.5	.5
Audio	247	2.3	250	250	-	*16	32
Rect.	280	4.8					20
				Plate current of each plate			20

The readings were made with the volume control in the full "on" position.

\*These voltages are the correct values altho the average test kit will probably give much lower readings (as low as 1/10 of these values) due to the high resistance included in the detector plate and screen circuits, and the audio grid circuit.

## RESISTOR COLOR CODE

200 ohms ----- Red -----Black -- Brown	50,000 ohms ---- Green ---Black -- Orange
400 ohms ----- Yellow --Black -- Brown	100,000 ohms --- Brown ---Black -- Yellow
10,000 ohms ---- Brown ---Black -- Orange	500,000 ohms --- Green ---Black -- Yellow
15,000 ohms ---- Brown ---Green -- Orange	1 megohm ----- Brown -- Black -- Green
20,000 ohms ---- Red -----Black -- Orange	2 megohms ----- Red ----- Black -- Green

## TEMPORARY CONDENSED SERVICE PARTS LIST

### FOR THE MODEL 200 RECEIVER

#### MAIN ASSEMBLIES

- 103491 Chassis (with tubes)
- 102280 Speaker
- 103876 Cabinet (Model "A")
- 103877 Cabinet (Model "B")

#### COILS

- 101858 Field Coil (speaker)
- 103494 R. F. Coil
- 103497 R. F. primary coil
- 103495 Antenna coil

#### CONDENSERS

- 102178 By-pass condenser
- 102022 Antenna trimmer
- 101143 Fixed (.0001 mfd.)
- 100705 Fixed (.006 mfd.)
- 101881 Large filter
- 103695 Condenser (.01 mfd.)

#### KNOBS

- 102445 Volume and tuning
- 103751 Knob for switch
- 100929 Trimmer knob

#### MISCELLANEOUS PARTS

- 101895 Dial and scale
- 102282 Diaphragm (speaker)
- 98713 Lamp for dial

#### RESISTORS

- 103706 Volume control
- 102314 Resistor (200 ohms)
- 102177 Resistor (400 ohms)
- 100825 Resistor (10,000 ohms)
- 101404 Resistor (15,000 ohms)
- 100813 Resistor (20,000 ohms)
- 100512 Resistor (50,000 ohms)
- 100727 Resistor (100,000 ohms)
- 100194 Resistor (1/2 megohm)

#### RESISTORS

- 100815 Resistor (1 megohm)
- 100196 Resistor (2 megohm)
- 99412 Resistor (mid tap)

#### SOCKETS


- 101890 Socket for dial light
- 103686 Tube socket (4 prong)
- 103514 Tube socket (5 prong)

#### SWITCHES

- 103703 Switch with nuts
- 103725 Switch (police)


#### TRANSFORMERS

- 102551 Out-put transformer
- 101939 Power transformer



# UNITED AMERICAN BOSCH CORP.

## SERVICE INSTRUCTIONS - MODELS 205 and 206



Schematic Diagram of Model 205 Receiver

### ELECTRICAL VALUES

R1 - 10,000 ohms	R11 - 10,000 ohms	C9 - .006 mfd.	C19 - 8. mfd.
R2 - 200 ohms	R12 - 400 ohms	C10 - .0001 mfd.	C20 - .01 mfd.
R3 - 50,000 ohms	C1 - Trimmer	C11 - .05 mfd.	C21 - 4 mfd.
R4 - 2 megohms	C2 - Tuning	C12 - .05 mfd.	L1 - Ant. Coil
R5 - 1 megohm	C3 - Tuning	C13 - .25 mfd.	L2 - Primary
R6 - 500,000 ohms	C4 - Tuning	C14 - .01 mfd.	L3 - Secondary
R7 - 100,000 ohms	C5 - Alignment	C15 - 1. mfd.	L4 - Primary
R8 - Center Tap	C6 - Alignment	C16 - .25 mfd.	L5 - Secondary
R9 - 20,000 ohms	C7 - Coupling	C17 - .05 mfd.	L6 - Voice Coil
R10 - 15,000 ohms	C8 - Coupling	C18 - .01 mfd.	L7 - Field Coil

Note: Electrolytic filter condensers C19 and C21 are a single assembly. Condensers C11 to C18 inclusive are also a single assembly contained in the square can underneath the base plate.


# UNITED AMERICAN BOSCH CORP.

## SOCKET VOLTAGES

STAGE	TUBE	FIL.	PLATE	SCREEN	CATHODE	GRID	PLATE MA.
1st RF	551	2.3	250	90	2.5	3.0	4.5
2nd RF	551	2.3	250	90	2.5	3.0	4.5
Det.	224	2.3	*150	*20	3.0	1.5	.5
Audio	247	2.3	250	250	--	*16	*32
Rect.	280	4.8	Plate current of each plate				20

The readings were made with the volume control in the full "on" position.

\*These voltages are the correct values. The average test kit will give much lower readings, (as low as 1/10 of these values) due to the low resistance of the meters compared to the high resistance included in the detector plate and screen circuits and the audio grid circuit.



### IMPORTANT

**Antenna Adjustment:** The small knob located on the loud speaker must be adjusted at the time of installation to obtain the best reception. Make this adjustment on a weak station which is received at some point near 30 on the dial and then re-check the adjustment at several other points to make sure that it has been accurately done.

**Chassis:** The chassis may be removed by pulling off the knobs and unscrewing the felt feet.

### RESISTOR COLOR CODE

200 ohms ----- Red ---- Black -- Brown	50,000 ohms ---- Green -- Black -- Orange
400 ohms ----- Yellow - Black -- Brown	100,000 ohms ---- Brown -- Black -- Yellow
10,000 ohms ---- Brown -- Black -- Orange	500,000 ohms ---- Green -- Black -- Yellow
15,000 ohms ---- Brown -- Green -- Orange	1 megohm ----- Brown -- Black -- Green
20,000 ohms ---- Red ---- Black -- Orange	2 megohms ----- Red ---- Black -- Green


### TEMPORARY CONDENSED SERVICE PARTS LIST FOR TYPE R.S. 205 RADIO RECEIVER

<b>MAIN ASSEMBLIES</b>	<b>KNOBS</b>	100727 Resistor (100,000 ohms)
103655 Chassis (with tubes)	102445 Volume and tuning knobs	100194 Resistor (1/2 megohm)
102280 Speaker	100929 Trimmer cond. knob	100815 Resistor (1 megohm)
103878 Cabinet with plates	<b>MISCELLANEOUS PARTS</b>	100196 Resistor (2 megohms)
<b>COILS</b>	101895 Dial with scale	99412 Mid tap resistance
101858 Field coil (speaker)	102282 Diaphragm for speaker	<b>SOCKETS</b>
102438 R. F. coil complete	98713 Lamp for dial	101890 Dial light socket
102243 R. F. primary coil	<b>RESISTORS</b>	102447 Tube socket for '24 tube
102439 Antenna coil	102342 Volume control & switch	102449 Tube socket for '80 tube
<b>CONDENSERS</b>	102437 Volume control only	102446 Tube socket for '47 tube
102178 By-pass assembly	102314 Resistor (200 ohms)	102448 Tube socket for '51 tube
102022 Antenna trimmer	102177 Resistor (400 ohms)	<b>SWITCH</b>
101143 Fixed (.0001 mfd.)	100825 Resistor (10,000 ohms)	101930 Switch with (2) nuts
101881 Large filter cond.	101404 Resistor (15,000 ohms)	<b>TRANSFORMER</b>
103695 Cond. (.01 mfd-4ply)	100813 Resistor (20,000 ohms)	102551 Output transformer
100705 Cond. (.006 mfd.)	100512 Resistor (50,000 ohms)	101939 Power transformer



# UNITED AMERICAN BOSCH CORP.

## SERVICE INSTRUCTIONS - MODELS 236 AND 237



Schematic Diagram of Model 236 Receiver


### ELECTRICAL VALUES

- |                  |                 |                   |
|------------------|-----------------|-------------------|
| R1 - 10000 ohms  | C1 - Trimmer    | C17 - .25 mfd.    |
| R2 - 1000 ohms   | C2 - Tuning     | C18 - .0001 mfd.  |
| R3 - 5000 ohms   | C3 - Tuning     | C19 - .05 mfd.    |
| R4 - 1000 ohms   | C4 - Tuning     | C20 - .01 mfd.    |
| R5 - 25000 ohms  | C5 - Alignment  | C21 - .006 mfd.   |
| R6 - Mid Tap     | C6 - Alignment  | C23 - 8. mfd.     |
| R7 - .5 megohm   | C7 - Alignment  | C24 - .05 mfd.    |
| R8 - .1 megohm   | C8 - Alignment  | C25 - 4. mfd.     |
| R9 - .5 megohm   | C9 - .05 mfd.   | C26 - .01 mfd.    |
| R10 - .5 megohm  | C10 - .05 mfd.  | C27 - 8. mfd.     |
| R11 - .1 megohm  | C11 - Alignment | C28 - .02 mfd.    |
| R12 - 20000 ohms | C12 - Alignment | C29 - .0001 mfd.  |
| R13 - 30000 ohms | C13 - .05 mfd.  | C30 - .01 mfd.    |
| R14 - 350 ohms   | C14 - Alignment |                   |
| R15 - 300 ohms   | C15 - .05 mfd.  | T1 - Power Trans. |
| R16 - .1 megohm  | C16 - .5 mfd.   | T2 - Audio Trans. |

# UNITED AMERICAN BOSCH CORP.

STAGE	TUBE	PLATE	SCREEN	CATHODE	GRID	FIL.	PLATE MA
1st Det.	551	250	80	35	8	2.2	2
Osc.	227	75	--	* .1	* .1	2.2	8
I.F.	551	250	80	3	3	2.2	4
2nd Det.	224	60	*5	2	2	2.2	*.1
Audio	247	250	250	-	*3	2.2	32
Rect.	280					4.8	29

\* These values will vary considerably with the type of test kit employed, due to the high resistance in the circuit.



### RESISTORS

300 ohms	-	Orange, Black, Brown
350 ohms	-	Orange, Green, Brown
1,000 ohms	-	Brown, Black Red
5,000 ohms	-	Green, Black, Red
20,000 ohms	-	Red, Black, Orange
25,000 ohms	-	Red, Green, Orange
30,000 ohms	-	Orange, Black, Orange
.1 megohm	=	Brown, Black Yellow
.5 megohms	-	Green, Black, Yellow

### TEMPORARY CONDENSED PARTS LIST

FOR MODEL 236 RECEIVER

#### MISCELLANEOUS PARTS

103110 Dial assembly with scale  
 103238 Diaphragm (speaker)  
 98713 Lamp for dial

#### RESISTORS

102552 Volume control and switch  
 102684 Volume control only  
 101181 Resistor (300 ohms)  
 102564 Resistor (350 ohms)  
 100729 Resistor (1,000 ohms)  
 100824 Resistor (5,000 ohms)  
 100813 Resistor (20,000 ohms)  
 100197 Resistor (25,000 ohms)  
 103293 Resistor (30,000 ohms)  
 100727 Resistor (100,000 ohms)  
 100194 Resistor (1/2 megohm)  
 99412 Mid tap resistance

#### SOCKETS

101890 Dial Light socket  
 101641 Tube socket for '27 tube  
 102162 Tube socket for '47 tube  
 101643 Tube socket for '80 tube  
 102161 Tube socket for '51 tube  
 103513 Tube socket for '57 tube

#### TRANSFORMERS

103171 Power transformer  
 102551 Output transformer

#### MAIN ASSEMBLIES

103792 Chassis with tubes  
 103173 Speaker  
 103211 Cabinet (Model A)

#### COILS

101858 Field Coil (speaker)  
 103119 1st intermediate coil  
 103106 2nd intermediate coil  
 103118 Oscillator coil  
 103121 R. F. coil

#### CONDENSERS

102768 Housed filter condenser  
 101143 Fixed (.0001 mfd.)  
 100705 Cond. (.006 mfd.)  
 102500 Cond. (.01 mfd. - 3 ply)  
 103695 Cond. (.01 mfd. - 4 ply)  
 102504 Cond. (.02 mfd.)  
 102493 Cond. (.05 mfd. - 2 ply)  
 102492 Cond. (.05 mfd. - 3 ply)  
 102497 Cond. (.25 mfd. - 2 ply)  
 102499 Cond. (.5 mfd. - 2 ply)  
 103037 Cond. (8 mfd.)


102253 Double alignment  
 103148 Antenna trimming  
 103310 Condenser and resistor

#### KNOBS

102445 Knob for both shafts

# UNITED AMERICAN BOSCH CORP.

SERVICE INSTRUCTIONS - MODELS 242 and 243




SCHEMATIC DIAGRAM OF MODEL 242 RECEIVER

- C1 - Antenna Trimmer
- C2 - Tuning
- C3 - Tuning
- C4 - Osc. Tuning
- C5 - Alignment
- C6 - IF Alignment
- C7 - IF Alignment
- C8 - Osc. End Cond.
- C10 - .05 mfd. 2 ply
- C11 - .05 mfd. 2 ply
- C12 - .05 mfd. 2 ply
- C13 - .05 mfd. 2 ply
- C14 - 1100 mmf.
- C15 - .05 mfd. 2 ply
- C16 - .05 mfd. 3 ply
- C17 - IF Alignment
- C18 - .05 mfd. 2 ply
- C19 - .0001 mfd.
- C20 - .05 mfd. 2 ply
- C21 - .0001 mfd.
- C22 - .0001 mfd.
- C23 - .05 mfd. 2 ply
- C24 - 25 mfd.
- C25 - .01 mfd. 3 ply
- C26 - 1100 mmf.
- C27 - .002 mfd. 4 ply
- C28 - .05 mfd. 3 ply
- C29 - .05 mfd. 2 ply
- C30 - .05 mfd. 2 ply
- C31 - .05 mfd. 2 ply
- C32 - .0001 mfd.
- C33 - .05 mfd. 2 ply
- C34 - .01 mfd. 4 ply
- C35 - 4 mfd. (60)
- C36 - 8 mfd. (25)
- C37 - 8 mfd.
- R1 - 10,000 ohms
- R2 - 1000 ohms
- R3 - 10,000 ohms
- R4 - 600 ohms
- R5 - 25,000 ohms
- R6 - 100,000 ohms
- R7 - 600 ohms
- R8 - 15,000 ohms
- R9 - 15,000 ohms
- R10 - 500,000 ohms
- R11 - 500,000 ohms
- R12 - 100,000 ohms
- R13 - 5000 ohms
- R14 - 75,000 ohms
- R15 - 500,000 ohms
- R16 - 100,000 ohms
- R17 - 500,000 ohms
- R18 - 1000 ohms
- R19 - 500,000 ohms
- R20 - 1 megohm
- R21 - 1500 ohms
- R22 - 2500
- R23 - 150
- R24 - 1400
- R25 - 250
- R26 - 100,000 ohms
- R27 - 5000 ohms

# UNITED AMERICAN BOSCH CORP.

Stage	Tube	Fil.	Plate	Screen	Cathode
1st Det.	58	2.4	200	90	7 - 10
1st IF	58	2.4	115	95	4
2nd IF	58	2.4	115	95	3.4
2nd Det.	56	2.4	0	-	38
Osc.	56	2.4	95	-	2 - 4
Output	247	2.4	260	265	20
Rect.	280	4.8	-	-	-

Note: These values are readings of a high resistance voltmeter to ground, with the exception of filament voltages. Cathode voltages are given instead of grid voltages, inasmuch as the grid is at ground potential.



## TEMPORARY CONDENSED SERVICE PARTS LIST FOR MODEL 242 and 243 RADIO RECEIVERS

### MAIN ASSEMBLIES

103573 Chassis with tubes (RS 242)  
 104089 Chassis with tubes (RS 243)  
 103838 Speakers (2) on baffle  
 103839 Speaker with transformer  
 103840 Speaker (has no transformer)  
 103881 Cabinet (Model E).

102500 .01 mfd. - 3 ply  
 103695 .01 mfd. - 4 ply  
 102493 .05 mfd. - 2 ply  
 102492 .05 mfd. - 3 ply  
 103668 25 mfd.  
 102463 Alignment cond. on 103593  
 102253 Alignment cond. on 103527  
 103521 Alignment cond. on 103568  
 104060 Antenna trimming cond.

102095 " (1500 ohms)  
 100824 " (5000 ohms)  
 100825 " (10000 ohms)  
 102875 " (15000 ohms)  
 100197 " (25000 ohms)  
 101163 " (75000 ohms)  
 100727 " (100000 ohms)  
 100194 Resistor (1/2 megohm)  
 100815 " (1 megohm)  
 103609 " (tapped)  
 99412 Mid tapped resistor

### COILS

103527 1st intermediate coil  
 103593 2nd intermediate coil  
 103568 Oscillator coil  
 103121 R.F. coil  
 103554 Filter choke  
 101858 Field coil (speaker 103839)  
 103818 Field coil (speaker 103840)

### KNOBS

102445 Knobs for all controls  
 102272 Antenna knob and screw

### MISC. PARTS

103198 Dial scale with bracket  
 102282 Diaphragm (speaker)  
 98713 Lamp for dial

### SOCKETS

103686 Socket (4 prong)  
 103514 Socket (5 prong)  
 103513 Socket (6 prong)  
 103196 Speaker socket

### CONDENSERS

103595 Housed filter (Model 242)  
 103950 Housed filter (Model 243)  
 101143 .0001 mfd. straight term.  
 101301 .0001 mfd. offset terminals  
 102349 .0011 mfd.  
 103852 .002 mfd. - 4 ply

### RESISTORS


103017 Volume control with switch  
 102959 Tone control  
 103616 Resistor (250 ohms)  
 101211 Resistor (600 ohms)  
 100729 " (1000 ohms)

### TRANSFORMERS

103565 Power transformer (242)  
 104174 Power transformer (243)  
 103849 Output transformer

# UNITED AMERICAN BOSCH CORP.

## SERVICE INSTRUCTIONS - MODELS 250 and 251



SCHMATIC DIAGRAM OF MODEL 250 RECEIVER


- |                    |                 |                |               |
|--------------------|-----------------|----------------|---------------|
| R1 - 100,000 ohms  | C1 - Trimmer    | C23 - .05 mfd. | L2 - RF coil  |
| R2 - 100,000 ohms  | C2 - Tuning     | C24 - 100 mmf. | L3 - RF coil  |
| R3 - 100,000 ohms  | C3 - Tuning     | C25 - .05 mmf. | L4 - RF coil  |
| R4 - 500 ohms      | C4 - Tuning     | C26 - .5 mfd.  | L5 - IF coil  |
| R5 - 500,000 ohms  | C5 - Tuning     | C27 - .05 mfd. | L6 - IF coil  |
| R6 - 100,000 ohms  | C6 - Alignment  | C28 - .06 mfd. | L7 - IF coil  |
| R7 - 100,000 ohms  | C7 - Alignment  | C29 - .05 mfd. | L8 - IF coil  |
| R8 - 500,000 ohms  | C8 - Alignment  | C30 - .05 mfd. | L9 - IF coil  |
| R9 - 1500 ohms     | C9 - IF         | C31 - .05 mfd. | L10 - IF coil |
| R10 - 25,000 ohms  | C10 - IF        | C32 - .05 mfd. | L11 - Choke   |
| R11 - 100,000 ohms | C11 - IF        | C33 - .05 mfd. | L12 - Oso.    |
| R12 - Center Tap   | C12 - IF        | C34 - 100 mmf. | L13 - Oso.    |
| R13 - 30,000 ohms  | C13 - 2nd Det.  | C35 - .05 mfd. | L14 - Choke   |
| R14 - 1000 ohms    | C14 - Alignment | C36 - 4        | L15 - Field   |
| R15 - 1000 ohms    | C15 - .05 mfd.  | C37 - 8        | L16 - Field   |
| R16 - 3700         | C16 - .05 mfd.  | C38 - 8        | L17 - Voice   |
| R17 - 2270 } ohms  | C17 - .05 mfd.  | C39 - 4        | L18 - Voice   |
| R18 - 230          | C18 - .05 mfd.  | C40 - 8        |               |
| R19 - 1280         | C19 - .05 mfd.  | C41 - 8        |               |
| R20 - 10,000 ohms  | C20 - .05 mfd.  | C42 - .01 mfd. |               |
| R21 - 100,000 ohms | C21 - 100 mmf.  |                |               |
| R22 - 5000 ohms    | C22 - .05 mfd.  | L1 - RF coil   |               |
|                    |                 |                | T1 - Power    |
|                    |                 |                | T2 - Input    |
|                    |                 |                | T3 - Output   |

# UNITED AMERICAN BOSCH CORP.

## SOCKET VOLTAGES

Stage	Tube	Fil.	Plate	Screen	Cathode	Grid
RF	58	2.4	200	100	4.5	0
1st Det.	58	2.4	200	100	8.5	0
Osc.	56	2.4	85	-	0	7.8
1st IF	58	2.4	200	100	4.5	0
2nd IF	58	2.4	200	100	4.5	0
2nd Det.	56	2.4	0	-	47	0
1st AF	56	2.4	175	1	47	0
2nd AF	245	2.4	350	-	-	55
2nd AF	245	2.4	350	-	-	55
Rect.	280	4.8				

Note: These values are readings of a high resistance voltmeter to ground with the exception of the filament voltages. Cathode voltages are given for those tubes having the grid at ground.



## TEMPORARY CONDENSED SERVICE PARTS LIST FOR MODEL 250 and 251 RECEIVERS

### MAIN ASSEMBLIES

103562 Chassis with tubes (250)  
 104064 Chassis with tubes (251)  
 103796 Two speakers on baffle  
 103731 Speaker only (small)  
 103669 Speaker only (large)  
 103882 Cabinet with plates (Model M)

### COILS

103712 Field coil (small speaker)  
 103675 Field coil (large speaker)  
 103586 1st & 3rd I. F. transformer  
 103587 2nd I. F. transformer  
 103519 Oscillator coil  
 103525 R. F. transformer (single)  
 103526 R. F. transformer (double)  
 103588 Coil for 1st I. F. trans.  
 102463 Coil for 2nd I. F. trans.  
 103584 Choke coil (small)  
 103554 Choke coil (filter)

### CONDENSERS

103950 Housed filter (250-251) 6 wire  
 103740 Housed filter (251) 5 wire  
 101301 Cond. .0001 mfd.

101143 Cond. .0001 mfd.  
 103695 Cond. .01 mfd. - 4 ply.  
 102493 Cond. .05 mfd. - 2 ply.  
 102492 Cond. .05 mfd. - 3 ply.  
 102498 Cond. .5 mfd. - 3 ply.  
 104060 Antenna trimmer cond.

### FUSE

101723 Fuse (2 amp.)

### KNOB

103625 Dial knob  
 101445 Mute switch knob  
 102272 Antenna trimmer knob

### METER

103296 Tuning meter

### MISC. PARTS

103560 Dial scale only  
 102282 Diaphragm (small)  
 102283 Diaphragm (large)  
 98713 Lamp for dial

### RESISTORS

103539 Volume control (Round)  
 103858 Volume control (Square)  
 103548 Tone control

99583 500 ohms  
 100729 1000 ohms  
 102095 1500 ohms  
 100824 5000 ohms  
 100825 10000 ohms  
 100197 25000 ohms  
 101722 30000 ohms  
 100727 100000 ohms  
 100194 500000 ohms  
 100815 1 megohm

99412 Mid tap resistor  
 103614 Tapped resistor

### SOCKETS

103686 Socket (4 prong)  
 103514 Socket (5 prong)  
 103513 Socket (6 prong)

### SWITCH


103901 Mute switch

### TRANSFORMERS

103236 Power for RS 250  
 104144 Power with laminations for RS 251  
 103232 Output transformer  
 103578 Input transformer

# UNITED AMERICAN BOSCH CORP.

## SERVICE INSTRUCTIONS - MODELS 260 and 261




SCHMATIC WIRING DIAGRAM OF THE MODEL 260 RECEIVER

- |                     |                     |                  |                  |                   |
|---------------------|---------------------|------------------|------------------|-------------------|
| R 1 - 500,000 ohms  | R 20 - 100,000 ohms | C 6 - alignment  | C 25 - 100 mmf.  | C 40 - alignment  |
| R 2 - 5,000 ohms    | R 21 - 10,000 ohms  | C 7 - alignment  | C 26 - .25 mfd.  | C 41 - alignment  |
| R 3 - 1,000 ohms    | R 22 - 50,000 ohms  | C 8 - alignment  | C 27 - .05 mfd.  | C 42 - alignment  |
| R 4 - 100,000 ohms  | R 23 - 150 ohms     | C 9 - alignment  | C 28 - .025 mfd. | C 43 - alignment  |
| R 5 - 1,500 ohms    | R 24 - 10,000 ohms  | C 10 - alignment | C 29 - 4. mfd.   | C 44 - alignment  |
| R 6 - 1,000 ohms    | R 25 - 10,000 ohms  | C 11 - alignment | C 30 - .001 mfd. | C 45 - alignment  |
| R 7 - 100,000 ohms  | R 26 - 3700)        | C 12 - alignment | C 31 - .5 mfd.   | C 46 - alignment  |
| R 8 - 1,500 ohms    | R 27 - 2270) ohms   | C 13 - .005 mfd. | C 32 - .05 mfd.  | C 47 - .01 mfd.   |
| R 9 - 1,000 ohms    | R 28 - 230 )        | C 14 - .005 mfd. | C 33 - .05 mfd.  | C 48 - 8 mfd.     |
| R 10 - 350 ohms     | R 29 - 1280)        | C 15 - .05 mfd.  | C 34 - .05 mfd.  | C 49 - 8 mfd.     |
| R 11 - 1,000 ohms   | R 30 - 10,000 ohms  | C 16 - .005 mfd. | C 35 - .05 mfd.  | C 50 - 4 mfd.     |
| R 12 - 500,000 ohms | R 31 - Mid tap      | C 17 - .005 mfd. | C 36 - .25 mfd.  | C 51 - 1,000 mmf. |
| R 13 - 1 meg ohm    | R 32 - Mid tap      | C 18 - .05 mfd.  | C 37 - .05 mfd.  | C 52 - 8 mfd.     |
| R 14 - 100,000 ohms | C 1 - Tuning        | C 19 - .005 mfd. | C 38 - 100 mmf.  | C 53 - 4 mfd.     |
| R 15 - 10,000 ohms  | C 2 - Tuning        | C 20 - .05 mfd.  | C 39 - alignment |                   |
| R 16 - 500,000 ohms | C 3 - Tuning        | C 21 - .005 mfd. |                  |                   |
| R 17 - 100,000 ohms | C 4 - Tuning        | C 22 - .05 mfd.  |                  |                   |
| R 18 - 1,500 ohms   | C 5 - 100 mmf.      | C 23 - 100 mmf.  |                  |                   |
| R 19 - 25,000 ohms  | C 5 - .05 mfd.      | C 24 - .05 mfd.  |                  |                   |
- (R26, R27, R28, R29 - tapped unit  
 (C13, C14, C16, C17, C19, C21 - single unit  
 (C29, C48, C49, C50 - single unit

# UNITED AMERICAN BOSCH CORP.

Stage	Tube	Fil.	Plate	Screen	Cathode	Grid
1st Det.	58	2.4	215	90	7.5	0
1st IF	58	2.4	215	90	5.0	0
2nd IF	58	2.4	215	105	48	0
3rd IF	58	2.4	215	105	32	0
Oso.	56	2.4	70	-	0	0
2nd Det.	56	2.4	0	-	45	-
1st AF	56	2.4	180	-	50	12
Output	245	2.4	350	-	60	0
Output	245	2.4	350	-	60	0
Rect.	280	4.8	-	-	-	-

Note: These values are readings of a high resistance voltmeter from each socket terminal to ground, with the exception of the filament voltages. Cathode readings are given for those tubes having the grid at ground. The values are only approximate and will vary with the line voltage and the type of meter employed.



### TEMPORARY CONDENSED PARTS LIST FOR MODEL 260 AND 261 RECEIVERS

#### MAIN ASSEMBLIES

103564	Chassis with tubes (260)
104119	Chassis with tubes (261)
103796	Speakers on baffle (260B)
103904	Speakers on baffle (260C)
103669	Speaker only - large
103731	Speaker only - small
103883	Cabinet (Model C)
103884	Cabinet (Model B)

#### COILS

103675	Field coil - large
103712	Field coil - small
103658	1st and 2nd. I. F. trans
103897	3rd I. F. transformer assy.
103778	4th I. F. transformer assy.
103661	Coil for 1st and 3rd I. F.
103776	Coil for 2nd I. F. trans
103727	Pre-selector coil #1
103728	Pre-selector coil #2
103729	Pre-selector coil #3
103730	Pre-selector coil #4
103822	Oscillator coil #1
103821	Oscillator coil #2
103822	Oscillator coil #3
103797	Oscillator coil #4
103554	Choke filter
103584	Choke coil - small

#### CONDENSERS

103950	Housed filter (260)(261)
103740	Housed filter - (261)

101301	.0001 mfd.
103775	.001 mfd.
103659	.005 mfd. - 3 ply
104080	.006 mfd.
103695	.01 mfd. - 4 ply
102493	.05 mfd. - 2 ply
102492	.05 mfd. - 3 ply
102497	.25 mfd. - 2 ply
102499	.15 mfd. - 2 ply
104060	Antenna trimmer
103148	Alignment (square) 7 to 70
103801	Alignment (square) 600 to 1600
103800	Alignment (square) 1000 to 2000
103798	Alignment (on oscillator coil)
102253	Alignment (on I. F. coils 103897) & 103658)

#### FUSE

101723	Fuse (2 amp)
--------	--------------

#### KNOBS

100798	Dial knob
101445	Mute switch knob
102272	Antenna trimmer knob

#### MISC. PARTS

103813	Dial scale
102282	Diaphragm (small)
102283	Diaphragm (large)
98713	Lamp for dial

#### METER

103296	Tuning meter
--------	--------------

#### RESISTORS

103539	Volume control
103548	Tone Control
103810	(150 ohms)
102564	(350 ohms)
100729	(1000 ohms)
102095	(1500 ohms)
100824	(5000 ohms)
100825	(10000 ohms)
100197	(25000 ohms)
103811	(50000 ohms)
100727	(100000 ohms)
103812	$\frac{1}{2}$ megohm (7/8" long)
100194	$\frac{1}{2}$ megohm (1" long)
100815	1 megohm
99412	Mid tap resistor
103614	Tapped resistor

#### SOCKETS

103686	Socket (4 prong)
103514	Socket (5 prong)
103513	Socket (6 prong)

#### SWITCH

103901	Mute switch
103570	Wave change switch

#### TRANSFORMERS


104049	Power for 260
104156	Power for 261
103232	Output transformer
103945	Input transformer



# UNITED AMERICAN BOSCH CORP.

## AMERICAN BOSCH RADIO (SUPER-FIVE)

### Service Instructions --- Model 305-A



SCHEMATIC WIRING DIAGRAM - MODEL 305A

#### Electrical Values

C-1 )	Vari.oond.	C-11	.5 - 2 ply	R3 -	25,000 ohms
C-2 )		C-12	.0004 mica	R4 -	30,000 ohms
C-3	.002 mica	C-13	.005 - 3 ply	R5 -	7,500 ohms
C-4	70 to 140 mmf.	C-14	.05 - 2 ply	R6 -	2,000 ohms
C-5	.05 - 2 ply	C-15	.005 - 3 ply	R7 -	25,000 ohms
C-6	.25- 2 ply	C-16	8 mfd.	R8 -	500,000 ohms
C-7	.01 - 3 ply	C-17	4 mfd.	R9 -	500,000 ohms
C-8	70 to 140 mmf.	C-18	.01 4 ply	R10 -	100,000 ohms
C-9	7 - 80 mmf.	R1 -	volume control	R11 -	5 ohms (mid tap)
C-10	7-80 mmf.	R2 -	300 ohms	R12 -	400 ohms

#### RESISTOR COLOR CODE

300 ohms	orange	-	black	-	brown
400 ohms	yellow	-	black	-	brown
2000 ohms	red	-	black	-	red
7500 ohms	violet	-	green	-	red
25,000ohms	red	-	green	-	orange
30,000 ohms	orange	-	black	-	orange
100,000 ohms	brown	-	black	-	yellow
500,000 ohms	green	-	black	-	yellow

## UNITED AMERICAN BOSCH CORP.

Stage	Tube	Fil.	Plate	Screen	Cathode	Grid
Detc. & Osc.	57	2.47	245	95	7	0
2nd Det.	57	2.48	48	95	5	0
I. F.	58	2.47	248	95	3.3	0
Output	47	2.5	235	248	0	17
Rect.	80	5	360	-	-	-

Note: These values are readings of a high resistance voltmeter from each socket terminal to ground. The filament voltages are, of course, an exception. Cathode readings are given for those tubes having the grid at ground. The values are only approximate and will vary with the line voltage and the type of meter employed.

### ALIGNING INSTRUCTIONS --- MODEL 305-A

#### I. F. ADJUSTMENT: 456 K. C.

1. Connect volume indicator to speaker.
2. Set volume control on max.
3. Connect generator to grid of 1st I. F. tube, and adjust both condensers on coil nearest the back of set to max. output.
4. Sensitivity should be 3200 m. v.
5. Connect signal generator to grid of 1st det.; adjust both condensers on forward coil to max. output.  
Sensitivity should be 30 m. v. with gang closed.
6. Check I. F. stability.


#### OSCILLATOR ADJUSTMENT

1. Connect R. F. signal generator to antenna lead.
2. Set scale to 100 with gang closed tight.
3. With generator set at 1400 K. C. and dial scale at 21, peak the oscillator trim condenser. This condenser is the back alignment condenser on gang.
4. Check sensitivity at 1400 K. C.      Limits 5 m. v.  
     Set dial 50      1000 K. C.      Limits 10 m. v.  
     Set dial 89      600 K. C.      Limits 30 m. v.  
     Set dial      800 K. C.      Limits 20 m. v.

If it is necessary to improve sensitivity at 600 or 1000 K. C., adjust plates until the set reaches the sensitivity limits. If bending plates does not help, change tubes.

# UNITED AMERICAN BOSCH CORP.

## SERVICE INSTRUCTIONS - MODELS 312 and 313



SCHMATIC WIRING DIAGRAM OF MODEL 312 RECEIVER


- |                    |                 |                 |
|--------------------|-----------------|-----------------|
| R1 - 100,000 ohms  | C10 - Alignment | C30 - .1 mfd.   |
| R2 - 100,000 ohms  | C11 - Alignment | C31 - .05 mfd.  |
| R3 - 100,000 ohms  | C12 - Alignment | C32 - 8. mfd.   |
| R4 - 500 ohms      | C13 - Alignment | C33 - 4. mfd.   |
| R5 - 500,000 ohms  | C14 - .05 mfd.  | C34 - 4. mfd.   |
| R6 - 1 megohm      | C15 - .05 mfd.  | C35 - 8. mfd.   |
| R7 - 1 megohm      | C16 - .05 mfd.  | C36 - 4. mfd.   |
| R8 - 2 megohm      | C17 - .05 mfd.  | C37 - 8. mfd.   |
| R9 - 500,000 ohms  | C18 - .05 mfd.  | C38 - 4. mfd.   |
| R10 - 1 megohm     | C19 - .05 mfd.  | C39 - 4. mfd.   |
| R11 - 1 megohm     | C20 - .05 mfd.  | C40 - .05 mfd.  |
| R12 - 1000 ohms    | C21 - .05 mfd.  | C41 - .05 mfd.  |
| R13 - 10,000 ohms  | C22 - .05 mfd.  | C42 - Alignment |
| R14 - 10,000 ohms  | C23 - 100 mmf.  | C43 - 100 mmf.  |
| R15 - 10,000 ohms  | C24 - .05 mfd.  | C44 - .05 mfd.  |
| R16 - 100,000 ohms | C25 - .05 mfd.  | C45 - .05 mfd.  |
| R17 - Center Tap   | C26 - 100 mmf.  | C46 - .05 mfd.  |
| R18 - 1500 ohms    | C27 - .1 mfd.   | C47 - .01 mfd.  |
| R19 - 5000 ohms    | C28 - .05 mfd.  | C48 - 2. mfd.   |
| R20 - 5000 ohms    | C29 - .5 mfd.   | C49 - .01 mfd.  |
| R21 - 100,000 ohms |                 |                 |
| R22 - 30,000 ohms  |                 |                 |
| R23 - 1000 ohms    |                 |                 |
| R24 - 1000 ohms    |                 |                 |
| R25 - 2800 ohms    |                 |                 |
| R26 - 2400 ohms    |                 |                 |
| R27 - 3000 ohms    |                 |                 |
| R28 - 10,000 ohms  |                 |                 |
| R29 - Mid Tap      |                 |                 |
| R30 - 2100 ohms    |                 |                 |
| C1 - Trimmer       |                 |                 |
| C2 - Tuning        |                 |                 |
| C3 - Tuning        |                 |                 |
| C4 - Tuning        |                 |                 |
| C5 - Tuning        |                 |                 |
| C6 - Alignment     |                 |                 |
| C7 - Alignment     |                 |                 |
| C8 - Alignment     |                 |                 |
| C9 - Alignment     |                 |                 |

# UNITED AMERICAN BOSCH CORP.

## MODELS 312 AND 313

Stage	Tube	Fil.	Plate	Screen	Cathode	Grid
1st R.F.	58	2.4	180	85	3-6	0
1st Det.	58	2.4	180	90	4.5-10	0
1st I.F.	58	2.4	195	90	3.5-6	0
2nd I.F.	58	2.4	195	90	3.5-6	0
2nd Det.	58	2.4	0	2	40	0
Relay	57	2.4	2	25	0-45	0
1st A.F.	56	2.4	120	1	45	0
Driver	46	2.4	290	390	-	30
Output	46	2.4	430	0	-	0
Output	46	2.4	430	0	-	0
Osc.	56	2.4	75	-	-	-
Rect.	82	2.4	-	-	-	-

Note: These values are readings of a high resistance voltmeter from each socket terminal to ground. The filament voltages are, of course, an exception. Cathode readings are given for those tubes having the grid at ground. The values are only approximate and will vary with the line voltage and the type of meter employed.



### TEMPORARY CONDENSED PARTS LIST FOR MODEL 312 RADIO RECEIVERS

#### MAIN ASSEMBLIES

103563 Chassis with tubes	101143 .0001 mfd.	103549 Volume control
103854 Speakers (2) with baffle (C)	103696 .01 mfd. - 4 ply	103548 Tone control
103802 Speakers (2) with baffle (G)	102500 .01 mfd. - 3 ply	99583 (500 ohms)
103805 Speaker only (small)	102493 .05 mfd. - 2 ply	100729 (1000 ohms)
103806 Speaker only (large)	102492 .06 mfd. - 3 ply	99581 (1500 ohms)
103885 Cabinet (Model C)	102494 .1 mfd. - 3 ply	103836 (3000 ohms)
103886 Cabinet (Model G)	102498 .5 mfd. - 3 ply	100824 (5000 ohms)
	103828 2. mfd. - 2 ply	98366 (5000 ohms)
	103037 8. mfd.	100825 (10000 ohms)
	104060 Antenna trimmer	101722 (30000 ohms)
		100727 (100000 ohms)

#### COILS

103675 Field coil (either speaker)	FUSE
103525 R.F. transformer (single)	101723 Fuse (2 amp.)
103526 R.F. transformer (double)	
103519 Oscillator coil	KNOB
103586 1st and 3rd I. F. transformer	100798 Dial knob
103587 2nd. I. F. transformer	102272 Antenna trimmer knob
103588 Coil only for 1st. I. F.	101445 Potentiometer knob
102841 Coil only for 2nd. I. F.	
103736 Inductance coil	MISC. PARTS
104116 Choke filter (2 leads)	103560 Dial scale only
103554 Choke filter (3 leads)	102282 Diaphragm (small)
103746 Rectifier R. F. choke	102283 Diaphragm (large)
103584 Choke coil (small)	98713 Lamp for dial

#### CONDENSERS

103740 Housed filter (5 leads)	METER
103595 Housed filter (6 leads)	103296 Tuning meter
101301 .0001 mfd. (offset terminals)	RESISTORS

#### FUSE

101723 Fuse (2 amp.)

#### KNOB

100798 Dial knob
102272 Antenna trimmer knob
101445 Potentiometer knob

#### MISC. PARTS

103560 Dial scale only
102282 Diaphragm (small)
102283 Diaphragm (large)
98713 Lamp for dial

#### METER

103296 Tuning meter

#### RESISTORS

#### SOCKETS


103686 Socket (4 prong)
103514 Socket (5 prong)
103513 Socket (6 prong)

#### TRANSFORMERS

103738 Power transformer
103815 Output transformer
103765 Input transformer
103737 Driver output trans

# U. S. RADIO & TELEVISION CORP.

## MODEL 5A (502 CHASSIS)




I.F. = 455 K.C.

# U. S. RADIO & TELEVISION CORP.


## MODEL 5 A (502 CHASSIS)

NO. 502 CHASSIS—VOLTAGES AT SOCKETS										
LINE VOLTAGE 115—VOLUME CONTROL AT MAXIMUM										
Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Screen Grid Volts	Screen Grid Current M A	Cathode Volts	Plate M A	Grid Test M A
57	1	1st Det. & Osc.	2.15	245	4.3-5.9 <sup>(1)</sup>	100	.6	4.3-5.9 <sup>(1)</sup>	.95	2.0
58	2	I. F.	2.15	240	3.0	100	1.5	3.0	6.6	10.4
57	3	2nd Det.	2.15	166	9.0	235	1	9.0	.35	.45
247	4	Audio	2.15	215	17.0 <sup>(2)</sup>	240	8.0		30.	48.
280	5	Rect.	4.6						30. Per Plate	


- (1) Varies with frequency setting of dial approximately as shown.  
 (2) Measured across 300 ohm section of voltage divider resistor.



Power Transformer Terminals



Electrodynamic Speaker and Connections.



Top View of Chassis Showing Location and Function of Tubes

# U. S. RADIO & TELEVISION CORP.

## MODEL 5A - (502 CHASSIS)

### CONTINUITY CHART

#### REFERENCE POINT— B (AUDIO SCREEN CONTACT)

Measurement Point	Correct Reading (Ohms)	Incorrect Reading (Ohms)	Defect
1st Detector Screen Grid	10,650	Open	Open R-8C
1st Detector Plate	18.5	2 Open	Shorted C-4 Open L-4 or L-6
I. F. Plate	20	Open 0	Open L-10 Shorted C-6
2nd Detector Screen Grid	0	Open	Open Connection
2nd Detector Plate	100,070	Open	Open R-6 or L-12
Audio Plate	700	Open	Open Pri. T-2
Rectifier Plate	14,800	Open	Open R-8 or Sec. T-1
Rectifier Filament	1,000	Open	Open L-13

#### MISCELLANEOUS

2nd Detector Plate to Audio Grid	Open	70	Shorted C-12
2nd Detector Plate to 2nd Detector Cathode	170,000	0 70	Shorted C-10 Shorted C-11
Rectifier Plate to Plate	600	Open	Open Secondary T-1
Rectifier Filament to Filament	Very Low	Open	Open Fil. Winding T-1
Between Filament Contacts of Other Sockets	Very Low	Open	Open Heater Winding
Across A. C. Plug	9	Open	Open Pri. T-1
Across Secondary T-2 (Unsolder Voice Coil Lead)	.8	Open	Open Sec. T-2
Across Voice Coil	1.8	Open	Open Voice Coil
Across C-15	Open	0	Shorted C-15
Chassis to Common Connection C-16 and C-17	Open	0	Shorted C-2 or Trimmer
Stator C-2 to Cathode 1st Detector	Open	2,854	Shorted C-16 or C-18

#### BAND SELECTOR SWITCH IN SHORT WAVE POSITION

Chassis to Antenna Binding Post	3.5	4 21	Open L-2 Open L-1
Chassis to Control Grid 1st Detector	1.6	0	Shorted C-1 or Trimmer
Chassis to Cathode 1st Detector	600	Open .3	Open R-3B or L-9 Shorted C-3
Audio Screen to 1st Detector Plate	18	Very Low Open	Shorted C-4 Open L-4 or L-8

# U. S. RADIO & TELEVISION CORP.

## CONTINUITY CHART

NO. 502 CHASSIS

Volume Control at Maximum—Switch in Broadcast Position

REFERENCE POINT—CHASSIS			
Measurement Point	Correct Reading (Ohms)	Incorrect Reading (Ohms)	Defect
Antenna Post	21	8000 0	Open L-2 Shorted C-14
1st Detector Control Grid	5	1.2 Open	Shorted C-1 or Trimmer Open L-3
1st Detector Cathode	2,850	Open .4	Open R-3 Shorted C-3
1st Detector Screen Grid	8,600	0 10,000	Shorted C-8 Open R-8C
1st Detector Plate	14,400	18.5 50,000	Shorted C-20 Open R-8B or R-8C
I. F. Control Grid	28	Open 0	Open L-4 Shorted C-5
I. F. Cathode	350	Open 0	Open R-2 Shorted C-15
I. F. Plate	14,000	20 50,000 Open	Shorted C-20 Open R-8B or R-8C Open R-4 or L-10
2nd Detector Control Grid	20	0 Open	Shorted C-7 Open L-11
2nd Detector Cathode	20,000	0 Open	Shorted C-9 Open R-5
2nd Detector Screen Grid	14,000	Open 0 300 1,300	Open R-4 or R-8 Shorted C-20 Shorted C-22 Shorted C-21
2nd Detector Plate	114,000	Open 150,000 120,650 20,000	Open R-6 Open R-8 Open R-4 Shorted C-10 or C-11
Audio Control Grid	400,300	Open	Open R-7 or R-8A
Audio Screen Grid	14,200	20,650 0 50,000	Open R-4 Shorted C-20 Open R-8B or R-8C
Audio Plate	14,900	0 50,000 Open	Shorted C-13 Open R-8B or R-8C Open Pri. T-2
Rectifier Either Plate	600	300 Open	Shorted C-23 Open Secondary T-2 or Open R-8A
Rectifier Either Filament	15,000	Open 300 1,300	Open L-13 or R-8 Shorted C-21 Shorted C-22








# U. S. RADIO & TELEVISION CORP.

## MODEL - 7 D

### No. 700 CHASSIS—VOLTAGES AT SOCKETS VOLUME CONTROL AT MAXIMUM—LINE VOLTAGE 115

Type of Tube	Position of Tube	Function	A Volts	B Volts	Control Grid C Volts	Screen Grid Volts	Screen Grid Current MA	Cathode Volts	Plate Current MA	Grid Test MA
56	1	Osc.	2.4	70	18 <sup>(1)</sup>			0	6.2	6.2
57	2	1st Det.	2.4	170	8.0	170	.3	8.0	1.2	1.6
58	3	1st I.F.	2.4	260	7.0	90 <sup>(2)</sup>	.6	7.0	2.5	4.0
58	4	2nd I.F.	2.4	260	7.0	90 <sup>(2)</sup>	.6	7.0	2.5	4.0
56	5	2nd Det.	2.4	200 <sup>(3)</sup>	17.0 <sup>(2)</sup>			17.0	.2	.3
247	6	Audio	2.4	240	1.6 <sup>(4)</sup>	265	6.8		33.0	38.0
280	7	Rect.	5.0						39 Per Plate	

- (1) Varies with frequency. Actual voltage measured across 25,000 ohm bias resistor—39 Volts.
- (2) Voltage measured with 120,000 ohm meter.
- (3) Voltage measured with 600,000 ohm meter.
- (4) Actual voltage measured across 225 ohm section of voltage divider resistor—17 Volts.






# U. S. RADIO & TELEVISION CORP.


No. 900 and No. 902 CHASSIS—VOLTAGES AT SOCKETS—LINE VOLTAGE 115  
VOLUME CONTROL AT MAXIMUM—"Q" CONTROL AT MAXIMUM

Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Screen Volts	Screen Current MA	Cathode Volts	Plate MA	Grid Test MA
58	1	R.F.	2.25	125	5.0 <sup>(1)</sup>	125	1.7	5.0	6.0	10.0
57	2	1st Det	2.25	125	5.0 <sup>(2)</sup>	125	.3 <sup>(2)</sup>	5.0 <sup>(2)</sup>	1.2 <sup>(2)</sup>	2.0
58	3	I.F.	2.25	125	5.0 <sup>(1)</sup>	125	1.7	5.0	6.0	10.0
57	4	AVC	2.25	100 <sup>(3)</sup>	24.0 <sup>(4)</sup>	145	0	24.0	0	0
56	5	2nd Det.	2.25	150	12.0			12.0	.4	.5
46	6	Driver	2.25	215	19.0 <sup>(5)</sup>				25.0	30.0
46	7	Power	2.25	320					5.0 <sup>(6)</sup>	13.0
46	8	Power	2.25	320					5.0 <sup>(6)</sup>	13.0
280	9	Rect.	4.8						41 Per Plate	

- (1) Measured from movable arm of "Q" control to ground. Reads 26 volts with "Q" control at minimum.
- (2) Values read with analyzer plug in socket. Actual values different as analyzer prevents oscillating.
- (3) Measured with 600,000 Ohm Meter.
- (4) Measured across 1000 Ohm Resistor.
- (5) Measured across 10,000 Ohm Carbon Voltage Divider Resistor.
- (6) Plate current at no signal. At full output plate current is 60 to 70 MA.





No. 4245 Electrodynamic Speaker and Connections




Top View of Chassis Showing Tube Location

# U. S. RADIO & TELEVISION CORP.



No. 4246 and 4247 Electrodynamic Speakers and Connections



Wiring Diagram, Osc. and I.F. Assembly

## SUPPLEMENTARY NOTES FOR No. 902 CHASSIS

Chassis No. 902 is very similar to Chassis No. 900, except that it is designed for dual-speaker operation. Two speakers, Part No. 4246 and 4247 are supplied with this chassis, the No. 4246 speaker being identical with the No. 4245 speaker used with the No. 900 chassis as regards electrical constants with the exception that the speaker input transformer is designed with a secondary impedance to match two voice coils in parallel. The No. 4247 speaker is supplied with a field having a resistance of 9600 ohms which is connected in the power supply system of the No. 902 chassis in place of the 2500 and 7100 ohm sections of the Candohm resistor which is used in the No. 900 chassis. The speaker field is tapped at 2500 ohms and there is a voltage drop of 115 and 130 volts across the 2500 and 7100 sections respectively.

It is essential that the polarity of the leads which connect the voice coils of the two speakers in parallel be correct. If the blue and white leads are reversed, very poor audio quality will result because one cone will be moving out while the other is moving in and vice versa.

If the 7100 ohm section of the field in the No. 4247 speaker is open the receiver will continue to operate. The volume will, however, be reduced and the reproduction will be distorted.

It will be noted that a number of the speaker parts for the No. 900 chassis are interchangeable with parts used in the No. 4246 speaker with the No. 902 chassis. Therefore, it has not been thought necessary to make a repetition of these part numbers in the accompanying list of the changes in parts for the No. 902 chassis.




# U. S. RADIO & TELEVISION CORP.

No. 1200 CHASSIS—VOLTAGES AT SOCKETS—LINE VOLTAGE 115  
VOLUME CONTROL AT MAXIMUM —“Q” CONTROL AT MAXIMUM


Tube No.	Type of Tube	Function	“A” Volts	“B” Volts	Control Grid “C” Volts	Screen Grid Volts	Screen Grid MA	Cathode Volts	Plate Current MA	Grid Test MA
1	58	R.F.	2.25	140	3.2 <sup>(1)</sup>	80	.9	3.2	3.6	7.6
2	58	1st Det.	2.25	130	7.5	74	.5	7.5	2.0	2.3
3	58	I. F.	2.25	140	3.2 <sup>(1)</sup>	80	.9	3.2	3.6	7.6
4	56	2nd Det.	2.25							
5	56	1st Audio	2.25	110	5.5 <sup>(2)</sup>			0	4.2	8.6
6	56	Osc.	2.25	110	10-23 <sup>(3)</sup>			0	3.4	
7	57	AVC	2.25	65 <sup>(4)</sup>	35 <sup>(5)</sup>	85	0	35 <sup>(5)</sup>	0	0
8	57	“Q”	2.25	120 <sup>(6)</sup>	3.5 <sup>(7)</sup>	20	0	3.5 <sup>(7)</sup>	0	0
9	46	Driver	2.25	235	28 <sup>(8)</sup>				26.0	28
10	46	Power	2.25	335	0				5.5 <sup>(9)</sup>	13
11	46	Power	2.25	335	0				5.5 <sup>(9)</sup>	13
12	82	Rect.	2.2						51	

Per Plate


- (1) Measured across 350 Ohm Resistor.
- (2) Measured across 1600 Ohm section of Voltage Divider Resistors.
- (3) Varies as shown with frequency—measured across 500,000 Ohm Resistor.
- (4) Measured with 600,000 Ohm Meter.
- (5) Measured across 850—5,000—4100 Ohm sections of Voltage Divider Resistors.
- (6) Measured across 5,000—4100—25,000 Ohm sections of Voltage Divider Resistors.
- (7) Measured across 850 Ohm “Q” Tube Bias Resistor.
- (8) Measured across 850 Ohm Driver Tube Bias Resistor.
- (9) Plate Current at No Signal.




Top View of No. 1200 Chassis Showing Tube Location



Electrodynamic Speakers and Connections




Revised Audio Circuit in No. 1200 Chassis  
above Serial No. 1189197



Power Transformer Terminals

U. S. RADIO & TELEVISION CORP.

MODEL 24 (No 400 CHASSIS)



I.F. = 455 K.C.



No. 400 CHASSIS—VOLTAGES AT SOCKETS—LINE VOLTAGE 115  
VOLUME CONTROL AT MAXIMUM

Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Screen Grid Volts	Screen Grid Current MA	Cathode Volts	Plate Current MA
57	1	1st Det. & Osc.	2.4	235	8	120	— <sup>(1)</sup>	8	— <sup>(1)</sup>
57	2	2nd Det.	2.3	45 <sup>(2)</sup>	0	20 <sup>(2)</sup>	.2	0	.7
247	3	Audio	2.3	235	1.0 <sup>(3)</sup>	245	5.2		26
280	4	Rect.	4.8						16 Per Plate


(1) Can only be read with special adapter.  
 (2) Voltage as read with 600,000 ohm meter.  
 (3) Not true reading. Actual voltage across 500 ohm resistor—17 volts.




# U. S. RADIO & TELEVISION CORP.




Wiring Diagram, Oscillator-I. F. Assembly



Transformer  
Electrodynamic Speaker and Connections



I.F. PRIMARY TRIMMER      600 K.C. OSC. TRIMMER  
Location of Trimmers beneath Chassis



Power Transformer Lead Identification

# U. S. RADIO & TELEVISION CORP.

## CONTINUITY TEST CHART

NO. 400 CHASSIS

Remove all tubes and disconnect power cord. Disconnect antenna and ground and turn Volume Control to maximum. Read from Reference Points to each Measurement Point until defect is isolated.

### REFERENCE POINT—CHASSIS

Measurement Point	Correct Reading (Ohms)	Incorrect Reading (Ohms)	Defect
Antenna (Vol. Control Maximum)	3	20,000	Open L-1
1st Detector Control Grid	4	0 Open	Shorted C-1 or Trimmer Open L-2
1st Detector Cathode	5000	Open	Open R-2
1st Detector Screen Grid	Open	255,000 0 253,000 250,500	Shorted C-3 Shorted C-13 Shorted C-14 Shorted C-15
1st Detector Plate	Open	5031 3034 534	Shorted C-3 Shorted C-14 Shorted C-15
2nd Detector Control Grid	3,000,000	31 Open	Shorted C-9 Open R-3
2nd Detector Cathode	0	Open	Open Connection
2nd Detector Screen Grid	Open	0	Shorted C-8
2nd Detector Plate	Open	Very Low 10,000	Shorted C-10 Shorted C-12
Audio Grid	500,500	500,000 Open	Shorted C-16 Open R-7 or R-9
Audio Screen Grid	Open	3000 500	Shorted C-14 Shorted C-15
Audio Plate	Open	3520 1020	Shorted C-14 Shorted C-15
Rectifier Filament	Open	500 3000	Shorted C-14 Shorted C-15
Rectifier Plate	875	375 Open	Shorted C-16 Open Secondary or Power Trans.
Coil Side of C-9	31	0 Open	Shorted C-5 Open L-4
Negative Terminal of Filter Condenser	500	Open 0	Open R-9 Shorted C-16

# U. S. RADIO & TELEVISION CORP.

## CONTINUITY TEST CHART

REFERENCE POINT—CHASSIS  
MODEL 400 CHASSIS


Measurement Point	Correct Reading (Ohms)	Incorrect Reading (Ohms)	Defect
Stator C-2	Open		Shorted C-2 or Trimmer
<b>REFERENCE POINT—+B (RED SPEAKER LEAD)</b>			
1st Detector Plate	34	Open 3	Open L-3 or L-5 Shorted C-4
1st Detector Screen Grid	250,000	Open	Open R-8
1st Detector Cathode	Open	1.5	Shorted C-3
2nd Detector Plate	260,000	Open	Open R-4 or R-6
2nd Detector Screen Grid	1,000,000	Open	Open R-5
Audio Plate	530	Open	Open Primary T-2
Rectifier Filament	2500	Open	Open Speaker Field
<b>MISCELLANEOUS</b>			
Plate to Plate Rectifier	750	Open	Open High Voltage Secondary
Filament to Filament Rectifier	Very Low	Open	Open 280 Fil. Winding
Between Filament Contacts of Other Sockets	Very Low	Open	Open Heater Winding
Across AC Plug	17	Open	Open Primary Power Transformer
2nd Det. Plate to Audio Grid	Open	10,000	Shorted C-11
1st Det. Plate to Stator C-2	Open	31	Shorted C-6 or C-7
2nd Det. Plate to Insulated Terminal On Back Panel	10,000	Open	Open R-4
Across Secondary T-2 (Unsolder Voice Coil Lead)	.6	Open	Open Sec. T-2
Across Voice Coil (Unsolder Voice Coil Lead)	2.2	Open	Open Voice Coil
Across Volume Control (Unsolder Black Ground Lead)	20,000	Open	Open R-1

# U. S. RADIO & TELEVISION CORP.


## NO. 500 CHASSIS—VOLTAGES AT SOCKETS LINE VOLTAGE 115—VOLUME CONTROL AT MAXIMUM ANALYZER PLUG IN SOCKET—TUBE IN ANALYZER SOCKET

Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Screen Grid Volts	Screen Grid Current MA	Cathode Volts	Plate MA	Grid Test MA
57	1	1st Det. & Osc.	2.15	245	4.3-5.9 <sup>(1)</sup>	100	.6	4.3-5.9 <sup>(1)</sup>	.95	2.0
58	2	I.F.	2.15	240	3.0	100	1.5	3.0	6.6	10.4
57	3	2nd Det.	2.15	166	9.0	115 <sup>(2)</sup>	.1	9.0	.35	.45
247	4	Audio	2.15	215	17.0 <sup>(3)</sup>	240	8.0		30.	48.
280	5	Rect.	4.6						30 Per Plate	



- (1) Varies with frequency setting of dial approximately as shown.
- (2) Voltage as measured with 120,000 ohm meter.
- (3) Measured across 300 ohm section of voltage divider resistor.



## 25 SERIES (No 500 CHASSIS)



Top View of Chassis Showing Tube Location








# U. S. RADIO & TELEVISION CORP.

## MODEL 69 (906 CHASSIS)



**No. 906 CHASSIS—VOLTAGES AT SOCKETS**  
**AIR CELL "A" BATTERY—180 VOLTS "B" BATTERY**

Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Screen Grid Volts	Screen Grid Current MA	Plate Current MA
232	1	R. F.	2.0	152	.2 <sup>(1)</sup>	54 <sup>(2)</sup>	.5	1.4
232	2	1st Det.	2.0	150	3.0 <sup>(1)</sup>	54 <sup>(2)</sup>	.3	1.1
230	3	Osc.	2.0	63	4.0-5.0 <sup>(3)</sup>			1.8
234	4	I. F.	2.0	150	.2 <sup>(1)</sup>	54 <sup>(2)</sup>	1.2	2.1
230	5	AVC	2.0	3.5 <sup>(4)</sup>	1.8 <sup>(2)</sup>			0
230	6	1st Audio	2.0	150	2.0 <sup>(2)</sup>			4.1
230	7	2nd Det.	2.0	125 <sup>(5)</sup>	6.0 <sup>(2)</sup>			.1
230	8	Power	2.0	152	14.5			.9 <sup>(6)</sup>
230	9	Power	2.0	152	14.5			.9 <sup>(6)</sup>

- (1) Voltage as read with 60,000 Ohm meter.
- (2) Voltage as read with 120,000 Ohm meter.
- (3) Varies with frequency approximately as indicated.
- (4) Reversed reading—plate negative with respect to filament.
- (5) Voltage as read with 600,000 Ohm meter.
- (6) Plate current with no signal applied to receiver.

# U. S. RADIO & TELEVISION CORP.

## MODEL 69

### CONTINUITY TEST CHART

REFERENCE POINT—+180 B (RED LEAD)			
Measurement Point	Correct Reading (Ohms)	Incorrect Reading (Ohms)	Defect
R. F. Screen Grid	50,000	Open	Open R-1
R. F. Plate	2.5	Open	Open L-3
1st Detector Plate	48	Open 0	Open L-5 Shorted C-6
Oscillator Plate	50,000	Open	Open R-10
I. F. Plate	48	Open 0	Open L-7 Shorted C-8
2nd Detector Plate	100,070	Open	Open R-4 or L-10
1st Audio Plate	350	Open	Open Pri. T-1
Power Stage Either Plate	400	Open	Open Pri. T-2
MISCELLANEOUS			
+A Lead to +Fil. Contact of R. F., I. F., Osc., AVC, 2nd Det., or Audio	.6	Open	Open R-6
+A Lead to +Fil. Contact 1st Det.	5	Open	Open L-7
+A Lead to -A Lead	Open	0	Shorted C-10
-A Lead to -Fil. Contact 1st Det.	.6	Open	Open L-11
-A Lead to -B Lead	1,600	45,000 1,650 1,625	Open R-19 A or R-19 B Open R-14, R-15, R-16, R-17 or R-18 Open R-12 or R-13
Plate to Plate Power Tubes	800	Open 0	Open Pri. T-2 Shorted C-16
Oscillator Plate to Grid (Tone Control at Min.)	Open	3	Shorted C-21
AVC Plate to Grid	610,000	0 Open	Shorted C-19 Open R-8 or R-9
Across Voice Coil (Unsolder Lead)	1.3	Open	Open Voice Coil
Across Sec. T-2 (Unsolder Lead)	.14	Open	Open Sec. T-2



# U. S. RADIO & TELEVISION CORP.

## MODEL 69

### CONTINUITY CHART

All tubes removed from sockets--Batteries disconnected — Volume Control at Maximum—  
Switch in "On" position—Tone Control at Maximum.

REFERENCE POINT—CHASSIS OR -A LEAD			
Measurement Point	Correct Reading (Ohms)	Incorrect Reading (Ohms)	Defect
Antenna Post	30	Open	Open L-1
R. F. Control Grid	510,000	0 6 Open	Shorted C-1 or Trimmer Shorted C-4 Open R-3, R-8 or L-2
R. F. Screen Grid	Open	100,000 0	Shorted C-12 Shorted C-17
R. F. Plate	Open	25,000 50,000	Shorted C-12 Shorted C-17
1st Detector Control Grid	520,000	0 6 Open	Shorted C-2 or Trimmer Shorted C-5 Open L-4, R-2, R-9
Oscillator Control Grid	500,000	2.5 2 Open	Shorted C-20 Shorted C-3 or Trimmer Open L-12 or R-11
Oscillator Plate	Open	100,000	Shorted C-17
I. F. Control Grid	510,000	360,000 Open	Shorted C-19 Open L-6, R-3 or R-8
2nd Detector Control Grid	200,000	23	Shorted C-9
2nd Detector Plate	Open	0 70 150,000 550,000	Shorted C-11 Shorted C-13 Shorted C-12 Shorted C-14
1st Audio Control Grid (Vol. Control at Min.)	25,000	0	Shorted C-15
1st Audio Plate	Open	50,350	Shorted C-17
Power Stage Control Grids	1,375	Open 45,000	Open Sec. T-1 Open R-19
A V C Control Grid	310,000	Open 150,000 365,000	Open R-8 Shorted C-19 Open R-14
AVC Plate	320,000	Open	Open R-9

# U. S. RADIO & TELEVISION CORP.

## S.W. CONVERTER NO 300 SERIES CHASSIS

### DESCRIPTION

The No. 300 Chassis is an A. C. operated Short Wave Converter utilizing the Super-Heterodyne principle and when used in conjunction with any standard broadcast band receiver permits the reception of stations transmitting on frequencies ranging from 550 K.C. to 20,000 K.C. This chassis is used in U. S. Radio Table Models 12A and 12AX Short Wave Converters and Console Models 712A and 712AX Combination Short Wave and Broadcast Band Receivers.

The chassis is self-powered and is designed to operate satisfactorily on a power supply of from 105 to 125 volts and from 50 to 60 cycles alternating current. The No. 300X Chassis is designed for 25 cycle, 115 volt operation. The tube sequence (top view) is shown in Fig. 2.

The broadcast receiver used in connection with the converter is tuned for the best performance to a frequency of 1000 K.C. Unless proper precaution were taken in the design of the converter troublesome interference would be introduced if it so happened a station broadcasting on 1000 K.C. was within the receiving range of the receiver. In the No. 300 Chassis this possibility is very effectively overcome by incorporating in the antenna circuit of the antenna transformer a parallel combination of inductance and capacity. The values of these parts are, as can be seen by referring to Fig. 1, 84.5 microhenries and 300 Mmf. respectively. This parallel impedance constitutes the frequency filter and offers maximum opposition to the undesirable 1000 K.C. frequency without, however, preventing the passage of currents of other frequencies and for which the tuning range of the converter is designed.

The capacity of coils frequently causes peculiar and undesirable effects in radio circuits caused by the capacities of those parts of a coil which are not connected in the circuit. Referring to the schematic wiring diagram it will be noted the unused sections of the secondary of the antenna transformer are short circuited by the band selector switch as the frequency tuning range is increased. The effect of "dead ends" in a coil, especially at the higher frequencies, is to produce undesirable effects and to produce energy loss and considerably effect the frequency of resonance of the circuit, because the unused turns are in the magnetic field of the used portion of the coil and are closed by the inherent distributed capacity. Due to the close coupling, if the resonant frequency of this circuit is near that of the first it will greatly affect the resonant frequency of the first circuit. This undesirable effect is counteracted by short circuiting the unused portions of the coil, increasing the impedance of this circuit and causing very little current to flow, thus preventing the possibility of the circuit from responding to two frequencies.

The output from the plate of the 1st detector of the converter is fed through a .0005 coupling condenser to the antenna post of the broadcast receiver by means of a shielded cable with the shield grounded. The capacity reactance between the antenna lead and the grounded shield is of the order of a few hundred ohms and would, were not proper provisions taken in the design, seriously affect the sensitivity. This effect is satisfactorily overcome by choosing an inductance coil of suitable value and connecting it in parallel to the inherent capacity reactance of the shielded cable. This coil is the 250 microhenry choke shown in the schematic wiring diagram and it greatly increases the impedance between the antenna lead and the ground, thus preventing any loss in sensitivity.

The Band Selector Switch permits the selection of any of the three bands. The tuning knob has letters upon its face designating the three bands. The frequency band covered by the tuning condenser with the switch in the "L" position is 1.5 M.C. to 3.75 M.C.; in the "M" position, 3.58 M.C. to 9.10 M.C.; and from 8.40 M.C. to 20 M.C. with the switch at the "H" position. This switch is of excellent design and under normal conditions of service no inherent trouble should develop in its function.

The Antenna and A. C. Rotor Switch serves a dual purpose. It turns the power on to the converter and connects the antenna to the converter when turned clockwise. When

turned counterclockwise the power supply to the converter is disconnected and the antenna connected to the broadcast receiver.

The broadcast receiver is turned on and off by its own On-Off switch in the normal manner.

The volume and tone of the short wave signals are controlled by the volume and tone controls on the broadcast receiver.

NOTE: In No. 300 Chassis below Serial No. 1155363 there is incorporated in the circuit of the oscillator and the "M" range of the band selector switch a variable padding condenser in addition to a fixed condenser of 1100 Mmf. The fixed condenser was subsequently changed to one having a capacity of 1130 Mmf. as shown in the schematic wiring diagram, thus making the use of a variable padding condenser unnecessary. The location of this condenser is shown at the point "M" of Fig. 2, and aligning instructions are given in the alignment paragraph in this manual.

### DETECTOR

The 1st detector stage consists of a 224 type tube functioning as a grid-condenser-and-leak detector. The 224 type tube, due to its inherently low input capacity, is used in this stage in preference to other tubes which would, due to their high input resistance, as one component of the impedance of the input circuit, seriously affect the selectivity.

### OSCILLATOR

The oscillator is of the tuned grid type and has combined inductive and capacity coupling. The oscillator pick-up coil which is inductively coupled to the oscillator coil is connected in the cathode circuit of the 1st detector. The signal generated by the oscillator is 1000 K.C. in frequency above the frequency to which the 1st detector is tuned. The drop across the 250,000 ohm resistor in the oscillator brought about by the D.C. component of the oscillatory current establishes the bias voltage.

### POWER UNIT

The power system consists of the conventional, power transformer, full wave rectifier, filter choke and filter condensers. The filter condensers are of the dry electrolytic type having a capacity of 2 Mfd. each and rated at 450 volts. The high potential side of the system is connected to the 13,000 ohm and 100,000 ohm carbon resistors supplying plate voltage to the oscillator and 1st detector tubes respectively.

### ALIGNMENT

The excellent performance of which the No. 300 Chassis is capable depends to a large degree on the correct alignment of the antenna and oscillator trimmer located on their respective sections of the two-gang tuning condenser and the oscillator padding condenser. The actual mechanics of the alignment procedure is, with the exception of the frequency range involved, identically the same as in those Super-Heterodyne chassis designed for the regular broadcast band.

The signal generator or test oscillator must be one designed to cover a frequency range of from 1500 K.C. to 20,000 K.C. or 1.5 megacycles to 20 megacycles, and accurately calibrated to obviate any possibility of misalignment that might otherwise arise. It is quite likely a few of the well-known and reputable manufacturers of service test equipment will in the near future, due to the exceptional popularity and general trend of the public towards short wave receivers, have oscillators for this purpose available to the radio trade as the demand becomes more acute.

The adjustable trimmers are accurately aligned at the factory with accurately calibrated signal generators and output meters and the receivers should not as a general rule require alignment unless mishandled or tampered with. If realignment is found necessary the chassis should be removed from the cabinet. The complete aligning procedure and location of the different condensers is as follows:

# U. S. RADIO & TELEVISION CORP.


**ALIGNING OSCILLATOR TRIMMER**—The chassis must be connected to a broadcast receiver in the usual manner with the ground wire connected but the antenna lead disconnected. The signal generator placed in operation and coupled with a wire to the antenna post on the converter. The signal generator must be grounded and adjusted to 20,000 K.C.

Then turn the tuning condenser rotor until the dial pointer is at exactly 100 with the rotor plates completely out of mesh, indicating minimum capacity. If the dial does not correspond to a reading of 100 with the plates out of mesh the set screws that secure the drive to the tuning condenser shaft should be loosened and the dial shifted until the pointer is at exactly 100 on the dial scale.

The band selector switch should be turned to the "H" position and the oscillator trimmer screw turned up or down until maximum deflection on the output indicating meter is obtained. It will be noted two peaks can be obtained and the correct one is with the trimmer screw farthest out.

**ALIGNING ANTENNA TRIMMER**—The position of the band selector switch should be retained as in the case above with the signal generator adjusted to 20,000 K.C. and the tuning condenser rotor turned until the pointer is at 10 on the dial scale. The adjusting screw of this trimmer is then turned up or down until maximum deflection on the output meter is obtained.


**ALIGNING OSCILLATOR PADDING CONDENSER**—The band selector switch must be turned to the "L" position and the signal generator adjusted to 1500 K.C. The adjusting screw for this condenser is located to the right outer edge of the subpanel as indicated by "L" in Fig. 2, and it should be turned up or down until maximum output is obtained.



NO. 300 CHASSIS—VOLTAGES AT SOCKETS—LINE VOLTAGE 115  
BAND SELECTOR SWITCH ON "L"—TUNING DIAL AT "0"


Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Plate MA	Grid Test MA
224	1	1st Det.	2.45	50.	4.	1.	—
227	2	Osc.	2.45	135.	28. (*)	5.5	5.9
280	3	Rect.	5.			2.8	
						Per Plate	

\*Measured across 250,000 ohm oscillator bias resistor.



# U. S. RADIO & TELEVISION CORP.

## MODELS 3040, 3056 (507 CHASSIS)




I. F. = 455 K.C.

# U. S. RADIO & TELEVISION CORP.


No. 507 CHASSIS—VOLTAGES AT SOCKETS—LINE VOLTAGE 115  
VOLUME CONTROL AT MAXIMUM

Type of Tube	Position of Tube	Function	"A" Volts	"B" Volts	Control Grid "C" Volts	Screen Grid Volts	Screen Grid Current MA	Cathode Volts	Plate Current MA
57	1	1st Det. & Osc.	2.3	125	5.0	120	— <sup>(1)</sup>	12.0	— <sup>(1)</sup>
58	2	I. F.	2.3	230	7.0	120	1.0	10.0	4.2
57	3	2nd Det.	2.3	40 <sup>(2)</sup>	0	24 <sup>(2)</sup>	.2	17.0	.7
247	4	Audio	2.3	210	1.5 <sup>(3)</sup>	225	5.2		25.0
280	5	Rect.	4.7						22 Per Plate


- (1) Can only be read with special adapter.
- (2) Voltage as read with 600,000 ohm meter.
- (3) Not true reading. Actual voltage across 500 ohm resistor—17 volts.




Top View of Chassis Showing Tube Location



Oscillator—I. F. Assembly



Power Transformer Lead Identification




Electrodynamic Speaker and Connections

# WELLS-GARDNER & CO.

## No. 05A Series

### 5 Tube A.C. - D.C.

### Superheterodyne Receiver



Schematic Circuit Diagram

### Voltages at Sockets

Antenna lead connected to ground lead (not external ground).—Volume Control at Maximum.  
CAUTION—Do not put chassis on any grounded surface or let chassis touch any ground.


Type of Tube	Function	A.C. Line Voltage—115 Use High Resistance A.C. Meter, Rectifier Type, for Heater Voltage Measurements					D.C. Line Voltage—110 Use High Resistance D.C. Meter for Heater Voltage Measurements				
		Across Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.	Across Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.
77	1st Det. Osc.	5.8	106	106	5.2	.8	5.6	87	87	4.3	.6
78	I.F.	5.8	108	108	3.0 <sup>(1)</sup>	7.4	5.6	88	88	2.4 <sup>(1)</sup>	6.0
77	2nd Det.	5.8	65 <sup>(2)</sup>	104	6.0 <sup>(3)</sup>	.14	5.6	58 <sup>(2)</sup>	82	5.0 <sup>(3)</sup>	.11
43	Output	24.	95	110	18.0 <sup>(4)</sup>	22.0	23.0	80	90	15.0 <sup>(4)</sup>	17.0
25Z5	Rect.	24.	110 <sup>(5)</sup>			84.0	23.0	5.0 <sup>(5)</sup>			74.0
			155			Total		6.0			Total

- (1) Cathode to Ground.
- (2) With 1,000,000 ohm meter—reading will be lower with lower resistance meter.
- (3) Cathode to ground—read with 100,000 ohm meter.
- (4) Read across filter choke.
- (5) Readings from plate to two cathodes with 250,000 ohm meter


# WELLS-GARDNER & CO.

## No. 022 Series

### 12 Tube Superheterodyne



Schematic Circuit Diagram




### Voltages at Sockets

LINE VOLTAGE 115—ANTENNA SHORTED TO GROUND—NOISE SUPPRESSOR AT MAXIMUM CLOCKWISE POSITION

Type of Tube	Function	Across Filament or Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.
58	R. F.	2.4	242	90	4 <sup>(1)</sup>	4
58	1st Det.	2.4	250	86	7 <sup>(1)</sup>	2
56	Osc.	2.4	24		0	8
58	1st I.F. <sup>(2)</sup>	2.4	252	90	4 <sup>(1)</sup>	4
58	2nd I.F. <sup>(2)</sup>	2.4	254	91	3	5.7
56	2nd Det.	2.4	0		0	0
57	1st Audio	2.4	65	55	4 <sup>(3)</sup>	.4
57	Noise Sup.	2.4	55	20	3 <sup>(1)</sup>	0
56	2nd Audio	2.4	255		14 <sup>(4)</sup>	3.3
46	Power	2.4	260	260	34	23
82	Rectifier	2.4	880 volts plate to plate			53 per plate


- (1) Read from cathode to ground.
- (2) If I.F. readings are made with a cord and plug, ground the control grid through a condenser to prevent oscillation and motor boating.
- (3) Read across 30 ohm section of voltage divider.
- (4) Read across 30 ohm and 100 ohm section of voltage divider.

# WELLS-GARDNER & CO. No. 052 Series



FORM 399-J

Schematic Circuit Diagram



Top View of Chassis

## Twenty-Five Cycle Receivers

The twenty-five cycle receiver differs from the sixty-cycle receiver only in the fact that a different power transformer is used. The correct power transformer is shown in the parts list.

The twenty-five cycle chassis can be operated satisfactorily from a sixty-cycle power supply. However, the reverse is not true, the sixty-cycle receiver cannot be operated from a twenty-five cycle power supply.

Voltages at Sockets						
LINE VOLTAGE 115 — VOLUME CONTROL AT MAXIMUM — ANT. SHORTED TO GND.						
Type of Tube	Function	Across Filament or Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate MA
'57	1st Det.	2.15	225	90	4	.5
'35	I.F.	2.15	230	90	3.2 <sup>(1)</sup>	6.2
'57	2nd Det.	2.15	170	90	4.3	.2
'47	Audio	2.15	225	240	14 <sup>(2)</sup>	23.
'80	Rect.	4.75	620 volts plate to plate			20. per plate

(1) If read with cord and plug, ground the control grid.  
 (2) Computed figure—cannot be accurately read with ordinary voltmeter. Voltage consists of drop across 1 megohm resistor, R 8.

## Oscillation and Whistle



Should the set oscillate on being connected up, it may be due to tubes whose characteristics vary considerably from the standard. In case of oscillation, therefore, change the two '57's around and try out some new tubes.

See if the receiver is properly grounded and if it is, try out a new ground. Investigate the line voltage to see if it is excessively high.

The tube shields must all be on and the control grid leads to the top grid connection tubes firmly in place. Otherwise oscillation may result.



# WELLS-GARDNER & CO. No. 092 Series



Tube Arrangement and Battery Connections

## Voltages at Sockets

"B" AND "C" BATTERIES UP TO RATED VOLTAGE—FILAMENT CONTROL KNOB SET SO THAT FILAMENT VOLTAGE IS 2—ANTENNA LEAD SHORTENED TO GROUND—VOLTAGES READ FROM NEGATIVE FILAMENT LEG

Type of Tube	Function	Across Filament	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate MA
'34	R.F.	2.0	125	65	2.88 <sup>(1)</sup>	2.3
'34	1st Det.	2.0	130	65	7.5 <sup>(1)</sup>	1.4
'30	Osc.	2.0	67		4-15 <sup>(2)</sup>	1.6-4 <sup>(2)</sup>
'34	I.F.	2.0	120	65	2.38 <sup>(1)</sup>	2.4
'30	2nd Det.	2.0	0		0	0
'30	1st Audio	2.0	85		7.5 <sup>(1)</sup>	.5
'30	Driver	2.0	125		7.5 <sup>(1)</sup>	4.0
'30	Output	2.0	130		10.	1.1


(1) Computed figure—cannot be read with ordinary voltmeter because of high resistance in this circuit. See article "Voltages" for further information.

(2) Subject to variation with dial setting.

# WELLS-GARDNER & CO.


## No. 20 Series

### 10 Tube Super-Heterodyne Receivers



Schematic Circuit Diagram

FORM 325-J



Top View of Chassis.

### Voltages at Sockets

**LINE VOLTAGE 115—VOLUME CONTROL AT MAXIMUM—SECOND DETECTOR TUBE REMOVED FROM SOCKET**

Type of Tube	Function	Across Filament or Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate MA
'35	R.F.	2.2	180	92	3 <sup>(1)</sup>	6.2
'35	1st. Det.	2.2	178	85	10 <sup>(1)</sup>	2.2
'27	Oscil.	2.2	94		6 <sup>(2)</sup>	4.0 <sup>(2)</sup>
'35	1st. I.F.	2.2	180	92	3 <sup>(1)</sup>	6.0
'35	2nd. I.F.	2.2	260 <sup>(3)</sup>	90	6	5.5
'27	1st. Audio	2.2	105		5 <sup>(3)</sup>	4.2
'47	2nd. Audio	2.2	245	260	17 <sup>(4)</sup>	31.
'80	Rect.	4.8	725 volts plate to plate			66 per plate

(1) Read from cathode to ground.  
 (2) Subject to variation with dial setting.  
 (3) Read across 38 ohm section of voltage divider resistor.  
 (4) Read across 38 and 100 ohm sections of voltage divider.  
 (5) Changes to 178 volts in latest models.  
 NOTE:—All readings, except heater, for second detector tube are zero.

# WELLS-GARDNER & CO. MODEL 20

## Data on Earlier Models in This Series

The foregoing service manual describes the chassis of this series as it is manufactured at the present time. However, when the model was first brought out it was slightly different mechanically and electrically than the present model.

In this supplement, the changes of importance from a servicing standpoint from the first models to the present are discussed. This section should be gone over carefully by the service technician, as it is of importance both in servicing the set and when ordering replacement parts. The changes described were not all made at the same time. Investigation of the chassis will show which of the changes are incorporated. One way of eliminating error in replacing parts is to return the old part when ordering a new one.

### Key Numbers

In Fig. 3 is shown the schematic circuit diagram of the original model. In the changes as described below, reference will be made both to this diagram and to the schematic circuit diagram of the present model Fig. 1. Note that the key numbers of the resistors and condensers in Figs. 1 and 3 do not coincide.

### Interstage Transformer

The interstage R.F. transformer of the original sets contained a 250,000 ohm isolating resistor shown in Fig. 3 as R3. This is replaced by the present type of interstage R.F. transformer with no resistor:

### Isolating Resistors

Isolating resistor R3, as shown in Fig. 3 is omitted and isolating resistor R4, 250,000 ohms, is changed in the later models to 500,000 ohms.

### Tone Control and On-Off Switch


The early models in this series used a combination tone control and On-Off switch. In the later models these units are separate.

### I.F. Transformer Assemblies

The old I.F. assemblies were in square cans and the condenser adjusting screws were reached from the top of the chassis. The new assemblies as used on the present models are in round cans and the adjusting screws are reached from the bottom of the chassis through holes in the sub-panel.

### Oscillator Assembly

The oscillator assembly as used in the early models had the 600 K.C. tracking condenser in the same can as the balance of the assembly. In the new assembly as used in the present models, the 600 K.C. trimmer is mounted separately under the sub-panel. The adjusting screw for this condenser is reached from the top of the chassis. It is just in back of and to the side of the oscillator coil can.





Schematic Circuit Diagram of Early Model

# WELLS-GARDNER & CO.

## Series 40 and Series 40-A


### 8 Tube Super-Heterodyne AC Receivers



270-J

# WELLS-GARDNER & CO.

## SERIES 40-40 A



### Voltages at Sockets

The voltages shown in the chart were taken with a 1,000 ohm per volt voltmeter; voltage measurements taken with a voltmeter having a different resistance will, of course, differ from those shown.

Turn the volume control all the way on, connect the antenna and ground leads together and turn the gang condenser plates all the way out. Check the line voltage.

Tube	Circuit	LINE VOLTAGE				
		90 V.	100 V.	110 V.	120 V.	130 V.
R. F. '35	Screen-Grid Plate	70	78	85	92	100
		143	159	175	191	207
1st Det. '35	Screen-Grid Plate	70	78	85	92	100
		143	159	175	191	207
I. F. '35	Screen-Grid Plate	70	78	85	92	100
		143	159	175	191	207
Oscillator '27	Plate	70	78	85	92	100
2nd Det. '24	Screen-Grid Plate	66	73	80	87	94
		127	134	141	148	155
A. V. C. '24	Grid Screen-Grid	14	15.5	17	18.5	20
		24	26	28	30	32
Audio '47	Accelerating-Grid Plate	199	221	244	267	289
		171	190	210	230	250
Rectifier '80	Current (both plates) Plate to Plate Volt.	67	75	82	89	96
		512	569	625	682	739

### Condenser Alignment

A thorough check of the receiver should be made before any attempt is made to re-align any circuits. Examine the antenna and ground connections. Test all the tubes and check all voltages to determine if the failure of the receiver to operate properly is not due to some fault other than misalignment. A superheterodyne receiver must be accurately aligned to be selective and sensitive. This receiver has been accurately aligned at the factory, and due to the mechanical design of the gang and adjustable condensers, will not lose its alignment unless damaged by abuse or accident.

A modulated test oscillator and an output meter **MUST** be used when aligning this receiver to insure accurate alignment. It is important that the oscillator deliver a signal at exactly 175 K.C. in addition to frequencies in the broadcast band.

The adjustable condensers which tune the primaries and secondaries of the I.F. transformers are adjusted by inserting a screw driver through the holes in the chassis base directly below the I.F. transformer assemblies.

A trimmer condenser is mounted over each section in the gang and is adjusted by turning the screw located under the hole in the top of the gang shield.

The oscillator 600 K.C. tracking condenser is on the back of the chassis near the "QUIET-POWER" switch.

Make each adjustment in the order given below or the receiver may be thrown further out of alignment and it will then be a difficult task to align it properly.

The receiver and test oscillator must be well grounded and the output kept within the range of the output meter at all times.

All shields must be in place when making the adjustments.

**INTERMEDIATE CIRCUITS.**—Tune the test oscillator to exactly 175 K.C., and connect its output to the grid of the first detector tube after removing the clip on the tip of the tube. Connect the output meter across the secondary of the speaker coupling transformer and then adjust all four condensers which tune the intermediate transformers, for the greatest deflection on the output meter. Check the settings of all four condensers to make certain the maximum output has been obtained.

When the above instructions have been followed remove the test oscillator coupling and replace the grid clip on the tip of the first detector tube.

**GANG CONDENSERS.**—Turn the gang condenser plates all the way in and see that the dial pointer is on the first dial division point below 550 K.C.


Tune the test oscillator to 1,400 K.C., turn the dial to read 1,400 K.C., and then adjust each gang condenser trimmer for maximum output.

**OSCILLATOR.**—Tune the test oscillator to 600 K.C., and tune the receiver to the signal. Disconnect the output meter and then rotate the adjusting screw on the oscillator 600 K.C. tracking condenser. Rock the gang condenser back and forth across the signal at the same time, and listen closely until the maximum volume is obtained. The tracking condenser is then properly adjusted and remains fixed thereafter.

The gang condenser trimmers only must then be adjusted again at 1,400 K.C. for maximum output.

The receiver should be accurately aligned if the above instructions have been followed and no further adjustments need be made.

# WELLS-GARDNER & CO. SERIES 50



TURN THE VOLUME CONTROL ALL THE WAY ON, CONNECT THE ANTENNA AND GROUND LEADS TOGETHER AND TURN THE GANG CONDENSER PLATES ALL THE WAY OUT. CHECK THE LINE VOLTAGE.


TUBE	CIRCUIT	LINE VOLTAGE				
		90 V.	100 V.	110 V.	120 V.	130 V.
R. F. '35	Screen-Grid	70	78	85	92	100
	Plate	192	213	234	256	277
Det.-Modulator '24	Screen-Grid	70	78	85	92	100
	Plate	192	213	234	256	277
I. F. '35	Screen-Grid	70	78	85	92	100
	Plate	192	213	234	256	277
2nd Detector '24	Screen-Grid	70	78	85	92	100
	Plate	154	171	187	204	221
Audio '47	Accelerating Grid	199	221	244	267	289
	Plate	181	200	220	240	260
A. V. C. '24	Grid	12.3	13.7	15.1	16.5	17.8
	Screen-Grid	34.5	38.5	42	46	50
Rectifier '80	Plate to Plate	308	342	376	410	445
	Current (both plates)	52.3 MA	58.1 MA	64 MA	69.7 MA	75.5 MA

The voltages shown are measured to the cathode of the heater type tubes and to filament of the '47 Pentode.

# WELLS-GARDNER & CO.

## SERIES 50

R1—25,000 ohm resistor and R3—27,000 ohm resistor formerly were 9,000 ohms and 12,500 ohms respectively. The latter values apply for all sets having Cand-ohm units; the former values for all sets having vitreous enamel units.



### Voltages at Sockets

LINE VOLTAGE 115—ANTENNA LEAD SHORTED TO GROUND—VOLUME CONTROL AT MAXIMUM

Type of Tube	Function	Across Filament or Heater	For early Models with 2-section vitreous enamel resistor.				For later Models with 4-section armoured wire-wound resistor.			
			Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.
'58	R.F.	2.4	282	107	4(1)	8.	258	106	2.8 <sup>(1)</sup>	8.0
'57	1st Det.	2.4	270	100	5	.4	250	103	5	.4
'58	I.F. <sup>(2)</sup>	2.4	282	107	4(3)	8.	258	106	2.8 <sup>(1)</sup>	8.0
'57	A.V.C.	2.4	90	40	9.5	0	103	45	10	0
'57	2nd Det.	2.4	207	98	6	.15	190	101	6	.15
'47	Audio	2.4	262	280	24 <sup>(3)</sup>	31	242	260	17 <sup>(3)</sup>	30
'80	Rect.	4.8				30 per plate				34 per plate

(1) Read Across R-14.

(2) If I.F. readings are made with a cord and plug, ground the control grid through a condenser to prevent oscillation.

(3) Read Across R12 and R14.

### Twenty-five Cycle Receivers

The twenty-five cycle receiver differs from the sixty cycle receiver only in the fact that a different power transformer and an additional filter condenser are used. Also, a slight change is made in the power unit wiring. In the twenty-five cycle set, condenser C-17, the dry electrolytic unit is put in parallel with condenser C-14. An 8.0 mfd. wet electrolytic condenser is put in place of condenser C-17.

The twenty-five cycle chassis can be operated satisfactorily from a sixty cycle power supply. However, the reverse is not true, that is the sixty cycle chassis cannot be operated from a twenty-five cycle power supply.

A 110-220 volt 40-60 cycle power transformer is also available for this model.

### Excessive Hum



Defective tubes are very often the cause of excessive hum. Try out a complete new set of tubes and note any difference. The hum may be due to external pick-up. Disconnect the antenna and ground and see if the hum disappears.

Open filter condensers can cause excessive hum. Inspect these condensers and the leads to them. Other causes of excessive hum are, unequal rectifier plate currents, defects in grid circuits and defective power transformer.

If Microphonic hum or howl is encountered, switch the tubes of the same type around in the sockets and try out some new ones.

# WELLS-GARDNER & CO.

## Models No 92-93



270-J  
Top View of Chassis

TURN THE VOLUME CONTROL ALL THE WAY ON, CONNECT THE ANTENNA AND GROUND LEADS TOGETHER AND TURN THE GANG CONDENSER PLATES ALL THE WAY OUT. CHECK BATTERY VOLTAGES.

TUBE	CIRCUIT	VOLTAGE
R.F. '32	Filament .....	2.
	Screen Grid .....	65.
	Plate .....	127.
	Control Grid .....	1.4
1st Det. & Oscillator '32	Filament .....	2.
	Screen Grid .....	65
	Plate .....	85.
	Control Grid .....	No Reading
I.F. '32	Filament .....	2.
	Screen Grid .....	65.
	Plate .....	125.
	Control Grid .....	5. *
2nd Det '32	Filament .....	2.
	Screen Grid .....	67.
	Plate .....	127.5
	Control Grid .....	3.2
Audio '33	Filament .....	2.
	Screen Grid .....	132.5
	Plate .....	117.5
	Control Grid .....	7.5 **


\*This includes filament voltage.  
\*\*250 v. Scale.

**CAUTION:** Do not attempt to take voltage measurements or test the '33 pentode tube with a set analyzer which is not designed to test that type of tube. A special adaptor is necessary. The latest type analyzers only are designed to test pentode tubes. The UY socket in an analyzer which is used to test '24, '35, and '27 tubes cannot be used to test '33 pentode tubes. A break-in adaptor and the external binding posts of the set analyzer may be used to take voltage measurements when an adaptor is not available.



# WELLS-GARDNER & CO.

## No. 322 Series




### Voltages at Sockets

LINE VOLTAGE 115—ANTENNA SHORTED TO GROUND—NOISE SUPPRESSOR AT MAXIMUM CLOCKWISE POSITION


Type of Tube	Function	Across Filament or Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.	
58	R.F.	2.4	242	90	4 <sup>(1)</sup>	4	
58	1st Det.	2.4	250	86	7 <sup>(1)</sup>	3	
56	Osc.	2.4	24	0	0	8	
58	1st I.F. <sup>(2)</sup>	2.4	252	90	4 <sup>(1)</sup>	4	
58	2nd I.F. <sup>(2)</sup>	2.4	254	91	3	5.7	
56	2nd Det.	2.4	0	0	0	0	
57	1st Audio	2.4	65	55	4 <sup>(3)</sup>	.4	
57	Noise Supp.	2.4	55	20	3 <sup>(1)</sup>	0	
56	2nd Audio	2.4	255		14 <sup>(4)</sup>	3.3	
46	Power	2.4	260	260	34	23	
82	Rectifier	2.4	880 volts plate to plate			53	per plate

- (1) Read from cathode to ground.
- (2) If I.F. readings are made with a cord and plug, ground the control grid through a condenser to prevent oscillation and motor boating.
- (3) Read across 30 ohm section of voltage divider.
- (4) Read across 30 ohm and 100 ohm section of voltage divider.



# WELLS-GARDNER & CO.

## No. 352 Series




### Voltages at Sockets


LINE VOLTAGE 115 — VOLUME CONTROL AT MAXIMUM — ANT. SHORTED TO GND.

Type of Tube	Function	Across Filament or Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M.A.
'57	1st Det.	2.15	225	90	4	.5
'35	I.F.	2.15	230	90	3.2 <sup>(1)</sup>	6.2
'57	2nd Det.	2.15	170	90	4.3	.2
'47	Audio	2.15	225	240	14 <sup>(2)</sup>	23.
'80	Rect.	4.75	620 volts plate to plate			20. per plate



(1) If read with cord and plug, ground the control grid.  
 (2) Computed figure—cannot be accurately read with ordinary voltmeter. Voltage consists of drop across 1 megohm resistor, R 8.



Terminal Arrangement of 57 and 58 Tubes



# WELLS-GARDNER & CO. No. 502 Series





### Voltages at Sockets

LINE VOLTAGE, 115 — ANTENNA LEAD SHORTED TO GROUND

Type of Tube	Function	Across Filament or Heater	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M.A.
58	R.F.	2.4	275	100	4.2 <sup>(1)</sup>	5.2
57	1st Det.	2.4	265	99	5.4	.9
56	Osc.	2.4	28		0	8.6
58	1st I.F.	2.4	275	100	4.2 <sup>(1)</sup>	5.2
58	2nd I.F.	2.4	275	102	3.0	8.5
56	2nd Det.	2.4	0		0	0
57	1st Audio	2.4	12	102	3.0 <sup>(1)</sup>	1.8
47	Output	2.4	265	280	18.5 <sup>(2)</sup>	30.0
80	Rect.	4.9				55.0 per plate

(1) Measured from cathode to ground.  
(2) Measured across Resistor R6.

# WELLS-GARDNER & CO. No. 572 Series



### Change in Later Models

In the first models of this chassis, resistors R-1 and R-3 were carbon resistors of the values as shown in Fig. 1. Resistors R-12 and R-14, were in one vitreous enamel unit. The voltages for the sets with these resistors are shown in the voltage chart on Page 4 at the left.


In later models the four above mentioned resistors were replaced by one armored wire wound resistor unit. New values are used as follows:

Code	Resistance
R-12	220 ohms
R-14	40 ohms
R-1	9,540 ohms
R-3	10,650 ohms

The voltages for the sets with the four-section wire wound resistor are shown in the second voltage chart

# WELLS-GARDNER & CO.

## No. 872 Series



### Voltages at Sockets

LINE VOLTAGE 115—ANTENNA LEAD SHORTED TO GROUND—VOLUME CONTROL AT MAXIMUM

Type of Tube	Function	Across Filament or Heater	For early Models with 2-section vitreous enamel resistor.				For later Models with 4-section armoured wire-wound resistor.			
			Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.	Plate to Cathode	Screen to Cathode	Grid to Cathode	Normal Plate M. A.
'58	R.F.	2.4	282	107	4 <sup>(1)</sup>	8.	258	106	2.8 <sup>(1)</sup>	8.0
'57	1st Det.	2.4	270	100	5	.4	250	103	5	.4
'58	I.F. (2)	2.4	282	107	4 <sup>(1)</sup>	8.	258	106	2.8 <sup>(1)</sup>	8.0
'57	A.V.C.	2.4	90	40	9.5	0	103	45	10	0
'57	2nd Det.	2.4	207	98	6	.15	190	101	6	.15
'47	Audio	2.4	262	280	24 <sup>(3)</sup>	31	242	260	17 <sup>(3)</sup>	30
'80	Rect.	4.8				30				34
						per plate				per plate

(1) Read Across R-14.

(2) If I.F. readings are made with a cord and plug, ground the control grid through a condenser to prevent oscillation.

(3) Read Across R12 and R14.

### Condenser Alignment

Misalignment or mistracking of condensers generally manifests itself in broad tuning and lack of volume at portions or all of the broadcast band. The receivers are all properly aligned at the factory with precision instruments and realignment should not be attempted unless all other possible causes of the faulty operation have first been investigated and unless the service technician has the proper equipment. A signal generator that will provide an accurately calibrated signal of 175 K.C. and accurately calibrated

signals over the broadcast band, and an output indicating meter are necessary. The procedure is as follows:

Set the signal generator for 175 K.C. Connect the signal lead from the signal generator to the grid of the 1st detector tube through a .05 mfd. condenser. Turn the tuning condenser rotor until the plates are completely out. The ground lead from the signal generator goes to the ground lead of the receiver. Then adjust the four intermediate frequency condensers for maximum output. The adjusting screws for these condensers are reached from the bottom of the chassis.















# THE RUDOLPH WURLITZER MFG. CO.




**NOTE: ALL VOLTAGE READINGS LISTED ARE TAKEN WITH ALL CONTROLS TURNED ON FULL AND NO SIGNAL - USE 1000<sup>Ω</sup> PER VOLT - VOLTMETER.**



SERVICE SCHEMATIC MODEL S-50


# THE RUDOLPH WURLITZER MFG. CO.



NOTE: ALL VOLTAGE READINGS LISTED ARE TAKEN WITH ALL CONTROLS TURNED ON FULL AND NO SIGNAL. USE 1000 OHM PER VOLT-VOLTMETER

9		02		010		03
1		0		0		00
7		04		05		06


POWER TRANSFORMER  
TERMINAL BOARD.




SERVICE SCHEMATIC **LYRIC** MODEL S-63



# THE RUDOLPH WURLITZER MFG. CO.




NOTE: ALL VOLTAGE READINGS LISTED ARE TAKEN WITH ALL CONTROLS TURNED ON FULL AND NO SIGNAL - USE 1000W PER VOLT - VOLTMETER.




SERVICE SCHEMATIC **LYRIC** MODEL SA-90

# THE RUDOLPH WURLITZER MFG. CO.




NOTE: ALL VOLTAGE READINGS LISTED ARE TAKEN WITH ALL CONTROLS TURNED ON FULL AND NO SIGNAL - USE 1000<sup>m</sup> PER VOLT - VOLTMETER.

20 V. WHEN TURNED ALL WAY TO LEFT.





POWER TRANSFORMER TERMINAL BOARD




SERVICE SCHEMATIC **LYRIC** MODEL SA-91

# THE RUDOLPH WURLITZER MFG. CO.

## SERVICE SCHEMATIC **LYRIC** MODEL SA-130




DOTTED LINES SHOW CONNECTIONS FOR PHONE JACK AND SWITCH INSTALLATION




POWER TRANSFORMER TERMINAL BOARD




THE RUDOLPH WURLITZER MFG. CO.



NOTE: ALL VOLTAGE READINGS LISTED ARE TAKEN TO GND.  
 WITH ALL CONTROLS TURNED ON FULL AND NO  
 SIGNAL - USE 1000 $\omega$  PER VOLT - VOLTMETER.




SERVICE SCHEMATIC **LYRIC** MODEL SW-80







# ZENITH RADIO CORP.



# ZENITH RADIO CORP.

Socket Voltages

Models 215-216-225


Tube Type	Position	Fil. Volt.	Plate Volt.	Cath. Volt.	Screen Volt.	Supp. Volt.	Plate Current
Z-58	R.F.	2.5	270	8	107	8	5.8
Z-58	1st Det.	2.5	270	10	107	10	4.7
Z-56	Osc.	2.5	140	0	-	-	4.8
Z-58	I.F.	2.5	170	6	107	8	5.5
Z-55	2nd Det. AVC	2.5	70	7	-	-	1.4
Z-59	Power	2.5	250	0	250	0	26.
Z-80	Rect.	5.	360ea	-	-	-	34.ea.

Line 115 Volts

All Controls Maximum

(All readings, with exception of heaters and rectifier plates taken from socket connections to ground. Use 1,000 ohm per volt D.C. meter. Antenna disconnected).

BALANCE I.F. frequency at 175 K.C. Condenser gang at 1500 K.C. and oscillator padder at 600 K.C.



## ZENITH RADIO CORP.

MODELS 215 216 225

CHASSIS 2044

11-3	Dial Cord.....	per ft.	\$ .10
22-166	Three Gang Variable Condenser.....		3.50
26-38	Celluloid Dial Strip.....		.10
80-69	Dial Cord Tension Spring.....		.01
80-89	Dial Cord Guide Spring.....		.01
100-18	2½ Volt Dial Lamp.....		.12
S-2238	Dial Drum Assembly.....		.80
22-82	.001 mfd. 500 volt.....(2nd Det. Plate).....		.20
* 22-115	.1 " 200 " .....(5 Used. See Footnote).....		.35
22-117	.5 " 300 " .....(Screen Bypass).....		.50
22-137	.05 " 400 " .....(Oscillator Plate).....		.25
22-147	.0005 " 600 " .....(2nd Det. Cathode).....		.20
22-161	Padder.....		.45
* 22-170	.1 mfd. 400 volt.....(Four Used. See Footnote).....		.25
22-171	.05 " 600 " .....(Tone Control).....		.25
22-173	8. " 500 " .....(Filter).....		1.25
22-196	.01 " 600 " .....(Tone Control).....		.12
63-121	100M ohm.....(2nd Det. Plate).....		.25
63-136	50M " .....(RF Grid, 2nd Det. Plate).....		.25
63-137	250M " .....(Osc. Bias, Power Grid).....		.25
63-140	1Meg " .....(Grid).....		.25
63-160	100M " .....(2nd Det.).....		.25
63-232	Tone Control.....		.75
63-235	Volume Control.....		1.25
63-239	24M ohm.....(Oscillator Plate).....		.25
63-244	500 " .....(1st Det. Cathode).....		.25
63-254	5M " .....(2nd Det. Grid).....		.25
63-255	Sensitivity Control.....		.75
63-256	6950 ohm.....(Voltage Divider).....		.45
63-257	8350 " .....(Voltage Divider).....		.40
63-258	490 " .....(1st Det. & I.F. Grid Return).....		.25
20-30	Antenna Coil.....		.75
20-31	Oscillator Coil.....		.85
20-32	Detector Coil.....		1.00
S-2118	1st I.F. Coil Assembly..(Without Grid Lead).....		1.75
S-2611	2nd I.F. Coil Assembly..(With Grid Lead).....		1.75
S-2252	Detector Plate Choke.....		.60
* 22-115	RF Grid; RF 1st Det. and IF Cathode; 1st Det. Suppressor; 1st Det. IF Grid Return and Power Choke.		
* 22-170	2nd Det. Plate; 2nd Det. Grid Filter & Audio Coupling.		
46-61	Large Tuning Knob.....	\$ .10	
46-62	Small Control Knob.....	.10	
49-55	Dynamic Speaker for Model 215 and 216.....	7.00	
49-56	Dynamic Speaker for Model 225.....	8.00	
52-37	Speaker Multicable.....	.25	
57-370	Escutcheon Plate.....	.30	
78-56	Type 59 Tube Socket.....	.15	
78-57	Type 56 Tube Socket.....	.15	
78-58	Type 58 Tube Socket.....	.15	
78-60	Type 80 Tube Socket.....	.15	
78-61	Type 55 Tube Socket.....	.15	
93-167	Upper Cushion Washer for Chassis Mounting.....	.01	
95-153	Regular 117 volt 60 cycle Power Transformer.....	5.25	
95-154	Combination 240 volt 117 volt 60 cycle Power Transformer.....	5.25	
95-155	Regular 117 volt 25 cycle Power Transformer.....	7.50	
126-109	Tube Shields.....	.10	
15-16	Tube Shield Cap in AVC Tube.....	.05	



# ZENITH RADIO CORPORATION



Socket Voltages

Models 230-240-245


Tube Type	Position	Fil. Volt.	Plate Volt.	Cath. Volt.	Screen Volt.	Supp. Volt.	Plate Current
Z-58	R.F.	2.4	190	0	95	0	7.
Z-58	1st Det.	2.4	190	2.3	95	2.3	4.
Z-56	Osc.	2.4	100	0	-	-	4.
Z-58	I.F.	2.4	190	0	90	0	2.
Z-57	2nd Det.	2.4	90	-60	70	-60	.2
Z-57	A.V.C.	2.4	-10	-65	-2	-65	0
Z-59	Power	2.4	175	-70	165	-70	25
Z-80	Rect.	5.	*350	-	-	-	*36

Line 115 Volts

All Controls Maximum

(All readings, with exception of heaters, taken from socket connections to ground. Use 1,000 ohm per volt D. C. meter.)

BALANCE I.F. frequency at 175 K.C. Condenser gang at 1500 K.C. and oscillator pad-der at 600 K.C.



TUBE LAYOUT MODELS 230-240-245



# ZENITH RADIO CORPORATION

PARTS AND PRICES

MODELS 230 240 245

Dial Assembly

S-769	Dial Lamp Socket and Bracket (less lamp).....	\$ .15
S-2238	Dial Drum Assembly.....	.80
S-2248	Small Hypoid Gear Complete with Drive Shaft.....	1.25
11-3	Pulley String.....per ft.	.10
26-38	Celluloid Dial Strip.....	.10
34-23	Hypoid Drum Gear (large).....	1.00
34-24	Hypoid Drum Gear (small).....	1.00
80-69	Dial String Tension Spring.....	.01

Condensers

22-112	.1 mfd 300 V.(2nd Detector Screen & Power Grid).....	.25
22-113	.5 " .....(R.F.1st Detector & I.F.Grid Return).....	.35
*22-115	.1 " 200 V.(Four used, see below).....	.35
22-117	.5 " .....(R.F.1st Detector, & I.F. Screen).....	.50
22-137	.05 " 400V..(Oscillator Plate).....	.25
22-147	.0005" 600 V.(2nd Detector Plate & AVC Screen).....	.25
22-161	Padder.....	.45
22-166	Three Gang Variable.....	3.50
22-170	.1 mfd 400 V.(R.F. & 1st Detector Plate, 2nd Det. Plate)..	.35
22-171	.05 " 600 V.(Tone Control).....	.25
22-172	2. " 450 V.(Filter).....	.60
22-173	8. " 500 V.(Filter).....	1.25
22-175	.002 " 600 V.(A.V.C. Plate).....	.25

Resistors

63-121	100M ohm 1 Watt.....(2nd Detector Plate).....	.25
63-135	25M " " .....(2nd Detector Cathode).....	.25
63-136	50M " " .....(2nd Detector Grid Return).....	.25
63-137	250M " " .....(Oscillator & Power Grid).....	.25
63-140	1 meg " " .....(A.V.C. Screen).....	.25
63-160	100M " " .....(A.V.C. Plate, 2nd Detector Screen)..	.25
63-169	400M " " .....(A.V.C. Grid).....	.25
63-232	Manual Tone Control.....	.75
63-233	Manual Sensitivity Control.....	.75
63-235	Manual Volume Control.....	1.25
63-239	24M ohm 1 Watt.....(Oscillator Plate).....	.25
63-241	5M " 1 " .....(R.F., 1st Detector., I.F. Screen)...	.25
63-244	500 " $\frac{1}{4}$ " .....(1st Detector Cathode).....	.25
63-251	Voltage Divider.....(six tap).....	.65
63-252	Voltage Divider.....(five tap).....	.60

Chokes and Coils

S-2118	I.F. Coil Assembly.....	1.75
S-2437	Antenna Coil Assembly.....	.75
S-2438	Oscillator Coil Assembly.....	.85
S-2439	Detector Coil Assembly.....	.30
S-2252	Plate Choke and Bracket Assembly.....	.50
S-919	2nd Detector Choke Assembly.....	.60
*22-115	I.F. Cathode, 2nd Detector Grid Return, 1st and 2nd Detector Cathodes.	



# ZENITH RADIO CORP.



Socket Voltages

Models 250-260-272

Tube Type	Position	Fil. Volts	Plate Volts	Cath. Volts	Screen Volt.	Supp. Volt.	Plate Current
Z-58	R.F.	2.4	240	4	110	4	6.2
Z-24	1st Det.	2.4	235	8	110	-	.5
Z-57	S.W. 1st Det.	2.4	235	6	150	6	.5
Z-27	S.W. Osc.	2.4	150	10	-	-	5.
Z-27	Osc.	2.4	110	0	-	-	9.
Z-58	I.F.	2.4	235	3	110	3	8.
Z-27	2nd Det.	2.4	35	4	-	-	1.8
Z-47	PWR.	2.4	215	-	230	-	28.
Z-80	Rect.	5.	110 ea. to grd.				34. ea


Line 115 Volts

All Controls Maximum

(All readings, with exception of heaters, taken from socket connections to ground. Use 1,000 ohm per volt D.C. meter.)

**BALANCE - Standard Wave.** I.F. 175 K.C. Tuning condenser (three rear sections) 1500 K.C. Oscillator padder 600 K.C.

**Short Wave.** Set 1,000 K.C. adjustment shaft to the center of its tuning range and balance Short Wave I.F. trimmers (1, 2, and 3) to 1,000 K.C. with S.W. oscillator tube removed. Insert tube and place S.W. tuning on scale by adjusting S.W. oscillator trimmer on condenser gang until a station on the 1.5 to 3.75 megacycle band is resonated at its corresponding frequency on the dial.



Tube Position.

## ZENITH RADIO CORPORATION

Dial Assembly

11-3	Dial Cord.....	per ft.	\$ .10
12-251	Dial Slide Support Bracket.....		1.25
61-23	Dial Cord Pulley.....		.15
73-8	Dial Collar Set Screw.....		.01
80-77	Dial Cord Tension Spring.....		.01
84-41	Dial Lamp Support Slide.....		.60
S-2137	Dial Pointer Mask Assembly.....		1.70
S-2164	Dial Vernier Tuning Shaft and Bracket.....		1.50
S-2165	Dial Gear and Bushing Assembly.....		1.50
S-2166	Dial Strip Support and Strip Assembly.....		2.00

Condensers

22-82	.001 Mfd 500 volt.....	(Power Plate).....	.20
22-111	.03 " 600 " .....	(Filter).....	.20
22-112	.1 " 300 " .....	(S.W. Det. Screen).....	.25
22-113	.5 " 200 " .....	(2nd Det. Plate).....	.35
22-115	.1 " 200 " .....	(3 Used, See Below).....	.35
22-117	.5 " 300 " .....	(R.F. Det. & I.F. Screen).....	.50
22-137	.05 " 400 " .....	(3 Used, See Below).....	.25
22-138	.2 " 200 " .....	(Power Grid).....	.25
22-147	.0005 " 600 " .....	(2 Used, See Below).....	.25
22-153	Short Wave Variable Trimmer.....		1.00
22-155	Three Gang Variable Trimmer.....		2.40
22-156	6. Mfd Electrolytic.....	(Filter).....	1.25
22-157	8. " Electrolytic.....	(Filter).....	1.50
22-158	Three Section Padder.....		.75
22-160	Five Gang Variable Tuning Condenser.....		7.00
22-161	Single Padder.....		.45
22-162	.0001Mfd 600 volt.....		.20


Resistors

63-121	100M ohm 1 watt.....	(Det. Plate).....	.25
63-135	25M " $\frac{1}{2}$ " .....	(2 Used, 1st & 2nd Det. Cathode).....	.25
63-139	500M " " .....	(2 Used, Power Grid, Osc. Grid).....	.25
63-146	2M " " .....	(S.W. Osc. Grid, 2nd Det. Cathode).....	.25
63-160	100M " " .....	(Power Grid).....	.25
63-167	8M " 1 " .....	(S. W. Det. Cathode).....	.25
63-199	150 " .....	(R.F., I.F. Cathode).....	.25
63-200	Tone Control.....		.80
63-207	10M ohm $\frac{1}{2}$ watt.....	(Voltage Divider).....	.30
63-208	12M " .....	(Voltage Divider).....	.25
63-209	Volume Control and Switch Assembly.....		1.25
63-230	15M ohm .....	(S. W. Det. Screen).....	.35
22-115	S.W. Coupling, S.W. Oscillating Filter, and R.F. Cathode		
22-137	1st Detector Cathode, Audio Coupling, and Tone Control		
22-147	2nd Detector Plate		
S-919	2nd Detector Plate Choke.....		\$ .60
S-1193	S.W. Detector Plate Choke.....		.60
S-2117	2nd I.F. Coil Assembly.....	(No Grid Lead).....	1.75
S-2118	1st I.F. Coil Assembly.....	(With Grid Lead).....	1.75
S-2161	Detector S. W. Coil.....	(Mounted above Chassis).....	1.25
S-2162	Oscillator S. W. Coil.....	(Mounted under Chassis).....	1.25
S-2167	1st R.F. Coil Assembly.....		1.25
S-2169	Oscillator Coil L.W.....		.80
S-2171	1st Detector Coil L.W.....		1.25

# ZENITH RADIO CORPORATION

ZENITH RADIO CORP.  
 CHICAGO, ILL.  
 10-TUBE SUPERHETERODYNE  
 MODELS 410-411-420  
 P.A.C. 7-22-32

I.F. FREQUENCY  
 175 KC.



95-134 60 V  
 95-135 25 V

TO 115 OR 230 VOLT A.C.

2-AMP FUSE - 115-V.  
 1-AMP FUSE - 230-V.  
 ON-OFF SWITCH

ALL PILOT LIGHTS

TUNING INDICATOR  
 MOD. 40-411, MS-201  
 MOD. 420, MS-174

# ZENITH RADIO CORPORATION



Socket Voltages

Models 410-411-420



Tube Type	Position	Fil. Volt.	Plate Volt.	Cath. Volt.	Screen Volt.	Supp. Volt.	Plate Current
Z-58	R.F.	2.5	220	0	100	0	5.2
Z-58	1st Det.	2.5	220	+2	100	+2	3.
Z-56	Osc.	2.5	120	0	0	*	4.
Z-58	I.F.	2.5	220	0	100	0	6.
Z-56	2nd Det.	2.5	120	20	0	*	.75
Z-57	A.V.C.	2.5	-40	-75	-2	-75	0
Z-59	Driver	2.5	220	+25	220	+220	8.2
Z-59	Power	2.5	230	-65	230	+230	25.
Z-59	Power	2.5	230	-65	230	+230	25.
Z-80	Rect.	5.0	400*				62.5*

Line 115 Volts


All Controls Maximum

(All readings, with exception of heaters, taken from socket connections to ground. Use 1,000 ohm per volt D. C. meter).

BALANCE I.F. frequency at 175 K.C. Condenser gang at 1500 K.C. and oscillator padder at 600 K.C.



**SOCKET CONNECTIONS**



Model 420

SOCKET LAYOUT

Models 410-411

# ZENITH RADIO CORPORATION

PARTS AND PRICES  
 MODELS 410 411 420  
 CHASSIS #2030 - 2043

## Dial and Meter Assembly

11-3	Dial Pulley String.....per ft.	\$ .10
26-37	Dial Strip.....	.15
34-23	Large Hypoid Gear (Model 420 Only).....	.30
34-24	Small Hypoid Gear (Model 420 Only).....	.15
59-16	Volume Control Pointer.....	1.00
59-17	Tone Control Pointer.....	1.00
80-69	Dial String Tension Spring.....	.01
80-84	Volume and Tone Control Pointer Spring.....	.01
80-86	Volume and Tone Control Friction Spring.....	.01
83-272	Volume Control Dial Strip.....	.10
83-273	Tone Control Dial Strip.....	.10
83-277	Pointer Guide Strip.....	.01
100-18	Pilot Lamp.....	.12
122-6	Shadowgraph Meter.....	2.00
S-2255	Tone Control Pointer Cam.....	.25
S-2256	Volume Control Pointer Cam.....	.25
S-2265	Dial Drum Assembly.....	1.00

## Condensers

22-112	.1 mfd 300 volt (Filter).....	.25
22-115	.1 " 200 " (Six used, see footnote).....	.35
22-117	.5 " 200 " (Filter).....	.50
22-127	.000025 600 " (A. V. C. Grid).....	.35
22-137	.05mfd 400 " (Oscillator Plate).....	.25
22-142	.4 " 300 " (Filter 25 Cycle Only).....	.40
22-147	.0005 600 " (2nd Detector Plate).....	.20
22-161	Padder.....	.45
22-166	Three Gang Variable.....	3.50
22-167	8. mfd 500 volt (Filter).....	1.50
22-169	8. " 50 " (2nd Det. and Driver Cathodes).....	.55
22-170	.1 " 400 " (1st Det. plate, Audio Coup., Tone Control)..	.25
22-175	.002" 600 " (1st Det. cathode - Models 410-411 only).....	.20

## Resistors

63-121	100M ohm 1 watt (2nd Detector Plate).....	.25
63-135	50M " 1 " (2nd Detector Cathode).....	.25
63-137	250M " $\frac{1}{2}$ " (Oscillator Grid).....	.25
63-140	1 meg" $\frac{1}{2}$ " (A. V. C. Grid).....	.25
63-169	400 " $\frac{1}{2}$ " (A. V. C. Plate).....	.25
63-231	Volume Control Assembly.....	1.25
63-232	Tone Control Assembly.....	.75
63-233	Sensitivity Control.....	.75
63-236	500 ohm.....(Power Bias) (Wide Metal).....	.25
63-237	1500 " .....(Driver Bias) (Narrow Metal).....	.25
63-238	1M " $\frac{1}{4}$ watt (1st Detector Cathode).....	.25
63-239	24M " 1 " (Oscillator Plate).....	.25
63-240	1900 " $\frac{1}{4}$ " (R.F., 1st Detector and I.F. Grids).....	.25
63-242	2500 " $\frac{1}{2}$ " (A. V. C. Cathode).....	.25
63-243	18M " 1 " (A. V. C. Cathode).....	.25
63-244	500 " $\frac{1}{4}$ " (Acoustic Filter).....	.25

\*22-115 R. F., 1st Detector, I. F. Grid Return, I. F. Cathode, Acoustic Filter, (1st Detector Cathode Model 420 Only).

## ZENITH RADIO CORPORATION

PARTS AND PRICES  
MODELS 410 411 420

CHASSIS #2030 2043  
PAGE - 2 -

## Coils

20-30	Antenna Coil.....	\$ .75
20-31	Oscillator Coil.....	.85
20-32	Detector Coil.....	1.00
S-2252	Plate Choke and Bracket.....	.50
95-132	1st I. F. Transformer (With Grid Lead).....	1.25
95-138	2nd I. F. Transformer (Without Grid Lead).....	1.25
Miscellaneous		
46-49	Large Control Knob.....	.20
46-55	Small Control Knob.....	.15
49-47	Dynamic Speaker with Transformer.....	7.00
49-48	Dynamic Speaker without Transformer.....	8.25
52-35	Speaker Multicord.....	.35
57-341	Escutcheon Plate.....	.35
78-56	Type 59 Socket.....	.15
78-57	Type 56 Socket.....	.15
78-58	Type 58 Socket.....	.15
78-59	Type 57 Socket.....	.15
78-60	Type 80 Socket.....	.15
93-167	Upper Cushion Washer for Chassis Mounting.....	.01
93-168	Lower Cushion Washer for Chassis Mounting.....	.01
95-134	115 Volt 50-60 Cycle Power Transformer.....	5.50
95-136	115 Volt 25-30 Cycle Power Transformer.....	7.75
95-149	Acoustic Filter Choke.....	.30
126-109	Small Tube Shield.....	.10
136-2	2 amp Fuse.....	.06
MS-174	Power Choke (Model 420 Only).....	3.25
MS-200	Push Pull Input Transformer.....	3.50
MS-201	Power Choke (Models 410-411 Only).....	3.25

PARTS AND PRICES  
(Page - 2)

MODELS 230 240 244 245

## Miscellaneous

46-49	Large Knob for Model 240 - 245.....	\$.15
46-55	Small Knob for Model 240 - 245.....	.15
46-61	Large Knob for Model 230.....	.10
46-62	Small Knob for Model 230.....	.10
49-45	Dynamic Speaker for Model 240 - 245 (without transformer)..	6.00
49-46	Dynamic Speaker for Model 240 - 245 (with transformer)....	8.00
49-49	Dynamic Speaker for Model 230.....	7.00
52-32	Speaker Multicord.....	.35
57-326	Escutcheon Plate for Model 230.....	.30
57-353	Escutcheon Plate for Model 240 - 245.....	.30
78-56	59, 7 Prong Tube Socket.....	.15
78-57	56, 5 Prong Tube Socket.....	.15
78-58	58, 6 Prong Tube Socket.....	.15
78-59	57, 6 Prong Tube Socket.....	.15
78-60	80, 4 Prong Tube Socket.....	.15
95-140	110 Volt 50 - 60 cycle Power Transformer.....	5.00
95-141	110 Volt 25 - 30 cycle Power Transformer.....	6.75
95-150	110 Volt - 220 Volt 50 - 60 Cycle Power Transformer.....	5.00
136-2	2 amp Fuse.....(For 110 Volt Transformer).....	.06
136-4	1 amp Fuse.....(For 220 Volt Transformer).....	.06
126-109	Tube Shield.....(Small).....	.10
MS-196	Tube Shield.....(Large for Model 240 - 245 only).....	1.25
S-1183	Antenna and Ground Mounting Plate Assembly.....	.25



# ZENITH RADIO CORPORATION

## ZENITH MODELS 430 AND 440 12-TUBE SUPERHETERODYNE

(Dual reproducers, Zenith class AAA A.F. power amplifier; illuminated auto type full-vision control escutcheons; 540 to 1750 kc.—121 channels, including police band; silent tuning; A.V.C.; low-volume tone compensator; "shadowgraph" tuning; tone control; 110 V. or 220 V. line.)

The newest product of Zenith Radio Corp. is the model 430 receiver; equipped with the Zenith automatic tuning device, it is the model 440. The outstanding feature of this set is the "class AAA" system of A.F. amplification used.

Tube Type	Fil. Volts	C-G Volts	S-G Volts	Sup.-G Volts	Plate Volts	Plate Ma.
V1	2.5	2.2	75	2.2	175	5.7
V2	2.5	4.5	75	4.5	190	2.3
V3	2.5	0	.....	.....	100	3.5
V4	2.5	2.2	75	2.2	200	5.5
V5	2.5	10	.....	.....	110	.3
V6	2.5	80	.....	.....	170	.8
V7	2.5	20	190	190	190	.....
V8	2.5	-70	195	195	195	.....
V9	2.5	-70	195	195	195	13
V10	2.5	-85	.....	-85	.....	22
V11	2.5	13	75	13	30	22
V12	5.0	.....	.....	.....	360	65

Line potential, 115 V.; all controls maximum. All tube readings, except heaters, are socket to ground, using 1,000-ohms-per-volt D. C. meter.

Resistor R1, manual volume control, 0.5-meg., total, tapped at 0.4-meg. from ground end; R2, tone control, 0.5-meg.; R3, quiet-tuning control, 400 ohms; R4, R6, R10, 1,900 ohms; R5, 150 ohms; R7, R25, 1,500 ohms; R8, R17, 0.25-meg.; R9, R16, 24,000 ohms; R11, R12, 50,000 ohms; R13, 0.1-meg.; R14, R18, 500 ohms; R15, 8,000 ohms; R19, R20, 1-meg.; R21, 2,500 ohms; R22, 18,000 ohms; R23, R24, 400 ohms.

Condensers C1, C2, C3, tuning gang; C1A, C2A, C3A, tuning trimmers; C4 to C7, I. F. trimmers; C8, L. F. padder; C9, H. F. coupling condenser; C10, C11, C12, .2-mf.; C13, 0.1-mf.; C14, C15, C16, C17, C19, C20, C24 (25 cycles, 0.4-mf.), C30, C31, C35, .1-mf.; C18, .05-mf.; C21, C22, C23, C25, C26, C27, 8 mf.; C28, 0.5-mf.; C29, 25 mmf.; C32, C33, 500 mmf.; C34, .002-mf.

The condenser gang in this receiver is aligned at 1,500 kc.; the oscillator padder is aligned at 600 kc.

Field coil No. 1 has a resistance of 1,600 ohms; field coil No. 2 has a resistance of 2,000 ohms for section A and 3,500 ohms for section B. Choke Ch.2 has a resistance of 400 ohms.

There are no circuit changes or switches in this receiver for the reception of police calls. The tuning dial, itself, actually takes in the

police frequencies since it covers a total range of 540 to 1,750 kc.

"Shadowgraph" tuning is effected by means of a vane fastened to a meter movement connected in the plate supply circuit to tubes V1, V2, V3. The incoming signal causes this "meter" to move in the usual manner, thus twisting the vane so that it either obstructs the light and casts a wide shadow (off resonance), or permits the light to pass, casting a shadow no wider than the thickness of the vane (exact resonance of the tuned circuits).

Class AAA A.F. amplifier is the Zenith designation for a system employing three power tubes, each of which are biased as class A amplifiers, one of which is used to drive the other two in push-pull. If the grids were overdriven with the usual type of coupling transformer, having a high secondary impedance, between the driver and the output tubes and the push-pull grids overdriven, extreme distortion would take place. This difficulty is overcome by employing a special transformer of step-down ratio having larger wire and much less resistance in its secondary. This transformer is a very important part of the system. With such an arrangement it is possible to drive the grids of the power tubes positive without introducing distortion, because of the driver being a power tube and capable of supplying the necessary current on such peaks. The primary of this transformer has a higher impedance than is normally used, which value is somewhat reduced as the impedance changes in the secondary, when the power grids are driven positive. Its impedance, how-


ever, at the lowest value, still matches the driver plate circuit. It should be remembered that in an ordinary class A amplifier distortion enters when the grids are driven positive by virtue of the previous tube not supplying sufficient power for grid excitation of the output tubes. In other words, in class A, voltage on the power grids is available as long as they do not go positive. As soon as they are driven past zero in that direction the previous amplifier can no longer supply the necessary power.

Summing up the above, the triple A amplifier is a combination of both class A and class B. The exception being that the tubes are biased as class A, but by virtue of the power delivered by the driver and the special coupling transformer, sufficient power is supplied for the power tube to draw grid current and still prevent distortion as in the class B amplifier.



Many set analyzers will not accommodate the new tubes, consequently, all voltage readings are to ground. Thus, for instance, the actual voltage on the plates of the power tubes is 295 V.

The two reproducers are similar in construction but one is peaked at 90 cycles and the other at 70 cycles. (This is done to cancel the natural period of each reproducer.) The paralleled voice coils result in four times the power obtainable from a single reproducer, states the manufacturer.

An overall sensitivity of less than one-half microvolt-per-meter is obtained with an undistorted power output of 15 watts. The total line consumption at 115 V. is 125 W.




Above, Arrangement of the tubes in the "430." Right, Comparative figures indicating the effectiveness of A.F. amplifiers classes A, push-pull; B, push-push; pentodes in push-pull, and AAA, push-pull. Watts rating, respectively, 4.3 W., 0.8- to 24 W., 6.3 W., 14.2 W.



I.F. = 175 KC.

SW. IS GANGED WITH R1.

# ZENITH RADIO CORP.



TUBE OPERATING VOLTAGES

Position	Tube	E <sub>f</sub>	E <sub>k</sub>	E <sub>g<sup>1</sup></sub>	E <sub>g<sup>2</sup></sub>	E <sub>g<sup>3</sup></sub>	E <sub>p</sub>
1st Detector	6C6	4.8	6.5	0	6.5	120	150
1st I.F. Amp.	6D6	5.3	10.5	*	10.5	103.5	165
2nd I.F. Amp.	6D6	5.3	10.5	*	10.5	103.5	165
2nd Detector	85	5.3	8.	0	—	—	156
P. P. Audio	89	5.3	17.	0	17.	165	165
	89	5.3	17.	0	17.	165	165

f—Filament. k—Cathode. g<sup>1</sup>—Control grid. g<sup>2</sup>—Suppressor grid. g<sup>3</sup>—Screen grid. p—Plate.  
 \*Depends on applied signal strength. All voltages measured from indicated points to ground.


# ZENITH RADIO CORP.

## Alignment

Every Zenith Automobile receiver is balanced on an accurate, temperature controlled crystal oscillator before leaving the factory and unless a part is changed or the calibration has shifted, the adjustments should not be tampered with. Where it is absolutely necessary, however, a good test oscillator capable of delivering a modulated signal at 1500, 600 and 485 K.C. will be required.

To balance the I.F. circuit remove the cap and lead from the grid of the 6C6 tube in the control head and attach the test oscillator to the grid and to ground. Set to 485 K.C. and first adjust the primary I.F. trimmer shown (A) in Figure 1. Next trim the secondary (B). Now turn the plate trimmer (C) on the side of the chassis base to resonance, with a No. 4 Spintite wrench. Its (2nd I.F.) transformer is directly above the adjustment. Set the screw (D) in the top of the transformer shield to resonance also. The third I.F. transformer is adjusted through a hole in the rear of the chassis and also on top of the transformer indicated at E and F. This completes the I.F. circuit. Replace the grid lead on the 6C6 and screw the metal cap back in position.


Next attach the test oscillator to the antenna and ground lead of the control head and set it to 1500 K.C. Remove the control head cover and set the variable condenser trimmers (G and H) to a point where the 1500 K.C. signal is loudest at that frequency on the dial. Then set the test oscillator to 600 K.C. and rock the dial slowly at that frequency; at the same time turn the padder condenser adjusting screw. This trimmer is reached by removing the button plug on the bottom of the control head. The adjustments should be gone over twice to insure greater precision. Provided the test equipment is dependable, the entire receiver will now be in proper alignment and the calibration very accurate.



The following is a list of performance factors which information may be of assistance where accurate measurements are essential.

Intermediate Frequency	485 K.C.
Sensitivity in Microvolts	1.5
Power in Milliwatts	2200
Power Consumption in Watts	36

# ZENITH RADIO CORPORATION



I. F. FREQUENCY  
175 K. C.

MODELS  
500-501-503-514  
515-516-600-604  
606-610-616-618

CHASSIS 2037  
Z.R.C.

NOTE:  
TUNING INDICATOR 122-6  
NOT USED ON MODEL 516

95-147 60~  
95-146 25~

10-115-OR-230-VOLT A.C.

ALL PILOT LIGHTS

2-AMP FUSE FOR 115-V  
LAMP FUSE FOR 230-V

ON-OFF SWITCH

# ZENITH RADIO CORPORATION

## SOCKET VOLTAGES


Tube Type	Position	Fil. Volt.	Plate Volt.	Cath. Volt.	Screen Volt.	Supp. Volt.	Plate Current
Z-58	R.F.	2.4	190	0	95	0	7.
Z-58	1st Det.	2.4	190	2.3	95	2.3	4.
Z-56	Osc.	2.4	100	0	-	-	4.
Z-58	I.F.	2.4	190	0	90	0	2.
Z-57	2nd Det.	2.4	90	-60	70	-60	.2
Z-57	A.V.C.	2.4	-10	-65	-2	-65	0
Z-59	Power	2.4	175	-70	165	-70	25
Z-80	Rect.	5.	*350	-	-	-	*36

Line 115 Volts

All Controls Maximum

(All readings, with exception of heaters, taken from socket connections to ground. Use 1,000 ohm per volt D. C. meter.)

BALANCE I.F. frequency at 175 K.C. Condenser gang at 1500 K.C. and oscillator pad-der at 600 K.C.



### TUBE POSITION

57-543	Escutcheon Plate .....	\$ .50
78-56	59 Seven Prong Socket .....	.15
78-57	56 Five Prong Socket .....	.15
78-58	58 Six Prong Socket .....	.15
78-59	57 Six Prong Socket .....	.15
78-60	60 Four Prong Socket .....	.15
95-146	115 volt 25 cycle Power Transformer .....	5.50
95-147	115 volt 60 cycle Power Transformer .....	3.75
136-109	Tube Shield .....	.10
136-2	2 amp Fuse .....	.06

## ZENITH RADIO CORPORATION

## PARTS AND PRICES

## CHASSIS 2037

## Dial and Meter Assembly

11-3	Pulley String.....per ft....	\$	.10
26-38	Dial Drum Strip.....		.10
61-19	Tuning Shaft Pulley (small idler).....		.05
61-22	Tuning Shaft Pulley (large idler).....		.10
80-65	Dial Drum Pulley Tension Spring.....		.01
80-69	Volume and Tone Control Tension Spring.....		.01
100-18	2½ volt Pilot Lamp.....		.12
122-5	Shadow Meter .....(Not used on Model 516).....		2.00
S-2242	Volume Control Dial Assembly....." " " " " ).....		.35
S-2243	Tone Control Dial Assembly.....(" " " " " ).....		.35

## Condensers

22-112	.1 mfd 300 volt(2nd Detector Screen & Power Grid).....		.25
22-113	.5 " .....(R.F.1st Detector & I.F.Grid Return).....		.35
*22-115	.1 " 200 volt(Four used, see below).....		.35
22-117	.5 " .....(R.F.1st Detector, & I.F. Screen).....		.50
22-137	.05 " 400 volt(Oscillator Plate).....		.25
22-147	.0005 600 volt(2nd Detector Plate & A.V.C.Screen).....		.25
22-161	Padder.....		.45
22-165	Three Gang Variable.....		3.50
22-170	.1 mfd 400 volt(R.F.& 1st Detector Plate,2nd Detector Plate)..		.35
22-171	.05 " 600 volt(Tone Control).....		.25
22-172	2. " 450 volt(Filter).....		.60
22-173	8. " 500 volt(Filter).....		1.25

## Resistors

63-121	100M ohm, 1 Watt (2nd Detector Plate).....		.25
63-135	25M " ½ " (2nd Detector Cathode).....		.25
63-137	250M " ½ " (Oscillator & Power Grid).....		.25
63-140	1 meg" ½ " (A.V.C. Screen).....		.25
63-160	100M " ½ " (A.V.C.Plate).....		.25
63-169	400M " ½ " (A.V.C. Grid).....		.25
63-232	Manual Tone Control.....		.75
63-234	Manual Sensitivity Control.....		.75
63-235	Manual Volume Control.....		1.25
63-239	24M ohm 1 Watt (Oscillator Plate).....		.25
63-244	500 " ¼ " (1st Detector Cathode).....		.25
63-251	Voltage Divider (six tap).....		.65
63-252	Voltage Divider (five tap).....		.60


## Coils and Chokes

20-30	Antenna Coil.....		.75
20-31	Oscillator Coil.....		.85
20-35	Detector Coil.....		1.00
95-133	1st & 2nd I. F. Transformer.....		1.25
S-2252	Plate Choke and Bracket.....		.50

## Miscellaneous


46-46	Large Knob.....		.20
46-62	Small Knob.....		.10
49-45	Dynamic Speaker for Models 500, 516 without transformer.....		6.00
49-46	Dynamic Speaker for Models 500, 516 with transformer.....		8.00
49-49	Dynamic Speaker for Model 517.....		7.00
52-32	Speaker Multicord.....		.35

# ZENITH RADIO CORPORATION MODEL 701



## PARTS LIST

Part No.	Description	List Price
A 103	Same	.....
C 145	.1-300 Volt Condenser	\$.25 ea.
C 155	.0005 Mica Condenser	.20 ea.
C 521	Two Gang Condenser	2.50 ea.
C 522	.01-400 Volt Condenser	.25 ea.
C 523	600 Ohm Choke Coil	1.25 ea.
C 524A	Antenna Coil	.80 ea.
C 524B	Oscillator Coil	.70 ea.
C 524C	I. F. Transformer	1.25 ea.
C 524D	I. F. Transformer	1.25 ea.
C 525	5-25-10 Electrolytic Condenser	2.00 ea.
C 526	By-Pass Condenser Block	1.50 ea.
C 527	Special Cord and Plug	1.25 ea.
K 214	Knobs	.40 ea.
R 268	2480 Ohm Resistor	.50 ea.
R 270	250 Ohm—Wire Wound Resistor	.25 ea.
V 601	Volume Control	1.35 ea.
W 427	Antenna Wire	.30 ea.




### SERVICE SUGGESTIONS

**NOTE—CONNECTING CORD OF SET GETS WARM IN NORMAL OPERATION. DO NOT BECOME ALARMED.**  
Make sure that all tubes are pushed firmly in their proper sockets and that the clips are securely fastened to the caps on the tops of the tubes.  
That the aerial is stretched out and that the connections to an outdoor antenna (if used) are good.  
If necessary to change tubes or service chassis, UNDER NO CIRCUMSTANCES REMOVE BACK OF CHASSIS WITHOUT FIRST REMOVING PLUG FROM LIGHT SOCKET.  
To remove chassis from cabinet, pull off knobs from front, remove back (held with screws to case). Remove four mounting screws, then chassis can be slipped out of case.

Schematic circuit diagram Model 701 AC-DC Superheterodyne, with automatic volume control. Should it be necessary, at any time, to rebalance this set the procedure is as follows: Attach a 456 kilocycle oscillator to the grid of the variable capacitor and adjust the trimmer capacitors to the maximum deflection on an output meter connected across the primary of the speaker input transformer. While adjusting these trimmers, the variable capacitor should be at the maximum capacity position—at the extreme right of its rotation.  
Next disconnect the antenna wire and connect an oscillator in series with a 75 mmf. condenser to the antenna coil. Rotate the condenser plates to the minimum capacity position—extreme left turn, and adjust the trimmer capacitor of the rear section of the variable capacitor to resonance with an oscillator set at 1725 kilocycles, then adjust the condenser of the front section of the variable capacitor to resonance. Align at 1400—1200—1000—800—600—500—350 kilocycles, bend slotted plates of variable condenser if necessary.

# ZENITH RADIO CORP.

**ZENITH RADIO CORP.**  
 CHICAGO, ILL.  
**7-TUBE SUPERHETERODYNE**  
**2022-A&B**





## ZENITH RADIO CORP.

## MODEL 2022 A &amp; B

## Variable Condenser Assembly

22-159	Four Gang Condenser.....	\$6.00
S-2121	Dial Drum Assembly.....	.80
11-3	Pulley String.....per ft.	.10
26-34	Dial Strip.....	.10
100-18	2½ volt Pilot Lamp.....	.12
S-769	Dial Lamp Socket Assembly (Less Lamp).....	.15

## Fixed Condensers

22-82	.001 mfd.....(2nd Detector Plate).....	.30
22-111	.03 " .....(Filter Choke Bypass).....	.30
22-113	.5 " .....(2nd Detector Cathode).....	.50
22-115	.1 " .....(R.F. & I.F. Cathode).....	.35
22-117	.5 " .....(R.F. & I.F. Detector Screen).....	.50
22-161	Padder.....	.75
22-156	6. mfd.....(Power Filter).....	1.25
22-137	.5 " .....(3 used, see footnote).....	.25
22-138	.2 " .....(Power Grid).....	.25
22-157	8. " .....(Power Filter).....	1.50

## Resistors

63-135	25M ohm.....(1st, 2nd Detector Cathode).....	.30
63-139	500M " .....(Power Grid).....	.30
63-140	1Meg " .....(Oscillator Grid).....	.30
63-160	100M " .....(2nd Det. Plate & Power Grid).....	.30
63-199	150 " .....(R.F. & I.F. Cathode, Flexible).....	.30
63-200	Tone Control.....	1.00
63-207	10M ohm.....(Voltage Divider, Wire Wound).....	.35
63-208	12M " .....(Voltage Divider).....	.30
63-209	Volume control and switch assembly.....	1.25

## Coils


S-919	2nd Detector Choke.....	.60
S-2125	Detector Coil.....	.90
S-2126	Oscillator Coil.....	.90
S-2127	R.F. Pre-selector.....	1.50
S-1186	1st I.F. Transformer.....(175 K.C.).....	1.50
S-2136	2nd I.F. Transformer.....(175 K.C.).....	1.40

## Miscellaneous

49-44	Dynamic Speaker.....	8.00
46-58	Control Knobs, all sets, three used.....	.10
52-27	Speaker Cable.....	.25

\*A.F. COUPLING, TONE CONTROL, AND FIRST DETECTOR CATHODE.

# ZENITH RADIO CORP.



# Now... the wise serviceman BEATS COMPETITION

## NEW "SURE-FIRE" PLAN SHOWS HOW TO GET MORE JOBS—DO THEM QUICKER, BETTER—AND MAKE MORE MONEY

Your biggest Radio service problem is competition. Competition makes it much harder for the average service man to make a living. It cuts his profits to the bone.

There are just two things you can do about it. You either "take it" or find a way to beat the competition.

Most fellows will "take it"—they'll work harder and harder trying to make both ends meet until finally seeing they are "getting nowhere fast" they'll quit. The wise Radio service man uses another method. He gets above competition by a new Sure-Fire Plan—the special N.R.I. Professional Servicemen's Course.

### FOR ADVANCED RADIO MEN

This Course is NOT for beginners. They wouldn't know what it was all about. It is for the men with experience, previous Radio training, or both. It is the "ace in the hole" of the service man already in Radio.

### BIGGER EARNINGS RESULT

The Professional Servicemen's Course is a real Money Maker for you. It covers methods and plans unknown to men who form your biggest competition. It trains you to do a more thorough service job — to make satisfied customers who come back to you time and time again; the type of customer who wants good work and is willing to pay for it.

It teaches you to do the average job much more quickly — by special methods — by service "short-cuts"; eliminates the "trial and error" method of servicing — enabling you to handle more jobs in the same time with a greater dollars and cents profit.

You can handle "failure" jobs, where the other fellows fell down. Result, money in your pocket.

### YOU LEARN TESTED MONEY-MAKING METHODS

You learn the scientific methods—of finding Radio work and doing the jobs. The easiest—simplest—and more productive methods are pointed out to you—methods tested and found best—plans that beat out the "hit and miss methods" used by the majority of your competitors.

Only those things are included which the professional service man must know to beat competition and make good money. Every paragraph is chock full of meaty material—just what you need to be more successful in Radio servicing. There are fifty-two printed and illustrated books averaging thirty-two pages each, containing text diagrams, illustrations and questions.

In addition there are also ten reference books and eight service manuals containing valuable tips, servicing data and diagrams. Additional diagrams appear regularly in National Radio News, a subscription to which is included with the Course.

Get out of the rut—don't battle day by day for existence. You can go far as a Radio service man—with the National Radio Institute's Professional Servicemen's Course. The material can be put into practice immediately. It means added profit to you right from the start.

### RECOMMENDED BY PHILCO

Why did the Philco Radio and Television Corp. recommend this course to its thousands of dealers and servicemen? Because they realized its value to professional Radio servicemen; they realized it makes successful servicemen.

N.R.I. training has made many men successful in Radio servicing. Hundreds of success letters are on file here at N.R.I.—letters from men like you who wanted to go further than the ordinary Radio man—who wanted to make big money. Just a few are reproduced on this page to show how N.R.I. fits men to do the jobs where others fail. You, too, can get in on the big money end of Radio — you can override your competition — you can have the better things of life which you have always wanted. It's your "New Deal"—a "Sure-Fire" plan to success in Radio.

There is absolutely no obligation—it costs you nothing to find out more about this Professional Servicemen's Course. Clip out the coupon below and mail it today for a free outline of N.R.I.'s Professional Servicemen's Course.

### I SHOWED THESE MEN AND MANY OTHERS HOW TO GET AHEAD

#### \$40 to \$100 a Month In Spare Time



Radios are rapidly getting more complicated. My advice to any man in Radio is to "TRAIN." The day of the "magazine" service man is over. My Radio earnings run from \$40 to \$100 a month in my spare time.

J. J. Reider,  
536 Dayton Ave.,  
St. Paul, Minn.

#### Succeeds Where Others Fail



Every service man has competition. The way to beat it is to train to do your work better than the other fellow. I have made a number of sets work after others fell down. I cannot praise N.R.I. training enough.

D. O. Mount,  
Box 847,  
Libby, Montana

#### Not Bothered by Competition



There are sixty Radio repair men in this town, but I get a large percentage of the business. I attribute my ability to hold business against competition to what I learned from N.R.I.

Geo. A. Turner,  
211 Polk St.,  
Pueblo, Colo.

NOW I'LL SHOW YOU

JUST MAIL COUPON

NATIONAL RADIO INSTITUTE  
1536 You St., Washington, D. C.

I'd like to see a copy of the outline of your special course of training for Professional Service Men. Please rush my copy without cost or obligation to me.

(Name) \_\_\_\_\_  
(Address) \_\_\_\_\_  
(City) \_\_\_\_\_  
(State) \_\_\_\_\_

3HP8

## ZENITH RADIO CORP.


Tube Type	Position	Fil. Volt.	Plate Volt.	Cath. Volt.	Screen Volt.	Supp. Volt.	Plate Current
Z-58	R.F.	2.4	260	3.5	120	3.5	9.0
Z-24A	1st Det.	2.4	260	5.5	120	120	.2
Z-27	Osc.	2.4	120	0	-	-	4.2
Z-58	I.F.	2.4	260	3.5	120	3.5	8.4
Z-27	2nd Det.	2.4	180	10.	-	-	.3
Z-47	Power	2.4	240	-	260	-	30.
Z-80	Rect.	5.0	120	-	-	-	30.

Line 117 Volts

All Controls Maximum

(All readings, with exception of heaters, taken from socket connections to ground. Use 1,000 ohm per volt D. C. meter.)

BALANCE I.F. frequency at 125 K.C. Condenser gang at 1500 K.C. and oscillator padder at 600 K.C.



PARTS AND PRICES  
STANDARD AND LONG WAVE RECEIVER

CHASSIS 2046

Dial Assembly


11-3	Pulley String.....	per ft.	\$ .10
26-40	Calibrated Dial Strip.....		.25
80-69	Pulley String Tension Spring.....		.01
100-18	2½ volt Pilot Lamp.....		.12
S-769	Dial Lamp Socket Assembly (less lamp).....		.15
S-2578	Dial Drum Assembly.....		.80

# When formulas mean results—

Many well designed pieces of apparatus have failed due to improper selection of component parts. Don't YOU make this mistake when designing or building that new Set Analyzer, Decade Box or High Resistance Voltmeter. Use this FORMULA, as all the leading Analyzer manufacturers are, and be sure your efforts are not being wasted.

$$\frac{Q + A + Md}{LC} = PwwR$$

Where Q equals QUALITY and A equals ACCURACY, Md equals MODERN DESIGN and LC LOW COST and LAST COST, then PwwR is always PRECISION WIRE-WOUND RESISTORS.



## RESISTANCE RANGE

.25 Ohms to 200,000 Ohms

### TYPE L—A New Precision Resistor

Maximum Wattage ..... 1/4  
 Diameter ..... 3/8"  
 Length ..... 1/4"  
 Terminals ..... 2" Flexible Leads



## RESISTANCE RANGE — .25 Ohms to 5 Megohms

### TYPE A

Normal Rating 1 Watt  
 Maximum Length 2 1/4"  
 Maximum Diameter 3/8"  
 Furnished with Standard Caps

### TYPE B

Normal Rating 2 Watt  
 Maximum Length 2 1/4"  
 Maximum Diameter 5/8"  
 Furnished with Standard Caps

### TYPE C

Normal Rating 5 Watt  
 Maximum Length 4 1/2"  
 Maximum Diameter 3/4"  
 Furnished with Standard Caps


### TYPE BP

Maximum Wattage ..... 5  
 Maximum Resistance ..... 60,000  
 Diameter ..... 3/8"  
 Length ..... 1 1/2"

### TYPE VP

Maximum Wattage ..... 10  
 Maximum Resistance ..... 100,000  
 Diameter ..... 1/2"  
 Length ..... 2"

TOLERANCE 2% PLUS OR MINUS  
 RATED RESISTANCE




### TYPE D

Normal Rating 1/2 Watt  
 Maximum Length 3/4"  
 Maximum Diameter 5/8"  
 Length of Leads 1 1/4"  
 Furnished with No. 18 Tinned Copper Leads

### TYPE F

Normal Rating 1 Watt  
 Maximum Length 1"  
 Maximum Diameter 5/8"  
 Length of Leads 1 1/4"  
 Furnished with No. 18 Tinned Copper Leads



7 3/8" long, 2 1/2" high  
 1" wide

RC-120 100 Watt  
 Resistance Range, 3 ohms to 6,000 ohms

## FREE BOOKLET AND PRICE LIST

Precision Custom-Built Wire-Wound High Resistance Units

Manufactured by

PRECISION RESISTOR COMPANY

334 BADGER AVENUE, NEWARK, N. J.

## ZENITH RADIO CORP.

## Condensers

22-82	.001 mfd	500 volt	.....(two used, 2nd det. plate).....	.20
22-111	.03	" 600 "	.....(speaker field).....	.20
*22-113	.5	" 200 "	.....(two used, see below).....	.35
22-117	.5	" 300 "	.....(1st Det. Screen & R.F.).....	.50
*22-137	.05	" 400 "	.....(three used, see below).....	.25
22-138	.2	" 200 "	.....(power grid).....	.25
22-156	6.	" 450 "	.....(filter).....	1.25
22-157	8.	" 450 "	.....(filter).....	1.50
22-159	Four Gang Variable.....			6.00
22-161	Variable Padder.....			.45
22-179	Series Padder.....			.40

## Resistors

63-135	25M ohm	.....(1st & 2nd uet. cathodes).....	.25	
63-139	500M "	.....(power grid).....	.25	
63-140	1Meg "	.....(oscillator grid).....	.25	
63-156	10M "	.....(2nd det. plate).....	.25	
63-160	100M "	.....(2nd det. plate power grid).....	.25	
63-199	150 "	.....(R.F. & I.F. Cathode).....	.25	
63-200	Tone Control.....			.80
63-207	10M ohm	.....(voltage divider).....	.30	
63-208	12M "	.....(voltage divider).....	.25	
63-209	Volume Control and Switch Assembly.....			1.25

## Coils and Chokes

20-28	R. F. Plate Choke.....			.75
S-2212	1st I. F. Transformer.....			1.75
S-2213	2nd I. F. Transformer.....			1.75
S-2586	Oscillator Coil and Detector Coil..(below chassis).....			1.75
S-2587	Preselector Coil.....(above chassis).....			1.50
46-59	Large Knob.....			.15
46-60	Small Knob.....			.15
49-44	Dynamic Speaker.....			8.00
*22-113	R.F. and I.F. Cathode - 2nd Detector Cathode.			
*22-137	Tone Control, 1st Detector Cathode, Audio Coupling.			
52-27	Speaker Cable.....			\$ .25
57-326	Escutcheon Plate.....(Except Model 510-5).....			.30
78-37	Z-27 Tube Socket.....			.15
78-38	Z-24 Tube Socket.....			.15
78-39	Z-47 Tube Socket.....			.15
78-40	Z-80 Tube Socket.....			.15
78-54	Z-58 Tube Socket.....			.15
83-218	Single Terminal Soldering Brackets.....			.05
83-228	Speaker Cable Terminal Strip.....			.15
83-260	Double Terminal Soldering Brackets.....			.07
93-167	Rubber Cushion for Chassis Mounting (upper).....			.01
93-168	Rubber Cushion for Chassis Mounting (lower).....			.01
93-170	Metal Washer used with the above.....			.02
95-128	Combination 220-110 volt, 60 cycle Power Transformer.....			5.25
95-130	25-30 cycle 110 volt, 60 cycle Power Transformer.....			6.25
126-109	Tube Shields - Small.....			.06
136-2	2 amp Fuse.....			.06
136-4	1 amp Fuse.....			.06
S-2124	Heat Insulating Shield.....			.30
S-2218	Long Wave Switch, Shaft & Pin Assembly.....			.50
S-2219	Long Wave Switch Plate, Shaft and Bracket Assembly.....			2.00

Discriminating Service Men Follow the Choice  
of Well-known Engineers and Specify


# POLYMET PRODUCTS

These finely built parts are used by many leading radio receiver manufacturers, following thorough and successful laboratory tests. ENGINEERS DO NOT GUESS—THEY KNOW!

## ELECTROLYTIC CONDENSERS



Polymet Electrolytic Condensers are performing service in all parts of the world, in varied climates with freedom from trouble. Extreme care has been taken to assure a high quality product. Low leakage, low power factor and true capacity are a few of their outstanding features. In addition to the self-healing wet electrolytic condenser, the Polymet dry Electrolytic Condenser has become equally popular. Polymet Electrolytic Condensers are standard for years in many receivers—these condensers are leaders among such capacitors.



## WAXTITE & PETITE BY-PASS CONDENSERS




capacities from .001 Mfd. to .5 Mfd. in many voltages.

Polymet Waxtite and Pe-tite Condensers are the original type of paper-wrapped "cartridge" form of condensers. Due to special construction, they are thoroughly sealed. These Waxtite and Pe-tite Condensers are made in numerous capacities from .001 Mfd. to .5 Mfd. in many voltages.

## BY-PASS CONDENSERS

These Polymet By-pass Condensers are only too well known and are recognized in service work as most reliable for by-pass replacements. They are manufactured in strict accordance with RMA standards.



## AUTO-ELIMINATOR CONDENSERS



Auto-Eliminator Condensers were originated by Polymet and have been especially designed to withstand high temperature and excessive vibration. They are standard in many well-known auto-radio sets—they effectively eliminate spark interference.

## UNCASED PAPER CONDENSERS

Polymet has assembled a splendid variety of uncased condensers of the highest variety — strictly built to RMA standards—thoroughly wax-sealed, and marked with capacity and accurate voltage rating. They are furnished with flexible leads permitting easy assembly. There are none finer for economical service work.



## MICA CONDENSERS

In the construction of Polymet Mica Condensers only selected grades of mica and foil are used. They are entirely sealed in molded bakelite, and protected from atmospheric conditions. They are mechanically strong and electrically accurate. We fabricate many sizes. Our midget sizes are very popular in the small sets. Our large molded types are standard for many industrial concerns.



## FIXED RESISTORS

Polymet wire-wound tubular resistors are accurately made of the highest grade of resistance alloy wire, wound on refractory tubes. They are completely covered with heat-resisting, insulating enamel which protects the wire against oxidation, moisture or mechanical injury. Each resistor is accurately valued.



A Copy of Special Service Men's Catalog of  
POLYMET RADIO ESSENTIALS  
will be sent on request.

# POLYMET MANUFACTURING CORP.

833-S East 134th Street



New York City

VACUUM TUBE CHART

TYPE	NAME	BASE	SOCKET CONNECTIONS	DIMENSIONS		CATHODE TYPE	RATING			USE	PLATE SUPPLY VOLTS	GRID VOLTS	SCREEN VOLTS	SCREEN MILLI-AMP.	PLATE MILLI-AMP.	A-C PLATE RESISTANCE OHMS	MUTUAL INDUCTANCE MICROMHOS	VOLTAGE AMPLIFICATION FACTOR	LOAD FOR STATED POWER OUTPUT OHMS	POWER OUTPUT WATTS	TYPE	
				MAXIMUM OVERALL LENGTH x DIAMETER	FILAMENT OR HEATER		FILAMENT VOLTS	AMPERES	PLATE MAX. VOLTS													SCREEN MAX. VOLTS
RCA-1A8	PENTAGRID CONVERTER	SMALL 6-PIN	FIG. 20	4 1/2" x 1 1/8"	D-C FILAMENT	2.0	0.06	180	67.5	180	—	67.5	—	1.3	500000	5250	4.2	2500	3.5	C-1A8		
RCA-2A3	POWER AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	5 3/8" x 2 1/8"	FILAMENT	2.5	2.5	250	—	300	—62	—	—	40.0	Power Output is for 2 tubes at stated load, plate-to-plate	5000	—	5000	10.0	C-2A3		
RCA-2A5	POWER AMPLIFIER PENTODE	MEDIUM 6-PIN	FIG. 15A	4 1/8" x 1 1/8"	HEATER	2.5	1.75	250	250	250	-16.5	250	6.5	34.0	100000	2200	220	7000	3.0	C-2A5		
RCA-2A6	DUPLX-DIODE HIGH-MU TRIODE	SMALL 6-PIN	FIG. 13	4 1/2" x 1 1/8"	HEATER	2.5	0.8	250	—	250	-1.35	—	—	0.4	—	—	—	—	50-60	C-2A6		
RCA-2A7	PENTAGRID CONVERTER	SMALL 7-PIN	FIG. 20	4 1/2" x 1 1/8"	HEATER	2.5	0.8	250	100	250	-3.0	100	2.2	3.5	360000	—	—	—	—	C-2A7		
RCA-2B7	DUPLX-DIODE PENTODE	SMALL 7-PIN	FIG. 21	4 1/2" x 1 1/8"	HEATER	2.5	0.8	250	125	250	-3.0	100	1.7	5.8	300000	950	285	—	—	C-2B7		
RCA-6A4 also LA	POWER AMPLIFIER PENTODE	MEDIUM 5-PIN	FIG. 6	4 1/8" x 1 1/8"	FILAMENT	6.3	0.3	180	180	180	-4.5	50	0.65	—	83250	1200	100	11000	0.31	C-6A4		
RCA-6A7	PENTAGRID CONVERTER	SMALL 7-PIN	FIG. 20	4 1/2" x 1 1/8"	HEATER	6.3	0.3	250	100	250	-3.0	100	2.2	3.5	360000	—	—	—	—	C-6A7		
RCA-6B7	DUPLX-DIODE PENTODE	SMALL 7-PIN	FIG. 21	4 1/2" x 1 1/8"	HEATER	6.3	0.3	250	125	250	-3.0	100	1.7	5.8	300000	950	285	—	—	C-6B7		

UX-200-A	DETECTOR TRIODE	MEDIUM 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	5.0	0.25	45	—	45	-4.5	—	—	1.5	30000	666	20	—	—	CX-300-A
RCA-01-A	DETECTOR & AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	5.0	0.25	135	—	90	-4.5	—	—	2.5	11000	725	8.0	—	—	C-01-A
RCA-10	POWER AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	5 3/8" x 2 1/8"	FILAMENT	7.5	1.25	425	—	350	-31.0	—	—	16.0	5150	1550	8.0	11000	0.9	C-10
WD-11 WX-12	DETECTOR & AMPLIFIER TRIODE	WD 4-PIN MEDIUM 4-PIN	FIG. 12 FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	1.1	0.25	135	—	90	-4.5	—	—	2.5	13500	425	6.6	—	—	C-11 CX-12
UX-112-A	DETECTOR & AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	5.0	0.25	180	—	90	-4.5	—	—	5.0	5100	1575	8.5	—	—	CX-112-A
RCA-19	TWIN AMPLIFIER	SMALL 6-PIN	FIG. 25	4 1/8" x 1 1/8"	D-C FILAMENT	2.0	0.26	135	—	135	0	—	—	Power output value is for one tube at stated load, plate-to-plate.	4700	1800	8.5	10000	2.1	C-19
UX-120	POWER AMPLIFIER TRIODE	SMALL 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	3.3	0.132	135	—	90	-16.5	—	—	3.0	8000	415	3.3	9500	0.045	CX-220
RCA-22	R-F AMPLIFIER TETRODE	MEDIUM 4-PIN	FIG. 4	5 3/8" x 1 1/8"	D-C FILAMENT	3.3	0.132	135	67.5	135	-1.5	45	0.6*	1.7	725000	375	270	—	—	C-22
RCA-24-A	R-F AMPLIFIER TETRODE	MEDIUM 5-PIN	FIG. 8	5 3/8" x 1 1/8"	HEATER	2.5	1.75	275	90	250	-3.0	90	1.7*	4.0	400000	1000	400	—	—	C-24-A
RCA-26	AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	4 1/8" x 1 1/8"	FILAMENT	1.5	1.05	180	—	90	-7.0	—	—	2.9	8700	935	8.3	—	—	C-26
RCA-27	DETECTOR & AMPLIFIER TRIODE	MEDIUM 5-PIN	FIG. 8	4 1/8" x 1 1/8"	HEATER	2.5	1.75	275	—	135	-9.0	—	—	4.5	9000	1000	9.0	—	—	C-27
RCA-30	DETECTOR & AMPLIFIER TRIODE	SMALL 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	2.0	0.06	180	—	135	-21.0	—	—	5.2	9250	975	9.0	—	—	C-30

Grids #3 and #5 are screen. Grid #4 is signal-input control-grid.  
 \*Applied through plate coupling resistor of 200000 ohms.  
 \*Applied through plate coupling resistor of 250000 ohms.

\*For Grid-leak Detection—plate volts 45, grid return to + filament or to cathode.

Plate current to be adjusted to 0.1 milliamperes with no signal.  
 Plate current to be adjusted to 0.2 milliamperes with no signal.

Applied through plate coupling resistor of 250000 ohms or 500-henry choke shunted by 0.25 megohm resistor. \*Maximum.



THE BIGGEST RADIO VALUE IN AMERICA TODAY!

# Official RADIO SERVICE MANUAL

*and Complete Directory of all  
Commercial Wiring Diagrams*

IN LOOSELEAF, FLEXIBLE, LEATHERETTE BINDER

**N**EVER in the history of radio has there ever been published a manual, so complete as this new OFFICIAL RADIO SERVICE MANUAL. It is a veritable encyclopedia of service information — worth several times its regular price. It is invaluable not only to the Service Man, but to everyone interested in radio. For this Manual there has been collected available wiring diagrams and data of nearly every commercial set, of which there is any record, manufactured since 1927, and many earlier ones.

Additional service data for new receivers, as they appear on the market, will be supplied at a trifling cost so that the Manual might be kept up-to-date at all times. But that is not all.

### Service Information

The OFFICIAL RADIO SERVICE MANUAL contains a comprehensive instruction course for the serviceman, giving practical information from every angle on how to service the set. Here are only a small number of the articles mentioned:

- |            |                    |                  |
|------------|--------------------|------------------|
| Antennas   | Eliminators        | Radio-Phonograph |
| Amplifiers | Meters             | Equipment        |
| Automotive | Radio Power Supply | Resistors        |
| Condensers | Systems            | Short Wave Sets  |
| Detectors  | Tubes              | Speakers         |

You simply cannot realize what a tremendous work this is until you have held a copy in your hands and have gone through the 650 pages, including the supplements.

### What They Say

#### NOTHING CAN COMPARE WITH IT

I have received my copy of the OFFICIAL RADIO SERVICE MANUAL. I expected it would be good for I think you know as much as any of them what the average radio man wants, but I'll wager not very many expected to receive a book comparable to this one. I think you deserve a lot of credit for being the first to put out a real service manual that the amateur or professional can make good everyday use of. It's a good practical book and one that every service man will be proud of.—E. D. HANA, Haslett, Mich.

#### BEST BOOK IN THE FIELD

I received your book OFFICIAL RADIO SERVICE MANUAL and I find it is as yet the best book I have found in this field of radio. You are well justified in that this is the peer of service manuals. I wish you all the success possible in the publishing of future books on radio which are sure of great necessity.—WILLIAM R. BROWN, Brown Radio Service, 1010 Buckingham Street, Toledo, Ohio.

#### WORTH A GREAT DEAL MORE

Received your copy of OFFICIAL RADIO SERVICE MANUAL and am greatly pleased with same. It is worth a great deal more than it costs.—HAROLD AIGUIER, 41 Rutland Ave., Arlington, N. J.

#### A VERITABLE GOLD MINE

I received the OFFICIAL RADIO SERVICE MANUAL. I am well pleased. It is a veritable gold mine for the Service Man.—EUGENE BINFORD, Arkansas City, Kansas.

#### MAGNIFIQUE


Received my copy of the OFFICIAL RADIO SERVICE MANUAL this A.M. "She is what you call him? Magnifique! Exquisite!" A timely aid for the troubled sets. Thanks.—E. BOICE, 1118 W. Dauphin, Philadelphia, Pa.

HUGO GERNSBACK, *Editor*  
CLYDE FITCH, *Managing Editor*

650 PAGES — Including Supplements  
Over 1,500 Diagrams and Illustrations  
Flexible, Looseleaf Leatherette Binder

9 x 12 Inches

\$4.50  
A Copy



MAIL COUPON  
TODAY!

GERNSBACK PUBLICATIONS, Inc. RM-34  
96-98 Park Place, New York, N. Y.

As per your special offer, I enclose herewith \$4.50 for which you are to send me, postpaid, one copy of the OFFICIAL RADIO SERVICE MANUAL.

Name .....  
Address .....  
City ..... State .....

Prepared Especially for the Radio Service Man!

VACUUM TUBE CHART

TYPE	NAME	BASE	SOCKET CONNECTIONS	DIMENSIONS		CATHODE TYPE #	RATING			USE	PLATE SUPPLY VOLTS	GRID VOLTS #	SCREEN VOLTS	SCREEN MILLI-AMP.	SCREEN PLATE MILLI-AMP.	A-C PLATE RESISTANCE OHMS	MUTUAL CONDUCTANCE MICRO-MHOS	VOLT-AGE AMPLIFICATION FACTOR	LOAD FOR STATED POWER OUTPUT OHMS	POWER OUTPUT WATTS	TYPE
				LENGTH	DIAMETER		FILAMENT OR HEATER	PLATE	SCREEN												
RCA-31	POWER AMPLIFIER TRIODE	SMALL 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	2.0	0.13	180	CLASS A AMPLIFIER	135	-22.5	—	—	8.0	4100	925	3.8	7000	0.185	C-31	
RCA-32	R-F AMPLIFIER TETRODE	MEDIUM 4-PIN	FIG. 4	5 3/8" x 1 1/8"	D-C FILAMENT	2.0	0.06	180	SCREEN GRID R-F AMPLIFIER	135	-3.0	67.5	0.4*	1.7	950000	640	610	5700	0.375	C-32	
RCA-33	POWER AMPLIFIER PENTODE	MEDIUM 5-PIN	FIG. 6	4 1/8" x 1 1/8"	D-C FILAMENT	2.0	0.26	135	CLASS A AMPLIFIER	135	-13.5	135	3.0	14.5	50000	1430	70	7000	0.7	C-33	
RCA-34	SUPER-CONTROL R-F AMPLIFIER PENTODE	MEDIUM 4-PIN	FIG. 4A	5 3/8" x 1 1/8"	D-C FILAMENT	2.0	0.06	180	SCREEN GRID R-F AMPLIFIER	135	-3.0	67.5	1.0	2.8	600000	600	360	—	—	C-34	
RCA-35	SUPER-CONTROL R-F AMPLIFIER TETRODE	MEDIUM 5-PIN	FIG. 9	5 3/8" x 1 1/8"	HEATER	2.5	1.75	275	SCREEN GRID R-F AMPLIFIER	180	-3.0	90	2.5*	6.3	300000	1020	305	—	—	C-35	
RCA-36	R-F AMPLIFIER TETRODE	SMALL 5-PIN	FIG. 9	4 3/8" x 1 1/8"	HEATER	6.3	0.3	250	SCREEN GRID R-F AMPLIFIER	100	-1.5	90	2.5*	6.5	400000	1050	420	—	—	C-36	
RCA-37	DETECTOR* AMPLIFIER TRIODE	SMALL 5-PIN	FIG. 8	4 1/8" x 1 1/8"	HEATER	6.3	0.3	250	CLASS A AMPLIFIER	180	-13.5	—	—	4.3	11500	800	9.2	—	—	C-37	
RCA-38	POWER AMPLIFIER PENTODE	SMALL 5-PIN	FIG. 9A	4 3/8" x 1 1/8"	HEATER	6.3	0.3	250	CLASS A AMPLIFIER	250	-18.0	250	3.8	7.5	8400	1100	9.2	—	—	C-38	
RCA-39-44	SUPER-CONTROL R-F AMPLIFIER PENTODE	SMALL 5-PIN	FIG. 9A	4 3/8" x 1 1/8"	HEATER	6.3	0.3	250	SCREEN GRID R-F AMPLIFIER	180	-18.0	250	3.8	1.2	110000	1050	120	15000	0.27	C-39-44	
UX-240	VOLTAGE AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	4 1/8" x 1 1/8"	D-C FILAMENT	5.0	0.25	180	CLASS A AMPLIFIER	135	-1.5	—	—	0.2	150000	200	30	—	—	CX-340	
RCA-41	POWER AMPLIFIER PENTODE	SMALL 6-PIN	FIG. 19A	4 1/8" x 1 1/8"	HEATER	6.3	0.4	250	CLASS A AMPLIFIER	100	-7.0	100	1.6	9.0	103500	1430	150	2000	0.33	C-41	
RCA-42	POWER AMPLIFIER PENTODE	MEDIUM 6-PIN	FIG. 15A	4 1/8" x 1 1/8"	HEATER	6.3	0.7	250	CLASS A AMPLIFIER	250	-18.0	250	5.5	32.0	68000	2200	150	7000	3.40	C-42	

RCA-43	POWER AMPLIFIER PENTODE	MEDIUM 6-PIN	FIG. 15A	4 1/8" x 1 1/8"	HEATER	25.0	0.3	135	CLASS A AMPLIFIER	100	-15.0	100	4.0	20.0	45000	2000	90	4500	0.90	C-43
RCA-45	POWER AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	4 1/8" x 1 1/8"	FILAMENT	2.5	1.5	275	CLASS A AMPLIFIER	180	-31.5	180	31.0	34.9	35000	2300	80	4000	2.00	C-45
RCA-46	DUAL-GRID POWER AMPLIFIER	MEDIUM 6-PIN	FIG. 7	5 1/8" x 2 1/8"	FILAMENT	2.5	1.75	400	CLASS A AMPLIFIER	250	-50.0	250	34.0	36.0	1610	2175	3.5	2700	0.82	C-46
RCA-47	POWER AMPLIFIER PENTODE	MEDIUM 5-PIN	FIG. 6	5 1/8" x 2 1/8"	FILAMENT	2.5	1.75	250	CLASS A AMPLIFIER	250	-33.0	—	—	22.0	2380	2350	5.6	6400	1.25	C-47
RCA-48	POWER AMPLIFIER TETRODE	MEDIUM 6-PIN	FIG. 15	5 1/8" x 2 1/8"	D-C HEATER	30.0	0.4	125	CLASS A AMPLIFIER	95	-20.0	95	9.0	47.0	10000	2800	28	2000	1.6	C-48
RCA-49	DUAL-GRID POWER AMPLIFIER	MEDIUM 5-PIN	FIG. 7	4 1/8" x 1 1/8"	D-C FILAMENT	2.0	0.120	180	CLASS A AMPLIFIER	135	-20.0	—	—	5.7	4000	1125	4.5	11000	0.17	C-49
UX-950	POWER AMPLIFIER TRIODE	MEDIUM 4-PIN	FIG. 1	6 1/8" x 2 1/8"	FILAMENT	7.5	1.25	450	CLASS A AMPLIFIER	300	-54.0	—	—	35.0	2000	1900	3.8	4600	1.6	CX-350
RCA-53	TWIN-TRIODE AMPLIFIER	MEDIUM 7-PIN	FIG. 23	4 1/8" x 1 1/8"	HEATER	2.5	2.0	300	CLASS A AMPLIFIER	400	-70.0	—	—	55.0	1800	2100	3.8	3670	3.4	C-53
RCA-55	DUMPER DIODE TRIODE	SMALL 6-PIN	FIG. 13	4 3/8" x 1 1/8"	HEATER	2.5	1.0	250	CLASS A AMPLIFIER	135	-10.5	—	—	6.0	11000	750	8.3	25000	0.075	C-55
RCA-56	SUPER-TRIODE AMPLIFIER DETECTOR*	SMALL 5-PIN	FIG. 8	4 1/8" x 1 1/8"	HEATER	2.5	1.0	250	CLASS A AMPLIFIER	250	-13.5	—	—	5.0	9500	1450	13.8	20000	0.350	C-56

\*Applied through plate coupling resistor of 250000 ohms or 500-henry choke-shunted by 0.25 megohm resistor.  
 \*Applied through plate coupling resistor of 100000 ohms.  
 \*Applied through plate coupling resistor of 250000 ohms.

For Grid-leak Detection—plate volts 45, grid return to + filament or to cathode.  
 #Either A, C or D, C. may be used on filament or heater, except as specifically noted. For use of D, C. on A-C filament types, decrease stated grid volts by 1/2 (approx.) of filament voltage.

\*Maximum.

Plate current to be adjusted to 0.1 milliamperes with no signal.

Plate current to be adjusted to 0.2 milliamperes with no signal.

Power output value is for one tube at stated load, plate-to-plate.

Power output values are for 2 tubes at indicated plate-to-plate load.

Plate current to be adjusted to 0.2 milliamperes with no signal.

# Get in the **HABIT** of using the 1932 Official Radio Service Manual

## FREE Questions and Answers Service

### Schematic Diagrams of All Latest Midget Receivers

*Expert servicing or installation of radio receivers requires that the dealer, service man or radiotrician be thoroughly experienced in handling sets of any manufacture. Needless to mention how important are modern methods of servicing, and how easy it is to complete any service job when the OFFICIAL RADIO SERVICE MANUAL is on hand. The NEW 1932 MANUAL contains a Full Radio Service Guide and a most Complete Directory of all 1931-1932 Radio Receivers as well as models of older design. Everyone employed in the Radio Industry should have a copy available for his own use.*

**\$5.00**

*The Copy*

HUGO GERNSBACK,  
Editor

C. E. Denton  
Managing Editor

Clyde Fitch,  
Managing Editor



### Partial Contents of the Manual

A step-by-step analysis in servicing a receiver which embodies in its design every possible combination of modern radio practice; it is fully illustrated and thoroughly explained. It is the greatest contribution to the radio service field.

Chart showing the operation of all types of vacuum tubes, whether new, old or obsolete. An exclusive resumé of the uses of the Pentode and Variable Mu Tubes and their characteristics.

Complete discussion of the superheterodyne and its inherent peculiarities. Also a special chapter on tools used on superheterodyne circuits.

Schematic diagrams and circuits complete with color codings.

Important chapters on commercial aircraft radio equipment; new data on commercial short wave receivers and converters.

Servicing and installation of public address systems and talking machine equipment.

Standardized color codings for resistors.

Operation of old and new testing equipment; tube voltmeters, output meters, oscillators and aligning tools.

A full section on Midget radios—their design, circuits and types. How to service them most economically.

Hundreds of schematic diagrams of older radio receivers which have never been published.

Blank pages for recording notes, diagrams and sketches; these pages are transferable to any part of the book.

OVER 1,000 PAGES

Over 2,000 Diagrams,  
Charts and Illustrations

Flexible Loose Leaf Binder  
9 x 12 Inches

Complete Directory  
of All 1931-1932  
Radio Receivers

Full Radio Service Guide  
For Radio Service Men,  
Dealers, Jobbers, Manu-  
facturers and Set  
Builders

*Clip Coupon NOW!*

GERNSBACK PUBLICATIONS, Inc., RM-34  
96-98 Park Place, New York, N. Y.

I enclose herewith remittance of \$5.00, check or money order preferred, for which you are to send me the NEW 1932 OFFICIAL RADIO SERVICE MANUAL. I understand that all the New material will be included in the Manual and Supplements will be mailed FREE every 60 days.

Name .....

Address .....

City ..... State .....

VACUUM TUBE CHART

Model	Triple-Grid Amplifier Detector	Small 6-Pin	Fig. 11	4 1/2" x 1 1/8"	Heater	2.5	1.0	250	100	Screen Grid R.F. Amplifier	250	-3.0	100	0.5	2.0	exceeds 1.5 meg.	1225	exceeds 1500	C-57
RCA-57	TRIPLE-GRID AMPLIFIER DETECTOR	SMALL 6-PIN	FIG. 11	4 1/2" x 1 1/8"	HEATER	2.5	1.0	250	100	SCREEN GRID R.F. AMPLIFIER	250	-3.0	100	0.5	2.0	exceeds 1.5 meg.	1225	exceeds 1500	C-57
*For Grid-leak Detection—plate volts 45; grid return to + filament or to cathode. †Requires different socket from small 7-pin.																			
RCA-58	TRIPLE-GRID SUPER-CONTROL AMPLIFIER	SMALL 6-PIN	FIG. 11	4 1/2" x 1 1/8"	HEATER	2.5	1.0	250	100	SCREEN GRID R.F. AMPLIFIER SUPERHETERODYNE	250	-10.0	100	—	—	—	—	—	C-58
†Oscillator peak volts = 7.0.																			
RCA-59	TRIPLE-GRID POWER AMPLIFIER	MEDIUM 7-PIN	FIG. 18	5 1/2" x 2 1/8"	HEATER	2.5	2.0	250	250	CLASS A AMPLIFIER AS TRIODE AS PENTODE CLASS A AMPLIFIER CLASS B AMPLIFIER	250	-28.0	—	26.0	2400	2600	6.0	5000	1.25
†Power output values are for 2 tubes at indicated plate-to-plate load.																			
RCA-71-A	POWER AMPLIFIER TRIODE	MEDIUM 6-PIN	FIG. 1	4 1/2" x 1 1/8"	FILAMENT	5.0	0.25	180	—	CLASS A AMPLIFIER	90	-19.0	—	—	10.0	2170	1400	3.0	3000
RCA-75	DUPLEX-DIODE HIGH-MU TRIODE	SMALL 6-PIN	FIG. 13	4 1/2" x 1 1/8"	HEATER	6.3	0.3	250	—	TRIODE UNIT AS CLASS A AMPLIFIER	180	-43.0	—	—	20.0	1750	1700	3.0	4800
†Gain per stage = 50-60.																			
RCA-77	TRIPLE-GRID SUPER-CONTROL DETECTOR	SMALL 6-PIN	FIG. 11	4 1/2" x 1 1/8"	HEATER	6.3	0.3	250	100	SCREEN GRID R.F. AMPLIFIER	100	-1.5	60	0.4	1.7	650000	1100	715	—
†Cathode current 0.65 ma.																			
RCA-78	TRIPLE-GRID SUPER-CONTROL AMPLIFIER	SMALL 6-PIN	FIG. 11	4 1/2" x 1 1/8"	HEATER	6.3	0.3	250	125	SCREEN GRID R.F. AMPLIFIER	180	-3.0	75	1.0	4.0	1000000	1100	1100	—
†Cathode current 0.65 ma.																			
RCA-79	TWIN-TRIODE AMPLIFIER	SMALL 6-PIN	FIG. 19	4 1/2" x 1 1/8"	HEATER	6.3	0.6	250	—	CLASS B AMPLIFIER	180	0	—	—	—	—	—	—	—
†Power output value is for one tube at stated load, plate-to-plate.																			
RCA-85	DUPLEX-DIODE TRIODE	SMALL 6-PIN	FIG. 13	4 1/2" x 1 1/8"	HEATER	6.3	0.3	250	—	TRIODE UNIT AS CLASS A AMPLIFIER	135	-10.5	—	—	3.7	11000	750	8.3	25000
†Cathode current 0.160 ma.																			
RCA-89	TRIPLE-GRID POWER AMPLIFIER	SMALL 6-PIN	FIG. 14	4 1/2" x 1 1/8"	HEATER	6.3	0.4	250	250	CLASS A AMPLIFIER AS TRIODE AS PENTODE CLASS A AMPLIFIER CLASS B AMPLIFIER	160	-20.0	—	—	17.0	3300	1425	4.7	7000
†Cathode current 0.400 ma.																			
UV-199 UX-199	DETECTOR AMPLIFIER TRIODE	SMALL 4-PIN	FIG. 10 FIG. 1	3 1/2" x 1 1/8" 4 1/2" x 1 1/8"	D-C FILAMENT	3.3	0.063	90	—	CLASS A AMPLIFIER	90	-4.5	—	—	2.5	15500	425	6.6	—
RCA-864	AMPLIFIER TRIODE	SMALL 4-PIN	FIG. 1	4" x 1 1/8"	D-C FILAMENT	1.1	0.25	135	—	CLASS A AMPLIFIER	90	-4.5	—	—	2.9	13500	610	8.2	—
†Grid #1 is control grid. Grid #2 is screen. Grid #3 tied to cathode. †Grid #1 is control grid. Grids #2 and #3 tied to plate. †Grids #1 and #2 connected together. Grid #3 tied to plate.																			

†For Grid-leak Detection—plate volts 45; grid return to + filament or to cathode.  
 †Either A, C or D, C. may be used on filament or heater, except as specifically noted. For use of D, C. on A-C filament types, decrease stated grid volts by 1/2 (approx.) of filament voltage.  
 †Requires different socket from small 7-pin.


RECTIFIERS

Model	Rectifier Type	Fig.	Dimensions	Filament	5.0	3.0	3.0	500	250	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum D-C Output Current	250 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere
RCA-523	FULL-WAVE RECTIFIER	FIG. 2	5 1/2" x 2 1/8"	FILAMENT	5.0	3.0	—	—	—	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum D-C Output Current	250 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-1223	HALF-WAVE RECTIFIER	FIG. 22	4 1/2" x 1 1/8"	HEATER	12.6	0.3	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-2525	RECTIFIER-DOUBLER	FIG. 5	4 1/2" x 1 1/8"	HEATER	25.0	0.3	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-1-V	HALF-WAVE RECTIFIER	FIG. 22	4 1/2" x 1 1/8"	HEATER	6.3	0.3	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-80	FULL-WAVE RECTIFIER	FIG. 2	4 1/2" x 1 1/8"	FILAMENT	5.0	2.0	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
UX-981	HALF-WAVE RECTIFIER	FIG. 3	6 1/2" x 2 1/8"	FILAMENT	7.5	1.25	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-82	FULL-WAVE RECTIFIER	FIG. 2	4 1/2" x 1 1/8"	FILAMENT	2.5	3.0	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-83	FULL-WAVE RECTIFIER	FIG. 2	5 1/2" x 2 1/8"	FILAMENT	5.0	3.0	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-84 also 421	FULL-WAVE RECTIFIER	FIG. 23	4 1/2" x 1 1/8"	HEATER	6.3	0.5	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				
RCA-866	HALF-WAVE RECTIFIER	FIG. 15	6 1/2" x 2 1/8"	FILAMENT	2.5	5.0	—	—	—	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	250 Volts, RMS	Maximum D-C Output Current	90 Milliamperes	Maximum A-C Voltage per Plate	125 Volts, RMS	Maximum D-C Output Current	100 Milliamperes	Maximum A-C Voltage per Plate	350 Volts, RMS	Maximum D-C Output Current	50 Milliamperes	Maximum A-C Voltage per Plate	350	400	550	The 550 volt rating applies to filter circuits having an input choke of at least 20 henries.	Maximum A-C Plate Voltage	700 Volts, RMS	Maximum D-C Output Current	85 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	125 Milliamperes	Maximum Peak Inverse Voltage	400 Milliamperes	Maximum A-C Voltage per Plate	500 Volts, RMS	Maximum Peak Inverse Voltage	1400 Volts	Maximum D-C Output Current	250 Milliamperes	Maximum Peak Inverse Voltage	800 Milliamperes	Maximum A-C Voltage per Plate	250 Milliamperes	Maximum Peak Inverse Voltage	50 Milliamperes	Maximum Peak Inverse Voltage	7500 Volts	Maximum Peak Plate Current	0.6 Ampere				

†Mercury Vapor Type. \* Interchangeable with type 1.

Here comes the

# 1933 Official Radio Service Manual



**\$5.00**

OVER 2,000  
ILLUSTRATIONS

OVER 700 PAGES

9 x 12 INCHES

LOOSELEAF  
FORM

FLEXIBLE  
LEATHERETTE  
COVER

The importance of the last two OFFICIAL RADIO SERVICE MANUALS to those engaged in the Radio Industry has been shown by the fact that over 52,000 copies of both editions have been purchased and are in use by manufacturers, jobbers, dealers, Service Men and experimenters. Incessant demands have encouraged us to publish a new and bigger *Service Manual* for 1933.

The new manual will not contain so many full-page illustrations as in the past for the reason that not as many new sets are being put out at present, but will have in its contents important information that has not yet appeared in print. This new "dope" is invaluable to radio men. Stress has been emphasized on giving only practical material, not complicated theory. It is bound to save time and money for everyone.

The simplicity in the makeup of the 1933 Manual makes information easy to find, accurately and quickly. As in the past the size will be 9 x 12 inches, in loose-leaf form, with flexible leatherette covers.

Many additional features will be included in the new manual. The FREE QUESTION AND ANSWER SERVICE which was extremely popular in the previous edition will also be maintained. We assure you that the 1933 OFFICIAL RADIO SERVICE MANUAL will be a revelation in radio literature. Advance orders are now being accepted at the price of \$5.00. Take advantage of this low price—send your order today. Be among the early ones to get a copy from the first printing. Checks or money orders accepted—register letter if it contains cash or unused U. S. Postage Stamps.

## The following are partial contents of the 1933 Manual:

Complete operating notes, and hints from actual experience with radio receivers in the field, collected by practical Service Men all over the country.

Complete actual, pictorial views of hundreds of commercial receivers with additional schematic diagrams. Location of parts on the chassis are shown, and where important adjustments must be made. This section alone is worth the price of the book.

Values of all intermediate frequencies used in superheterodynes, and a complete section of valuable service data on superheterodynes.

Values of resistors and condensers, to aid in replacement work. Latest information on combination long- and short-wave receivers, short-wave adapters and converters.

How to tune and service short-wave receivers for best results.

How to use the most modern servicing instruments.

Complete section showing how the Service Man can build himself service instruments, oscillators, etc., at very low cost.

Complete section on the construction of all test equipment, including high- and low-frequency oscillators, tube checkers, ohmmeters, etc.

Tube-chart information on all new and old tubes, in handy form for quick reference; indicating socket connections and operating values, thereby preventing confusion.

An entire section on money-making suggestions for Service Men, written by the Service Men themselves who have made a success of the business; giving you short cuts and commercial information on how to get the most out of the servicing game.

Service information on interference elimination, with practical data and many examples of interference prevention.

Automobile radio installation and servicing—hints on automobile radio in general. Complete data on servicing all known, commercial, automobile receivers with short cuts to get quickly at the seat of the trouble.

Service kinks, servicing short cuts, and miscellaneous servicing information.

A complete section of various radio tables of every imaginable kind, in constant use by up-to-date Service Men.

A large section giving complete technical data on meters of every kind pertaining to servicing in general.

Complete index and cross-index to make it easy for you to find almost anything pertaining to service *instantly*.

## FREE QUESTION AND ANSWER SERVICE

In every copy of the 1933 Manual, 24 coupons will be found, which will entitle you to 24 thorough and complete answers by mail on servicing and operating on any of the sets or circuits mentioned in the manual, as well as any others not mentioned, for which you might have need. This service alone is worth \$6.00. But it is absolutely free to manual owners.

GERNSBACK PUBLICATIONS, Inc. RMA  
96-98 Park Place, New York, N. Y.

I am enclosing herewith my remittance of \$5.00 for which you are to send me one copy of the 1933 OFFICIAL RADIO SERVICE MANUAL at the price of \$5.00 each. Checks or money orders accepted. Register letter if it contains cash or unused U. S. postage stamps.


Name.....

Address.....

City..... State.....

THE OFFICIAL RADIO SERVICE MANUAL  
FOR 1933 COMES TO YOU COMPLETE  
THIS YEAR—NO SUPPLEMENTS

**VACUUM TUBE CHART**  
**TUBE SYMBOLS AND BOTTOM VIEWS OF SOCKET CONNECTIONS**



**INDEX OF TYPES BY USE AND BY CATHODE VOLTAGE**

CATHODE VOLTS	POWER AMPLIFIERS	VOLTAGE AMPLIFIERS <i>Including Duplex-Grid &amp; Triode</i>	CONVERTERS IN SUPERHETERODYNES	DETECTORS	MIKER TUBES IN SUPERHETERODYNES	RECTIFIERS	CATHODE VOLTS
5.0	112-A, 71-A	01-A, '40, 112-A	6A7, 6E7	01-A, 01-A, '40, 112-A	6A7, 6E7, 39-44, 7B	523, 80, 83	5.0
6.3	6A4, 38, 41, 42, 79, 89	6B7, 6E7, 36, 37, 39-44, 75, 77, 78, 85		6B7, 6E7, 36, 37, 75, 77, 85		1-4, 84	6.3
7.5	30, 50					81	7.5
12.6						1223	12.6
25.0	43					2525	25.0
30.0	48						30.0
1.5	19, 31, 33, 49	30, 32, 34	1A6	30, 32	1A6, 34		1.5
2.0	2A3, 2A5, 45, 46, 47, 53, 59	2A6, 2B7, 24-A, 27, 35, 55, 56, 57, 58	2A7	2A6, 2B7, 24-A, 27, 55, 56, 57	2A7, 35, 58	82, 866 (C-366)	2.0
2.5							2.5
3.3	'20	22, '99		'99			3.3

# The Radio-Craft Library Series covers accurately every branch of Radio—and thoroughly, too

Presented on this page are the new books of the RADIO-CRAFT LIBRARY—the most complete and authentic set of volumes treating individually, important divisions of radio. Each book has been designed to give radio men the opportunity to specialize in one or more of the popular branches of the industry. The material contained


in these books will increase your knowledge; you will find them a real help in your work and they will contribute to your money earning capacity. Read these books during your spare time at home.

The authors of these books are well-known to everybody. Each one is an expert radio man; an authority on the subject—each is thoroughly

familiar with the field which he represents.

This is perhaps the first real opportunity that you have ever had to build a radio library of books that are authentic, right-up-to-the-minute and written so that they are easily digested and clearly understood. Mail coupon below for your books.

**TO THE RIGHT  
WILL BE FOUND  
A SHORT RESUMÉ  
OF EACH BOOK**



**Book No. 1  
Radio Set Analyzers**

**And How To Use Them**  
With Full Instructions and Descriptions of Set Analyzers, Tube Checkers, Oscillators, Etc.  
By L. VAN DER MEL

This book explains thoroughly the operation of set analyzers, tube checkers, oscillators and other testing equipment. For every radio man this book is extremely helpful. It covers every phase of testing and gives you valuable short cuts; completely illustrated with photographs and diagrams to facilitate the use of modern testers. Recently reprinted.

**Book No. 2  
Modern Vacuum Tubes**

**And How They Work**  
With complete Technical Data on All Standard and Many Special Tubes  
By ROBERT HERTZBERG

MODERN VACUUM TUBES describes the fundamental electron theory which is the basis of all vacuum tube operation, and goes progressively from the simplest two-element tubes right up to the latest pentodes and thyatrons. It is written in clear, simple language and is devoid of the mathematics which is usually so confusing. Valuable reference charts and characteristic curves of standard and special tubes are to be found, also diagrams of sockets and pin connections.

**Book No. 3  
The Superheterodyne Book**

**All About Superheterodynes**  
How They Work. How to Build and How to Service Them  
By CLYDE FITCH

There is no more fascinating a subject in the large array of radio circuits than the famous superheterodyne circuit. Whether you are a Service Man or experimenter, first-hand knowledge about the construction of superheterodyne receivers is very important. The book on Superheterodynes gives underlying principles of their construction, right from the very first set made.

**Book No. 4  
Modern Radio Hook-Ups**

**The Best Radio Circuits**  
A Complete Compendium of the Most Important Experimental and Custombuilt Receivers  
By R. D. WASHBURNE

It is fascinating to the experimenter, or even to the up-to-date Service Man, to take a commercial set and to change it into one using a famous hookup that is not found in any manufactured set. Many excellent circuits have never been commercialized, but limited only to home set builders. Thousands of these popular circuits have been requested from time to time, and in this book we have included over 150 circuits, which include the famous Perldyne, Cash-Box A.C.-D.C. Set and others.

**Book No. 5  
How to Become a Radio Service Man**

**How to Get Started and How to Make Money in Radio Servicing**  
By LOUIS MARTIN

The ambition of many men in radio today is to become a first-grade Service Man. It is not as difficult as one might believe, but it cannot be done in a few short months. Following very carefully the advice of Mr. Martin, who has dealt with the problems of thousands of Service Men, this book deals very carefully with the essential stages in the preparation for qualifying as a Service Man.

**Book No. 6  
Bringing Electric Sets Up to Date**

**With Pentodes, Multi-Mus. Dynamic Speakers—Complete Information How to Modernize A. C., D. C. and Battery Operated Receivers**  
By CLIFFORD E. DENTON

In this country there are over ten million electrically operated receivers that could be modernized—by placing in them new type tubes, new speaker equipment and other modern improvements. This business of improving old sets ran so to the experimenters and Service Men if they will quickly jump into action.

**Book No. 7  
Radio Kinks and Wrinkles**

**For Service Men and Experimenters**  
A Complete Compendium on the Latest Radio Short-Cuts and Money-Savers  
By C. W. PALMER

It often becomes necessary for experimenters and Service Men to call upon their memory for some short cut or radio wrinkle that will solve a problem quickly. In business, "short cuts" mean time and money saved, and to the Service Man "time saved" means money earned.

**Book No. 8  
Radio Questions and Answers**

**A Selection of the Most Important of 5,000 Questions Submitted by Radio Men During the Course of One Year**  
By R. D. WASHBURNE

There have been collected a wide variety of questions which have come into our editorial offices during the past two years, and only those whose answers would benefit the majority of men engaged in radio have been incorporated in this amazing question and answer book. A tremendously long list of topics is treated.

**Book No. 9  
Automobile Radio and Servicing**

**A Complete Treatise on the Subject Covering All Phases from Installing to Servicing and Maintenance**  
By LOUIS MARTIN

Automobile radios are up and coming, and someone has to service them properly. It therefore behooves you to read this immensely important new book on the art of Automobile Radio. The book is concise, and full of illustrations, photographs, diagrams and hookups.

A few of the really interesting chapters: Introduction; Automotive Radio Installations; Complete Descriptions of Commercial Automotive Receivers; Servicing Automotive Receivers; The Ignition System; General Service Considerations; Effects of Temperature on Power Supply; Conclusion.

**Book No. 10  
Home Recording and All About It**

**A Complete Treatise on Instantaneous Recordings, Microphones, Recorders, Amplifiers, Commercial Machines, Servicing, etc.**  
By GEORGE J. SALIBA

If there is one subject that is fascinating to every radio man, it is that of Home Recording. Of course, this volume is not all on "Home" recording, but the information contained therein is important to commercial radio men, studio operators, engineers and others interested in this phase of radio.

The art of recording and reproducing broadcast selections is becoming more important every day to radio men, experimenters and Service Men. Equipping dance halls, auditoriums, churches, restaurants and homes with public address systems and amplifiers brings many extra dollars and often an excellent income.

**Book No. 11  
Point-to-Point Resistance Measurements**

**The Modern Method of Servicing Radio Receivers**  
By CLIFFORD E. DENTON

Of the difficult problems which Service Men face today when repairing receivers, the greatest is that of replacing proper resistance values in sets. This task becomes even more difficult when the values of resistors are unknown; and manufacturers of many standard sets do not use this information on to Service Men. In this new book radio men will find the information needed to quickly place a receiver in normal operating condition. This book cuts in half the time usually required to adjust the average set. Sufficient space has been devoted to the elementary problems and the theory of electricity as it is applied to resistance measurements so that the Service Man will have a comprehensive idea as to how to overcome this problem. Below you will find a partial list of the contents which will appear in this new book.

INTRODUCTION. Advantages of Resistance Measurement Method of Servicing for Radio Work; Basic Principles; Methods of Resistance Measurement; Resistors in Radio Receivers and Amplifiers; Point-to-Point Resistance Measurements in Typical Radio Set using Ohmmeter; Resistance Measurement using Modern Tester; Routine Testing where Circuit Diagram is Available and where Resistance are Unknown; the Relation of Voltage Testing Methods to Resistance Measurement; APPENDIX. Resistance Charts, etc.

**ALL BOOKS UNIFORM** The books in the new RADIO-CRAFT LIBRARY are all strictly up-to-date, and written by men who know their subjects. The volumes are all uniform size, 6x9 inches, and contain on an average of 50 to 120 illustrations. Each book is printed on fine book paper and no expense has been spared to make it an outstanding value, for its editorial contents as well as from the mechanical standpoint.

**Clip Coupon and Mail Today!**

RM-4

GERNSBACK PUBLICATIONS, INC., 96-98 Park Place, New York, N. Y.

I have circled below the numbers of books in the RADIO-CRAFT LIBRARY, which you are to send me, and have deducted 20% for ordering five (5) books or more. I have included my remittance in full, at the price of 50c each, when less than five books are ordered.

The amount of my remittance is.....(Stamps, checks or money orders accepted.)  
Circle numbers wanted: 1 2 3 4 5 6 7 8 9 10 11

Name ..... Address .....

City ..... State .....

## Big Discount to You

In order to make it possible for everyone to buy these books, the fifty (50) cent price has been made uniform for all volumes. You can buy these books separately, but you should take advantage of our special offer:

**When Five (5) Books or More Are Ordered**

**Deduct 20% from Your Remittance**

Simply fill in the coupon at left, and mail it to us together with your remittance. Checks, stamps or money orders accepted.





# The Best **NEWS** of the Year

Your Copy  
is Ready!

Every man connected in any way with the booming auto-radio business will want a copy of this book immediately. It is devoted exclusively to auto-radio service "dope," in complete, understandable form. The OFFICIAL AUTO-RADIO SERVICE MANUAL contains schematic diagrams, chassis layouts, mounting instructions, and trouble-shooting hints on all 1933 and many older model auto-radio receivers. This Manual contains a "gold-mine" of information.

Over 200 Pages

Over 500  
Illustrations

9x12 Inches

Flexible, Loose-  
Leaf Cover



## Order Your Copy Today!


You have the opportunity to get your copy of the 1933 OFFICIAL AUTO-RADIO SERVICE MANUAL from the first printing of which we have copies on hand. The Auto-Radio Service Manuals are selling so quickly that already another print order has been authorized. We urge you to get your copy now so that it will not be necessary for you to go through the summer without a copy of this manual.

**\$2<sup>50</sup>**  
PREPAID

**GERNSBACK PUBLICATIONS, Inc.**

96-98 Park Place

New York, N. Y.



**MAIL THIS COUPON TODAY!**

GERNSBACK PUBLICATIONS, Inc.  
96-98 Park Place, New York, N. Y.

RM 4

Enclosed you will find my remittance of \$2.50 for which please send me One Copy of the 1933 OFFICIAL AUTO-RADIO SERVICE MANUAL. (Send remittance in check or money order. Register letter if it contains cash or currency.)

Name .....

Address .....

City ..... State .....


# BROADCAST STATIONS OF THE U. S.

A list of all the broadcast stations in the U. S. as licensed by the Federal Radio Commission and brought up to date to May 1, 1933.

Abbreviations: T, location of transmitter; C. P., construction permit authorized; LS, power until local sunset.

Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)	Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)	Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)
KABC	San Antonio, Tex.	100	1420	211.3	KGDY	Huron, S. D.	250	1340	223.9	KOOS	Marshfield, Ore.	100	1370	219
KALE	Portland, Ore.	500	1300	230.8	KOEK	Yuma, Colo.	100	1200	250	KORE	Eugene, Ore.	100	1420	211.3
KARK	Little Rock, Ark.	250	890	337.1	KGER	Long Beach, Calif.	1kw	1360	220.6	KOY	Phoenix, Ariz.	1kw-LS	1390	215.8
KASA	Elk City, Okla.	100	1210	247.9	KGEZ	Kalispell, Mont.	100	1310	229	KPCB	Seattle, Wash.	100	650	462
KBPS	Portland, Ore.	100	1420	211.3	KGFF	Shawnee, Okla.	100	1420	211.3	KPJM	Prescott, Ariz.	100	1500	200
KBTM	Paragould, Ark.	100	1200	250	KGFG	Oklahoma City, Okla.	100	1370	219	KPO	San Francisco, Calif.	5kw	680	441
KCMC	Texarkana, Ark.	100	1420	211.3	KGFI	Corpus Christi, Tex.	100	1500	200		T-Near Belmont	C.P.50kw		
KCRC	Endid, Okla.	100	1370	219	KGFI	Los Angeles, Calif.	100	1200	250	KPQF	Denver, Colo.	500	880	341
KCRJ	Jerome, Ariz.	100	1310	229	KGFK	Moorehead, Minn.	100	1500	200	KPPC	Pasadena, Calif.	50	1210	247.9
KDB	Santa Barbara, Calif.	100	1500	200	KGFL	Raton, N. Mex.	50	1370	219	KPQ	Wenatchee, Wash.	100kw	1500	200
KDFN	Casper, Wyo.	500	1440	208.3		C. P. Roswell			KPRC	Houston, Tex.	1kw	920	326	
KDKA	Pittsburgh, Pa.	50kw	980	306	KGFW	Kearney, Nebr.	100	1310	229		T-Sugarland	2½kw-LS		
	T-Saxonburg				KGFX	Pierre, S. D.	200	630	476	KQV	Pittsburgh, Pa.	500	1380	217.4
KDLR	Devi's Lake, N. D.	100	1210	247.9	KGGC	San Francisco, Calif.	100	1420	211.3	KQW	San Jose, Calif.	500	1010	297
KDYL	Salt Lake City, Utah.	1kw	1290	232.6	KGGF	Coffeyville, Kans.	500	1010	297	KRE	Berkeley, Calif.	100	1370	219
KECA	Los Angeles, Calif.	1kw	1450	209.8		T. South Coffeyville, Okla.			KREG	Santa Ana, Calif.	100	1500	200	
KELW	Burbank, Calif.	500	750	385	KGGM	Albuquerque, N. M.	250	1230	243.9	KRGV	Harlingen, Tex.	500	1260	238.1
KERN	Bakersfield, Calif.	100	1260	250	KGHF	Pueblo, Colo.	250	1320	227.3	KRLD	Los Angeles, Calif.	500	1120	267.9
KEX	Portland, Ore.	5kw	1180	254.2	KGHI	Little Rock, Ark.	100	1200	250	KRMD	Dallas, Tex.	10kw	1040	288.5
KFAB	Lincoln, Nebr.	5kw	770	390	KGHL	Billings, Mont.	1kw	950	316	KROW	Shreveport, La.	100	1310	229
KFAC	Los Angeles, Calif.	1kw	1300	230.8	KGIR	Butte, Mont.	500	1360	220.6		Oakland, Calif.	500	930	323
KFBB	Great Falls, Mont.	1kw	1280	234.4	KGIW	Trinidad, Colo.	100	1420	211.3	KRSC	T-Richmond	1kw-LS		
KFBI	Abilene, Kans.	5kw	1050	285.7	KGIX	Las Vegas, Nev.	100	1420	211.3	KRSJ	Seattle, Wash.	100	1120	267.9
	T-Milford				KGIZ	Grant City, Mo.	100	1500	200	KSD	Manhattan, Kans.	500	580	517
KFBK	Sacramento, Calif.	100	1310	229	KGKB	Tyler, Tex.	100	1500	200	KSEI	Sioux City, Iowa.	1kw	1330	225.6
KFBL	Everett, Wash.	50	1370	219	KGKL	San Angelo, Tex.	100	1370	219	KSL	St. Louis, Mo.	500	550	545
KFOM	Beaumont, Texas.	500	560	536	KGKO	Wichita Falls, Tex.	250	570	526	KSEI	Pocatello, Idaho.	250	900	333
KFDY	Brook gs. S. D.	1kw	550	545	KGKX	Sandpoint, Idaho.	100	1420	211.3	KSO	Salt Lake City, Utah.	50kw	1130	265.5
KFEL	Denver, Colo.	500	920	326		C. P. Lewiston			KSOO	T-Saltair				
	T-Edgewater				KGKY	Scottsbluff, Nebr.	100	1500	200	KSTP	Des Moines, Iowa.	100	1370	219
KFEQ	St. Joseph, Mo.	2½kw	680	441	KGMB	Honolulu, Hawaii.	250	1320	227.3		Sioux Falls, S. D.	2½kw	1110	270.3
KFGQ	Boone, Iowa.	100	1310	229	KGNF	North Platte, Nebr.	500	1430	209.8	KTAB	St. Paul, Minn.	25kw-LS	1460	205.5
KFGU	Wichita, Kans.	1kw	1300	230.8	KGNO	Dodge City, Kans.	250	1340	223.9	KTAR	T-Radio Center			
KFH	Los Angeles, Calif.	50kw	640	469	KGOW	San Francisco, Calif.	7½kw	790	380	KTAT	San Francisco, Calif.	1kw	560	536
KFI	T-Buena Park				KGRS	T-Oakland			KTAT	T-Oakland				
KFIO	Spokane, Wash.	100	1120	267.9	KGU	Amarillo, Tex.	1kw	1410	212.8	KTAR	Phoenix, Ariz.	500	620	484
KFIZ	Fond du Lac, Wis.	100	1420	211.3	KGVO	Honolulu, Hawaii.	2½kw	750	400	KTAT	Fort Worth, Tex.	1kw	1240	241.9
KFJB	Marshalltown, Iowa.	100	1200	250	KGW	Missoula, Mont.	100	1200	250	KTBS	T-Birdville			
KFJI	Klamath Falls, Ore.	100	1210	247.9		Portland, Me.	1kw	620	484	KTFI	Shreveport, La.	1kw	1450	206.9
KFJM	Grand Forks, N. D.	100	1370	219	KGW	T-Faloma			KTHS	Twin Falls, Idaho.	1kw-LS	1240	241.9	
KFJR	Portland, Ore.	500	1300	230.8	KGW	Olympia, Wash.	100	1210	247.9		Hot Springs National Park, Ark.	10kw	1040	288.5
KFJZ	Fort Worth, Tex.	100	1370	219	KGH	Los Angeles, Calif.	1kw	900	333	KTM	Los Angeles, Calif.	500	780	385
KFKA	Greeley, Colo.	500	880	341	KHI	Spokane, Wash.	1kw	590	509	KTRH	T-Santa Monica	1kw-LS		
KFKU	Lawrence, Kan.	500	1220	245.9	KHK	Clovis, N. M.	100	1370	219	KTSA	Houston, Tex.	500	1120	267.9
	T-Tonganoxie				KHQ	Red Oak, Iowa.	100	1420	211.3	KTSM	San Antonio, Tex.	1kw	1290	232.6
KFKX	(See KYW-KFKX)				KIC	Idaho Falls, Idaho.	250	1320	227.3	KTUV	El Paso, Tex.	100	1310	229
KYW					KID	Boise, Idaho.	1kw	1350	222.2	KUJ	Seattle, Wash.	1kw	1220	245.9
KFLV	Rockford, Ill.	500	1410	212.8	KIDW	Lamar, Colo.	100	1420	211.3	KUM	Walla Walla, Wash.	100	1370	219
KFLX	Galveston, Tex.	100	1370	219	KIEV	Bureka, Calif.	100	1210	247.9	KUOA	Yuma, Ariz.	100	1420	211.3
KFNH	Shenandoah, Iowa.	500	890	337	KIFH	Glendale, Calif.	100	850	353	KUSO	Fayetteville, Ark.	1kw	1260	238.1
KFOR	Lincoln, Nebr.	100	1210	247.9	KIT	Juneau, Alaska.	100	1310	229	KVI	Vermillion, S. D.	500	890	337
KFOX	Long Beach, Calif.	1kw	1250	240	KJBS	Yakima, Wash.	100	1310	229	KWA	Tacoma, Wash.	500	570	526
KFPL	Dublin, Tex.	100	1310	229	KJR	San Francisco, Calif.	100	1070	280.4	KVL	T-Des Moines	100	1370	219
KFPW	Greenville, Tex.	15	1310	229	KJRN	Seattle, Wash.	5kw	970	309	KVOA	Seattle, Wash.	100	1570	219
KFPW	Ft. Smith, Ark.	100	1210	247.9	KKCN	Blytheville, Ark.	100	1290	232.6	KVOO	Tucson, Ariz.	500	1260	238.1
KFPY	Spokane, Wash.	1kw	1340	223.9	KLO	Ogden, Utah.	500	1400	214.3	KVOR	Tulsa, Okla.	5kw	1140	263.2
KFQD	Anchorage, Alaska.	250	1230	243.9	KLPM	Minot, N. D.	250	1240	241.9	KVOS	Colorado Spgs., Colo.	1kw	1270	236.2
KFRC	San Francisco, Calif.	1kw	610	492	KLRA	Little Rock, Ark.	1kw	1390	215.8	KWCR	Bellingham, Wash.	100	1200	250
KFRU	Columbia, Mo.	500	630	476	KLS	Oakland, Calif.	250	1440	208.3	KWEA	Cedar Rapids, Iowa.	100	1420	211.3
KFSO	San Diego, Calif.	1kw	600	500	KLX	Oakland, Calif.	1kw	880	341	KWG	Shreveport, La.	100	1210	247.9
KFSG	Los Angeles, Calif.	500	1120	267.9	KMA	Denver, Colo.	1kw	560	536	KWJ	Stockton, Cal.	100	1200	250
KFUO	Clayton, Mo.	500	550	545	KMC	Shenandoah, Iowa.	500	930	323	KWJJ	Portland, Ore.	500	1060	283
KFVO	Los Angeles, Calif.	250	1000	300	KMBC	San Antonio, Texas.	100	1370	219	KWK	St. Louis, Mo.	1kw	1350	222.2
KFVS	Cape Girardeau, Mo.	100	1210	247.9		Kansas City, Mo.	1kw	950	316		T-Kirkwood			
KFWB	Hollywood, Calif.	1kw	950	316	KMED	Medford, Ore.	100	1310	.....	KWKH	Kansas City, Mo.	100	1370	219
KFWI	St. Louis, Mo.	100	1200	250	KMJ	Fresno, Calif.	500	580	517	KWKC	Shreveport, La.	10kw	850	353
KFWI	San Francisco, Calif.	500	930	323	KMLB	Monroe, La.	100	1200	250	KWLC	T-Kennonwood			
KFXD	Nampa, Idaho.	100	1200	250	KMMJ	Clay Center, Neb.	1kw	740	405	KWSC	Decorah, Iowa.	100	1270	236.2
KFXD	Denver, Colo.	500	920	326	KMO	Tacoma, Wash.	250	1330	225.6	KWVG	Pullman, Wash.	1kw	1220	245.9
KFXJ	Grand Junction, Colo.	100	1200	250	KMOX	St. Louis, Mo.	50kw	1090	275.2	KX	Brownsville, Tex.	500	1260	238.1
KFXM	San Bernardino, Calif.	100	1210	247.9	KMPR	Beverly Hills, Calif.	500	710	423	KXA	Seattle, Wash.	250	760	395
KFXR	Oklahoma City, Okla.	100	1310	229	KMTR	Los Angeles, Calif.	500	570	526	KXL	Portland, Ore.	100	1420	211.3
KFYO	Lubbock, Texas.	100	1310	229	KMTR	Austin, Tex.	100	1500	200	KXO	El Centro, Calif.	100	1500	200
KFYR	Bismarck, N. D.	1kw	550	545	KMTR	Los Angeles, Calif.	500	570	526	KXRO	Aberdeen, Wash.	100	1310	229
KGA	Spokane, Wash.	5kw	1470	204.1	KMTR	Austin, Tex.	100	1500	200	KXYZ	Houston, Tex.	250	1440	208.3
KGAR	Tucson, Ariz.	100	1370	219	KMTR	Los Angeles, Calif.	500	570	526	KYA	San Francisco, Calif.	1kw	1230	243.9
KGB	San Diego, Calif.	1kw	1330	225.6	KMTR	Los Angeles, Calif.	500	570	526	KYW	Chicago, Ill.	10kw	1020	294.1
KGBU	Ketchikan, Alaska.	500	900	333	KMTR	Los Angeles, Calif.	500	570	526	KFKX	T-Bloomington Twp.			
KGBX	Springfield, Mo.	100	1310	229	KMTR	Los Angeles, Calif.	500	570	526	WAAB	Boston, Mass.	500	1410	212.8
KGBZ	York, Nebr.	500	930	323	KMTR	Los Angeles, Calif.	500	570	526		T-Quincy			
KGCA	Decorah, Iowa.	100	1270	236.2	KMTR	Los Angeles, Calif.	500	570	526	WAAF	Chicago, Ill.	500	920	326
KGCR	Watertown, S. D.	100	1210	247.9	KMTR	Los Angeles, Calif.	500	570	526	WAAM	Newark, N. J.	1kw	1250	240
KGCU	Mandan, N. D.	250	1240	241.9	KMTR	Los Angeles, Calif.	500	570	526	WAAT	Jersey City, N. J.	500	940	319
KGCV	Wolf Point, Mont.	100	1310	229	KMTR	Los Angeles, Calif.	500	570	526	WAAW	Omaha, Neb.	500	660	455
KGDA	Mitchell, S. D.	100	1370											

This



# Radio's GREATEST Servicing Book

**The Most Complete Directory of Radio Circuit Diagrams published!**

**In ONE VOLUME of over 2,300 Pages  
Extra Heavy Cover—Looseleaf Bound**

Buy this Big Volume on our *New*

## DEFERRED PAYMENT PLAN

Here are two of the most surprising announcements that we have ever made to the radio trade and we know that it is such good news that every radio man will be greatly enthused.

**FIRST**—that the three editions of the OFFICIAL RADIO SERVICE MANUALS have now been combined into one big volume of over 2,300 pages.

**SECOND**—that this new single volume of consolidated radio circuit diagrams and complete radio servicing course can be bought on a deferred payment plan—and at a big saving.

It is needless to say how valuable the OFFICIAL RADIO SERVICE MANUALS have been to members in every branch of the Radio Industry, and how many thousands of each edition have been sold to manufacturers, jobbers, dealers, Service Men and experimenters. But we must emphasize this one fact: Service Men now realize that they are tremendously handicapped without the full set of Gernsback Manuals. So much so, that those who have purchased only one or two volumes, are NOW ORDERING THE MISSING BOOKS. They want their files to be complete.

The complete book gives you a volume of over 2,300 pages with over 5,500 diagrams, charts and photos. There are absolutely no pages or illustrations or diagrams duplicated. There is no radio book published today which is so modern, up-to-the-minute, and which contains so much useful information as is to be found in this single volume. It is a book that will outlast any other radio book in print. Look carefully at the illustration of the complete edition on the top of page. It measures 9" wide, 12" long, 4 1/2" thick.

Included in this volume is a complete radio servicing course. This course covers every step needed to learn the servicing business . . . from starting in business . . . materials needed . . . and how to go about servicing receivers and repairing other radio equipment. This course in itself, is actually worth the price of the entire book.

Our new plan now enables every radio man to get this single volume—a Complete Directory of all Circuit Diagrams, of over 2,300 pages, on deferred payments. You can order this book immediately—get it in a few days, and use it while you are doing servicing work. You can make the first few calls pay for the entire cost of the book.

For you to get this book is quite simple and it is sent to you as soon as your order is received. You pay for it in small monthly amounts which can be taken from your earnings. If you were to buy the three volumes separately, the total cost would be \$17.00, including the supplements.

Now you can get the

1931 OFFICIAL RADIO SERVICE MANUAL, with Supplements,  
1932 OFFICIAL RADIO SERVICE MANUAL, with Supplements,  
and the 1933 OFFICIAL RADIO SERVICE MANUAL Complete  
at a big saving.

**THE SPECIAL NEW PRICE FOR ALL THREE MANUALS, WITH SUPPLEMENTS, IN ONE VOLUME, WITH HEAVY BINDER IS ONLY**

**\$14.00**

You buy this book this way—

Send \$3.00 with order—

Pay \$5.00 to Express Company upon receipt of book.

Send \$3.00 thirty days after receipt of book.

Send \$3.00 sixty days after receipt of book.

Total \$14.00.

**IF THE ENTIRE AMOUNT IS SENT WITH YOUR ORDER, WE WILL ALLOW YOU A 10% DISCOUNT. THIS CAN BE DEDUCTED FROM YOUR REMITTANCE.**

**IMMEDIATE SHIPMENT**

**Mail Coupon Today!**

**OVER 2,300 Pages  
5,500 Illustrations**

**THIS IS THE GREATEST SINGLE VOLUME RADIO BOOK IN PRINT TODAY**

GERNSBACK PUBLICATIONS, Inc.

96-98 Park Place

New York, N. Y.

GERNSBACK PUBLICATIONS, Inc. RM4  
96-98 Park Place, New York, N. Y.

Gentlemen:

In accordance with your Special Offer, I enclose herewith \$3.00 as first payment toward the One-Volume Radio Manual. Please forward it to me promptly. Upon receipt of the book, I shall pay express company \$5.00. Thirty days later I shall send you \$3.00, and sixty days after receipt of book, I shall send you my last payment of \$3.00.

If you want to take advantage of the Special Discount of 10%, remit only \$12.00 with this coupon.

Name \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_

Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)	Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)	Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)
WBOQ	T-Wayne, N. J.				WDBJ	Roanoke, Va.	250	930	323	WHBU	Anderson, Ind.	100	1210	247.9
WABI	Bangor, Maine	100	1200	250	WDJO	Orlando, Fla.	250	580	517	WHBY	Green Bay, Wis.	100	1280	250
WABO	(See WHEC-WABO)				WDEL	Wilmington, Del.	250	1120	267.9	WHDF	T-West De Pere			
WHEC					WDEW	Waterbury, Vt.	500	550	545	WHDH	Calumet, Mich.	100	1370	219
WACO	Waco, Tex.	1kw	1240	241.9	WDGY	Minneapolis, Minn.	1kw	1180	254.2	WHDL	T-Saugus	1kw	830	361
WADC	Tallmadge, Ohio	1kw	1320	227.3	WDDO	Chattanooga, Tenn.	1kw	1280	234.4	WHDR	Tupper Lake, N. Y.	100	1420	211.3
WAGM	Presque Isle, Maine	100	1420	211.3	WDRC	T-Brainerd	2 1/2 kw-LS			WHDR	Portsmouth, N. H.	250	740	405
WAIU	Columbus, Ohio	500	640	469	WDSU	Hartford, Conn.	500	1330	225.6	WHFC	T-Newington			
WALR	Zanesville, Ohio	100	1210	247.9	WDZ	T-Bloomfield				WHIS	Rochester, N. Y.	500	1440	208.3
WAMC	Anniston, Ala.	100	1420	211.3	WEAF	New Orleans, La.	1kw	1250	240	WHK				
WAML	Laurel, Miss.	100	1310	229	WEAO	T-Gretna				WHM				
WAPI	Birmingham, Ala.	5kw	1140	263.2	WEBC	Tuscola, Ill.	100	1070	280.4	WHN	Kosciusko, Miss.	100	1500	200
WARD	Brooklyn, N. Y.	500	1400	214.3	WEBC	New York, N. Y.	50kw	660	455	WHO	Troy, Ala.	100	1210	247.9
WASH	Grand Rapids, Mich.	500	1270	236.2	WEBC	T-Bellmore				WHOM	Cicero, Ill.	100	1420	211.3
WAWZ	Zarephath, N. J.	250	1350	222.2	WEBC	Providence, R. I.	250	780	385	WHOM	Bluefield, W. Va.	250	1410	212.8
WAZL	Hazleton, Pa.	100	1420	211.3	WEBC	Columbus, Ohio	750	570	526	WHOM	Cleveland, Ohio	1kw	1390	215.8
WBAA	W. Lafayette, Ind.	500	1400	214.3	WEBC	Superior, Wis.	1kw	1290	232.6	WHOM	T-Sevan Hills	2 1/2 kw-LS		
WBAC	Harrisburg, Pa.	1kw	1430	209.8	WEBC	Harrisburg, Ill.	100	1210	247.9	WHOM	New York, N. Y.	250	1010	297
WBAL	Baltimore, Md.	10kw	1060	283	WEBC	Buffalo, N. Y.	100	1310	229	WHOM	Des Moines, Iowa	5kw	1000	300
	T-Pikeville, Md.				WEBC	Chicago, Ill.	100	1210	247.9	WHOM	Jersey City, N. J.	250	1450	206.9
	Fort Worth, Tex.	50kw	800	375	WEBC	Boston, Mass.	1kw	590	509	WHOM	Harrisburg, Pa.	500	1430	209.8
WBAP	T-Grapevine				WEBC	T-Weymouth				WHOM	T-Lenoxyne	1kw-LS		
WBAX	Wilkes-Barre, Pa.	100	1210	247.9	WEBC	Reading, Pa.	1kw	830	361	WHOM	Ottumwa, Iowa	100	1310	229
	T-Plains Twp.				WEBC	Charlottesville, Va.	500	1350	222.2	WHOM	Madison, Wis.	500	1280	234.4
WBBL	Richmond, Va.	100	1210	247.9	WEBC	Cicero, Ill.	100	1420	211.3	WHOM	Glenside, Pa.	25	930	323
WBBM	Chicago, Ill.	25kw	770	390	WEBC	Battle Creek, Mich.	50	1420	211.3	WHOM	T-Elkins Park			
WJBT	T-Glenview				WEBC	Americus, Ga.	100	1420	211.3	WHOM	Jackson, Mich.	100	1370	219
WBBR	Brooklyn, N. Y.	1kw	1300	230.8	WEBC	Chicago, Ill.	50kw	870	345	WHOM	Chicago, Ill.	1kw	560	536
	T-Rossville				WEBC	T-Downers Grove				WHOM	T-Des Plaines	1 1/2 kw-LS		
WBBX	New Orleans, La.	100	1200	250	WEBC	(See WORC-WEPS)				WHOM	Poynette, Wis.	100	1210	247.9
WBBZ	Ponca City, Okla.	100	1200	250	WEBC					WHOM	Topeka, Kans.	1kw	580	517
WBCM	Bay City, Mich.	600	1410	212.8	WEBC					WHOM	Utica, N. Y.	100	1200	250
	T-Hampton Twp.				WEBC					WHOM	Bridgeport, Conn.	250	600	500
	(See WENR-WBCN)				WEBC					WHOM	T-Bridgeport	500-LS		
WBCN					WEBC					WHOM	St. Louis, Mo.	100	1200	250
WENR	Buffalo, N. Y.	1kw	900	333	WEBC					WHOM	Urbana, Ill.	250	890	337
WBEN	T-Martinsville				WEBC					WHOM	Wilmington, Del.	100	1420	211.3
WBEO	Marquette, Mich.	100	1310	229	WEBC					WHOM	T-Edge Moor			
WBHS	Huntsville, Ala.	100	1200	250	WEBC					WHOM	New York, N. Y.	500	1180	254.2
WBIG	Greensboro, N. C.	500	1440	208.3	WEBC					WHOM	T-Carlstadt, N. J.			
WBIS	(See WNAC-WBIS)				WEBC					WHOM	Miami, Fla.	1kw	1300	230.8
WNAC					WEBC					WHOM	T-Miami Beach			
WBMS	Hackensack, N. J.	250	1450	206.9	WEBC					WHOM	Philadelphia, Pa.	500	610	492
WBNO	New York, N. Y.	250	1350	222.2	WEBC					WHOM	Columbia, S. C.	500	1010	297
WBOQ	(See WABC-WBOQ)				WEBC					WHOM	Milwaukee, Wis.	250	1120	267.9
WABC					WEBC					WHOM	Johnstown, Pa.	100	1310	229
WBOW	Terre Haute, Ind.	100	1310	229	WEBC					WHOM	Norfolk, Nebr.	1kw	1060	283
WBRC	Birmingham, Ala.	500	930	323	WEBC					WHOM	Providence, R. I.	250	890	337
WBRE	Wilkes-Barre, Pa.	100	1310	229	WEBC					WHOM	Pittsburgh, Pa.	1kw	1290	232.6
WBST	Needham, Mass.	500	920	326	WEBC					WHOM	T-No. Fayette Twp.	2 1/2 kw-LS		
WBT	Charlotte, N. C.	25kw	1080	277.8	WEBC					WHOM	Jacksonville, Fla.	1kw	900	333
WBTM	Danville, Va.	100	1370	219	WEBC					WHOM	Cleveland, Ohio	500	610	492
WBZ	Boston, Mass.	25kw	990	303	WEBC					WHOM	La Salle, Ill.	100	1200	250
	T-Mills Twp.				WEBC					WHOM	Red Bank, N. J.	100	1210	247.9
WBZA	Boston, Mass.	1kw	990	303	WEBC					WHOM	Detroit, Mich.	50	1370	219
	T-East Springfield				WEBC					WHOM	T-Highland Park			
WCAC	Storrs, Conn.	250	600	500	WEBC					WHOM	Decatur, Ill.	100	1200	250
WCAD	Canton, N. Y.	500	1220	245.9	WEBC					WHOM	New Orleans, La.	100	1420	211.3
WCAE	Pittsburgh, Pa.	1kw	1220	245.9	WEBC					WHOM	C.P. Baton Rouge			
WCAH	Columbus, Ohio	500	1430	209.8	WEBC					WHOM	(See WBBM-WJBT)			
WCAJ	Lincoln, Neb.	500	590	509	WEBC					WHOM	Lewisburg, Pa.	100	1210	247.9
WCAL	Northfield, Minn.	1kw	1250	240	WEBC					WHOM	New Orleans, La.	100	1200	250
WCAM	Camden, N. J.	500	1280	234.4	WEBC					WHOM	Gadsden, Ala.	100	1210	247.9
WCAO	Baltimore, Md.	250	600	500	WEBC					WHOM	Jackson, Miss.	1kw	1270	236.2
WCAP	Asbury Park, N. J.	500	1280	234.4	WEBC					WHOM	Hagerstown, Md.	100	1210	247.9
	T-Whitesville				WEBC					WHOM	Tupelo, Miss.	500	990	303
WCAT	Rapid City, S. D.	100	1200	250	WEBC					WHOM	Williamsport, Pa.	100	1370	219
WCAU	Philadelphia, Pa.	50kw	1170	256.4	WEBC					WHOM	Mooseheart, Ill.	20kw	1130	265.5
	T-Newton, Square Co.				WEBC					WHOM	Gary, Ind.	1kw	1360	220.6
WCAX	Burlington, Vt.	100	1200	250	WEBC					WHOM	Ironwood, Mich.	100	1420	211.3
WCAY	Carthage, Ill.	50	1070	280.4	WEBC					WHOM	Detroit, Mich.	10kw	750	400
WCBA	Allentown, Pa.	250	1440	208.3	WEBC					WHOM	T-Sylvan Lake Village			
WCBD	Zion, Ill.	5kw	1080	277.8	WEBC					WHOM	Alexandria, Va.	10kw	1460	205.5
WCBE	Baltimore, Md.	100	1370	219	WEBC					WHOM	T-Mt. Vernon Hills			
WCBS	Springfield, Ill.	100	1210	247.9	WEBC					WHOM	C.P. Near Alexandria, Va.			
WCBO	Minneapolis, Minn.	50kw	810	370	WEBC					WHOM	Oglethorpe Univ., Ga.	100	1370	219
	T-Anoka				WEBC					WHOM	T-Atlanta			
WCDA	New York, N. Y.	250	1350	222.2	WEBC					WHOM	Akron, Ohio	100	1210	247.9
	T-Cliffside, N. J.				WEBC					WHOM	New York, N. Y.	30kw	760	395
WCFL	Chicago, Ill.	1 1/2 kw	970	309	WEBC					WHOM	T-Bound Brook, N. J.			
WCKY	Covington, Ky.	5kw	1490	201.3	WEBC					WHOM	San Juan, P. R.	1kw	1240	241.9
	T-Crescent Springs				WEBC					WHOM	E. Lansing, Mich.	1kw	1040	285.5
WCLO	Janesville, Wis.	100	1200	250	WEBC					WHOM	Laconia, N. H.	100	1310	229
WCLS	Joliet, Ill.	100	1310	229	WEBC					WHOM	Johet, Ill.	100	1310	229
WCOA	Pensacola, Fla.	500	1340	223.0	WEBC					WHOM	C.P. E. Dubuque	C.P. 1500		
WCOC	Meridian, Miss.	500	880	341	WEBC					WHOM	Birmingham, Ala.	100	1310	229
WCOD	Harrisburg, Pa.	100	1200	250	WEBC					WHOM	Indianapolis, Ind.	500	1400	214.3
WCOW	Chicago, Ill.	100	1210	247.9	WEBC					WHOM	T-Clermont			
WCRA	Charleston, S. C.	500	1360	220.6	WEBC					WHOM	C.P. T-Nr. Indianapolis			
WCSC	Portland, Me.	1kw	940	319	WEBC					WHOM	La Crosse, Wis.	1kw	1380	217.4
WCSH	T-Scarboro	2 1/2 kw-LS			WEBC					WHOM	Ciencero, Ill.	100	1420	211.3
WDAE	Tampa, Fla.	1kw	1220	245.9	WEBC					WHOM	Youngstown, Ohio	500	570	526
WDAF	Kansas City, Mo.	1kw	610	492	WEBC					WHOM	Connersville, Ind.	100	1500	200
WDAG	Amarillo, Tex.	1kw	1410	212.8	WEBC					WHOM	Buffalo, N. Y.	5kw	1480	202.7
WDAH	El Paso, Tex.	100	1310	229	WEBC					WHOM	T-Amberst Twp.			
WDAS	Philadelphia, Pa.	100	1370	219										



# these eminent Radio authors guide you through your service work for 1934

The importance of Radio Service Men can be appreciated when it is realized that of the 31,000,000 radio sets in the world, over one-half of that number are in use in this country. Approximately 17,000,000 must be serviced, *and the Radio Service Men are the only ones that can do this big job.*

RADIO-CRAFT is published exclusively for Service Men. It is edited with the view to give the Service Man the latest and most valuable service information obtainable. It is *the* magazine to read if you want to be successful in radio service work.

The list of contributors shown at the right represents the finest array of authorities on radio servicing on the staff of any publication. These writers are continually working for *your* benefit.

Get a copy of the current issue of RADIO-CRAFT from your newsdealer today—read it from cover to cover. Then judge for yourself if it is not the finest servicing magazine published today. Once you have read your first issue, you'll never let a month pass without getting the next issue.

As you are a Service Man, and an owner of the 1934 OFFICIAL RADIO SERVICE MANUAL, you can take advantage of this opportunity. We will send you RADIO-CRAFT for One Year at the Special Rate of \$2.00. (Canadian and foreign \$2.50). This is a saving of 1/3 over the regular newsstand rate. Send remittance in form of check, stamps or money order to

## RADIO-CRAFT MAGAZINE

96-98P PARK PLACE

NEW YORK, N. Y.



### Editors of RADIO-CRAFT

HUGO GERNSBACK  
Editor-in-Chief

R. D. WASHBURNE  
Technical Editor

C. W. PALMER  
Associate Editor

### Contributors to RADIO-CRAFT

BERTRAM M. FREED  
LOWRY E. EASLEY  
C. B. BROWN  
ALLEN BEERS  
CLYDE J. FITCH  
F. L. SPRAYBERRY  
H. G. CISIN  
ARTHUR H. LYNCH  
GEO. G. SEROTTA  
L. M. BARCUS  
DR. FRITZ NOACK  
MILTON REINER  
PAUL SHALLCROSS

Call Letters	Location	Power (watts)	Freq. kc.	Wave length (meters)	Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)	Call Letters	Location	Power (watts)	Freq. kc.	Wave-length (meters)	
WKFI	Greenville, Miss.	100	1210	247.9	WNBX	Springfield, Vt.	250	1260	238.1	WRHM	T-Tonganoxie				
WKJC	Lancaster, Pa.	100	1200	200	WNBZ	Saranac Lake, N. Y.	50	1290	232.6		Minneapolis, Minn.	1kw	1250	240	
WKRC	Cincinnati, Ohio	500	550	545	WNOX	Knoxville, Tenn.	2kw-L.S.	560	536	WRJN	Racine, Wis.	100	1370	219	
WKY	Oklahoma City, Okla.	1kw	900	333	WNYC	New York, N. Y.	500	570	526	WRNY	New York, N. Y.	250	1010	297	
WKZO	Kalamazoo, Mich.	1kw	590	509	WOAI	San Antonio, Tex.	50kw	1190	252.1		T-Coytesville, N. J.				
WLAC	Nashville, Tenn.	5kw	1470	204.1		(See WREC-WOAN)				WROL	Knoxville, Tenn.	100	1310	229	
WLAP	Louisville, Ky.	100	1200	250	WOAN-					WRR	Dallas, Tex.	500	1280	234.4	
WLB-	Minneapolis, Minn.	1kw	1250	240	WREC-					WRUF	Gainesville, Fla.	5kw	830	361	
WLGMS	T-St. Paul				WOBU	Charleston, W. Va.	250	580	517	WRVA	Richmond, Va.	5kw	1110	270.3	
WLBC	Muncie, Ind.	50	1310	229	WOC	Davenport, Iowa	5kw	1000	300		T-Mechanicsville				
WLBK	Kansas City, Kans.	100	1420	211.3	WOCL	Jamestown, N. Y.	50	1210	247.9	WSAI	Cincinnati, Ohio	500	1330	225.6	
WLBL	Stevens Point, Wis.	2 1/2kw	900	333	WODA	Paterson, N. J.	1kw	1250	240		T-Mason				
	T-Nr. Ellis				WODX	Mobile, Ala.	500	1410	212.8	WSAJ	Grove City, Pa.	100	1310	229	
WLBW	Erle, Pa.	500	1260	238.1	WOI	T-Springhill				WSAN	Allentown, Pa.	250	1440	208.3	
	T-Summit Township	1kw-L.S.			WOKO	Ames, Iowa	5kw	640	469	WSAR	Fall River, Mass.	250	1450	206.9	
WLBZ	Bangor, Me.	500	620	484	WOL	Albany, N. Y.	500	1440	208.3	WSAZ	Huntington, W. Va.	250	580	517	
WLCI	Ithaca, N. Y.	50	1210	247.9	WOMT	Washington, D. C.	100	1210	247.9	WSB	Atlanta, Ga.	5kw	740	405	
WLEY	Lexington, Mass.	100	1370	219	WOOD	Manitowoc, Wis.	100	1270	236.2	WSBC	Chicago, Ill.	100	1210	247.9	
WLIB-	(See WGN-WLIB)				WOPI	Grand Rapids, Mich.	500	1500	200	WSBT	South Bend, Ind.	500	1230	243.9	
WLIT	Philadelphia, Pa.	500	560	536	WOQ	Bristol, Tenn.	100	1270	236.2	WSEN	Columbus, Ohio	100	1210	247.9	
WLDE	Boston, Mass.	100	1500	200	WOR	Kansas City, Mo.	1kw	1300	230.8	WSFA	Montgomery, Ala.	500	1410	212.8	
	T-Chelsea	250-L.S.				Newark, N. J.	5kw	710	423	WSIX	Springfield, Tenn.	100	1210	247.9	
WLS	Chicago, Ill.	50kw	870	345	WORC-	T-Kearny	C.P. 50kw	100	1200	250	WWSJ	Winston-Salem, N. C.	100	1310	229
	T-Downers Grove				WOPS	Worcester, Mass.				WWSM	Nashville, Tenn.	50kw	650	462	
WLVA	Lynchburg, Va.	100	1370	219	WORK	T-Auburn					T-Franklin				
WLW	Cincinnati, Ohio	50kw	700	429	WOS	York, Pa.	1kw	1000	300	WSMB	New Orleans, La.	500	1320	227.3	
	T-Mason				WOW	T-W. Manchester				WSMK	Dayton, Ohio	200	1380	217.4	
WLWL	New York, N. Y.	5kw	1100	272.7	WOWO	Jefferson City, Mo.	500	630	476	WSOC	Gastonia, N. C.	100	1210	247.9	
	T-Kearny, N. J.				WPAD	New York, N. Y.	1kw	1130	265.5	WSPA	Spartanburg, S. C.	100	1420	211.3	
WMAC-	(See WSYR-WMAC)				WPAP-	T-Secaucus, N. J.				WSPD	Toledo, Ohio	1kw	1340	223.9	
WSYR					WQAC	Omaha, Nebr.	1kw	509	509	WSUI	Iowa City, Iowa	500	880	341	
WMAL	Washington, D. C.	250	630	476	WPAP-	Ft. Wayne, Ind.	10kw	1160	258.6	WSUN-	(See WFLA-WSUN)				
WMAQ	Chicago, Ill.	5kw	670	448	WQAC	Paducah, Ky.	100	1420	211.3	WSVA	Buffalo, N. Y.	50	1370	219	
	T-Addison				WPAP-	(See WPRO-WPAW)				WSYB	Rutland, Vt.	100	1500	200	
WMAS	Springfield, Mass.	100	1420	211.3	WPAP-					WSYR-	Syracuse, N. Y.	250	570	526	
WMAZ	Macon, Ga.	500	1180	254.2	WPAP-					WMAC					
WMBC	Detroit, Mich.	100	1420	211.3	WPRO	Chicago, Ill.	500	560	536	WTAD	Quincy, Ill.	500	1440	208.3	
WMBD	Peoria, Ill.	500	1440	208.3	WPRO	New York, N. Y.	500	810	370	WTAM	Worcester, Mass.	500-L.S.	580	517	
	T-Peoria Heights	1kw-L.S.			WPPC	T-Flushing					Cleveland, Ohio	50kw	1070	280.4	
	(See WIOD-WMBF)				WPCH	Philadelphia, Pa.	100	1500	200	WTAR-	T-Brecksville Village				
WMBF-					WPEN	Hattiesburg, Miss.	100	1370	219	WTAW	Eau Claire, Wis.	1kw	1330	225.6	
W100	Richmond, Va.	100	1210	247.9	WPFB	Atlantic City, N. J.	5kw	1100	272.7		T-Twp. of Washington				
WMBG	Joplin, Mo.	100	1420	211.3	WPG	Petersburg, Va.	100	1200	250	WTAR-	Norfolk, Va.	500	780	385	
WMBH	Chicago, Ill.	5kw	1080	277.8	WPHR	T-Ettrick				WPRO-	College Station, Tex.	500	1120	257.9	
	T-Addison					(See WTAR-WPOR)				WTAX	Springfield, Ill.	100	1210	247.9	
WMO	Auburn, N. Y.	100	1310	229	WPOR-	Providence, R. I.	100	1210	247.9	WTAX	Cumberland, Md.	100	1420	211.3	
WMBQ	Brooklyn, N. Y.	100	1500	200	WPRO-	T-Providence				WTBO	Philadelphia, Pa.	100	1310	229	
WMBR	Tampa, Fla.	100	1370	219	WPAW	Raleigh, N. C.	1kw	680	441	WTCL	Athens, Ga.	500	1450	206.9	
WMC	Memphis, Tenn.	500	780	385	WPTF	Miami, Fla.	1kw	560	536	WTFI	Hartford, Conn.	50kw	1060	283	
	T-Bartlett	1kw-L.S.			WQAM	Scranton, Pa.	250	880	341	WTIC	T-Avon				
WMCA	New York, N. Y.	500	570	526	WQAN	New York, N. Y.	250	1010	297	WTMJ	Jackson, Tenn.	100	1310	229	
	T-Flushing				WQAO-	T-Cliffside, N. J.					Milwaukee, Wis.	1kw	620	484	
WMIL	Brooklyn, N. Y.	100	1500	200	WQAO-	Vicksburg, Miss.	500	1360	220.6	WTNJ	T-Waukesha	2 1/2kw-L.S.			
WMMN	Fairmont, W. Va.	250	890	337	WQBC	St. Albans, Vt.	100	1370	219	WTOT	Trenton, N. J.	500	1280	234.4	
WMPC	Lapeer, Mich.	100	1500	200	WQDM	Thomasville, Ga.	100	1210	247.9	WTOT	Savannah, Ga.	500	1260	238.1	
WMSG	New York, N. Y.	250	1350	222.2	WQDX	Williamsport, Pa.	100	1370	219	WTOT	Elkhart, Ind.	100-L.S.	1310	229	
WMT	Waterloo, Iowa	500	600	500	WRAC	Wilmington, N. C.	100	1370	219	WVAE	Hammond, Ind.	100	1200	250	
WNAC-	Boston, Mass.	1kw	1230	243.9	WRAM	Reading, Pa.	100	1310	229	WWJ	Detroit, Mich.	1kw	920	326	
WBIS	T-Quincy				WRAP	Philadelphia, Pa.	250	1020	294.1	WWL	New Orleans, La.	10kw	850	353	
WNAD	Norman, Okla.	500	1010	297	WRAP	Columbus, Ga.	100	1200	250		T-Kenner				
WNAX	Yankton, S. D.	2 1/2kw-L.S.	570	526	WRAP	Roanoke, Va.	250	1410	212.8	WWNC	Asheville, N. C.	1kw	570	526	
WNBK	Binghamton, N. Y.	100	1500	200	WRAP	Washington, D. C.	500	950	316	WWRL	Woodside, N. Y.	100	1500	200	
WNBH	New Bedford, Mass.	100	1310	229	WRAP	Augusta, Me.	100	1370	219	WWSW	Pittsburgh, Pa.	100	1500	200	
	T-Fairhaven	250-L.S.			WRAP	Augusta, Ga.	100	1500	200	WWVA	T-Wilkinsburg	250-L.S.			
WNBO	Silverhaven, Pa.	100	1200	250	WRAP	Memphis, Tenn.	500	600	500	WXYZ	Wheeling, W. Va.	5kw	1160	258.6	
WNBR-	Memphis, Tenn.	500	1430	209.8	WRAP	T-Whitehaven	1kw-L.S.	1220	245.9		Detroit, Mich.	1kw	1240	241.9	
WGBC					WRAP	Lawrence, Kans.	1kw								
WNB	Carbondale, Pa.	10	1200	250	WRAP										

POLICE STATIONS ALPHABETICALLY BY CALL LETTERS

Call Letters	Location	Freq. kc.	Call Letters	Location	Freq. kc.	Call Letters	Location	Freq. kc.	Call Letters	Location	Freq. kc.
KGHO	Des Moines, Iowa	1534	KGZE	San Antonio, Tex.	2506	WPKD	Milwaukee, Wis.	2450	WPFL	W. Bridgewater, Mass.	1574
KGJX	Pasadena, Calif.	1712	KGZF	Chanute, Kans.	2450	WPKL	Lansing, Mich.	2442	WPPE	Arlington, Mass.	1712
KGOZ	Cedar Rapids, Iowa	2470	KGZH	Klamath Falls, Ore.	2442	WPKM	Dayton, Ohio	2430	WPET	Lexington, Mass.	1712
KGPA	Seattle, Wash.	2414	KGZI	Wichita Falls, Tex.	1712	WPKN	Auburn, N. Y.	2458	WPFF	Portable, Mass.	1574
KGFB	Minneapolis, Minn.	2416	KGZL	Shreveport, La.	1712	WPKO	Akron, Ohio	2458	WPFA	Newton, Mass.	1712
KGPC	St. Louis, Mo.	1712	KGZM	El Paso, Tex.	2414	WPKP	Philadelphia, Pa.	2470	WPFC	Muskegon, Mich.	2442
KGPD	San Francisco, Calif.	2470	KGZN	Tacoma, Wash.	2414	WPKR	Rochester, N. Y.	2458	WPFD	Highland Park, Ill.	2430
KGPE	Kansas City, Mo.	2422	KGZP	Coffeyville, Kans.	2450	WPKS	St. Paul, Minn.	2416	WPFE	Reading, Pa.	2442
KGPF	Vallejo, Calif.	2422	KGZR	Salem, Ore.	2442	WPKT	Kokomo, Ind.	2470	WPFF	Toms River, N. J.	2430
KGPH	Oklahoma City, Okla.	2450	KSW	Berkeley, Calif.	2422	WPKU	Pittsburgh, Pa.	1712	WPFG	Jacksonville, Fla.	2442
KGPI	Omaha, Neb.	2470	KVP	Dallas, Tex.	1712	WPKV	Charlotte, N. C.	2458	WPFH	Baltimore, Md.	2414
KGPJ	Beaumont, Tex.	1712	WCK	Belle Island, Mich.	2414	WPKW	Washington, D. C.	2422	WPFI	Columbus, Ga.	2414
KGPL	Los Angeles, Calif.	1712	WKDU	Cincinnati, Ohio	1712	WPKX	Detroit, Mich.	2414	WPFJ	Hammond, Ind.	1712
KGPM	San Jose, Calif.	2470	WKDZ	Indianapolis, Ind.	2442	WPKY	Atlanta, Ga.	2414	WPFK	Hackensack, N. J.	2430
KGPN	Davenport, Iowa	2470	WMIJ	Buffalo, N. Y.	2422	WPKZ	Fort Wayne, Ind.	2470	WPFL	Gary, Ind.	2470
KGPO	Tulsa, Okla.	2450	WMO	Highland Park, Mich.	2414	WPEA	Syracuse, N. Y.	2458	WPFM	Birmingham, Ala.	2414
KGPP	Portland, Ore.	2442	WMP	Framingham, Mass.	1574	WPEB	Grand Rapids, Mich.	2442	WPFN	Fairhaven, Mass.	1712
KGQP	Honolulu, T. H.	2450	WPDA	Tulare, Calif.	2414	WPEC	Memphis, Tenn.	2470	WPFO	Knoxville, Tenn.	2470
KGQS	Bakersfield, Calif.	2414	WPDB	Chicago, Ill.	1712	WPEE	New York, N. Y.	2450	WPFP	Clarksburg, W. Va.	2414
KGPV	Salt Lake City, Utah	2470	WPDC	Chicago, Ill.	1712	WPEF	New York, N. Y.	2450	WPFG	Swathmore, Pa.	2470
KGPK	Denver, Colo.	2442	WPDD	Chicago, Ill.	1712	WPEG	New York, N. Y.	2450	WPFH	Johnson City, Tenn.	2470
KGPY	Shreveport, La.	1574	WPDE	Louisville, Ky.	2422	WPEH	Flint, Mich.	2442	WPRD		

RT-I RADIO HOME TRAINING

OK

... say these **30**  
**Leading Radio Manufacturers**  
... to their **40,000**  
**DISTRIBUTORS**  
and **DEALERS**  
throughout **United States**  
and **Canada**

- AMERICAN BOSCH
- AMERICAN TELEVISION
- ARCTURUS TUBES
- BALKEIT • BRUNSWICK
- CAPEHART
- CLOUGH-BREngle CO.
- CROSLY • CLARION
- DEFORREST • ECHOPHONE
- FADA • GREBE • HOWARD
- HAMMERLUND • HICKOK
- INTERNATIONAL
- RESISTANCE CO.
- KENNEDY • KOLSTER • LYRIC
- MAJESTIC • PHILCO
- RADIO PRODUCTS CO.
- SANGAMO ELECTRIC
- SENTINEL • SHELDON
- SILVER-MARSHALL CO.
- STEWART RADIO
- STEWART-WARNER
- STROMBERG-CARLSON
- UNIVERSAL MICROPHONE
- ZENITH

The need for men, PROPERLY trained, is one of the Radio Industry's major problems, today.

In fact, the very future of the Radio Industry is dependent on the industry having available, at all times, an adequate supply of PROPERLY trained men to install and service—not only the present-day highly complicated Radio and Electronic equipment—but the still more complicated equipment that will be brought out by the industry, from time to time.

The above manufacturers all realize this. They know that under such circumstances, no ordinary Radio Training is going to give them the type of "trained" man they want. Only a Training that is right-up-to-the-minute, and properly prepared, highly practical, and properly supervised, will answer their purpose.

Radio and Television Institute home-training has successfully met their every test. That's why these manufacturers recommend R. T. I. Trainings, not only to their own men, everywhere—but to all men who want to get somewhere in Radio.

★This entire advertisement approved by the above thirty-two manufacturers.  
Copyright 1933 by R.T.I.

# LEARN RADIO FROM REAL RADIO ENGINEERS



**HERE THEY ARE:**  
 Dr. C. M. Blackburn, Chief Radio Engineer, Grigsby-Grunow Company (Majestic),  
 Kendall Clough, Chief Engineer Clough-Brengle Co. (Radio Engineers and Manufacturers)  
 Karl Hassel, Chief Engineer, Zenith Radio Corporation,  
 Homer Hoagan, Gen. Manager, Radio Station KYW, Chicago,  
 R. MacGregor, Service Manager and Sales Engineer, America (Clarion),  
 H. C. Tittle, Chief Radio Engr., Stewart-Warner Corporation,  
 F. D. Whitten, Service Manager, Chicago Plant, Philco Radio and Television Corporation,  
 —and R.T.I. Staff.

## LET THESE ENGINEERS RIGHT FROM THE HEART OF THE BIG RADIO INDUSTRY Train You at Home for GOOD PAY RADIO WORK

To the man who wants to make \$35 to \$75 a week and more—Here's a Message for You!

"The great Radio Industry, today—more than ever before—is on the lookout for PROPERLY trained men to fill its more responsible jobs. These are the better-paying jobs in Radio... jobs which give steady work at good pay, as a starter; and an early advancement to still better-paying jobs, as a future."

### HERE, THEN, IS REAL OPPORTUNITY

But to qualify for these better-paying jobs, men must be PROPERLY "trained"—they must know the theory of Radio, as well as the practical side, and be able to teach other men some of the things they know. The Radio Industry, itself, has no time to train these men. That's why the Radio & Television Institute, of Chicago, is doing the job. You'll be trained at home—in your spare time—easily and quickly, and at a cost of only a few cents a day. And as you are taught to "earn as you learn"—R. T. I. Training need cost you nothing.

### R.T.I. TRAINING IS "SHOP TRAINING" FOR THE HOME

It comes to you right from the Radio Industry—right out of the factories where Radio sets and other vacuum-tube devices are made. It was planned and prepared for you by big radio engineers IN these factories, most of whom are the Chief Engineers of these great Radio plants. And NOW these same engineers are actually supervising R. T. I. Training. Which means that trained the R.T.I. way, you'll be trained as the Radio Industry wants you trained—just as the Radio Industry, itself, would train you if it was doing the job.

You learn by doing, of course, because that's the Shop Way of teaching. But you also learn the theory of Radio—without which you can't hope to go far, or make much money, in this great industry.

**ELECTRONICS—SOUND PICTURES**  
**P. A. SYSTEMS—PHOTO CELLS—**  
**TELEVISION—all included**

Radio service is just the starting point in R.T.I. Training. From there we take you up through the very latest developments in Radio, and

then on into the new and larger field of Electronics—Sound Pictures, Public Address Systems, Photo Cells, and Television. This feature alone makes R. T. I. the outstanding home training in Radio.

### YOU GET "QUICK RESULTS"

C. E. Head, 431 Third St., Alexandria, La., Says: "Made my first money 11 days after starting your training—cleared \$14.25."

Frank E. Klemann, Lisle, Ill., writes: "Doubled my pay in less than six months."

Harry L. Stark, Ft. Wayne, Ind., writes: "Now making three times as much money as I was making when I started your training."

So, if you want to get out of a small pay, no-future job, and into good pay, big-future work—get into Radio. But let these big engineers direct your training.



### MAIL COUPON FOR FREE BOOK

Let me tell you more about this amazingly easy Shop-Type home-training, and more about the wonderful opportunities for the R. T. I. TRAINED man in this—the world's fastest growing industry. Everything is fully explained in my big, new booklet... "RADIO'S FUTURE, AND YOURS." Send today for your copy. The book is free.





















Ray D. Smith, President,  
Radio and Television Institute, Chicago

Ray D. Smith, President,  
RADIO AND TELEVISION INSTITUTE, (R.T.I.),  
2130 Lawrence Ave., Dept. 111, Chicago, Ill.  
Without obligation of any kind please send me a copy of "Radio's Future and Yours." I am interested in your home training and the opportunities you say exist in the great field of Radio for the R.T.I. Trained man.

Name.....  
Address.....  
City..... State.....

# VIBRATOR INVERTER SERVICE ADJUSTMENT CHART

Check All Adjustments on Vibrators Requiring Adjustments of Any Kind



DETAILS OF PROPER METHOD OF ADJUSTING VIBRATOR ARMATURE