



# Engineer's Mini-Notebook

Formulas, Tables and  
Basic Circuits




Forrest M. Mims III

**Radio Shack**

A Division of Tandy Corporation  
Fort Worth, TX 76102

PRINTED IN U.S.A.



276-5016

**Radio Shack**



# CIRCUIT SYMBOLS

FIXED RESISTOR	VARIABLE RESISTOR	FIXED CAPACITOR	POLARIZED CAPACITOR
RECTIFIER/DIODE	ZENER DIODE	PNP TRANSISTOR	NPN TRANSISTOR
LED	SOLAR CELL	PHOTO-RESISTOR	PHOTO-TRANSISTOR
CONNECTED WIRES	UNCONNECTED WIRES	POSITIVE SUPPLY	GROUND
SPST SWITCH	SPDT SWITCH	NORMALLY OPEN PUSHBUTTON	NORMALLY CLOSED PUSHBUTTON
RELAY	TRANSFORMER	SPEAKER	PIEZO-SPEAKER
METER	LAMP	BATTERY	OP-AMP

# ENGINEER'S MINI-NOTEBOOK

## FORMULAS, TABLES AND BASIC CIRCUITS

BY  
FORREST M. MIMS, III

FIRST EDITION  
FIRST PRINTING - 1988  
SECOND PRINTING - 1991  
THIRD PRINTING - 1993  
A SILICONCONCEPTS™ BOOK

COPYRIGHT © 1988 BY FORREST M. MIMS, III  
ALL RIGHTS RESERVED

PRINTED IN THE UNITED STATES OF AMERICA



THIS BOOK INCLUDES STANDARD APPLICATION CIRCUITS AND CIRCUITS DESIGNED BY THE AUTHOR. EACH CIRCUIT WAS ASSEMBLED AND TESTED BY THE AUTHOR AS THE BOOK WAS DEVELOPED. AFTER THE BOOK WAS COMPLETED, THE AUTHOR REASSEMBLED EACH CIRCUIT TO CHECK FOR ERRORS. WHILE REASONABLE CARE WAS EXERCISED IN THE PREPARATION OF THIS BOOK, VARIATIONS IN COMPONENT TOLERANCES AND CONSTRUCTION METHODS MAY CAUSE THE RESULTS YOU OBTAIN TO DIFFER FROM THOSE GIVEN HERE. THEREFORE THE AUTHOR AND RADIO SHACK ASSUME NO RESPONSIBILITY FOR THE SUITABILITY OF THIS BOOK'S CONTENTS FOR ANY APPLICATION. SINCE WE HAVE NO CONTROL OVER THE USE TO WHICH THE INFORMATION IN THIS BOOK IS PUT, WE ASSUME NO LIABILITY FOR ANY DAMAGES RESULTING FROM ITS USE. OF COURSE IT IS YOUR RESPONSIBILITY TO DETERMINE IF COMMERCIAL USE, SALE OR MANUFACTURE OF ANY DEVICE THAT INCORPORATES INFORMATION IN THIS BOOK INFRINGES ANY PATENTS, COPYRIGHTS OR OTHER RIGHTS.

DUE TO THE MANY INQUIRIES RECEIVED BY RADIO SHACK AND THE AUTHOR, IT IS NOT POSSIBLE TO PROVIDE PERSONAL RESPONSES TO REQUESTS FOR ADDITIONAL INFORMATION (CUSTOM CIRCUIT DESIGN, TECHNICAL ADVICE, TROUBLESHOOTING ADVICE, ETC.). IF YOU WISH TO LEARN MORE ABOUT ELECTRONICS, SEE OTHER BOOKS IN THIS SERIES AND RADIO SHACK'S "GETTING STARTED IN ELECTRONICS." ALSO, READ MAGAZINES LIKE MODERN ELECTRONICS AND RADIO-ELECTRONICS. THE AUTHOR WRITES A MONTHLY COLUMN, "ELECTRONICS NOTEBOOK," FOR MODERN ELECTRONICS.

# CONTENTS

1. ELECTRONIC FORMULAS	
DIRECT CURRENT	4-5
ALTERNATING CURRENT	6-7
2. MATHEMATICS	
SYMBOLS	8
POWERS OF TEN	8
ALGEBRAIC TRANSPOSITION	9
LAW OF EXPONENTS	9
COMMON LOGARITHMS	9
THE DECIBEL	10-11
NUMBER SYSTEMS (BINARY & HEX)	12-13
3. CONSTANTS AND STANDARDS	
U.S. & METRIC WEIGHTS & MEASURES	14-15
TEMPERATURE	16
COPPER WIRE; RELATIVE RESISTANCES	17
AUDIO FREQUENCY SPECTRUM	18
SOUND INTENSITY LEVELS	19
ELECTROMAGNETIC SPECTRUM	20
RADIO FREQUENCY SPECTRUM	21
FREQUENCY VS. WAVELENGTH	21
IMPORTANT FREQUENCIES	22
TIME CONVERSIONS	23
WAVES, PULSES AND SIGNALS	24-27
4. CODES AND SYMBOLS	
ALPHABET, ASCII AND MORSE CODE	28-29
GREEK ALPHABET AND SYMBOLS	30
RESISTOR COLOR CODE	31
TRANSFORMER COLOR CODE	31
5. ELECTRONIC ABBREVIATIONS	32-35
6. BASIC ELECTRONIC CIRCUITS	36-41
7. BASIC LOGIC CIRCUITS	42-45
8. POWER SUPPLIES	46-48
	3



# 1. ELECTRONIC FORMULAS

## DIRECT CURRENT

A DIRECT CURRENT (DC) FLOWS IN ONE DIRECTION, EITHER STEADILY OR IN PULSES.

CURRENT (I) - THE QUANTITY OF ELECTRONS PASSING A GIVEN POINT. (UNIT: AMPERE)

VOLTAGE (V) - ELECTRICAL PRESSURE OR FORCE. (UNIT: VOLT)

RESISTANCE (R) - RESISTANCE TO THE FLOW OF A CURRENT. (UNIT: OHM)

POWER (P) - THE WORK PERFORMED BY A CURRENT. (UNIT: WATT)

POTENTIAL DIFFERENCE - THE DIFFERENCE IN VOLTAGE BETWEEN THE TWO ENDS OF A CONDUCTOR THROUGH WHICH A CURRENT FLOWS. ALSO KNOWN AS VOLTAGE DROP.

## OHM'S LAW

A POTENTIAL DIFFERENCE OF 1 VOLT WILL FORCE A CURRENT OF 1 AMPERE THROUGH A RESISTANCE OF 1 OHM, OR:


$$V = I \times R$$

OHM'S LAW HELPER

$$I = \frac{V}{R}$$

$$R = \frac{V}{I}$$

$$P = I \times V \text{ (OR) } I^2 \times R$$




THIS DIAGRAM SHOWS THE RELATIONSHIP OF V, I AND R.

4

# RESISTOR NETWORKS


## SERIES

$R_T = \text{TOTAL RESISTANCE}$




$$R_T = R_1 + R_2 + R_3$$

## PARALLEL (2)




$$R_T = \frac{R_1 \times R_2}{R_1 + R_2}$$

## PARALLEL (2 OR MORE)



$$R_T = \frac{1}{\frac{1}{R_1} + \frac{1}{R_2} + \frac{1}{R_N}}$$

## VOLTAGE DIVIDER



$$V_{OUT} = V_{IN} \times \left( \frac{R_2}{R_1 + R_2} \right)$$


R1 AND R2 CAN BE A POTENTIOMETER.

5



# ALTERNATING CURRENT

AN ALTERNATING CURRENT (AC) FLOWS IN BOTH DIRECTIONS THROUGH A CONDUCTOR.



SEE THE DEFINITIONS OF I, V, R AND P ON PAGE 4.

**PEAK VOLTAGE** - MAXIMUM POSITIVE AND NEGATIVE EXCURSIONS OF AN ALTERNATING CURRENT.

**RMS VOLTAGE** - (ROOT-MEAN-SQUARE VOLTAGE) THAT AC VOLTAGE THAT EQUALS A DC VOLTAGE THAT DOES THE SAME WORK. FOR A SINE WAVE, 0.707 TIMES THE PEAK VOLTAGE.

**IMPEDANCE (Z)** - THE OPPOSITION TO AN ALTERNATING CURRENT PRESENTED BY A CIRCUIT. (UNIT: OHM)

$$\begin{aligned} \text{AVERAGE AC VOLTAGE} &= 0.637 \times \text{PEAK} \\ &= 0.9 \times \text{RMS} \end{aligned}$$

$$\begin{aligned} \text{RMS AC VOLTAGE} &= 0.707 \times \text{PEAK} \\ &= 1.11 \times \text{AVERAGE} \end{aligned}$$

$$\begin{aligned} \text{PEAK AC VOLTAGE} &= 1.414 \times \text{RMS} \\ &= 1.57 \times \text{AVERAGE} \end{aligned}$$

6

# OHM'S LAW

$$V = I \times Z$$

$$I = \frac{E}{Z}$$


$$Z = \frac{E}{I}$$

$$P = E \times I \times \cos \theta$$


$\theta$  IS PHASE ANGLE, THE DIFFERENCE IN DEGREES BETWEEN CURRENT AND VOLTAGE. CURRENT LEADS VOLTAGE IN A CAPACITIVE CIRCUIT AND LAGS VOLTAGE IN A REACTIVE CIRCUIT. IN A RESISTIVE CIRCUIT  $\theta$  IS  $0^\circ$ . THE COSINE OF  $0^\circ$  IS 1. THUS IN A RESISTIVE CIRCUIT  $P = E \times I$ .

# CAPACITOR NETWORKS


## SERIES



## SERIES



## PARALLEL (2 OR MORE)



7



## 2. MATHEMATICS

### SYMBOLS

+	PLUS, POSITIVE OR ADD
-	MINUS, NEGATIVE OR SUBTRACT
x OR *	MULTIPLY
÷ OR /	DIVIDE
=	EQUAL(S)
≠	DOES NOT EQUAL
≈	APPROXIMATELY EQUAL
>	GREATER THAN
≥	EQUAL TO OR GREATER THAN
<	LESS THAN
≤	LESS THAN OR EQUAL TO
±	PLUS OR MINUS; CHANGE SIGN
$\frac{1}{n}$	RECIPROCAL ( $\frac{1}{2} = 0.5$ )
$\sqrt{n}$	SQUARE ROOT OF n
$\sqrt[3]{n}$	CUBE ROOT OF n

### POWERS OF TEN

$10^{-9}$	= 0.000000001	1 BILLIONTH (NANO)
$10^{-8}$	= 0.00000001	
$10^{-7}$	= 0.0000001	
$10^{-6}$	= 0.000001	1 MILLIONTH (MICRO)
$10^{-5}$	= 0.00001	
$10^{-4}$	= 0.0001	
$10^{-3}$	= 0.001	1 THOUSANDTH (MILLI)
$10^{-2}$	= 0.01	
$10^{-1}$	= 0.1	
$10^0$	= 1	1 UNIT
$10^1$	= 10	
$10^2$	= 100	
$10^3$	= 1,000	THOUSAND (KILO)
$10^4$	= 10,000	
$10^5$	= 100,000	
$10^6$	= 1,000,000	MILLION (MEGA)
$10^7$	= 10,000,000	
$10^8$	= 100,000,000	
$10^9$	= 1,000,000,000	BILLION (GIGA)

8

## ALGEBRAIC TRANSPOSITION

IF  $A + B = C$ , THEN: IF  $\frac{A}{B} = \frac{C}{D}$ , THEN:

$$A = C - B$$

$$AD = BC$$

$$B = C - A$$

$$A = \frac{BC}{D}$$

$$A + B - C = 0$$

$$B = \frac{AD}{C}$$

IF  $A = \frac{B}{C}$ , THEN:

$$C = \frac{AD}{B}$$

$$B = AC$$

$$D = \frac{BC}{A}$$

$$C = \frac{B}{A}$$

### LAW OF EXPONENTS

$$\left(\frac{a}{b}\right)^x = \frac{a^x}{b^x} \quad (a^x)(a^y) = a^{x+y}$$

$$\frac{a^x}{a^y} = a^{x-y} \quad (a^x)^y = a^{xy}$$

$$a^{-x} = \frac{1}{a^x} \quad a^{\frac{x}{y}} = \sqrt[y]{a^x}$$

### COMMON LOGARITHMS

THE COMMON LOGARITHM ( $\log_{10}$  OR  $\log$ ) OF A NUMBER IS THE POWER OF 10 THAT EQUALS THE NUMBER. SINCE  $10^2 = 100$ , 2 IS THE LOG OF 100. THE ANTILOGARITHM (ANTILOG) IS THE NUMBER THAT EQUALS A LOGARITHM. THUS THE ANTILOG OF 2 IS 100. THE LOG OF NUMBERS GREATER THAN 1 IS POSITIVE; THE LOG OF NUMBERS LESS THAN 1 IS NEGATIVE. THUS THE LOG OF  $10^{-2}$  OR 0.01 IS -2.  $A \times B = \text{ANTILOG}(\log A + \log B)$ ;  $A \div B = \text{ANTILOG}(\log A - \log B)$ . SCIENTIFIC CALCULATORS HAVE LOG AND ANTILOG KEYS.

9



## THE DECIBEL

THE DECIBEL (dB) IS A UNIT OF MEASURE THAT PERMITS TWO DIFFERENT SIGNALS TO BE COMPARED ON A LOGARITHMIC SCALE. THE SENSITIVITY OF RECEIVERS AND THE GAIN OF AMPLIFIERS ARE OFTEN GIVEN IN DECIBELS. THE DIFFERENCE IN dB BETWEEN THE POWER OF A SIGNAL AT THE INPUT OF AN AMPLIFIER (P1) AND THE POWER OF THE AMPLIFIER'S OUTPUT (P2) IS:

$$dB = 10 \log (P2/P1)$$


THE DIFFERENCE IN dB BETWEEN THE VOLTAGE (V) AND CURRENT (I) AT THE INPUT (V1 AND I1) AND OUTPUT (V2 AND I2) OF AN AMPLIFIER IS:

$$dB = 20 \log (V2/V1)$$

$$dB = 20 \log (I2/I1)$$

NOTE THAT DECIBELS DEFINE THE RATIO BETWEEN TWO SIGNAL LEVELS, NOT THEIR ABSOLUTE VALUE.

EXAMPLE: DETERMINE THE VOLTAGE GAIN IN dB OF THIS OPERATIONAL AMPLIFIER.



$$R1 = 1,000 \Omega$$

$$R2 = 1,000,000 \Omega$$

$$\text{VOLTAGE GAIN} = R2/R1$$

$$dB = 20 \log (V2/V1)$$

$$dB = 20 \log (1,000 / 1) = 20 \log 1,000$$

$$\log 1,000 = 3 \text{ (FROM TABLE OR CALCULATOR)}$$

$$\text{GAIN} = 20 \times 3 = 60 \text{ dB}$$

10

## DECIBEL (dB) TABLE

-			+		
VOLTAGE OR CURRENT RATIO	POWER RATIO	dB	VOLTAGE OR CURRENT RATIO	POWER RATIO	dB
1.0000	1.0000	0	1.0000	1.0000	0
.8913	.7943	1	1.1220	1.2589	1
.7943	.6310	2	1.2589	1.5849	2
.7079	.5012	3	1.4125	1.9953	3
.6310	.3981	4	1.5849	2.5119	4
.5623	.3162	5	1.7783	3.1623	5
.5012	.2512	6	1.9953	3.9811	6
.4467	.1995	7	2.2387	5.0119	7
.3981	.1585	8	2.5119	6.3096	8
.3548	.1259	9	2.8184	7.9433	9
.3162	.1000	10	3.1623	10.000	10
.1000	.0100	20	10.000	100.00	20
.0316	.0010	30	31.623	1,000.0	30
.0100	.0001	40	100.00	10,000	40
.0032	.00001	50	316.23	100,000	50
.0010	10 <sup>-6</sup>	60	1,000.0	10 <sup>6</sup>	60
.0003	10 <sup>-7</sup>	70	3,162.3	10 <sup>7</sup>	70
.0001	10 <sup>-8</sup>	80	10,000	10 <sup>8</sup>	80
.00003	10 <sup>-9</sup>	90	31,623	10 <sup>9</sup>	90
.00001	10 <sup>-10</sup>	100	100,000	10 <sup>10</sup>	100

## POWER - dBm EQUIVALENTS

RECEIVER SENSITIVITY IS OFTEN GIVEN IN dB WITH RESPECT TO 1 MILLIWATT.

dBm	POWER (mW)	UNITS
10	10.000000	10 MILLIWATTS
0	1.000000	1 MILLIWATT
-10	.100000	100 MICROWATTS
-20	.010000	10 MICROWATTS
-30	.001000	1 MICROWATT
-40	.000100	100 NANOWATTS
-50	.000010	10 NANOWATTS
-60	.000001	1 NANOWATT

11



## NUMBER SYSTEMS

A NUMBER SYSTEM CAN BE BASED ON ANY NUMBER OF DIGITS. THE COMMON DECIMAL SYSTEM HAS 10 DIGITS. THE BINARY SYSTEM HAS 2 DIGITS; THE HEXADECIMAL SYSTEM HAS 16 DIGITS. NUMBERS ARE WRITTEN AS SUCCESSIVE POWERS OF THE BASE OF THE NUMBER SYSTEM. THUS:

$$\begin{array}{r}
 4327_{10} \\
 \leftarrow 7 \times 10^0 = 7 \times 1 = 7 \\
 \leftarrow 2 \times 10^1 = 2 \times 10 = 20 \\
 \leftarrow 3 \times 10^2 = 3 \times 100 = 300 \\
 \leftarrow 4 \times 10^3 = 4 \times 1000 = 4000 \\
 \hline
 4327
 \end{array}$$

## BINARY NUMBERS

IN ELECTRONIC CIRCUITS DECIMAL NUMBERS ARE USUALLY REPRESENTED BY BINARY NUMBERS. BINARY NUMBERS ALSO SERVE AS CODES THAT REPRESENT LETTERS OF THE ALPHABET, VOLTAGES, COMPUTER INSTRUCTIONS, ETC. A BINARY 0 OR 1 IS A BIT. A PATTERN OF 4 BITS IS A NIBBLE. A PATTERN OF 8 BITS IS A BYTE OR WORD.

### BINARY TO DECIMAL

$$\begin{array}{r}
 10011 \\
 \leftarrow 1 \times 2^0 = 1 \\
 \leftarrow 1 \times 2^1 = 2 \\
 \leftarrow 0 \times 2^2 = 0 \\
 \leftarrow 0 \times 2^3 = 0 \\
 \leftarrow 1 \times 2^4 = 16 \\
 \hline
 19
 \end{array}$$

### DECIMAL TO BINARY

$$\begin{array}{l}
 19 \div 2 = 9 + 1 \\
 9 \div 2 = 4 + 1 \\
 4 \div 2 = 2 + 0 \\
 2 \div 2 = 1 + 0 \\
 \phantom{2 \div 2} = 1^* \\
 19 = 10011
 \end{array}$$

\* FINAL QUOTIENT IS FINAL REMAINDER

BINARY CODED DECIMAL (BCD): A SYSTEM IN WHICH EACH DECIMAL DIGIT IS ASSIGNED ITS BINARY EQUIVALENT (19 = 0001 1001).

## NUMBER SYSTEM EQUIVALENTS

DEC (DECIMAL) BIN (BINARY)  
BCD (BINARY CODED DECIMAL) HEX (HEXADECIMAL)

DEC	BIN	BCD	HEX
0	0	0000 0000	0
1	1	0000 0001	1
2	10	0000 0010	2
3	11	0000 0011	3
4	100	0000 0100	4
5	101	0000 0101	5
6	110	0000 0110	6
7	111	0000 0111	7
8	1000	0000 1000	8
9	1001	0000 1001	9
10	1010	0001 0000	A
11	1011	0001 0001	B
12	1100	0001 0010	C
13	1101	0001 0011	D
14	1110	0001 0100	E
15	1111	0001 0101	F
16	10000	0001 0110	10
17	10001	0001 0111	11
18	10010	0001 1000	12
19	10011	0001 1001	13
20	10100	0010 0000	14
21	10101	0010 0001	15
22	10110	0010 0010	16
23	10111	0010 0011	17
24	11000	0010 0100	18
25	11001	0010 0101	19
26	11010	0010 0110	1A
27	11011	0010 0111	1B
28	11100	0010 1000	1C
29	11101	0010 1001	1D
30	11110	0011 0000	1E
31	11111	0011 0001	1F
32	100000	0011 0010	20
64	1000000	0110 0100	40
96	1100000	1001 0110	60
99	1100011	1001 1001	63



### 3. CONSTANTS AND STANDARDS

#### U.S. WEIGHTS AND MEASURES

##### LINEAR

1,000 MILS = 1 INCH (IN)    3 FT = 1 YARD (YD)  
12 INCHES = 1 FOOT (FT)    5,280 FT = 1 MILE (MI)

##### AREA

1 FOOT<sup>2</sup> = 144 IN<sup>2</sup>    1 ACRE = 43,560 FT<sup>2</sup>  
1 YARD<sup>2</sup> = 9 FT<sup>2</sup>    1 MILE<sup>2</sup> = 640 ACRES

##### VOLUME

1 FOOT<sup>3</sup> = 1,728 IN<sup>3</sup>    1 YARD<sup>3</sup> = 27 FEET<sup>3</sup>

##### MASS

16 OUNCES (OZ) = 1 POUND (LB)

#### METRIC WEIGHTS AND MEASURES

##### LINEAR

1,000 MICROMETERS ( $\mu\text{m}$ ) = 1 MILLIMETER (mm)  
10 mm = 1 CENTIMETER (cm)    100 cm = 1 METER (m)  
1,000 METERS = 1 KILOMETER (KM)

##### AREA

100 mm<sup>2</sup> = 1 cm<sup>2</sup>    10,000 cm<sup>2</sup> = 1 m<sup>2</sup>

##### VOLUME

1 cm<sup>3</sup> = 1 MILLILITER (ml)    1,000 ml = 1 LITER (l)

##### MASS

1,000 MILLIGRAMS (mg) = 1 gram (g)

14

### U.S. - METRIC CONVERSION

<u>TO CONVERT</u>	<u>INTO</u>	<u>MULTIPLY BY</u>
MICROMETERS	MILS	$3.937 \times 10^{-2}$
MILS	MICROMETERS	25.4
MILLIMETERS	MILS	39.37
MILS	MILLIMETERS	$2.54 \times 10^{-2}$
MILLIMETERS	INCHES	$3.937 \times 10^{-2}$
INCHES	MILLIMETERS	25.4
CENTIMETERS	INCHES	0.3937
INCHES	CENTIMETERS	2.54
INCHES	METERS	$2.54 \times 10^{-2}$
METERS	INCHES	39.37
FEET	METERS	$30.48 \times 10^{-2}$
METERS	FEET	3.281
METERS	YARDS	1.094
YARDS	METERS	0.9144
KILOMETERS	FEET	3281
FEET	KILOMETERS	$3.408 \times 10^{-4}$
KILOMETERS	MILES	0.6214
MILES	KILOMETERS	1.609
GRAMS	OUNCES	$3.527 \times 10^{-2}$
OUNCES	GRAMS	28.3495
KILOGRAMS	POUNDS	2.205
POUNDS	KILOGRAMS	0.4536

#### FAMILIAR EXAMPLES

##### DIMENSIONS

DIME  $\approx$  1 mm  $\times$  1.8 cm  
NICKEL  $\approx$  2 mm  $\times$  2.1 cm  
QUARTER  $\approx$  2 mm  $\times$  2.4 cm  
1-MIL PLASTIC FILM = 25.4  $\mu\text{m}$

##### MASS

PLASTIC TD-92 TRANSISTOR  $\approx$  0.25 g  
8-PIN MINI DIP IC  $\approx$  0.5 g  
16-PIN DIP IC  $\approx$  1.05 g  
NICKEL  $\approx$  5 g


15



# TEMPERATURE

$^{\circ}\text{FAHRENHEIT} = (^{\circ}\text{CELSIUS} \times \frac{9}{5}) + 32 = ^{\circ}\text{F}$

$^{\circ}\text{CELSIUS} = \frac{5}{9} \times (^{\circ}\text{FAHRENHEIT} - 32) = ^{\circ}\text{C}$



# SOLDER

THE MOST COMMON ELECTRONIC SOLDER IS 60/40 (60% TIN AND 40% LEAD). ITS MELTING POINT IS 183° TO 190°C (341° TO 374°F).

# COPPER WIRE

AWG	DIA	OHMS PER 1000 FT	FT PER POUND
10	101.9	9989	31.82
12	80.8	1588	50.59
14	64.1	2525	80.44
16	50.8	4016	127.9
18	40.3	6385	203.4
20	32.0	1015	323.4
22	25.4	1614	514.2
24	20.1	2567	817.7
26	15.9	4081	1300.0
28	12.6	6490	2067.0
30	10.0	1032	3287.0
32	7.9	1641	5227.0
34	6.3	2609	8310.0
36	5.0	4148	13210.0
38	4.0	6596	21010.0
40	3.1	10490	33410.0

AWG - AMERICAN WIRE GAUGE  
 DIA - DIAMETER IN MILS  
 OHMS PER 1000 FT - 20°C (68°F)


# RELATIVE RESISTANCES

MATERIAL	RELATIVE RESISTANCE	RELATIVE TO COPPER. 1 FOOT OF CIRCULAR COPPER WIRE 1 MIL IN DIAMETER HAS A RESISTANCE OF 10.37 OHMS.
SILVER	0.936	
COPPER	1.000	
GOLD	1.403	
CHROMIUM	1.530	
ALUMINUM	1.549	
TUNGSTEN	3.203	
BRASS	4.822	
PHOSPHOR-BRONZE	5.533	
NICKEL	5.786	
IRON	5.799	
TIN	6.702	
STEEL	9.932	
LEAD	12.922	
STAINLESS STEEL	52.941	
NICHROME	65.092	



# AUDIO FREQUENCY SPECTRUM

MECHANICAL VIBRATION IN SOLIDS, FLUIDS AND GASES PRODUCES WHAT THE BRAIN PERCEIVES AS SOUND.




# SOUND INTENSITY LEVELS

SOUND SOURCE (DISTANCE FROM OBSERVER)	LEVEL (dB)
THRESHOLD OF PAIN	120+
AIRCRAFT ENGINE (20')	120+
AMPLIFIED ROCK MUSIC	110
THUNDER	110
PIEZOELECTRIC BUZZER (12")	108
AIR FORCE T-38 (2,500' OVERHEAD)	90
CO <sub>2</sub> PELLET GUN (12")	90
DIGITAL ALARM CLOCK (12")	85
ELECTRIC TYPEWRITER (18")	80
AIR FORCE T-38 (1 MILE)	70
TYPICAL CONVERSATION	65
PAPER CLIP DROPPED ON DESK (12")	62
TELEPHONE DIAL TONE (1")	56
PENCIL ERASER TAPPED ON DESK (12")	54
COMPUTER KEYBOARD (18")	61
AVERAGE RESIDENCE	45
SOFT BACKGROUND MUSIC	30
QUIET WHISPER	20
THRESHOLD OF HEARING	0



# ELECTROMAGNETIC SPECTRUM



# RADIO FREQUENCY SPECTRUM

FREQUENCY	CLASSIFICATION
3-30 KHz	VERY LOW FREQUENCIES (VLF)
30-300 KHz	LOW FREQUENCIES (LF)
300-3000 KHz	MEDIUM FREQUENCIES (MF)
3-30 MHz	HIGH FREQUENCIES (HF)
30-300 MHz	VERY HIGH FREQUENCIES (VHF)
300-3000 MHz	ULTRA HIGH FREQUENCIES (UHF)
3-30 GHz	SUPER HIGH FREQUENCIES (SHF)
30-300 GHz	EXTREMELY HIGH FREQUENCIES (EHF)
300-3000 GHz	MICROWAVE FREQUENCIES

## FREQUENCY VS. WAVELENGTH

$$\lambda = \frac{c}{f} \quad f = \frac{c}{\lambda}$$

λ - WAVELENGTH (METERS)  
c - SPEED OF LIGHT ( $3 \times 10^8$  METERS/SEC)  
f - FREQUENCY (HERTZ)

EXAMPLE: THE WAVELENGTH OF A 108 MHz SIGNAL IS  $3 \times 10^8 / 1.08 \times 10^6$  OR 2.78 METERS.



## IMPORTANT FREQUENCIES (MHz)

.15 - .54: NAVIGATION BEACONS  
 .5 : INTERNATIONAL DISTRESS  
 .54 - 1.6: AM BROADCAST BAND  
 1.61: AIRPORT INFORMATION  
 1.8 - 2.0: 160 METER AMATEUR BAND  
 2.3 - 2.498: 120 METER INT. BROADCAST  
 2.5: WWV TIME SIGNAL  
 3.5 - 4.0: 80 METER AMATEUR BAND  
 5.0: WWV TIME SIGNAL  
 5.95 - 6.2: 49 METER INT. BROADCAST  
 6.2 - 6.525: MARITIME COMMUNICATIONS  
 7.0 - 7.3: 40 METER AMATEUR  
 7.0 - 7.3: 40 METER INT. BROADCAST  
 9.5 - 9.9: 31 METER INT. BROADCAST  
 10.0: WWV TIME SIGNAL  
 10.1 - 10.15: 30 METER AMATEUR BAND  
 10.15 - 11.175: INT. BROADCAST  
 11.7 - 11.975: 25 METER INT. BROADCAST  
 14.0 - 14.35: 20 METER AMATEUR BAND  
 15.0: WWV TIME SIGNAL  
 20.0: WWV TIME SIGNAL  
 21.0 - 21.45: 15 METER AMATEUR BAND  
 21.45 - 21.85: 13 METER INT. BROADCAST  
 24.89 - 24.99: 12 METER AMATEUR BAND  
 25.67 - 26.1: 11 METER INT. BROADCAST  
 26.9 - 27.4: CITIZENS BAND  
 28.0 - 29.7: 10 METER AMATEUR BAND  
 49.82 - 49.9: LOW POWER COMMUNICATIONS  
 50.0 - 54.0: 6 METER AMATEUR BAND  
 54.0 - 88.0: TELEVISION (CH. 2-6)  
 72.03 - 72.9: RADIO CONTROL (AIRCRAFT ONLY)  
 75.43 - 75.87: RADIO CONTROL  
 88.0 - 108.0: FM BROADCAST BAND  
 88.0 - 108.0: WIRELESS MICROPHONES  
 108.0 - 118.0: AIR NAVIGATION BEACONS  
 118.0 - 136.0: AIRCRAFT  
 153 - 155: POLICE, FIRE, MUNICIPAL  
 158 - 159: POLICE, FIRE, MUNICIPAL  
 162.4 - 162.55: NOAA WEATHER  
 174 - 216: TELEVISION (CH. 7-13)  
 470 - 890: TELEVISION (CH. 14-83)

22

## TIME CONVERSIONS

UTC	PST	MST	CST	EST	AST
0000	4 PM	5 PM	6 PM	7 PM	8 PM
0100	5 PM	6 PM	7 PM	8 PM	9 PM
0200	6 PM	7 PM	8 PM	9 PM	10 PM
0300	7 PM	8 PM	9 PM	10 PM	11 PM
0400	8 PM	9 PM	10 PM	11 PM	MIDNT
0500	9 PM	10 PM	11 PM	MIDNT	1 AM
0600	10 PM	11 PM	MIDNT	1 AM	2 AM
0700	11 PM	MIDNT	1 AM	2 AM	3 AM
0800	MIDNT	1 AM	2 AM	3 AM	4 AM
0900	1 AM	2 AM	3 AM	4 AM	5 AM
1000	2 AM	3 AM	4 AM	5 AM	6 AM
1100	3 AM	4 AM	5 AM	6 AM	7 AM
1200	4 AM	5 AM	6 AM	7 AM	8 AM
1300	5 AM	6 AM	7 AM	8 AM	9 AM
1400	6 AM	7 AM	8 AM	9 AM	10 AM
1500	7 AM	8 AM	9 AM	10 AM	11 AM
1600	8 AM	9 AM	10 AM	11 AM	12 AM
1700	9 AM	10 AM	11 AM	12 AM	1 PM
1800	10 AM	11 AM	12 AM	1 PM	2 PM
1900	11 AM	12 AM	1 PM	2 PM	3 PM
2000	12 AM	1 PM	2 PM	3 PM	4 PM
2100	1 PM	2 PM	3 PM	4 PM	5 PM
2200	2 PM	3 PM	4 PM	5 PM	6 PM
2300	3 PM	4 PM	5 PM	6 PM	7 PM

UTC - COORDINATED UNIVERSAL TIME  
(GREENWICH MERIDIAN TIME, LONDON)

PST - PACIFIC STANDARD TIME

MST - MOUNTAIN STANDARD TIME

CST - CENTRAL STANDARD TIME

EST - EASTERN STANDARD TIME

AST - ATLANTIC STANDARD TIME


DAYLIGHT SAVINGS TIME - ADD 1 HOUR

23



# THE SINE WAVE

THE SINE OR SINUSOIDAL WAVE IS THE MOST COMMON PERIODIC WAVE IN ANALOG ELECTRONIC CIRCUITS. IF PEAK AMPLITUDES ARE +1 AND -1, THEN:



FREQUENCY OF A SINE WAVE IS THE NUMBER OF CYCLES PER SECOND. HERTZ (Hz) IS THE UNIT OF FREQUENCY. ONE HERTZ (1Hz) IS ONE CYCLE PER SECOND (1 CPS).

PERIOD OF A SINE WAVE IS THE TIME FOR ONE COMPLETE CYCLE TO OCCUR.

# PERIODIC WAVES

MANY DIFFERENT PERIODIC WAVEFORMS CAN BE PROCESSED OR GENERATED BY ANALOG ELECTRONIC CIRCUITS. THEY INCLUDE:


## SQUARE WAVE




## RECTANGULAR WAVE




## TRIANGLE WAVE




## SAWTOOTH WAVE




PERIODIC WAVES CAN BE RECTIFIED BY DIODES AND CLIPPED BY ZENER DIODES:




## HALF-WAVE RECTIFIED SINE WAVE




## RECTIFIED SINE WAVE



## FULL-WAVE RECTIFIED SINE WAVE



## CLIPPED SAWTOOTH



## TRAPEZOIDAL WAVE







# PULSES

SINGLE PULSES OR TRAINS OF PERIODIC PULSES ARE PROCESSED AND GENERATED BY DIGITAL ELECTRONIC CIRCUITS. THEY ARE ALSO USED TO TRIGGER (ACTIVATE) MANY KINDS OF CIRCUITS.

## THE IDEAL PULSE



## A REAL PULSE



## PULSE TRAIN




# SIGNALS

ELECTRONIC SIGNALS RANGE FROM AUDIBLE TONES TO COMPLEX INFORMATION CARRIED BY A FLUCTUATING (ANALOG) OR PULSATING (DIGITAL) WAVE, CURRENT OR VOLTAGE. MANY MODULATION METHODS ARE USED TO IMPRESS A SIGNAL ON A CARRIER.


## MODULATION METHODS

### ANALOG

### PULSE



### DIGITAL









## GREEK ALPHABET

NAME	U	L	NAME	U	L
ALPHA	A	α	NU	Ν	ν
BETA	B	β	XI	Ξ	ξ
GAMMA	Γ	γ	OMICRON	Ο	ο
DELTA	Δ	δ	PI	Π	π
EPSILON	Ε	ε	RHO	Ρ	ρ
ZETA	Z	ζ	SIGMA	Σ	σ
ETA	H	η	TAU	Τ	τ
THETA	Θ	θ	UPSILON	Υ	υ
IOTA	I	ι	PHI	Φ	φ
KAPPA	K	κ	CHI	Χ	χ
LAMBDA	Λ	λ	PSI	Ψ	ψ
MU	M	μ	OMEGA	Ω	ω

U - UPPER CASE

L - LOWER CASE

## COMMON GREEK SYMBOLS

LETTER	SYMBOLIZES OR DESIGNATES
α	ANGLES, ACCELERATION, AREA
β	ANGLES,
γ	CONDUCTIVITY, SPECIFIC GRAVITY
Δ	INCREMENT, DECREMENT
ε	DIELECTRIC CONSTANT
E	ENERGY
Z	IMPEDANCE
η	FM MODULATION INDEX
θ	ANGLES, TIME CONSTANT, TEMPERATURE
λ	WAVELENGTH, CONDUCTIVITY
μ	MICRO (PREFIX), AMPLIFICATION FACTOR
ν	FREQUENCY
π	CIRCUMFERENCE ÷ DIAMETER (3.14159...)
ρ	RESISTIVITY, REFLECTANCE
Σ	SUMMATION SIGN
τ	TIME CONSTANT, TRANSMITTANCE
φ	ANGLE, RADIANT POWER
ω	ANGLE, ANGULAR FREQUENCY
Ω	SOLID ANGLE, RESISTANCE (OHMS)

30

## RESISTOR COLOR CODE

COLOR	SIGNIFICANT DIGITS (1&2)	MULTIPLIER (3)	TOL. (4)
BLACK	0	1	
BROWN	1	10	± 1%
RED	2	100	
ORANGE	3	1,000	
YELLOW	4	10,000	NO
GREEN	5	100,000	COLOR
BLUE	6	1,000,000	BAND:
VIOLET	7	10,000,000	± 20%
GRAY	8	100,000,000	
WHITE	9	-	
GOLD	-	-	± 5%
SILVER	-	-	± 10%

EXAMPLE:



1 = BROWN = 1

2 = BLACK = 0


3 = YELLOW = × 10,000

4 = SILVER = ± 10% TOLERANCE

100,000 Ω  
± 10%

## TRANSFORMER COLOR CODE

AUDIO INTERSTAGE AND OUTPUT:



POWER: UNTAPPED PRIMARY - BLACK; FILAMENT SECONDARY - GREEN (ADDITIONAL FILAMENT - YELLOW, BROWN AND SLATE); HIGH-VOLTAGE SECONDARY - RED. COLORS MAY VARY.

NOTE: THESE ARE EIA RECOMMENDED COLORS. SEE TRANSFORMER SPECIFICATIONS TO VERIFY CODE.

31



## 5. ELECTRONIC ABBREVIATIONS

AC - ALTERNATING CURRENT  
AF - AUDIO FREQUENCY  
AFC - AUTOMATIC FREQUENCY CONTROL  
AGC - AUTOMATIC GAIN CONTROL  
AM - AMPLITUDE MODULATION  
AMP - AMPLIFIER  
ANL - AUTOMATIC NOISE LIMITER  
ANT - ANTENNA  
AVC - AUTOMATIC VOLUME CONTROL  
AWG - AMERICAN WIRE GAUGE  
B - BASE OF TRANSISTOR  
BC - BROADCAST  
BFO - BEAT FREQUENCY OSCILLATOR  
BP - BANDPASS  
C - COLLECTOR OF TRANSISTOR  
CAL - CALIBRATE  
CAP - CAPACITOR  
CB - CITIZENS BAND  
CKT - CIRCUIT  
CLK - CLOCK  
CRT - CATHODE RAY TUBE  
C/S - CYCLES PER SECOND (HERTZ; HZ)  
CT - CENTER TAP  
CW - CONTINUOUS WAVE  
CY - CYCLE  
°C - DEGREES CELSIUS  
D - DRAIN OF FET  
dB - DECIBEL  
DBLR - DOUBLER  
DC - DIRECT CURRENT  
DEG - DEGREES  
DEMOD - DEMODULATION  
DF - DIRECTION FINDER  
DPDT - DOUBLE POLE DOUBLE THROW  
DPST - DOUBLE POLE SINGLE THROW  
DSB - DOUBLE SIDEBAND  
E - EMITTER OF TRANSISTOR ; ENERGY  
EM - ELECTROMAGNETIC  
EMF - ELECTROMOTIVE FORCE  
EMP - ELECTROMAGNETIC PULSE  
ERP - EFFECTIVE RADIATED POWER  
32

F - FREQUENCY  
°F - DEGREES FAHRENHEIT  
FDBK - FEEDBACK  
FET - FIELD EFFECT TRANSISTOR  
FF - FLIP FLOP  
FIL - FILAMENT  
FM - FREQUENCY MODULATION  
FREQ - FREQUENCY  
FSC - FULL SCALE  
FWHM - FULL WIDTH HALF MAXIMUM  
G - GATE OF FET  
GA - GAUGE  
GND - GROUND  
HF - HIGH FREQUENCY  
HI FI - HIGH FIDELITY  
HV - HIGH VOLTAGE  
HZ - HERTZ  
I - CURRENT  
IC - INTEGRATED CIRCUIT  
IMPD - IMPEDANCE  
IR - INFRARED  
JFET - JUNCTION FIELD EFFECT TRANSISTOR  
KWH - KILOWATT HOUR  
LED - LIGHT EMITTING DIODE  
LP - LOW PASS  
LSI - LARGE SCALE INTEGRATION  
MA - MILLIAMPERES  
MIC - MICROPHONE  
MOS - METAL-OXIDE-SEMICONDUCTOR  
MOSFET - MOS FIELD EFFECT TRANSISTOR  
NC - NO CONTACT  
NEG - NEGATIVE  
NF - NOISE FIGURE  
NO - NORMALLY OPEN  
NOM - NOMINAL  
NPN - NEGATIVE-POSITIVE-NEGATIVE  
OP AMP - OPERATIONAL AMPLIFIER  
OSC - OSCILLATOR  
OUT - OUTPUT  
PAM - PULSE AMPLITUDE MODULATION  
PC - PRINTED CIRCUIT  
PCM - PULSE CODE MODULATION  
PDM - PULSE DURATION MODULATION  
33




PF - PICO FARAD  
PFM - PULSE FREQUENCY MODULATION  
PK - PEAK  
PLL - PHASE LOCKED LOOP  
PNP - POSITIVE - NEGATIVE - POSITIVE  
POS - POSITIVE  
POT - POTENTIOMETER  
PREAMP - PREAMPLIFIER  
PRI - PRIMARY  
PRV - PEAK REVERSE VOLTAGE  
PVC - POLYVINYL CHLORIDE  
PWR - POWER  
PWR SUP - POWER SUPPLY  
PZ - PIEZOELECTRIC  
Q - QUALITY FACTOR  
QTZ - QUARTZ  
R - RESISTANCE  
RAD - RADIAN  
RC - RESISTANCE - CAPACITANCE  
RCDR - RECORDER  
RCV - RECEIVE  
RCVR - RECEIVER  
RECHRG - RECHARGE  
RECT - RECTIFIER  
REF - REFERENCE  
RF - RADIO FREQUENCY  
RFC - RADIO FREQUENCY CHOKE  
RFI - RADIO FREQUENCY INTERFERENCE  
RL - RESISTANCE - INDUCTANCE  
RLC - RESISTANCE - INDUCTANCE - CAPACITANCE  
RLY - RELAY  
RMS - ROOT MEAN SQUARE  
RMT - REMOTE  
ROT - ROTATE  
RPM - REVOLUTIONS PER MINUTE  
RPS - REVOLUTIONS PER SECOND  
RTTY - RADIO TELETYPEWRITER  
RY - RELAY  
S - SOURCE OF FET  
SB - SIDEBAND  
SCR - SILICON CONTROLLED RECTIFIER  
SEC - SECONDARY  
SERVO - SERVOMECHANISM

SHLD - SHIELD  
SIG - SIGNAL  
SNR - SIGNAL-TO-NOISE RATIO (ALSO S/N)  
SPDT - SINGLE POLE DOUBLE THROW  
SPKR - SPEAKER  
SPST - SINGLE POLE SINGLE THROW  
SQ - SQUARE  
SSB - SINGLE SIDEBAND  
SUBMIN - SUBMINIATURE  
SW - SHORTWAVE  
SWL - SHORTWAVE LISTENING  
SWR - STANDING WAVE RATIO  
SYM - SYMBOL  
T - TIME  
TACH - TACHOMETER  
TEL - TELEPHONE  
TELECOM - TELECOMMUNICATIONS  
TEMP - TEMPERATURE  
TERM - TERMINAL  
TRF - TUNED RADIO FREQUENCY  
TTL - TRANSISTOR - TRANSISTOR LOGIC  
TVI - TELEVISION INTERFERENCE  
UHF - ULTRA HIGH FREQUENCY  
UJT - UNIJUNCTION TRANSISTOR  
UTC - COORDINATED UNIVERSAL TIME  
V - VOLTAGE  
VAC - VACUUM; AC VOLTAGE  
VC - VOICE COIL  
VCO - VOLTAGE CONTROLLED OSCILLATOR  
VF - VARIABLE FREQUENCY  
VHF - VERY HIGH FREQUENCY  
VID - VIDEO  
VLF - VERY LOW FREQUENCY  
VOL - VOLUME  
VOM - VOLT-OHM METER  
VT - VACUUM TUBE  
VOX - VOICE-OPERATED TRANSMITTER  
W - WATT  
WHM - WATT-HOUR METER  
WV - WORKING VOLTAGE  
X - REACTANCE  
XMTR - TRANSMITTER  
Z - IMPEDANCE




## 6. BASIC ELECTRONIC CIRCUITS

### HALF-WAVE RECTIFIER




D1 MUST BE RATED FOR THE INPUT VOLTAGE.

### FULL-WAVE RECTIFIER



D1-D4 MUST BE RATED FOR THE INPUT VOLTAGE. USE INDIVIDUAL DIODES OR RECTIFIER MODULE.

### VOLTAGE DOUBLER




CAUTION: C1 AND C2 CAN HOLD CHARGE WITHOUT VIN.

D1-D4, C1 AND C2 MUST BE RATED FOR AT LEAST TWICE THE INPUT VOLTAGE.

36


## BASIC LED DRIVER




EXAMPLE: ASSUME  $V_{IN} = 9$  VOLTS AND  $V_{LED} = 1.7$  VOLTS. CALCULATE VALUE OF  $R_s$  FOR  $I_{LED} = 20$  mA.

$$R_s = \frac{9 - 1.7}{.02} = 365 \text{ OHMS (OK TO USE CLOSEST STANDARD VALUE)}$$

## LOGIC GATE LED DRIVERS



NOTE: CMOS WILL DIRECTLY DRIVE SUPER BRIGHT LEDS IF  $I_{LED}$  IS KEPT BELOW A FEW MILLIAMPERES.




THIS CIRCUIT WILL DRIVE LED WHEN SUPPLY VOLTAGE TO LOGIC GATE AND Q1-LED ARE DIFFERENT.

37




## INVERTING AMPLIFIER



EXAMPLE: IF  $R1 = 4,700$  OHMS AND  $R2 = 47,000$  OHMS, THEN GAIN IS  $-(47,000/4,700)$  OR  $-10$ .  $R3 = 4,273$  OHMS (USE CLOSEST STANDARD VALUE).


## NON-INVERTING AMPLIFIER



EXAMPLE: IF  $R1 = 4,700$  OHMS AND  $R2 = 47,000$  OHMS, THEN GAIN IS  $1 + (47,000/4,700)$  OR  $11$ .


38

## VOLTAGE-TO-CURRENT CONVERTER



EXAMPLE: ASSUME  $R1$  IS A RESISTOR AND LED WITH COMBINED RESISTANCE OF  $1,000$  OHMS AND  $R2$  IS  $470$  OHMS. WHEN  $V_{IN} = 5$  VOLTS, CURRENT ( $I_{OUT}$ ) THROUGH LED IS  $10.6$  MA.

## CURRENT-TO-VOLTAGE CONVERTER




EXAMPLE: ASSUME A SOLAR CELL CONNECTED TO  $I_{IN}$  DELIVERS A CURRENT OF  $1$  MA. IF  $R1$  IS  $1,000$  OHMS, THEN  $V_{OUT} = -(1,000 \times 0.001) = -1$  VOLT.

39




## INVERTING COMPARATOR




WHEN  $V_{REF}$  EXCEEDS  $V_{IN}$ , OUTPUT SWINGS FROM HIGH TO LOW.

## NON-INVERTING COMPARATOR




WHEN  $V_{IN}$  EXCEEDS  $V_{REF}$ , OUTPUT SWINGS FROM LOW TO HIGH.

## WINDOW COMPARATOR




40

## TIMER



## PULSE GENERATOR






## 7. BASIC LOGIC CIRCUITS

### AND GATE




A	B	OUT
L	L	L
L	H	L
H	L	L
H	H	H

### NAND GATE




A	B	OUT
L	L	H
L	H	H
H	L	H
H	H	L

### OR



A	B	OUT
L	L	L
L	H	H
H	L	H
H	H	H

### NOR



A	B	OUT
L	L	H
L	H	L
H	L	L
H	H	L


### EXCLUSIVE OR



A	B	OUT
L	L	L
L	H	H
H	L	H
H	H	L


42

## EXCLUSIVE NOR




A	B	OUT
L	L	H
L	H	L
H	L	L
H	H	H

## BUFFER (3-STATE BUFFER)




(C)	A	OUT
(L)	L	L
(L)	H	H
(H)	(X)	(HI-Z)

## INVERTER (3-STATE INVERTER)



(C)	A	OUT
(L)	L	H
(L)	H	L
(H)	(X)	(HI-Z)

## 3-STATE BUS




COMPUTERS  
USUALLY HAVE  
A 3-STATE  
BUS.

CONTROL			GATE OUTPUT TO BUS
A	B	C	
L	H	H	A
H	L	H	B
H	H	L	C
H	H	H	NONE

43




## RS FLIP-FLOP (LATCH)



S	R	Q	Q̄
L	L	(DISALLOWED)	
L	H	H	L
H	L	L	H
H	H	NO CHANGE	

Q̄ = NOT Q


## CLOCKED RS FLIP-FLOP



AFTER CLOCK PULSE ARRIVES:

S	R	Q	Q̄
L	L	NO CHANGE	
L	H	L	H
H	L	H	L
H	H	(DISALLOWED)	

## JK FLIP-FLOP




AFTER CLOCK PULSE ARRIVES:

J	K	Q	Q̄
L	L	NO CHANGE	
L	H	L	H
H	L	H	L
H	H	TOGGLE*	

\*SEE FACING PAGE.


44

## D (DATA OR DELAY) FLIP-FLOP





## T (TOGGLE) FLIP-FLOPS

THE Q (OR Q̄) OUTPUT IS L (OR H) FOR EVERY OTHER INPUT PULSE. THEREFORE THE OUTPUT IS THE INPUT ÷ 2:



CHAINS OF T FLIP-FLOPS ARE USED TO MAKE BINARY COUNTERS. THE JK FLIP-FLOP (FACING PAGE) FUNCTIONS AS A T FLIP-FLOP WHEN BOTH THE J AND K INPUTS ARE KEPT HIGH AND INPUT PULSES ARE APPLIED TO THE CLOCK INPUT. OTHER T FLIP-FLOPS:





45



## 8. POWER SUPPLIES


### BATTERIES

#### SYMBOLS


SINGLE CELL:  MULTIPLE CELL: 

#### CONNECTIONS


##### SERIES:



##### PARALLEL:



##### BIPOLAR:



### STORAGE BATTERIES

STORAGE BATTERIES CAN BE USED AND RECHARGED MANY TIMES. PRINCIPLE TYPES:

LEAD-ACID — 2.0 VOLTS PER CELL. HIGH CURRENT CAPACITY. GOOD AT LOW TEMPERATURE.

NICKEL-CADMIUM (NICAD) — 1.2 VOLTS PER CELL. CAN BE STORED FOR EXTENDED TIME WHEN DISCHARGED. MANY DIFFERENT KINDS AVAILABLE. VERY ECONOMICAL POWER SOURCE.

46

## PRIMARY BATTERIES

PRIMARY BATTERIES ARE NOT RECHARGEABLE. CHIEF AMONG THE MANY TYPES AVAILABLE:

CARBON-ZINC — 1.5 VOLTS PER CELL. READILY AVAILABLE AND LOW COST.

ZINC-CHLORIDE — 1.5 VOLTS PER CELL. TWICE THE ENERGY DENSITY OF CARBON-ZINC.

ALKALINE — 1.5 VOLTS PER CELL. USE FOR HIGH CURRENT LOADS (MOTORS, LAMPS, ETC.).

MERCURY — 1.35 AND 1.4 VOLTS PER CELL. UNIFORM VOLTAGE DURING DISCHARGE.

SILVER OXIDE — 1.5 VOLTS PER CELL. NEARLY UNIFORM VOLTAGE DURING DISCHARGE.

LITHIUM MANGANESE — 3.0 VOLTS PER CELL. EXCEPTIONALLY LONG STORAGE LIFE. VERY HIGH ENERGY DENSITY.


### BATTERY PRECAUTIONS

1. DO NOT CHARGE PRIMARY CELLS.
2. BATTERIES MAY EXPLODE WHEN HEATED.
3. DO NOT SOLDER LEADS TO A BATTERY. USE A BATTERY CLIP OR HOLDER.
4. NEVER SHORT CIRCUIT A BATTERY'S TERMINALS.
5. MOST BATTERIES SHOULD BE REMOVED FROM EQUIPMENT IN STORAGE. EXCEPTIONS ARE STORAGE BATTERIES AND LITHIUM CELLS.
6. WHEN BATTERY LEADS EXCEED  $\approx 6$  INCHES, CONNECT  $0.1 \mu\text{F}$  CAPACITOR ACROSS LEADS AT CIRCUIT BOARD.


47



# LINE-POWERED SUPPLY



# RESISTOR COLOR CODE



BLACK	0	0	x 1
BROWN	1	1	x 10
RED	2	2	x 100
ORANGE	3	3	x 1,000
YELLOW	4	4	x 10,000
GREEN	5	5	x 100,000
BLUE	6	6	x 1,000,000
VIOLET	7	7	x 10,000,000
GRAY	8	8	x 100,000,000
WHITE	9	9	—

FOURTH BAND INDICATES TOLERANCE (ACCURACY):  
GOLD =  $\pm 5\%$  SILVER =  $\pm 10\%$  NONE =  $\pm 20\%$

OHM'S LAW:  $V = IR$   $R = V/I$   
 $I = V/R$   $P = VI = I^2R$

# ABBREVIATIONS

A = AMPERE	R = RESISTANCE
F = FARAD	V (OR E) = VOLT
I = CURRENT	W = WATT
P = POWER	$\Omega$ = OHM

M (MEG-)	= x 1,000,000
K (KILO-)	= x 1,000
m (MILLI-)	= .001
$\mu$ (MICRO-)	= .000 001
n (NANO-)	= .000 000 001
p (PICO-)	= .000 000 000 001